
11 Elevation

11.1 Options

- posx: initial x position of right bottom node
- posy: initial y position of right bottom node
- End0: End_0 length
- End1: End1 length
- Var0: Var₀ length
- Var1: Var₁ length
- L: L length
- dimline: when on shows dimension line
- supportlabel: when on shows I, II, and III
- shownodes: when on shows nodes name
- showdimname: if on will show the dimensions line name
- showparameter: if on will show the drawing parameters
- varnames: when on shows variables' name instead of dimensions
- mirror: when y prints the drawing on the right

The genscope environment can be used with the argument elevation.

11.2 Examples



\begin{concrtikz}[S=0.006mm]

\elevation{

```
End_0
Var_0
Var_1
L_0/4
Var_0
Var_1
Var_0
Var_
```

```
\begin{concrtikz}[S=0.006mm]
  \elevation{
    dimline=on,
    supportlabel=on,
    varnames=on,
    End0=640,
    End1=1000,
    Var0=2700,
    Var1=3465,
    L=29940,
    }
\end{concrtikz}
```