Version: V1.0 (Release)

Documentation for C/C++ code comprising the Multi-scale Cardiac Simulation Framework (MSCSF)

– Human atrial cell model specific version

By Michael A. Colman

This code is associated with Colman, MA, Saxena P, Kettlewell S, and Workman AJ. 2018. "Description of the Human Atrial Action Potential Derived from a Single, Congruent Data Source: Novel Computational Models for Integrated Experimental-Numerical Study of Atrial Arrhythmia Mechanisms." *Frontiers in Physiology* 9. https://doi.org/10.3389/fphys.2018.01211.

#### Please visit

https://github.com/michaelcolman/

and

https://physicsoftheheart.com/

for other models, updates, corrections etc, including the parent and more generally applicable code (of which this is a stripped-down version).

# Read the disclaimer on the next pages carefully before use of this code.

Source code and documentation by Michael A. Colman, 2016-2019.

For major queries, notification of errors etc, please contact:

m.a.colman@leeds.ac.uk

#### DISCLAIMER

COPYRIGHT MICHAEL A. COLMAN 2016-2019.

THIS PROGRAM IS FREE SOFTWARE: YOU CAN REDISTRIBUTE IT AND/OR MODIFY IT UNDER THE TERMS OF THE GNU GENERAL PUBLIC LICENSE AS PUBLISHED BY THE FREE SOFTWARE FOUNDATION, EITHER VERSION 3 OF THE LICENSE, OR (AT YOUR OPTION) ANY LATER VERSION. THIS PROGRAM IS DISTRIBUTED IN THE HOPE THAT IT WILL BE USEFUL, BUT WITHOUT ANY WARRANTY; WITHOUT EVEN THE IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SEE THE GNU GENERAL PUBLIC LICENSE FOR MORE DETAILS. YOU SHOULD HAVE RECEIVED A COPY OF THE GNU GENERAL PUBLIC LICENSE ALONG WITH THIS PROGRAM. IF NOT, SEE <a href="https://www.gnu.org/licenses/">https://www.gnu.org/licenses/</a>

THIS SOFTWARE IS PROVIDED OPEN SOURCE AND MAY BE FREELY USED, DISTRIBUTED AND UPDATED, PROVIDED:

- (i) THE APPROPRIATE WORK(S) IS(ARE) CITED. THIS PERTAINS TO THE CITATION OF COLMAN 2019 PLOS COMP BIOL (FOR THIS IMPLEMTATION) AND ALL WORKS ASSOCIATED WITH THE SPECIFIC MODELS AND COMPONENTS USED IN PARTICULAR SIMULATIONS. IT IS THE USER'S RESPONSIBILITY TO ENSURE ALL RELEVANT WORKS ARE CITED. PLEASE BELOW AND ON-SCREEN DISCLAIMER OUTPUTS FOR A GUIDE.
- (ii) ALL OF THIS TEXT IS RETAINED WITHIN OR ASSOCIATED WITH THE SOURCE CODE AND/OR BINARY FORM OF THE SOFTWARE.

ANY INTENDED COMMERCIAL USE OF THIS SOFTWARE MUST BE BY EXPRESS PERMISSION OF MICHAEL A COLMAN ONLY. IN NO EVENT ARE THE COPYRIGHT HOLDERS LIABLE FOR ANY DIRECT, INDIRECT INCIDENTAL, SPECIAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES ASSOCIATED WITH USE OF THIS SOFTWARE.

THIS SOFTWARE CONTAINS IMPLEMENTATIONS OF MODELS AND COMPONENTS WHICH I (MICHAEL COLMAN) DID NOT DEVELOP. ALL OF THESE COMPONENTS HAVE BEEN CODED FROM PROVIDED SOURCE CODE OR INFORMATION IN THE PUBLICATIONS. I CLAIM NO RIGHTS OR INTELLECTUAL PROPERTY OWNERSHIP FOR THESE MODELS AND COMPONENTS, OTHER THAN THEIR SPECIFIC IMPLEMENTATION IN THIS CODE PACKAGE. FURTHER TO THE ABOVE STATEMENT, ANY INDTENDED COMMERCIAL USE OF THOSE COMPONENTS MUST BE BY EXPRESS PERMISSION OF THE ORIGINAL COPYRIGHT HOLDERS. WHERE IMPLEMENTED FROM PROVIDED CODE, ANY DISCLAIMERS PRESENT IN THE ORIGINAL CODE HAVE BEEN RETAINED IN THE RELEVANT FILE.

#### Any use of this baseline implementation must cite:

Colman MA. "Arrhythmia Mechanisms and Spontaneous Calcium Release: Bi-directional coupling between re-entry and focal excitation" PLOS Comp Biol 2019.

This includes any use of the baseline source code even if all components actually used have been added by the user and were not packaged with the code.

This is referred to as the "baseline publication" for this framework throughout the documentation.

Use of other specific components must cite as appropriate and detailed on the next page.

#### **CITATION LIST**

#### Human atrial cell models:

Use of any of the Workman-lab based human atrial cell models ("Model hAM\_WL\_x; Model hAM\_x\_mWL") must cite:

Colman, MA, Saxena P, Kettlewell S, and Workman AJ. 2018. "Description of the Human Atrial Action Potential Derived from a Single, Congruent Data Source: Novel Computational Models for Integrated Experimental-Numerical Study of Atrial Arrhythmia Mechanisms." *Frontiers in Physiology* 9. https://doi.org/10.3389/fphys.2018.01211.

Use of the original Courtemanche-Ramirez-Nattel 1998 model ("Model hAM\_CRN"), modified model ("Model hAM\_CRN\_mWL") or Workman-lab model using the CRN Ca<sup>2+</sup> handling system ("Model hAM\_WL\_CRN") must cite the original paper:

Courtemanche, M., R. J. Ramirez, and S. Nattel. 1998. "Ionic Mechanisms Underlying Human Atrial Action Potential Properties: Insights from a Mathematical Model." *The American Journal of Physiology* 275 (1 Pt 2): H301-321.

Use of the original Nygren et al. 1998 model ("Model hAM\_NG") or modified model ("Model hAM\_NG\_mWL") must cite the original paper:

Nygren, A., C. Fiset, L. Firek, J. W. Clark, D. S. Lindblad, R. B. Clark, and W. R. Giles. 1998. "Mathematical Model of an Adult Human Atrial Cell: The Role of K+ Currents in Repolarization." *Circulation Research* 82 (1): 63–81. https://doi.org/10.1161/01.RES.82.1.63.

Use of the original Grandi et al. 2011 model ("Model hAM\_GB"), modified model ("Model hAM\_GB\_mWL") or Workman-lab model using the GB Ca<sup>2+</sup> handling system ("Model hAM\_WL\_GB") must cite the original paper [1] and the updated model [2]:

[1] Grandi, Eleonora, Sandeep V. Pandit, Niels Voigt, Antony J. Workman, Dobromir Dobrev, Jose Jalife, and Donald M Bers. 2011. "Human Atrial Action Potential and Ca2+ Model: Sinus Rhythm and Chronic Atrial Fibrillation." Circulation Research 109 (9): 1055–66. https://doi.org/10.1161/CIRCRESAHA.111.253955.

[2] Chang, Kelly C., Jason D. Bayer, and Natalia A. Trayanova. 2014. "Disrupted Calcium Release as a Mechanism for Atrial Alternans Associated with Human Atrial Fibrillation." *PLOS Computational Biology* 10 (12): e1004011. https://doi.org/10.1371/journal.pcbi.1004011.

Use of the Maleckar et al. 2009 update of the Nygren et al. 1998 model ("Model hAM\_MT") must cite the original Nygren paper as well as:

Maleckar, Mary M., Joseph L. Greenstein, Wayne R. Giles, and Natalia A. Trayanova. 2009. "K+ Current Changes Account for the Rate Dependence of the Action Potential in the Human Atrial Myocyte." *American Journal of Physiology. Heart and Circulatory Physiology* 297 (4): H1398-1410. <a href="https://doi.org/10.1152/ajpheart.00411.2009">https://doi.org/10.1152/ajpheart.00411.2009</a>.

Use of the family of human atrial heterogeneity cell-types ("Celltype RA/PM/CT/BB/RAA/LAA/LA/AVR/AS/PV"), implemented within any human atrial cell model must cite:

Colman, Michael A., Oleg V. Aslanidi, Sanjay Kharche, Mark R. Boyett, Clifford Garratt, Jules C. Hancox, and Henggui Zhang. 2013. "Pro-Arrhythmogenic Effects of Atrial Fibrillation-Induced Electrical Remodelling: Insights from the Three-Dimensional Virtual Human Atria." *The Journal of Physiology* 591 (17): 4249–72. https://doi.org/10.1113/jphysiol.2013.254987.

Use of AF remodelling models ("Remodelling AF\_col\_1/2/3/4 [1] or AF\_GB [2]") must cite:

[1] Colman, Michael A., Oleg V. Aslanidi, Sanjay Kharche, Mark R. Boyett, Clifford Garratt, Jules C. Hancox, and Henggui Zhang. 2013. "Pro-Arrhythmogenic Effects of Atrial Fibrillation-Induced Electrical Remodelling: Insights from the Three-Dimensional Virtual Human Atria." *The Journal of Physiology* 591 (17): 4249–72. https://doi.org/10.1113/jphysiol.2013.254987.

# MSCSF - HAM\_WL, DOCUMENTATION BY MICHAEL COLMAN 2019

[2] Grandi, Eleonora, Sandeep V. Pandit, Niels Voigt, Antony J. Workman, Dobromir Dobrev, Jose Jalife, and Donald M Bers. 2011. "Human Atrial Action Potential and Ca2+ Model: Sinus Rhythm and Chronic Atrial Fibrillation." Circulation Research 109 (9): 1055–66. https://doi.org/10.1161/CIRCRESAHA.111.253955.

#### Use of the isoprenaline models ("ISO [0-1] ISO\_model GB [1] /Col [2]") must cite:

[1] Grandi, Eleonora, Sandeep V. Pandit, Niels Voigt, Antony J. Workman, Dobromir Dobrev, Jose Jalife, and Donald M Bers. 2011. "Human Atrial Action Potential and Ca2+ Model: Sinus Rhythm and Chronic Atrial Fibrillation." Circulation Research 109 (9): 1055–66. https://doi.org/10.1161/CIRCRESAHA.111.253955

[2] Colman, Michael A. 2013. Mechanisms of Atrial Arrhythmias: Insights from the Development of a Biophysically Detailed Model of the Human Atria. Springer Science & Business Media.

#### Use of the included mutation models ("Mutation D322H/Y155C") must cite:

Colman, Michael A., Haibo Ni, Bo Liang, Nicole Schmitt, and Henggui Zhang. 2017. "In Silico Assessment of Genetic Variation in KCNA5 Reveals Multiple Mechanisms of Human Atrial Arrhythmogenesis." *PLOS Computational Biology* 13 (6): e1005587. https://doi.org/10.1371/journal.pcbi.1005587.

BY USING THIS SOFTWARE, YOU AGREE THAT YOU WILL APPROPRIATELY AND FULLY CITE THE RELEVANT WORKS.

# Contents

I - Using the software	6
Forward	6
0. Package contents	6
1. Setup and basic usage	6
2. Basic arguments	7
3. Available cell model list	8
4. Output directories and files	9
4.1. Simulation log	9
4.2. The Outputs Directory	9
4.3. Output directory contents	9
5. Full list of arguments	14
5.1. Simulation settings	14
5.2. Model and Cell conditions	16
5.3 Tissue model options	18
5.6. Direct control parameters (all implementations).	23
5.7. Settings files	24
6. Examples of various protocols	25
6.1. Basic, single-cell examples	25
6.2 Tissue model examples – idealised tissue models	28
6.3 Tissue model examples – anatomically detailed/complex tissue models	38
II - Modifying the code	43
Forward - general philosophy of the framework	43
1. Introduction	43
2. Variable naming conventions	44
3. Variable structs and contents	44
4. Adding new variables	45
5. Adding a new celltype or modulation model	46
5.1. The modifier variables	46
5.2 Types of modulation	46
5.3. Adding your new modulation; model-specific	47
5.4. Adding your new modulation; common or global	47
5.5. Adding your new modulation; spatial tissue gradients	48
6. Adding a new tissue model	48
7. Adding a full new, or updated, cell model	49
9. Adding a new current	50

# I - Using the software

# **Forward**

This source-code forms the Multi-scale Cardiac Simulation Framework (MSCSF), a C/C++ implementation for the simulation of cardiac electrophysiology from the sub-cellular to the organ scales. It is packaged with multiple cell and tissue models and various protocols for simulation, and is designed to be easy to modify. This version includes only:

#### "Native" models

- Implementations of multiple published single cell models ("traditional" Hodgkin-Huxley and whole-cell concentration models).
- Tissue model (1D-3D idealised; anatomically detailed) implementations of the native single cell models.

Functionality for multiple protocols, measurements and modulation components has been included, not all of which are associated directly with a previous publication and some of which may be validated for specific models only. Please see Disclaimer for sources of published components; it is the user's responsibility to sufficiently check and validate any use of these components in models other than originally presented.

I hope you may find this useful in your own research. Enjoy!

**Nomenclature convention:** the convention used throughout this code and documentation when referring to gating and computed variables for the currents is as such:  $I_{\text{X\_type\_specifier}}$ . For example, the "voltage-activation" (va) gate for  $I_{\text{to}}$  is " $I_{\text{to\_va}}$ "; the "calcium-inactivation" (ci) gate for  $I_{\text{CaL}}$  is  $I_{\text{CaL\_ci}}$ ; the steady state (ss) and time constant (tau) of the "voltage-inactivation" (vi) gate for  $I_{\text{Kur}}$  are:  $I_{\text{Kur\_vi\_ss}}$  and  $I_{\text{Kur\_vi\_tau}}$ . I personally find this more convenient and with a greater level of consistency than assigning specific variables for each gate (e.g. m, h and j for  $I_{\text{Na}}$  variables).

# O. Package contents

- CODE source code
- MSCSF\_state\_and\_geometry\_files state and geometry files
- Simulations simulations directory
- Example\_scripts contains sub-directories with example scripts for different functionality.

# 1. Setup and basic usage

\*This code is designed to be used within a linux/mac command-line environment, but has not been extensively tested on different operating systems\*. It requires g++/clang++ compilers and openMP parallelisation libraries. For installation on windows, refer to the separate documentation.

- 1. Build the code: Once unzipped and placed in a sensible location, navigate to the code directory ("MSCSF/CODE") in a terminal. Copy "Makefile\_linux" or "Makefile\_mac" to a file simply called "Makefile." Type "make" to compile the full package. This will create the following executables:
- "model\_single\_native" Single cell implementations for traditional cell models
- "model\_tissue\_native" Tissue implementations using traditional cell models
- "bin\_to\_vtk\_tissue" converts binary data to plain text or vtk, tissue models

Each of these executables can be compiled individually by typing "make" followed by the identifier – the executable name without the "model\_" prefix (or the entire executable name for bin\_to\_vtk\_X).

- 2. Set your state and geometry file path: The folder "MSCSF\_state\_and\_geometry\_files" (present in the parent MSCSF directory) is the location to/from which all state files will be written/read and all geometry and map files are stored. To avoid having to repeatedly copy files between directories for new projects, place this directory somewhere sensible (such as a Projects parent folder) and add the full path of the location to "PATH.txt". Ensure PATH.txt is present in every simulation directory.
- **3.** Check everything is setup: Execute the code ("./model\_single\_[X]" in the terminal) with no additional options to run the default model and conditions. The path location, as well as output filenames, will be output to screen check that this PATH is correct.
- **3a.Your simulations folder:** Rather than running simulations in the same folder as the code, it is suggested to use different (project-specific) folders. Copy *model\_X* and **PATH.txt** to the appropriate project folder.

### 4. Executing the code

To run the code with specific settings, pass in command-line arguments at the time of execution. Arguments are passed as argument and value, separated by spaces; any number of argument-value pairs may be passed in any order:

./model\_X [ARG1] [VALUE1] [ARG2] [VALUE2]...

The full argument list for each associated implementation can be output to screen by typing any incorrect argument, e.g.

./model\_X Display\_args

# 2. Basic arguments

#### For all implementations:

Argument	Description	Options	Variable default	Notes
Reference	Identifier for the	string	-	Adds a specific
	simulation group			identifier to the
				Outputs directory
				name
Results_Reference	Identifier for the	string	-	Adds a specific
	specific simulation			identifier to the
				Results directories
BCL	Basic cycle length	int [ms]	1000	
Beats	Number of beats	int	10	
Model	Selects which model to	minimal	minimal	Full model list
	run	hAM_WL		presented in full
				arguments section
S2	Cycle length of S2 or	int [ms]	0	For single or
	second pacing rate			multiple stimuli
				applied after the
				regular train of
				pacing
Settings_file	Identify a file to read in	String – filename	N/A	See section on
	with all options, rather			Settings_files for
	than passing explicitly			instructions
	in command line			

#### All tissue models:

Argument	Description	Value	Variable default	Notes
Tissue_order	Determines the spatial dimensional order of tissue model	1D, 2D, 3D, geo	2D	Use geo for anatomically detailed tissue models
Tissue_model	Specifier for specific tissue model and settings	string [basic,]	basic	Reference for all specific settings
Tissue_type	Electrophysiogically homogeneous or heterogeneous	homogeneous heterogeneous	homogeneous	May be automatically set by Tissue_model; in which case, argument will overwrite automatic settings
Orientation_type	Determines whether isotropic or anisotropic	isotropic anisotropic	isotropic	^^
D_uniformity	Whether the magnitude of the diffusion coefficient varies in space	uniform regional map regiona_map	uniform	regional means will vary according to celltype; map means according to a read-in scaling map; default automatically set by Tissue_model
Spatial_output_int erval_{data/vtk}	The period for which spatial data will be output, for either binary arrays (data) or vtk files (vtk)	int [ms]	5 ms (data); 0 ms = off (vtk)	Set to 0 to prevent spatial file outputs

# 3. Available cell model list

A list of all available cell models, and their associated source files. Full model description and options are found in the <u>full argument list</u>; here is just a quick reference.

Identifier	Model	Primary reference	Source file
minimal	Hybrid-minimal model	Colman 2019 PLOS Comp. Biol.	lib/Model_minimal.cpp
hAM_CRN	Human atrial cell model	Courtemanche et al. 1998 Am. J. PhysiolHeart Circ. Physiol. 275, H301–H321	lib/Model_hAM_CRN.cpp
hAM_NG	Human atrial cell model	Nygren et al. 1998 Circ. Res. 82, 63–81	lib/Model_hAM_NG.cpp
hAM_MT	Human atrial cell model	Maleckar et al. 2009 Am. J. Physiol. Heart Circ. Physiol. 297, H1398- 1410	lib/Model_hAM_MT.cpp
hAM_GB	Human atrial cell model	Grandi et al. 2011 Circ. Res. 109, 1055–1066	lib/Model_hAM_GB.cpp
hAM_WL_CRN	Human atrial cell model	Colman et al. 2018 Front. Physiol. 9 1211	lib/Model_hAM_WL.cpp
hAM_WL_GB	Human atrial cell model	Colman et al. 2018 Front. Physiol. 9 1211	lib/Model_hAM_WL.cpp
hAM_CRN_mWL	Human atrial cell model	Colman et al. 2018 Front. Physiol. 9 1211	lib/Model_hAM_WL.cpp
hAM_NG_mWL	Human atrial cell model	Colman et al. 2018 Front. Physiol. 9 1211	lib/Model_hAM_WL.cpp
hAM_GB_mWL	Human atrial cell model	Colman et al. 2018 Front. Physiol. 9 1211	lib/Model_hAM_WL.cpp

# 4. Output directories and files

Running the simulation will create all of the directories and files for output.

## 4.1. Simulation log

In the parent simulation directory, "Log.dat" contains a record of all simulations performed within the parent directory, displaying the time of execution and command-line arguments passed.

## 4.2. The Outputs Directory

Data associated with the simulation is written to the "Outputs\_X" directory. The directory name will be defaulted based on the implementation used:

model\_single\_native
 model\_tissue\_native
 "Outputs\_single\_native"
 "Outputs\_tissue\_native"

If a *reference* has been passed, this folder will be called "Outputs\_X\_[reference]".

## 4.3. Output directory contents

Within the *Outputs* directory are the directories "Parameters" and "Results" and the files "Properties\_log.dat" and "Settings.dat". For specific tissue models, "Conduction\_velocity\_log.dat" and "1D\_conduction\_success\_log.dat" will be also created.

**Outputs\_X\_reference/Properties\_log.dat** (and similar tissue-specific equivalents) records the final beat properties, and is appended with each simulation; it therefore provides a log of the final properties of all simulations performed in **Outputs\_X\_reference** i.e. associated with implementation X and *reference*.

Outputs\_X\_reference/Results/ contains the raw data associated with the simulation (time-courses of AP, currents, concentrations, measured properties etc), in files "Currents.dat" and "Properties.dat" (and "CRU.dat" if using an integrated implementation). If a results\_reference has been passed, the folder name will be appended with this reference Outputs\_X\_reference/Results\_results\_reference. All files within Results are overwritten with each simulation associated with implementation X, reference and results\_reference.

Outputs\_X\_reference/Results\_results\_reference/Settings.dat contains a copy of the on-screen settings outputs for the most recent simulation associated with implementation X and reference/results\_reference.

Outputs\_X\_reference/Parameters/ contains outputs of the model parameters, voltage-dependent ion current functions, and voltage clamp data (if performed) under the exact conditions of the simulation. This directory name will also be appended with *results\_reference* and is overwritten in the same way as **Results**.

Thus, use *reference* and *results\_reference* to distinguish and save data accordingly; raw data should be saved with *results\_reference* if you need to also track final beat properties across multiple simulations associated with *reference* (e.g. for an APDr protocol, use *reference* to label the APDr protocol, model etc, within which Properties\_log.dat will contain a list of BCL and APD for all simulations performed with *reference*; save raw data at each cycle length by using *results\_reference* to identify each BCL performed).

#### 4.3.1. File contents: Settings and simulation logs

"Settings.dat" contains a copy of the screen outputs for settings associated with the most recent simulation passed with *reference* and *results\_reference*.

"Properties\_log.dat" contains an output of the BCL, S2 and measured properties (such as action potential amplitude, action potential duration, and calcium transient properties) associated with the final two beats of the simulation.

	Variable		Variable		Variable		Variable
1	BCL (ms)	8	P - APD <sub>50</sub> (ms)	15	F - V <sub>min</sub> (mV)	22	P - CaT <sub>min</sub> (µM)
2	S2 (ms)	9	F - APD <sub>70</sub> (ms)	16	P - V <sub>min</sub> (mV)	23	F - CaT <sub>max</sub> (µM)
3	F - APD <sub>-70mV</sub> (ms)	10	P - APD <sub>70</sub> (ms)	17	F - V <sub>max</sub> (mV)	24	P - CaT <sub>max</sub> (µM)
4	P - APD <sub>-70mV</sub> (ms)	11	F - APD <sub>90</sub> (ms)	18	P - V <sub>max</sub> (mV)	25	F - CaSR <sub>min</sub> (mM)
5	F - APD <sub>30</sub> (ms)	12	P - APD <sub>90</sub> (ms)	19	F - V <sub>amp</sub> (mV)	26	P - CaSR <sub>min</sub> (mM)
6	P - APD <sub>30</sub> (ms)	13	$F - dV/dt_{max} (V/s)$	20	P - V <sub>amp</sub> (mV)	27	F - CaSR <sub>max</sub> (mM)
7	F - APD <sub>50</sub> (ms)	14	P - dV/dt <sub>max</sub> (V/s)	21	F - CaT <sub>min</sub> (µM)	28	P - CaSR <sub>max</sub> (mM)

 $\overline{(F - and P - refer to final and penultimate beats, respectively)}$ .

"Conduction\_velocity\_log.dat" contains the tissue parameters and the conduction velocities in the principal and diagonal directions; created only when "Tissue\_model conduction\_velocity" is selected.

	Variable		Variable		Variable		Variable
1	Tissue_order	6	OY	11	CV_xy_plus	16	CV_yz_minus
2	D1 (mm/ms)	7	OZ	12	CV_xy_minus	17	CV_xyz_ppp
3	D2 (mm/ms)	8	CV_x	13	CV_xz_plus	18	CV_xyz_ppm
4	dx (mm)	9	CV_y	14	CV_xz_minus	19	CV_xyz_pmp
5	OX	10	CV_z	15	CV_yz_plus	20	CV_xyz_mpp

Where all conduction velocities are in m/s, OX, OY and OZ refer to the X,Y,Z component of the orientation (this tissue model is idealised and all fibres point in the same direction), and xy\_plus refers to the symmetrically identical x\_plus-y\_plus and x\_minus-y\_minus directions, xy\_minus refers to the symmetrically identical x\_plus-y\_minus and x\_minus-y\_plus directions, and so on.

"1D\_conduction\_success\_log.dat" contains the S2 stimulus information and whether the excitation propagated in both directions in the 1D strand; valid for any 1D tissue model with S2 argument passed. Simply outputs:

- $1 S2 \times location;$
- 2 S2 cycle length;
- 3 left edge excited?;
- 4 right edge excited?;
- 5 excitation type.

#### Where:

for left and right edge excited, 0 = no and 1 = yes; excitation type = left+right = 0 for full block, = 1 for unidirectional conduction block, = 2 for full conduction.

## 4.3.2. File contents: Results data files

## "Outputs\_X\_[reference]/Results\_[results\_reference]/Currents.dat"

This contains the time-courses of the membrane potential, ion currents, gating variables, and intracellular concentrations. These files are created, and thus overwritten, with each simulation associated with *reference* and *results\_reference*. These files are created for all implementations (native + integrated; single cell + tissue). For tissue models, files are created for 3 specified cells in the tissue, and the name is appended "/Currents\_cell{1-3}.dat".

	Variable		Variable		Variable		Variable
1	sim_time (ms)	13	I <sub>CaL_va</sub>	25	<i>I</i> <sub>K1_v_ti</sub>	37	Ca_jSR (mM)
2	V <sub>m</sub> (mV)	14	<i>I</i> <sub>CaL_vi</sub>	26	I <sub>NCX</sub> (A/F)	38	Ca_nSR (mM)
3	I <sub>stim</sub> (A/F)	15	I <sub>CaL_vi_slow</sub>	27	I <sub>CaP</sub> (A/F)	39	Ca_o (mM)
4	I <sub>Na</sub> (A/F)	16	I <sub>Kur</sub> (A/F)	28	I <sub>Nab</sub> (A/F)	40	RyR_o
5	I <sub>Na_va</sub>	17	I <sub>Kur_va</sub>	29	I <sub>Cab</sub> (A/F)	41	RyR_r
6	I <sub>Na_vi_1</sub>	18	I <sub>Kur_vi</sub>	30	I <sub>Kb</sub> (A/F)	42	RyR_i
7	I <sub>Na_vi_2</sub>	19	I <sub>Kr</sub> (A/F)	31	I <sub>NaK</sub> (A/F)	43	Nai (mM)
8	I <sub>to</sub> (A/F)	20	I <sub>Kr_va</sub>	32	I <sub>CICa</sub> (A/F)	44	Nai_sl (mM)
9	I <sub>to_va</sub>	21	I <sub>Kr_v_ti</sub>	33	I <sub>Clb</sub> (A/F)	45	Nai_j (mM)
10	I <sub>to_vi</sub>	22	I <sub>Ks</sub> (A/F)	34	Cai (µM)	46	Ki (mM)
11	I <sub>to_vi_s</sub>	23	$I_{Ks\_va}$	35	Cai_sl (mM)	47	Nao (mM)
12	I <sub>CaL</sub> (A/F)	24	I <sub>K1</sub> (A/F)	36	Cai_j (mM)	48	Ko (mM)

#### "Outputs\_X\_[reference]/Results\_[results\_reference]/Properties.dat(Properties\_Cell\_{1-3}.dat)"

This contains the beat-by-beat measured properties corresponding to those which are output for the final beat in "**Properties\_log.dat**". These files are created, and thus overwritten, with each simulation associated with both *reference* and *results\_reference*. These files are also created for all implementations, and in tissue models the output is for the same three cells as **Currents.dat** and the filename is appended accordingly.

	Variable		Variable		Variable		Variable
1	sim_time (ms)	6	$V_{min}$ (mV)	11	APD <sub>30</sub> (ms)	16	CaT <sub>max</sub> (µM)
2	V <sub>m</sub> (mV)	7	$V_{max}(mV)$	12	APD <sub>50</sub> (ms)	17	CaSR <sub>min</sub> (mM)
3	excitation_state	8	V <sub>amp</sub> (mV)	13	APD <sub>70</sub> (ms)	18	CaSR <sub>max</sub> (mM)
4	dV <sub>m</sub> /dt (V/s)	9	APD_switch	14	APD <sub>90</sub> (ms)		
5	dV <sub>m</sub> /dt_max (V/s)	10	APD <sub>-70mV</sub> (ms)	15	CaT <sub>min</sub> (µM)		

#### 4.3.3. Spatial maps and results data files (Tissue models)

For tissue models, the geometry, fibres, diffusion coefficient and stimulus and modulation maps are all output as vtks into the **Outputs\_X\_[reference]** directory for verification, monitoring and figure making; these are overwritten for every simulation performed with implementation X and *reference* (files are only written/overwritten if relevant: geometry, fibres, D and stimulus are written every time; modulation maps only if they are applied). Files are (hopefully!) obviously named.

#### "Outputs\_X\_[reference]/Results\_[results\_reference]/[V]\_linescan\_{x,y,z}.dat"

Contains linescan data of variable V (Vm, Cai, CaSR) in direction x (x,y,z). I.e. one line per ms, with the line scanning through the tissue/cell in the x/y/z-direction. (x-direction only for tissue models; all for 3D cell models).

#### "Outputs\_X\_[reference]/Spatial\_Results\_[results\_reference]/[V]\_output\_[time]{.bin/.vtk}"

Contains full output of spatial data for variable V (Vm, Cai, CaSR) at a specific time. VTK data is in 3D ("-100" representing empty space); binary data contains a 1D array of actual data only (no empty space). Convert binary data to plain text and/or vtk data using the provided  $bin_to_vtk_tissue/3D_cell$  tools (see below sub-section).

#### "Outputs\_X\_[reference]/Spatial\_Results\_[results\_reference]/Activation\_output{.vtk/.dat}"

Contains the activation time of the final excitation (tissue models and voltage only).

#### Converting binary spatial data to plain text and/or vtk

If running these models, with default settings, the simulation will output only binary data for the spatial outputs (vtk files can also be output directly by the model - see arguments section.)

Use the provided tools to convert the binary data to plain text or vtk data files:

From within the same directory where the simulation was performed, or in a parent directory containing the **Outputs** directory you want to analyse, run: "./bin\_to\_vtk\_{tissue/3Dcell}" with arguments identifying the simulation and conversion settings:

- Any **Reference** and **Results\_Reference** passed (so it knows which directory to look in to read binary and write data/vtk files)
- The variable you want to convert (i.e. Vm, Ca, CaSR etc): Variable [V]
- The **Tissue\_order** and **Tissue\_model** (tissue) or **Cell\_size** and **Sim\_cell\_size** (3Dcell) used to perform the simulation (so it knows geometry sizes and files etc).
- Which type of data to write: Write\_data [On/Off] (plain text) and/or Write\_vtk [On/Off]
- The time range and time interval over which to convert data: start\_time [n1] end\_time [n2] interval [n3]
- For tissue models, you need to also specify the model type (Model\_type [native/integrated])

#### Examples:

"./bin\_to\_vtk\_tissue start\_time 100 end\_time 200 interval 10 Model\_type integrated Variable Cai Write\_vtk On Write\_data On Tissue\_order 2D Tissue\_model basic Reference X Results\_Reference Y"

#### 4.3.4. - Simulation model parameters, functions and voltage clamp data

When using single cell models (native or integrated), the model parameters and voltage-dependent functions will also be output to the **Parameters\_[results\_reference]** directory, along with voltage clamp data if the voltage clamp protocol is turned on. These files contain information on the parameters and functions exactly as they were used in the simulation, with any and all modulation incorporated.

"Outputs\_X\_[reference]/Parameters\_[results\_reference]/Magnitude\_parameters.dat" contains a list of all the ion current densities and Ca<sup>2+</sup> handling system maximal flux rates as used in implementation X, reference and results\_reference. These pertain to the parameter multiplied by the scale factor.

"Outputs\_X\_[reference]/Parameters\_[results\_reference]/Modifier\_parameters.dat" contains a list of the final value for all the modifiers (scale factors, voltage shifts etc), after sequential application of all heterogeneity and modulation.

"Outputs\_X\_[reference]/Parameters\_[results\_reference]/I[x].dat" contains the voltage-dependent current variables (transition rates, steady-states, time constants etc) as a function of voltage. This includes voltage shifts and time-constant scaling.

File	1	2	3	4	5	6	7	8	9	10	11	12	13
INa.dat	Vm	va_α	va_β	va_∞	va_τ	$vi_{1}$ $\alpha$	vi <sub>1</sub> _β	vi <sub>1</sub> _∞	$vi_1_\tau$	vi <sub>2</sub> _ α	vi <sub>2</sub> _β	vi₂_∞	vi <sub>2</sub> _τ
INaL.dat	Vm	va_α	va_β	va_∞	va_τ	vi_ α	vi_β	vi_∞	vi_τ	-	-	-	-
Ito.dat	Vm	va_∞	va_τ	vi_∞	vi_τ	vi3_∞	vi <sub>3</sub> _τ	vi_Fs	-	-	-	-	-
ICaL.dat	Vm	va_∞	va_τ	vi_∞	vi_τ	vi_s_τ	-	-	-	-	-	-	-
IKur.dat	Vm	va_∞	va_τ	vi_∞	vi_τ	g <sub>Kur</sub>	-	-	-	-	-	-	-
IKr.dat	Vm	va_∞	va_τ	v_ti	-	-	-	-	-	-	-	-	-
IKs.dat	Vm	va_∞	va_τ	va <sub>2</sub> _τ	-	-		-	-	-	-	-	-
IKACh.dat	Vm	va_∞	va_τ	v_ti	-	-	-	-	-	-	-	-	-

#### Voltage-clamp data files

And if Voltage clamp is turned on, a simple Voltage clamp protocol will be applied, and the following files created:

"Outputs\_X\_[reference]/Parameters\_[results\_reference]/ICaL\_IV.dat" contains the peak current of  $I_{CaL}$  (A/F) at each voltage step with column  $1 = V_m$  and  $2 = I_{Cal}$  peak

"Outputs\_X\_[reference]/Parameters\_[results\_reference]/IK\_IV.dat" contains the peak current of  $I_{\text{to}}$ ,  $I_{\text{Kur}}$ ,  $I_{\text{Kr}}$  and  $I_{\text{Ks}}$  (A/F) at each voltage step with column  $1 = V_{\text{m}}$ ,  $2 = I_{\text{to}}$  peak,  $3 = I_{\text{Kur}}$ ,  $4 = I_{\text{Kr}}$ ,  $5 = I_{\text{Ks}}$ .

"Outputs\_X\_[reference]/Parameters\_[results\_reference]/IK1\_IV.dat" contains the value of  $I_{K1}$  at each voltage in range -150 mV to 100 mV.

"Outputs\_X\_[reference]/Parameters\_[results\_reference]/ICaL\_Vclamp\_trace{s/\_Y}.dat" contains the time courses of the voltage and current for all steps ("..traces.dat") or just step [Y]. 1 = time;  $2 = V_m$ ;  $3 = I_{CaL}$  (A/F); 4 = Cai (mM).

"Outputs\_X\_[reference]/Parameters\_[results\_reference]/IK\_Vclamp\_trace{s/\_Y}.dat" contains the time courses of the voltage and current for all steps ("..traces.dat") or just step [Y]. 1 = time;  $2 = V_m$ ;  $3 = I_{to}$ ;  $4 = I_{Kur}$ ;  $5 = I_{to} + I_{Kur}$ ;  $6 = I_{Kr}$ ;  $7 = I_{Ks}$  (A/F).

# 5. Full list of arguments

Below are listed the full range of arguments (and specific options) which may be used to control and vary the models without having to adjust and re-compile the code. An error message will be produced if an invalid argument has been passed; most options/values also have error checking for validity. However, invalid values may not give an error in all cases. Because this error message prints all valid argument options to screen, you may simply type any incorrect argument (e.g. "Display Arguments") for a full argument list.

Any number of arguments may be passed; where none are passed, defaults will be used. For modulation (ISO, remodelling etc) only one modifier of each type can be passed (i.e. cannot have two remodelling models simultaneously, but can have ISO, remodelling and various direct control modifiers simultaneously).

# 5.1. Simulation settings

#### Reference [string]

- **Description:** Adds a specific identifier to the **Outputs** directory name.
- E.g. "./model\_single\_0D Reference ERP" will produce the directory Outputs\_0DCell\_ERP
- Notes: [Reference] is only appended to the directory name if argument is passed.

#### Results\_Reference [string]

- Description: Adds a specific identifier to the Results, Spatial\_Results and Parameters directory names.
- **E.g.** "./model\_single\_0D Reference ERP Results\_Reference S2\_50" will produce the directory **Outputs\_0DCell\_ERP/Results\_S2\_50.**
- **Notes:** /Results\_Reference is only appended to the directory names if argument is passed.

#### Settings\_file [string]

- **Description:** Instructs the model to read in argument settings from a settings\_file.
- Notes:
  - o Must pass the full path and filename of the settings file.
  - o Must pass this argument first; further arguments can be passed after this one.

#### BCL [int ms]

- **Description:** Basic pacing cycle length for applied stimuli (S1 stimulus).
- **Default value**: 1000 ms.

#### Beats [int]

- **Description:** Number of times to apply S1 stimulus.
- **Default value:** 10.

#### S2 [int ms]

• **Description:** Cycle length for S2 stimulus, applied after the train of S1 stimuli.

#### NS2 [int]

- **Description:** Number of S2 stimuli to apply; only applies if **S2** argument has been passed.
- Notes: Can be used for single or few short-coupled stimuli or to implement two different pacing rates.
- Default value: 1.

#### Total\_time [int ms]

- **Description:** Total simulation time.
- **Default value:** The parameter of Total\_time is automatically set by BCL, Beats, S2 and NS2. Passing this argument overwrites the calculated default.
- Notes: For native implementations, the default Total\_time is simply the time required for the number of stimuli (including S2 if passed); for integrated implementations (3D cell and 0D models), 2 seconds of a quiescent period is added to the end (to observe spontaneous activity). Use this argument to set something different to these.

#### Paced\_time [int ms]

- **Description:** Time during which to apply stimuli.
- Notes: Use to set Total\_time and Paced\_time independently from each-other and Nbeats.

#### dt [double ms]

- **Description:** Sets the integration time-step.
- **Default value** is model dependent; this will overwrite any defaults set.

#### Vclamp [On/Off]

- Valid for single cell models only.
- **Description:** Will apply voltage clamp protocols for  $I_{CaL}$ ,  $I_{to}$ ,  $I_{Kur}$ ,  $I_{Kr}$ ,  $I_{Ks}$  and  $I_{K1}$ . Specifics of the protocols must be viewed and modified in the source code.
- Default: Off.

#### {Read/Write}\_state [string]

- **Description:** Define if and how to write the model state to file, or read state files as initial conditions.
- Options (native and 0D single cell models): On or Off.
- Options (tissue models):
  - On will read/write the whole tissue state. The **Tissue\_model**, **Tissue\_type** and **Orientation\_type** are also encoded into the state file name; **Celltype** is <u>not</u>.
  - o **single\_cell** (read only) will read state files written by the single cell model to all of that cell-type in the tissue model. A state file for every cell-type present in the tissue model must have been written using the single cell models.
  - o **ave** will write the values of an individual coupled cell, and read these into all cells of that cell-type. For write, must be performed on homogeneous tissue for all cell-types required.
  - o **phase** for implementation of the phase-distribution method of initiating re-entry.
- **Default value**: Off

#### State\_Reference\_{read/write} [string]

- **Description:** Adds a specific identifier to the state file to be written/read.
- Notes: State files are automatically named using the following condition variables: Model, BCL, celltype, ISO, ACh, Remodelling, Agent, Mutation, environment (and Tissue\_model, Tissue\_order, Tissue\_type, Orientation\_type). Use state references to distinguish and identify state files which have the same values for the above variables, but differ for others (e.g. direct modulation such as INa\_scale, Ito\_ac\_vshift, or writing the state at different time-points during a simulation.)

#### 5.2. Model and Cell conditions

#### Model [string]

- **Description:** Selects which baseline cell model to use. Some models may only be appropriate for specific implementation types (native vs integrated; single cell vs tissue).
- **Default:** minimal
- Options (General):
  - o minimal
    - Novel hybrid minimal model for controllable AP in the integrated models.
    - Appropriate implementations: All
- Options (human atrial cell models):
  - o hAM\_CRN
    - Citation: Courtemanche et al. 1998 Am. J. Physiol.-Heart Circ. Physiol. 275, H301–H321.
    - Appropriate implementations: Native.
  - o hAM NG
    - **Citation:** Nygren et al. 1998 Circ. Res. *82*, 63–81.
    - Appropriate implementations: Native.
  - o hAM MT
    - Citation: Maleckar et al. 2009 Am. J. Physiol. Heart Circ. Physiol. 297, H1398-1410.
    - Appropriate implementations: Native.
  - o hAM GB
    - Citations:
      - Grandi et al. 2011 Circ. Res. 109, 1055–1066
      - Chang et al. 2014 PLOS Comp Biol 10 (12): e1004011.
    - Appropriate implementations: Native.
  - hAM\_WL\_{CRN/GB} / hAM\_{CRN/NG/GB}\_mWL
    - Colman-Workman human atrial cell model (hAM\_WL\_X) or Workman-lab modified cell models (hAM\_X\_mWL)
    - Citations:
      - Colman et al. 2018 Front. Physiol. 9 1211
      - Courtemanche et al. 1998 Am. J. Physiol.-Heart Circ. Physiol. 275, H301–H321. (any with "CRN")
      - Nygren et al. 1998 Circ. Res. 82, 63-81. (any with "NG")
      - Grandi et al. 2011 Circ. Res. 109, 1055–1066. (any with "GB")
    - Appropriate implementations: Native

#### Celltype [string]

- **Description:** Specifies the cell-type/region to be used, within a baseline cell model.
- Notes: Each individual or group of cell model(s) can have its own set of regional cell models.
- **Default value** is model dependent.
- Options:
  - o minimal:
    - EPI/M/ENDO/RA
  - O All human atrial cell models (hAM\_X):
    - RA/PM/CT/RAA/AVR/BB/LA/AS/LAA/PV
    - Specific implementation: Colman et al. 2013 J. Physiol. *591*, 4249–4272.

#### Remodelling [string]

- **Description:** Sets a disease remodelling model to apply.
- Default value: "none".
- Options:
  - O All human atrial models:
    - Multiple implementations of "AF-remodelling"
    - **AF\_GB** as presented in Grandi et al. 2011 Circ. Res. 109, 1055–1066.
    - **AF\_Col\_{1-4}** as presented in Colman et al. 2013 J. Physiol. *591*, 4249–4272.

#### Remodelling\_proportion [double 0-1]

- **Description:** Sets the scaling between control and full remodelling.
- Notes: Implementations can be linearly or non-linearly scaled. All currently packaged implementations are linear.
- **Default value**: 1.0 (full effect).

#### ISO [double 0-1]

- **Description:** Concentration (µM) or proportion of saturating concentration of ISO.
- Notes: Applies according to ISO\_model, which will either be default or specified.

#### ISO\_model [string]

- **Description:** Selects a specific implementation of ISO.
- **Notes:** This is only relevant where multiple different implementations of ISO exist for single or a group of cell models.
- Options:
  - o All **human atrial cell** models (hAM\_X):
    - **GB** for implementation presented in Grandi et al. 2011 Circ. Res. 109, 1055–1066.
    - **Col** for implementation presented in Colman 2013 (New York; Springer).

#### ACh [double 0-1]

- **Description:** Concentration (μM) or proportion of saturating concentration of ACh.
- **Notes:** Applies according to **ACh\_model**, which will either be default (for single, model-specific) or specified (for multiple models and/or implementations).

#### ACh\_model [string]

- Description: Selects a specific implementation of ACh. Currently, only an illustrative test example is presented for assistance in adding a model; not to be used in research.
- **Notes:** This is only relevant where multiple different implementations of ACh exist or where multiple cell models share the same implementation.

#### Agent [string]

- **Description:** Pharmacological agent to apply.
- Default value: none.
- Options (all models):
  - o **MC-II-157c**: compound which affects  $I_{Kr}$
  - O Citations:
    - Colman et al. 2017 Front. Physiol 8.
    - Guo et al. 2014 PLOS One 9, e105553.
  - Notes: Only validated in hVM\_ORD\_s for human ventricular cells

# MSCSF - HAM\_WL, DOCUMENTATION BY MICHAEL COLMAN 2019

#### • Options (model-specific):

O Currently no further agents have been included in the framework; as with ACh, a testing example has been presented to assist in addition of your own models.

#### Agent\_proportion [double 0-1 (scaling) or x (concentration)]

- **Description:** Scaling between control and full Agent / concentration of Agent.
- **Default value**: 1 (full effect).

#### Spatial\_gradient [string]

- **Description:** Apply a spatial gradient model. In tissue, needs a map; in single cells, used to inspect and plot the effect of the gradient at any point.
- Default value: none
- Options:
  - o apico\_basal\_example, SAN\_distance\_example
  - o Both of these are NOT physiological or real models simply examples of implementation

# Spatial\_gradient\_prop [double 0-1]

• **Description:** Determines where the single cell model lies within the gradient. Single-cell implementations only (in tissue this must be defined by a spatial gradient map).

#### Environment [intact/isolated]

- **Description:** Sets environmental conditions to **intact** (default for previously published models) or **isolated** (change of  $I_{K1}$  formulation; removal of  $I_{Kr}$  and  $I_{Ks}$ ; addition of  $I_{hyp}$ ).
- Notes: Relevant for human atrial cell models only (hAM\_X).
- Specific citation: Colman et al. 2018 Front. Physiol. 9.

#### Ihyp [double pA/pF]

- **Description:** Determines the magnitude of applied hyperpolarising current,  $I_{hyp}$
- Notes: relevant only for human atrial cell models in isolated environment.

### 5.3 Tissue model options

#### Tissue\_order [1D/2D/3D/geo]

- **Description:** Defines the dimensional order of the tissue model.
- 1D-3D refer to idealised models.
- **geo** refers to those where geometry file is to be used.

#### Tissue\_model [string]

- **Description:** Identifier for the tissue model to be used
- **Notes:** This determines tissue dimensions, conduction parameters, heterogeneity and anisotropy automatically from pre-defined settings.
- Notes: Specific parameter settings can be passed directly as a command-line argument (see below)
  which can overwrite individual default settings specified by the Tissue\_model. Listed are the
  defaults for each tissue model.
- **Default value:** basic
- Options (idealised tissue models; 1D-3D):

# MSCSF - HAM\_WL, DOCUMENTATION BY MICHAEL COLMAN 2019

#### o basic

- NX=NY=100; NZ=10.
- Homogeneous, isotropic, uniform D.
- dx = 0.2 mm; D1 = 0.2, D2 = 0.05, Diso = 0.1 mm/ms.
- Stimulus location: edge and shape: cuboid

#### o functional\_model\_test

- Testing example will all functionality included
- Has settings for: heterogeneity, anisotropy, D non-uniformity, multiple cell models, multiple stimulus shapes, modulation maps.

#### conduction\_velocity

- For assessing conduction velocity.
- 2D or 3D sheets only (NX=NY=201 for 2D; NX=NY=NZ=101 for 3D)
- Homogeneous, anisotropic, uniform D.
- dx = 0.25 mm; D1 = 0.2 and D2 = 0.05 mm/ms.
- Stimulus location: centre and shape: sphere
- Automatically calculates and outputs longitudinal, transverse and diagonal conduction velocities from the final beat of the simulation.

# • Options (idealised tissue models; 1D-3D - continued):

#### o re-entry

- Settings for re-entry simulations.
- 2D or 3D sheets only (NX=NY=200; NZ = 10)
- homogeneous, isotropic, unform\_D.
- dx = 0.25 mm; D1 = 0.2 and D2 = 0.05 mm/ms.
- S1 stimulus type: edge.
- S2 stimulus type: cross\_field.

#### Vent\_transmural

- Heterogeneous transmural strand or sheet of the ventricle.
- Only valid for models which have ENDO, M and EPI celltypes.
- Simple heterogeneity ratio 1:1:1.

#### o Heterogeneous\_human\_atria

- Idealised fully segmented strand/slice/3D\_slab with all regions of human atria implemented
- Valid only for human\_atrial cell models (hAM\_X).
- Celltypes: RA, PM, CT, RAA, AVR, BB, LA, AS, LAA, PV evenly distributed.

#### • Options (anatomically detailed tissue models; geo):

#### functional\_model\_test

- Testing example will all functionality included
- Has settings for: heterogeneity, anisotropy, D non-uniformity (regional and map), multiple cell models, multiple stimulus shapes, modulation maps (coords and files), multi-timed stimulus
- Available map files:
  - Stim: functional\_model\_test\_stim.dat; functional\_model\_test\_S2.dat; functional\_model\_test\_S2\_2.dat; functional\_model\_test\_multi\_stim.dat
  - Diffusion: functional\_model\_test\_Dscale\_base\_map.dat; functional\_model\_test\_D\_AR\_scale\_base\_map.dat
  - Modulation: functional\_model\_test\_ISO\_map.dat; functional\_model\_test\_ACh\_map.dat; functional\_model\_test\_remod\_map.dat; functional\_model\_test\_SRF\_map.dat;

functional\_model\_test\_Dscale\_mod\_map.dat; functional\_model\_test\_D\_AR\_scale\_mod\_map.dat; functional\_model\_test\_Direct\_modulation\_map.dat

• Phasemap: functional\_model\_test\_phasemap.dat

#### Tissue\_type [homogeneous/heterogeneous]

- **Description:** Whether the tissue is electrophysiologically homogeneous or heterogeneous.
- **Notes:** If heterogeneous is specified, the cell-types present in the tissue model must already be specified by the **Tissue\_model** and must have an entry in the cell **Model** used.
- **Default value** is **Tissue\_model** dependent. This will overwrite the default.

#### Orientation\_type [isotropic/anisotropic]

- **Description:** Selects between using the isotropic or anisotropic FDM implementations.
- **Notes:** If isotropic, the parameter **Diso** (set by the **Tissue\_model** or overwritten by the specific argument) defines the diffusion tensor; if anisotropic, **D1** and **D2** define the diffusion tensor.
- **Default value** is **Tissue\_model** dependent.

#### D\_uniformity [uniform/map/regional/regional\_map]

- **Description:** Defines whether **Diso** or **D1 and D2** vary spatially.
- map will scale all **D** parameters according to a specified map; map must exist in **Tissue\_model**.
- regional will set **D** properties according to tissue-region. Specific settings must exist in Tissue\_model.
- regional\_map will sequentially apply regional and map non-uniformity.
- **Default value**: uniform (majority of Tissue\_models; some may have different defaults.)

#### Stimulus\_location\_type / S2\_Stimulus\_location\_type [string]

- Description: Selects pre-defined settings for stimulus location and size (across all models).
- **Notes:** Individual or all settings can be manually controlled/overwritten with command-line arguments. These just define some common defaults.
- Options (S1; idealised tissue models):
  - o edge stimulates an edge of the tissue; 10 nodes in x-direction, all in y and z.
  - centre stimulates from centre of tissue; 11 nodes in all directions.
  - o whole\_tissue stimulates the whole tissue simultaneously.
- Options (S2; idealised tissue models):
  - o **S1** applies the same settings as the S1 stimulus.
  - o edge/centre same settings as described for S1
  - o **cross\_field** stimulates half the tissue (in y; all x and z).
- Options (geo / anatomical reconstruction models):
  - o **file** read in the stimulus site from a file (as set in tissue\_model, or passed as an argument)
  - o **coords -** like with idealised, set stimulus from coordinates. Requires the settings to be set in Tissue\_model or passed in directly as arguments.
- **Default value:** edge (idealised models); file (geo models)

#### {S1/S2}\_shape [cuboid/sphere]

- **Description:** Defines shape of stimulus.
- **Notes:** If using geo, this will only apply if "coords" is set for Stimulus\_location\_type; if "file" is selected, the map is read from a file and so shape doesn't have any effect.

#### ${S1/S2}_{x/y/z}_{loc}[int]$

- **Description:** Defines the centre of the stimulus in each dimension.
- Notes: Value is array index.

#### ${S1/S2}_{x/y/z}$ \_size [int]

- **Description:** Defines the size of the stimulus in each direction.
- **Notes:** Value is array index either side of centre: a size of 5 in x would give a total size of 11 in x, 5 either side of the centre-point.

#### Multi\_stim [On/Off]

- **Description:** Sets whether to use a multi-site and timed stimulus. E.g. ventricular stimulation.
- Notes: Only valid for geo models; a file with the stimulus information must be supplied.

#### {D1/D\_AR/dx} [double]

- **Description:** Explicitly sets any of these values, overwriting default settings associated with the tissue model.
- Notes: If the Orientation\_type is *isotropic* then using the argument **D1** will set **Diso**, the value of D used for isotropic simulations. If *anisotropic*, D2 = **D1/D\_AR**.

#### {OX/OY/OZ} [double 0-1]

- **Description:** Explicitly sets the global fibre orientation. Valid for idealised models only.
- Notes: Will automatically set the final orientation to impose normalisation; in 2D, only OX or OY needs to be defined; in 3D, any two of OX, OY and OZ must be defined.

#### Global\_orientation\_direction

#### [X/Y/Z/{XY/XZ/YZ}\_{plus/minus}/XYZ\_{ppp/ppm/pmp/mpp}]

• **Description:** Automatically sets OX, OY and OZ to point in the direction specified (idealised models only).

#### {ISO/ACh/Remodelling/Direct\_modulation}\_map [Off/On]

- **Description:** Defines whether ISO, ACh, Remodelling or Direct\_modulation (the direct control parameters listed later) are to be applied homogeneously to the tissue, or according to a map to localise.
- Notes: For anatomically detailed models, a map file must also exist and be specified.
- Notes: ISO, ACh and Remodelling are continuous maps, where map = 0 means no modulation applied, map = 1 means full modulation (set by the value of ISO, ACh, Remodelling\_prop) applies, and between 0 and 1 is linearly scaled between none and maximum modulation. Direct\_modulation is a discrete map where it can only be off or on (0 or 1).
- Default value: Off.

#### Dscale/D\_AR\_scale [double]

- **Description:** Scales the diffusion tensor (**D1** and **D2**) and/or the anisotropy ratio uniformly throughout tissue.
- Notes: Dscale applies equally to D1 and D2 if anisotropic (preserves anisotropy ratio). D\_AR\_scale scales D\_AR i.e. D2 = D1/(D\_AR . D\_AR\_scale).

#### {Dscale/D\_AR\_scale}\_mod\_map [Off/On]

- Description: Defines whether Dscale and/or D\_AR\_scale will be applied by a map or homogeneously.
- **Notes:** Similar to ISO/ACh/Remodelling maps can be continuous, and determines region where and to what extent Dscale or D\_AR\_scale are applied.

#### map\_in\_type [file/coords]

- **Description:** Defines whether the modulation map (ISO/ACh/Remodelling/Direct\_modulation /Dscale/D\_AR\_scale) will be set by coordinates (idealised or anatomically detailed) or from a file (anatomically detailed only).
- Note: For coordinates, all modulations must use the same map; for file, all can be different.

 $map_{x/y/z}_{shape/loc/size}$  control the modulation map in exactly the same way as the stimulus shape/loc/size arguments above. Applies for  $map_{in}$  type coords only.

 $\label{lem:continuous} $$ \left[ \frac{s tim}{S2\_s tim} \right] - AR\_s cale\_base\_map/D\_AR\_s cale\_map/D\_AR\_s cale\_map/ISO\_map/remod\_map/ACh\_map/Direct\_modulation\_map/Spatial\_gradient\_map-file [string]$ 

- **Description:** Specifies a file to be read in for any of the above; valid for "geo" models only.
- Note: {Dscale/D\_AR\_scale}\_base\_map refers to the map file used for D\_uniformity; {Dscale/D\_AR\_scale}\_mod\_map refers to the map file used for Dscale and D\_AR\_scale.
- **Notes:** This will overwrite the default file set for specific use. E.g. if a default stimulus location is for sinus rhythm, and it is desired to pace from elsewhere, can simply specify the file as an argument rather than having to make new settings.

#### Multiple\_models [Off/On]

- **Description:** Sets whether multiple baseline cell models are to be used for different regions of the tissue model (e.g. a separate atrial and ventricular cell model).
- Notes: The specific tissue model must have settings for multiple models enabled.

#### Tissue\_model\_2 [string]

• **Description:** Exactly the same as Model argument, where it sets the cell model to be used in the Model\_2 region of tissue model, if Multiple\_models is On.

#### Spatial\_output\_interval\_{data/vtk} [int (ms)]

- **Description:** The interval period for which spatial data will be output, for either binary arrays (data) or vtk files (vtk).
- **Notes:** vtk data is 3D, including any empty space (represented by "-100"); binary data is real nodes only.
- **Notes:** set to "0" to prevent spatial outputs.
- **Default:** vtk 0 = off; data 5 ms.

#### Spatial\_output\_range\_{start/end} [int (ms)]

- **Description:** Specify the time range over which spatial data will be output
- **Default:** Start set to 0 and end set to total\_time.

# 5.6. Direct control parameters (all implementations).

Many properties of the ion current formulations and calcium dynamics can be directly modified by passing arguments. The following options are available for some or all of the following: Current scaling, voltage dependence, time-constant scaling  $-I_{Na}$ ,  $I_{to}$ ,  $I_{Kur}$ ,  $I_{CaL}$ ,  $I_{Kr}$ ,  $I_{Ks}$ ,  $I_{NaL}$ ; Scaling only  $-I_{NCX}$ ,  $I_{CaP}$ ,  $I_{Cab}$ ,  $I_{Nab}$ ,  $I_{up}$ ,  $I_{rel}$ ,  $I_{leak}$ . Pass argument "Display Arguments" (or any invalid argument) to receive the error message which will display the full list of the available options and the specific syntax. Modifications will be applied in addition to any other modifications set by model conditions.

**NOTE**: in 3D/0D models, there are two parameters which can control magnitude of  $I_{Cal.}$ ,  $J_{rel}$ : one is the expression (N per dyad ave – controlled by "**ICal\_scale**", "**Jrel\_scale**") and the other is the transition rate to open state (controlled by "**LTCC\_Po**", "**RyR\_Po**"); these therefore have different effects, and represent different things (e.g. remodelling may change channel expression i.e. N, whereas ISO or a drug may only change channel availability).

Argument	Description	Type/default	Notes
X_scale	Scales the current or flux directly	double/1.0	
X_va_tau_scale	Scales the time constant of the voltage-dependent activation gate of current X.	double/1.0	If multiple gates exist, multiple variables may exist with specific reference.
X_vi_tau_scale	Same as above, for the voltage- dependent inactivation gate(s)	double/1.0	^^
X_shift	Shifts the voltage dependence of all voltage dependent functions associated with current X	double/0	Convention is as if being positively applied to the half-maximal constant $(V_{1/2})$ – thus is subtracted from the voltage "seen" by the current
X_{va/vi}_{ss/tau} _shift	Individually shifts the voltage- dependence of the steady-state (ss) or time-constant (tau) for the activation or inactivation gate(s)	double/0	^^
X_{va/vi}_ss_ksc ale	Scales the gradient parameter of regular sigmoidal steady-state voltage dependence functions	double/1.0	

# 5.7. Settings files

You can use settings files to store the options passed in, for quick reproduction, saving a long list of arguments etc.

These files can be anywhere, where the full path of the file must be passed in after "Settings\_file" argument.

You can use a settings file AND command line arguments:

"Settings\_file" argument must be passed FIRST (this is the only restriction on order of arguments)

Any arguments passed after this will supplement or overwrite the options in the file; command line args supersede settings files if the same argument is in both.

Settings files must have the following format as a plain text document, new line for each argument, spaces or tabs to separate arg and value:

```
Contents of "Settings_file_X.txt"

Number of args

ARG 1 Value 1

ARG 2 Value 2

...

Example: An example settings_file could have contents:

3

BCL 345

Model hAM_CRN

Results_Reference file_test

And performing:

./model_single_native Settings_file [filename] Remodelling AF_GB

will apply BCL = 345; Model = hAM_CRN; Results_Reference = file_test; Remodelling = AF_GB

Or with the same argument in the file and passed afterwards:

./model_single_native Settings_file [filename] Remodelling AF_GB Results_Reference remod will apply BCL = 345; Model = hAM_CRN; Results_Reference = remod; Remodelling = AF_GB
```

# 6. Examples of various protocols

Here are listed examples/pseudo-scripts of how to run various models and protocols. The examples given are equivalent or similar to the script files provided in MSCSF/Example\_scripts.

## 6.1. Basic, single-cell examples

#### 1. Control pacing

Apply pacing to a specified model at a constant BCL for 200 beats, using references to identify data.

./model\_single\_native Model hAM\_CRN BCL 750 Beats 200 Reference Control\_pacing\_hAM\_CRN Results\_Reference BCL\_750

This will create an Outputs directory named: "Outputs\_single\_native\_Control\_pacing\_hAM\_CRN", within which results directory for the two BCLs "Results\_750".

#### 2. Including multiple modulations applied to multiple cell models

Compare control and remodelling at three ISO concentrations to two cell models.

For model in [hAM\_CRN, hAM\_GB]

For remodelling in [none, AF\_GB]

For *iso* in [0, 0.5, 1]

./model\_single\_native Model *model* Beats 50 ISO *iso* Remodelling *remodelling* Reference Control\_modulation\_*model* Results\_Reference ISO\_*iso*\_Remodelling\_*remodelling* 

This will create an Outputs directory associated with each model: "Outputs\_single\_native\_Control\_modulation\_model" and Results directories for each condition: "Results\_ISO\_iso\_Remodelling\_remodelling"

#### 3. APD restitution protocol

Apply multiple BCLs to a single model for control and remodelling condition

For bcl in sequence 200 to 1000 in steps of 50

./model\_single\_native Model hAM\_CRN Beats 200 BCL *bcl* Reference APDr\_CRN\_control Results\_Reference *bcl* 

./model\_single\_native Model hAM\_CRN Beats 200 BCL *bcl* Remodelling AF\_Col\_1 Reference APDr\_CRN\_remodelling Results\_Reference *bcl* 

This will create an Outputs directory each for control and remodelling, within properties and raw data are stored: "Outputs\_single\_native\_APDr\_CRN\_{control/remodelling}" and Results directory "Results\_bcl". "Outputs\_single\_native\_APDr\_CRN\_X/Properties\_log.dat" will contain a list of the final 2 beat properties for all simulations under this reference (so here, lines in sequence for each BCL from 200 to 1000 with APD, dvdt\_max, amplitude etc) and "Results\_bcl/Currents.dat" will contain the raw AP data for each pacing rate.

#### 4. State read and write

Apply a long train of stimuli at a rapid rate, until the model reaches stable state, at which point write the state file. Then, read in the state file as initial conditions and apply just a few beats. Compare final properties for stability.

./model\_single\_native Model hAM\_CRN BCL 450 Beats 200 Write\_state On Reference State\_write\_read\_example Results\_Reference Write

# ./model\_single\_native Model hAM\_CRN BCL 450 Beats 5 Read\_state On Reference State\_write\_read\_example Results\_Reference Read

Note that state files are saved independently of the results data (being placed in the PATH directory), and so you need not worry about accidentally deleting state files when deleting redundant or old data.

#### 5. ERP protocol, using state read and write

First, apply pacing at a control BCL until steady state and write the state:

#### ./model\_single\_native Model hAM\_CRN BCL 1000 Beats 200 Write\_state On

We don't pass a reference here as we don't need to save the results data associated with the simulation – it was simply used to write the state file.

Now, read the state, apply 5 beats for S1 and then cycle through S2 intervals:

For s2 in sequence 400 down to 80 in steps of -10

# ./model\_single\_native Model hAM\_CRN BCL 1000 Beats 5 Read\_state On S2 s2 Reference CRN\_ERP Results\_Reference s2

"Outputs\_single\_native\_CRN\_ERP/Properties\_log.dat" contains the measured data (relevantly Vmin, Vmax, Vamp) for each S2. Plot: column 2 (S2) vs 15 (Vmin) 17 (Vmax) or 19 (Vamp) for these properties in the final beat (i.e. S2). Can compare to columns 16, 18 and 20 for the same properties on the penultimate beat (i.e. S1 and thus should be a flat line). And/Or inspect / run a script to determine at what S2 the Vamp (column 19) reaches below e.g. 80% of that for S1 (column 20). Use the raw data in "../Results\_s2/Currents.dat" to inspect and check the AP train and that nothing funny is happening! (e.g. alternans, missed excitations etc).

For efficiency, you probably want to run it using a coarse S2 interval at first (to identify the S2 range for the ERP) and then use a finer interval to find the actual ERP.

#### 6. Applying a train of two different pacing rates

You can use the argument NS2 to apply multiple S2 stimuli, for example to apply a train of one pacing rate followed by another (rather than using S2 for an S1S2 protocol).

./model\_single\_native Model hAM\_CRN BCL 1000 Beats 50 S2 500 NS2 50 Reference two\_pacing\_rates

Which will apply 50 beats at a cycle length of 1000 ms followed by 50 beats at a cycle length of 500 ms.

#### 7. Multiple and direct modulation

Example where multiple modulation models are applied with and without some direct control modulation.

./model\_single\_native Model hAM\_CRN BCL 1000 Beats 10 Celltype PV ISO 0.5 Reference Direct\_modulation Results\_Reference Without\_direct\_modulation

./model\_single\_native Model hAM\_CRN BCL 1000 Beats 10 Celltype PV ISO 0.5 INa\_scale 0.5 Jup\_scale 0.5 Ito\_va\_tau\_scale 5 ICaL\_vi\_ss\_shift -10 IKur\_va\_ss\_kscale 2 Ito\_vi\_tau\_shift 10 ICaL\_scale 0.5 Reference Direct\_modulation Results\_Reference With direct modulation

Further to the results data, compare the parameters list in "../Parameters\_Without\_direct\_modulation" and "../Parameters\_With\_direct\_modulation" and the voltage-dependent steady-state of ICaL\_vi, IKur\_va and time constants of Ito\_va and vi in in "../Parameters\_X/Ix.dat" to visualise the effect of the voltage shift, time-constant scaling and kscale:

# MSCSF - HAM\_WL, DOCUMENTATION BY MICHAEL COLMAN 2019

- "../Parameters...Without../ICaL.dat" 1 vs 4 against
- "../Parameters...Without../IKur.dat" 1 vs 2 against
- "../Parameters...Without../Ito.dat" 1 vs 3, 5 against
- "../Parameters...With../ICaL.dat" 1 vs 4
- "../Parameters...With../IKur.dat" 1 vs 2
  "../Parameters...With../Ito.dat" 1 vs 3, 5

#### 8. Using state references to identify state files

State files are automatically named for a number of parameters. For single cell state files, these are: **Model**, **BCL**, **Celltype**, **ISO**, **ACh**, **Remodelling**, **Agent**, **Mutation** and **Environment**. This means that any other conditions/settings (ISO\_model, Remodelling\_prop, any direct control modulation) are not encoded automatically - state files with different settings here will overwrite each other. In order to distinguish and identify specific state files which are not differentiated by the automatically encoded conditions, you can use a State\_reference (for reading or writing) - this appends the reference to the state files.

So, if we want to write state files for a simulation which includes differences in these additional variables – let's say including a direct control modulation of  $I_{K1}$  – we will need a state reference to differentiate the state file with and without  $I_{K1}$  modulation:

./model\_single\_native Model hAM\_CRN Beats 100 ISO 1 Write\_state On Reference State\_reference\_example Results\_Reference hAM\_CRN\_ISO\_control\_write

./model\_single\_native Model hAM\_CRN Beats 100 ISO 1 IK1\_scale 1.5 Write\_state On **State\_Reference\_write IK1\_scale\_1p5** Reference State\_reference\_example Results\_Reference hAM\_CRN\_ISO\_IK1\_write

Now, if we are reading in the state, we need to ensure we read in the correct one. Notice that:

./model\_single\_native Model hAM\_CRN Beats 5 ISO 1 IK1\_scale 1.5 Read\_state On Reference State\_reference\_example Results\_Reference hAM\_CRN\_ISO\_control\_read

reads in the state file written without the  $I_{K1}$  modulation (i.e. the resting potential at the start of the simulation does not match the end of the simulation performed with IK1\_scale 1.5). Whereas:

./model\_single\_native Model hAM\_CRN Beats 5 ISO 1 IK1\_scale 1.5 Read\_state On **State\_Reference\_read IK1\_scale\_1p5** Reference State\_reference\_example Results\_Reference hAM\_CRN\_ISO\_IK1\_read

does read in the correct state file. Note the reference you pass is completely up to you and doesn't have to link directly to the additional modulation – use sensible references to identify and distinguish your simulations.

Another reason you may need to use state references would be to write the state at different time points during a simulation. As the simulation conditions are identical, you need state references to identify specifically the time point you wrote the state file.

#### 9. Settings file example

Example 7 above, "Multiple and direct modulation", required the application of multiple modulation runtime arguments. In order to tidy this up a little, and not require so many arguments, we can use a settings file to encode most or all of the arguments we want to pass. Settings files can be used in combination with further command-line arguments, as long as the **settings file argument is passed first**. Any command-line arguments passed after then supplements or overwrite the arguments in the settings file.

So, for example, to repeat example 7 but this time for multiple cell models and varying the ICaL\_scale amount (but not the others), we could first create a settings file called "SF\_example\_modulation.txt" with the following contents:

11 BCL 1000 Beats 10

# MSCSF - HAM\_WL, DOCUMENTATION BY MICHAEL COLMAN 2019

Celltype PV
ISO 0.5
INa\_scale 0.5
Jup\_scale 0.5
Ito\_va\_tau\_scale 5
ICaL\_vi\_ss\_shift -10
IKur\_va\_ss\_kscale 2
Ito\_vi\_tau\_shift 10
Reference Direct\_modulation\_settings\_file

And then call this file in a loop over different cell models can ICaL scales:

For model in hAM\_CRN hAM\_GB hAM\_NG

For *ical* in 0 0.5 1 1.5 2

./model\_single\_native Settings\_file SF\_example\_modulation.txt Model *model* ICaL\_scale *ical* Results\_Reference *model\_ical* 

Which will now create specific Results directories for each model and ICaL\_scale.

#### 10. Applying a voltage clamp

We can also apply simple voltage clamp protocols (the details of which have been hard-coded into the source code; you need to change the code in order to include different or more complex voltage clamp protocols in **lib/Model.c**). Passing Vclamp On will apply three simple voltage clamp protocols ( $I_{Cal.}$ ,  $I_{K}$  and  $I_{K1}$ ) before the simulation is performed (or set Beats to 0 to perform the voltage clamp only).

./model\_single\_native Model hAM\_CRN Beats 0 Vclamp On Reference Voltage\_clamp\_example

And now the data for the voltage clamp is found in:

 $"Outputs\_single\_native\_Voltage\_clamp\_example/Parameters/I\{CaL/K\}\_Vclamp\_trace\{s/\_Y.dat\}" and the properties of the pro$ 

"Outputs\_single\_native\_Voltage\_clamp\_example/Parameters/I{CaL/K/K1}\_IV.dat"

# 6.2 Tissue model examples – idealised tissue models

### 1. Basic pacing in an idealised tissue model at different dimensional orders

We will use the idealised tissue model "basic" and apply control pacing in a 1D strand, 2D sheet and 3D cuboid:

./model\_tissue\_native Model minimal BCL 500 Beats 20 Tissue\_model basic Tissue\_order 1D Reference Basic model pacing 1D

./model\_tissue\_native Model minimal BCL 500 Beats 2 Tissue\_model basic Tissue\_order 2D Reference Basic\_model\_pacing\_2D

./model\_tissue\_native Model minimal BCL 500 Beats 1 Tissue\_model basic Tissue\_order 3D Reference Basic\_model\_pacing\_3D

This will create an Outputs directory named for the model: "Outputs\_tissue\_native\_Basic\_model\_pacing\_{1D/2D/3D}". In the Outputs directories are the files "Geometry\_idealised.vtk" and the stimulus and diffusion map files: "Map\_{S1/S2}.vtk" and "Map\_{D1/D2}.vtk". Notice for the 1D models, these contain just one line of data, with either the value of D1 or, for the stim map, 1s for stimulus regions and 0s for non-stimulus regions. For the 2D or 3D models, we can visualise this using visualisation software (such as the free Paraview (tm) program).

Our results are now in "Results", which contains files "Currents\_cell{1-3}.dat" and "Properties\_cell{1-3}.dat" - simply the single-cell outputs, as produced using model\_single\_native, for three different cells in the tissue. "Results/Vm\_linescan\_x" contains a linescan of voltage in the x-direction, each line for 1 ms intervals. "Spatial\_Results" then contains outputs of the voltage in all space at specific time points (by default, binary data with an interval of 5 ms). The next example gives an example of how to convert these binary data into plain text and/or vtk.

#### 2. Convert binary data to plain text and/or vtk files

As, by default, the model outputs spatial data only in binary form, we need to use the tool "bin\_to\_vtk\_tissue" to convert the binary data into plain text and/or vtk. This must be executed in the same directory as the simulations were performed, or a parent directory which contains the "Outputs\_" directories required.

In order to access the data correctly and with the correct settings, we must pass arguments:

- 1. Any Reference and/or Results\_Reference passed (to look in correct Outputs and Spatial\_Results directories)
- 2. The variable we wish to convert (Vm only for native tissue models by default)
- 3. The start, end and interval time over which convert data (binaries written at interval of 5 ms as default)
- 4. The Tissue\_order and Tissue\_model used to perform the simulation (necessary for array sizes etc)
- 5. The data you want to write: Write\_vtk, Write\_data, On or Off
- 6. The model type (integrated or native)

So, for the 2D and 3D simulations performed in the previous example, we will run: (note – we did not pass a Results\_Reference for the simulations, so don't pass one here!)

Convert the 2D data into vtk and plain text, for the second beat (t = 500 ms to 1000 ms in 20 ms intervals):

./bin\_to\_vtk\_tissue Reference Basic\_model\_pacing\_2D Tissue\_model basic Tissue\_order 2D start\_time 500 end\_time 1000 interval 20 Variable Vm Write\_vtk On Write\_data On Model\_type native

Convert the 3D data into vtk only, for the first beat (t = 500 ms to 1000 ms in 10 ms intervals):

./bin\_to\_vtk\_tissue Reference Basic\_model\_pacing\_3D Tissue\_model basic Tissue\_order 3D start\_time 0 end\_time 500 interval 10 Variable Vm Write\_vtk On Write\_data Off Model\_type native

And now you'll see in the Spatial\_Results directories are also .dat and .vtk files.

#### 3. Controlling spatial outputs at run-time

We may want to change the interval over which binary data are written, or to output vtk files directly from the simulation for fast inspection of results, or output no spatial data at all if the excitation data is sufficient and we want to save disk space. To do this, we use "Spatial\_output\_interval\_{data/vtk} [x]", where "0" will prevent data being output.

We will run the same simulation as example 1, for the 2D case, except now we will output binary spatial data every ms, and a vtk for inspection every 10 ms.

./model\_tissue\_native Model minimal BCL 500 Beats 2 Tissue\_model basic Tissue\_order 2D Reference Basic\_model\_pacing\_2D Results\_Reference Controlling\_output\_intervals Spatial output interval data 1 Spatial output interval vtk 10

Or output no spatial data:

./model\_tissue\_native Model minimal BCL 500 Beats 2 Tissue\_model basic Tissue\_order 2D Reference Basic\_model\_pacing\_2D Results\_Reference Preventing\_spatial\_data\_output Spatial\_output\_interval\_data 0 Spatial\_output\_interval\_vtk 0

Notice now, in "Outputs\_tissue\_native\_Basic\_model\_pacing\_2D", we have new Results and Spatial\_Results directories, with the Results\_References appended. Note that in ".../Spatial\_Results\_Controlling\_output\_intervals", there are binary data at intervals of 1 ms rather than 5 ms, and a vtk at intervals of 10 ms, while in ".../Spatial\_Results/Preventing\_spatial\_data\_output" there are no spatial data. Also note that the Currents data in ".../Results\_X/" are the same for all simulations, as the conditions were identical.

We may now want to convert the 1ms interval binary data into vtk files, for which we use the "bin\_to\_vtk\_tissue" tool, as before, but now need to also pass the Results Reference:

./bin\_to\_vtk\_tissue Reference Basic\_model\_pacing\_2D Tissue\_model basic Tissue\_order 2D start\_time 500 end\_time 700 interval 1 Variable Vm Write\_vtk On Write\_data On Model\_type native Results\_Reference Controlling\_output\_intervals

Note how now, vtk files before 500 ms have intervals of 10 ms (as output by the simulation), whereas between 500 and 700 the vtk interval is 1ms.

#### 4. Controlling stimulus spatial properties

There are different ways we can control the stimulus spatial properties from the command-line (i.e. to differ from any default settings). For the Tissue\_model basic, which we used for the above examples, the default settings for both S1 and S2 stimulus "edge" with a shape "cuboid" – which simply means stimulate from the small-x end of the tissue, using a cuboid stimulus shape.

The first way we can change the stimulus spatial settings is to pass in some of the other pre-defined types, and change the shape from cuboid to sphere. These pre-defined types set the location and sizes of the stimulus in all directions, based on the tissue dimensions.

First, let's make the S1 stimulus from the centre and a sphere/circular shape (we limit total time as this is sufficient to inspect the stimulus):

./model\_tissue\_native Tissue\_model basic Tissue\_order 2D Stimulus\_location\_type centre S1\_shape sphere Reference Stimulus\_S1\_centre\_sphere Total\_time 20 Spatial\_output\_interval\_vtk 5

We can now inspect the stimulus site using

"Outputs\_tissue\_native\_Stimulus\_S1\_centre\_sphere/Map\_S1.vtk" and can check the vtk files for voltage evolve as we would expect.

We can set the S1 stimulus to be "edge", "centre" or "whole-tissue" and shape to be "cuboid" or "sphere". Using "S2\_Stimulus\_location\_type", we can also do the same for the S2 stimulus, where now our options are: "S1" – to be identical to the S1 stimulus; "edge", "centre" or "cross\_field".

Let's try setting an S2 of 300 ms and set the stimulus to be "cross\_field":

./model\_tissue\_native Tissue\_model basic Tissue\_order 2D Reference Stimulus\_S2\_cross\_field Total\_time 500 Beats 1 S2 300 S2\_Stimulus\_location\_type cross\_field Spatial\_output\_interval\_vtk 5

And we can inspect the S2 stimulus settings in

"Outputs\_tissue\_native\_Stimulus\_S2\_cross\_field/Map\_S2.vtk".

Finally, we can also control explicitly the location (centre-points) and sizes (distance from the centre to the edge) of both stimuli. We can define every single value ourselves, or start from a pre-defined setting and overwrite just some parameters.

Let's start with Stimulus\_location\_type edge, but move it in the x-direction; let's also set the S2 stimulus to be centre, move its centre in y and adjust its size in x and y:

./model\_tissue\_native Tissue\_model basic Tissue\_order 2D Reference Explicit\_stimulus\_settings Stimulus\_location\_type edge S1\_shape cuboid S1\_x\_loc 50 S2\_Stimulus\_location\_type centre S2\_shape cuboid S2\_y\_loc 25 S2\_x\_size 15 S2\_y\_size 5 S2 300 Total\_time 500

Note: if we set the shape to "sphere", then the only size parameter is the radius (as elliptical stimulus functionality has not been included yet) – the only size argument we can use is "..x\_size", to define the radius; y\_size and z\_size will have no affect if shape is sphere.

#### 5. Heterogeneity, anisotropy and diffusion tensor spatial variation

We will now show examples of turning on or off heterogeneity, anisotropy and D\_uniformity. To turn any of these on, first, the tissue model must have appropriate settings (in lib/Tissue.cpp – see the available functionality of each tissue model in the full arguments section or AVAILABLE\_MODEL\_LIST.txt) – we will use the Tissue model "functional\_model\_test" now, as this has settings for all of these functionalities, with the defaults set to off (homogeneous, isotropic and uniform).

First, let's run the model with defaults (so we can make comparisons):

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Reference functional test defaults Total time 500

Note that the on-screen settings show: Tissue type = homogeneous, Orientation type = isotropic and D\_uniformity = uniform.

Now, let's make the model heterogeneous, anisotropic, and vary D according to region:

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Reference functional\_test\_het\_aniso\_regional\_D Total\_time 500 Tissue\_type heterogeneous Orientation\_type anisotropic D\_uniformity regional

First, we can compare "Outputs...Defaults/Geometry\_idealised.vtk" with the file in "Outputs...het\_aniso\_regional\_D/" to inspect the geometry and the celltype segmentation.

We can also compare "Outputs...Defaults/Map\_{D1/D2}.vtk" with those in "Outputs...\_het\_aniso\_regional\_D" and confirm that they both do, indeed, vary in space. Moreover, "Outputs...het\_aniso\_regional\_D" also contains a file "Orientation.vtk" of the fibre orientation (note this is global with them all pointing in the same direction).

Let's also inspect the evolution of voltage in the tissue:

./bin\_to\_vtk\_tissue Tissue\_model functional\_model\_test Tissue\_order 2D start\_time 0 end\_time 500 interval 10 Reference functional\_test\_defaults

./bin\_to\_vtk\_tissue Tissue\_model functional\_model\_test Tissue\_order 2D start\_time 0 end\_time 500 interval 10 Reference functional\_test\_het\_aniso\_regional\_D

And we can clearly see the influence of the myocyte orientation, regionally dependent D1 and D2, and the heterogeneity (and thus repolarisation time) on the activation and repolarisation patterns.

Note that we need heterogeneity settings in order to apply regional D uniformity (as it depends on cell number in the tissue geometry), but we can set the Tissue\_type to homogeneous to apply homogeneous electrophysiology.

## 6. Setting the diffusion parameters at run-time

You can explicitly set the values of the diffusion properties (D1 and D\_AR) and the spatial integration step (dx) through command-line arguments. Note: If D\_uniformity is not uniform, then D1 and D\_AR set the baseline values, from which regional variation is scaled. Let's run the heterogeneous, anisotropic and regional D simulation from the previous example, except with a larger D1, larger anisotropy ratio, and larger space step. You may have noticed the on-screen outputs for the previous simulation (also in "Outputs\_tissue\_native\_functional\_test\_het\_aniso\_regional\_D/Settings.dat") that this model has default settings: D1 = 0.2 mm/ms; D\_AR = 4; dx = 0.2 mm.

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Reference functional\_Diffusion\_params Total\_time 500 Tissue\_type heterogeneous Orientation\_type anisotropic D\_uniformity regional D1 0.3 D\_AR 10 dx 0.25

Now, inspecting the D1 and D2 maps compared to the previous simulation should clearly show the larger D1 and anisotropy ratio (smaller D2 relative to D1). And if we analyse the voltage evolution data, we can see the impact this has (also reflected in the Activation\_output.vtk data):

./bin\_to\_vtk\_tissue Tissue\_model functional\_model\_test Tissue\_order 2D start\_time 0 end\_time 500 interval 10 Reference functional\_Diffusion\_params

#### 7. Setting the global orientation at run-time

Idealised tissue models can only have global myocyte orientation (i.e. the same orientation for every cell in the tissue). You can directly control what this orientation is, through either explicitly setting each component (**OX**, **OY**, **OZ**) or by selecting a pre-set global orientation direction using the **Global\_orientation\_direction** argument. If setting directly, you only need to specify N-1 components, as the code will automatically set the final component from the normalisation constraint. Obviously, Orientation\_type anisotropic must be set in order for the orientation to have any effect.

Let's set the stimulus to be centre and sphere, and change the default components explicitly, in both 2D and 3D:

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Stimulus\_location\_type centre S1\_shape sphere Total\_time 200 Orientation\_type anisotropic OX 1 Reference 2D\_OX\_1 Spatial\_output\_interval\_vtk 10

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Stimulus\_location\_type centre S1\_shape sphere Total\_time 200 Orientation\_type anisotropic OY 0.2656 Reference 2D OY 0p2656 Spatial output interval vtk 10

./model\_tissue\_native Tissue\_order 3D Tissue\_model functional\_model\_test Stimulus\_location\_type centre S1\_shape sphere Total\_time 200 Orientation\_type anisotropic OX 0.7 OY 0.1 Reference 3D\_OX\_0p7\_OY\_0p1 Spatial\_output\_interval\_vtk 10

./model\_tissue\_native Tissue\_order 3D Tissue\_model functional\_model\_test Stimulus\_location\_type centre S1\_shape sphere Total\_time 200 Orientation\_type anisotropic OX 0.2 OZ 0.5 Reference 3D\_OX\_0p2\_OZ\_0p5 Spatial\_output\_interval\_vtk 10

Note that the on-screen settings (and in Settings.dat) prints the values of all the orientation components. Visualise the orientations using "Outputs\_X/Orientation.vtk" and check they align with what is expected from the settings, and do indeed control the preferential direction of propagation correctly (which should be apparent from the voltage spatial outputs and the activation map).

We can also use Global\_orientation\_direction to set the fibres pointing in any of the principal or diagonal directions. Let's set Total\_time to zero so we can quickly output the Orientation for different pre-set directions.

For *orientation* in X Y Z XY\_plus XY\_minus XZ\_plus XZ\_minus YZ\_plus YZ\_minus XYZ\_ppp XYZ\_ppm XYZ\_ppm XYZ\_mpp

./model\_tissue\_native Tissue\_order 3D Tissue\_model functional\_model\_test Total\_time 0 Orientation\_type anisotropic Global\_orientation\_direction orientation Reference orientation

And again, we can inspect the orientation in "Outputs\_X/Orientation.vtk"

#### 8. Using model "conduction\_velocity" to parameterise a tissue model

The **Tissue\_model conduction\_velocity** has been provided to calculate and parameterise conduction velocities relative to the myocyte orientation. For this specific model only, certain cells are set for the conduction velocity to be automatically calculated in all principal and diagonal directions (rather than requiring post-processing of the results data to make these calculations). Combining this tissue model with direct settings of **D1**, **D\_AR** and **dx** allows other tissue model properties to be matched, to provide a clean method to calculate and parameterise these parameters to match experimentally measured conduction velocities. The model must be run using homogeneous, where the influence of celltype on conduction velocity can be investigated by passing different celltypes.

By default, the model is 2D and sets the global orientation in the x-direction, and applies a spherical stimulus to the centre; the conduction velocity in the x-direction thus gives the longitudinal velocity, and in the y-direction gives the transverse conduction velocity. The velocities and diffusion parameters are stored in the file "Outputs\_tissue\_native\_X/Conduction\_velocity\_log.dat" and output to screen.

Let's run the model with default parameters, then set a different dx (to correspond to the space step of an anatomical reconstruction) and cycle through a couple of diffusion parameter combinations to see the effect on the conduction velocity. We'll use just 1 beat here to save time; ensure you are at stable state for real parameterisation. We'll use Results\_Reference to distinguish individual simulations, such that a list of our conduction velocity data is stored in Conduction\_velocity\_log.dat.

./model\_tissue\_native Tissue\_model conduction\_velocity Beats 1 BCL 500 Reference Conduction\_velocity Results\_Reference default\_params

./model\_tissue\_native Tissue\_model conduction\_velocity Beats 1 BCL 500 dx 0.3 Reference Conduction\_velocity Results\_Reference dx

./model\_tissue\_native Tissue\_model conduction\_velocity Beats 1 BCL 500 dx 0.3 D1 0.25 D\_AR 8 Reference Conduction\_velocity Results\_Reference dx\_D1\_D\_AR\_1

./model\_tissue\_native Tissue\_model conduction\_velocity Beats 1 BCL 500 dx 0.3 D1 0.35 D\_AR 10 Reference Conduction\_velocity Results\_Reference dx\_D1\_D\_AR\_2

We are then interested in Conduction\_velocity\_log.dat which lists D1 (column 2), D2 (3), dx (4) and the conduction velocities in the x-direction (longitudinal; column 8), y-direction (transverse; column 9) and the xy-diagonal-directions (11 and 12).

We can also set the model to 3D for a more accurate representation of a 3D tissue model, or change the global orientation to point in any direction and calculate the conduction velocity in all the principal and diagonal directions.

#### 9. Applying cellular and tissue modulation and modulation maps

Cellular modulation (ISO, Remodelling, ICaL\_scale etc) can be applied to tissue models exactly as with single-cell models. By default, they apply homogeneously to the tissue, on top of any local heterogeneity due to celltype. We can also apply tissue modulation – i.e. Dscale and/or D\_AR\_scale, to multiply the values of D1 and D2 or the anisotropy ratio, relative to the set values.

Let's create a control and modulation simulation:

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Total\_time 200 Reference Tissue\_control

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Total\_time 200 ISO 1 ICaL\_scale 0.5 Dscale 2 D\_AR\_scale 4 Reference Tissue\_modulation

We can also define whether to apply the modulation homogeneously, or by a spatial map. Whereas we can individually turn the modulation map on or off for all different modulations (Dscale\_mod\_map, D\_AR\_mod\_map, Remodelling\_map, ISO\_map, ACh\_map, Direct\_modulation\_map [Off/On]), we can only use a single map itself for idealised models. If you require different maps for different modulations, you must use an anatomically detailed model and provide map files. Note: "Direction\_modulation\_map" will control where any direct\_modulations are applied (ICaL\_scale, INa\_va\_shift, IKur\_vi\_tau\_scale etc).

Let's apply Dscale and ISO by a spatial map, but leave D\_AR\_scale and ICaL\_scale to apply homogeneously. Maps are defaulted to off, but we will include explicit settings for each map here just for clarity.

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Total\_time 200 ISO 1 ICaL\_scale 0.5 Dscale 2 D\_AR\_scale 4 Dscale\_mod\_map On D\_AR\_scale\_mod\_map Off ISO\_map On Direct\_modulation\_map Off Reference Tissue\_modulation\_map

Note that in "Outputs\_tissue\_native\_Tissue\_modulation\_map" there are now two additional files: Map\_Dmod .vtk and Map\_ISO.vtk, each with a region of 1s and a region of 0s. This number is what determines the magnitude of the modulation – so where it is 1, ISO will be set to the value of ISO and Dscale\_mod will be set to the value of Dscale. Where it is 0, ISO = 0 and Dscale = 0 and thus parameters = control. You can also visualise D1 (D1\_map.vtk) to see if the modulation map has the intended effect.

We can control the shape, size and location of the map at run-time in an exactly analogous way to setting the stimulus spatial properties, by using map\_shape, map\_x\_loc, map\_x\_size etc. As with stimulus, this sets the centre and size from centre to edge; spherical maps can only have an x\_size which determines radius.

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Total\_time 200 ISO 1 ICaL\_scale 0.5 Dscale 2 D\_AR\_scale 4 Dscale\_mod\_map On D\_AR\_scale\_mod\_map Off ISO\_map On Direct\_modulation\_map Off Reference Tissue\_modulation\_map\_controlled map\_shape sphere map\_x\_loc 90 map\_x\_size 5 map\_y\_loc 7

Finally, let's also turn D\_uniformity to regional to demonstrate how regional D and Dscale with a map can combine:

./model\_tissue\_native Tissue\_order 2D Tissue\_model functional\_model\_test Total\_time 0 ISO 1 ICaL\_scale 0.5 Dscale 2 D\_AR\_scale 4 Dscale\_mod\_map On D\_AR\_scale\_mod\_map Off ISO\_map On Direct\_modulation\_map Off Reference Tissue\_modulation\_map\_and\_regional\_D map\_shape sphere map\_x\_loc 90 map\_x\_size 35 map\_y\_loc 7 D\_uniformity regional

And you may notice now that D1\_map.vtk has clear regional variation, and an additional area where the modulation map is applied (we made the map larger so we can see it affecting different regions).

#### 10. Reading and writing state in tissue models; efficient pre-pacing protocols

There are multiple ways to read and write state files using tissue models.

Setting Write\_state to On will write the state of the whole tissue, which can then be read in with Read\_state On. Setting Write\_state to ave will write the state of the centre cell in the tissue, which can then be read into the whole tissue with Read\_state ave (you will need to create a state file for every celltype and modulation condition used in your tissue model). Finally, you can also read in state files created by the single cell models using Read\_state single cell.

**Read/Write\_state On** can be used to save whole tissue states for more efficient simulations (e.g. pace to stable state, then test S2 intervals and locations, or pharma action, or similar). The **single cell** and **ave** functionality can be used sequentially to to get to stable state on a large tissue model more efficiently.

Let's explore that, using Tissue\_model functional\_model\_test at a rapid rate, with heterogeneity turned on, and ISO applied according to a map (reproducing a complex situation).

First, we'll create state files using the single cell models paced to stable states. We need a state file for each celltye in the model (EPI, M and RA) and with and without ISO.

For celltpye in ENDO, M, RA

For iso in 0.1

./model\_single\_native Model minimal BCL 400 Celltype celltype ISO iso Beats 200 Write\_state On Reference single\_cell\_pre\_pace Results\_Reference celltype\_iso

Now we'll use these state files as a starting point, and pace a 1D homogeneous tissue for each condition to output the coupled cell properties. We'll use fewer beats as we already paced the single cell models to stable state over 200 beats. Note: we need to set some stimulus properties, as the default for this tissue model (centre and sphere) does not create a stimulus region in 1D (due to the sphere; we also move region to edge so that we are not writing the state of a cell in the stimulus region).

For celltpye in ENDO, M, RA

For iso in 0 1

./model\_tissue\_native Tissue\_model functional\_model\_test Tissue\_order 1D Model minimal BCL 400 Stimulus\_location\_type edge S1\_shape cuboid Tissue\_type homogeneous Celltype ISO iso Beats 20 Read\_state single\_cell Write\_state ave Reference Tissue\_state\_read Results\_Reference ave\_coupled\_write\_celltype\_iso

And finally, we'll read the average coupled state files into our full 2D or 3D tissue model, pace for five beats, and write the whole tissue state:

./model\_tissue\_native Tissue\_model functional\_model\_test Tissue\_order 2D Tissue\_type heterogeneous Model minimal BCL 400 ISO 1 ISO\_map On Beats 5 Read\_state ave Write\_state On Reference Tissue\_state\_read Results\_Reference ave\_coupled\_read\_whole\_tissue\_write

Which can now be read in to start a new simulation from that point:

./model\_tissue\_native Tissue\_model functional\_model\_test Tissue\_order 2D Tissue\_type heterogeneous Model minimal BCL 400 ISO 1 ISO\_map On Beats 2 Read\_state On Reference Tissue\_state\_read Results\_Reference whole\_tissue\_read

This process is limited if we are using complex tissue models with continuous maps, as creating state files for every individual condition becomes infeasible or impossible. The ISO and ACh concentrations are written to two decimal places in the state files, so if a continuous ISO or ACh map is used, we would need

to create a state file for every celltype and every concentration in two decimal place intervals between 0 and max concentration; other modulation proportions or maps (Remodelling\_prop, Direct\_modulation map) are not encoded into state files and so tissue models which contain these cannot read from single\_cell or ave coupled cell state files; only full state reading and writing will work. For heterogeneity and discrete ISO, ACh, mutation and Remodelling maps, we can feasibly use the above process to create state files for every celltype and modulation condition in the tissue model.

#### 11. Using multiple baseline cell models for different regional celltypes

Functionality to use two different cell models for different regions has been included. For example, to use a ventricular and atrial cell model for different parts of a whole-heart model. The tissue model must have the appropriate settings, and the celltypes must exist for each region which that cell model is applied to.

We'll again use functional\_model\_test, where the heterogeneity celltypes are set to ENDO, M and RA. We'll turn Multiple\_models On, use the minimal model for the ventricular cell types (model 1) and set the second model (applied for region RA) to an atrial cell model.

./model\_tissue\_native Tissue\_model functional\_model\_test Tissue\_type heterogeneous Multiple\_models On Model minimal Tissue\_model\_2 hAM\_GB Beats 2 Reference Multiple\_model\_example

#### 12. Calculating a 1D Vulnerability window

You can use any 1D tissue model to calculate the vulnerability window for conduction block at different S2 locations and coupling intervals. We'll use the model "Vent\_transmural" which has celltypes EPI, M and ENDO evenly spaced. In this example, we'll just consider a couple of S2 locations and a coarse coupling interval, but you could cycle through S2 locations at any interval to provide a picture over the whole tissue. You should also pre-pace the model to stable state at the desired BCL and write the state file to read in for the vulnerability window calculations, for actual investigations.

For s2\_location in 25 75

For s2 in sequence 200 to 150 in steps of -5

./model\_tissue\_native Tissue\_model Vent\_transmural Tissue\_order 1D Beats 1 S2 s2 S2\_x\_loc s2\_location Reference Vulnerability\_window Results\_Reference location\_s2\_location\_S2\_s2

And now the file "Outputs\_tissue\_native\_Vulnerability\_window/1D\_conduction\_success\_log.dat" contains a list of the S2 locations (column 1), coupling intervals (column 2), conduction success at either edge of the tissue (columns 3 and 4, where 0 = failure and 1 = success) and the conduction type (column 5, where 0 = failure, 1 = unidirectional conduction and 2 = full conduction). The raw data can be inspected using "Outputs\_tissue\_native\_Vulnerability\_window /Results\_location\_x\_S2\_y/Vm\_linescan.dat." For a quick inspection (rather than plotting the full colour-map linescan in 2D), you can simply plot columns 10 and 90, representing the voltage in cells 10 and 90 with the x-axis intervals representing the 1 ms increments of linescan output.

In this example, we can see that for the location at x = 25, the S2 interval 155 resulted in uni-directional conduction and for x = 75 it occurred for 185 and 180. We could then cycle within those coupling intervals in 1 ms increments to determine the full vulnerability window to an accuracy of 1ms.

#### 13. Inducing re-entry example using cross-field stimulation

**Tissue\_model re-entry** has been designed for simulations of re-entry in idealised 2D and 3D sheets. It is a relatively large tissue, with S1 stimulus from the x=0 edge and the default S2\_Stimulus\_location\_type set to "cross\_field". Thus, passing an S2 argument will apply cross-field stimulation in an attempt to induce reentry. By default, the model is isotropic, but anisotropy can be included by setting Orientation\_type to anisotropic and setting the orientation directions as in example 7. You may also want to define the diffusion parameters at run-time (example 6) as the defaults may not be desired for your investigation.

In this example, we'll set D1 and dx directly, and set Dscale to 0.75 to promote sustained re-entry. We'll use the state write and read functionality to pace to stable state, and save the stable re-entry.

First, we'll pace a 1D model with matched D1 and dx to stable state at a relative rapid pacing rate. We'll write the state as an ave coupled cell, and pass a state reference to identify the specific tissue simulation.

./model\_tissue\_native Tissue\_model re-entry Tissue\_order 1D D1 0.25 dx 0.3 Dscale 0.75 BCL 300 Beats 100 Write\_state ave State\_Reference\_write Re\_entry\_1D\_pre\_pace Reference Re\_entry\_example Results\_Reference 1D\_pre\_pace

We'll then pace the 2D re-entry tissue model for a couple beats to settle it into a stable state (you should ensure this is actually the case for any real investigations) and write the whole-tissue state file (with another reference – this is now very important as we will also perform a whole-tissue state write after inducing reentry, and we want to preserve the separate state files):

./model\_tissue\_native Tissue\_model re-entry D1 0.25 dx 0.3 Dscale 0.75 BCL 300 Beats 2 Read\_state ave State\_Reference\_read Re\_entry\_1D\_pre\_pace Write\_state On State\_Reference\_write Re\_entry\_2D\_pre\_pace Reference Re\_entry\_example Results\_Reference 2D\_pre\_pace

And finally, apply just one S1 beat, an S2 of 155 (or cycle through different intervals – which is why we wrote the tissue state at stable S1 pacing). These parameters don't actually lead to sustained re-entry – it self-terminates within one second – so we will set the Total\_time to 450, where a re-entrant circuit still persists, to illustrate the state-read protocol next.

./model\_tissue\_native Tissue\_model re-entry D1 0.25 dx 0.3 Dscale 0.75 BCL 300 Beats 1 Total\_time 450 S2 155 Read\_state On State\_Reference\_read Re\_entry\_2D\_pre\_pace Write\_state On State\_Reference\_write Re\_entry\_2D\_stable\_at\_3secs Reference Re\_entry\_example Results\_Reference S2\_155

We can visualise the spatial data with:

./bin\_to\_vtk\_tissue Reference Re\_entry\_example Results\_Reference S2\_155 Tissue\_model re-entry start\_time 0 end\_time 450 interval 10

We can then read this (semi) stable re-entrant state to start any number of simulations from a stable re-entry point (for example to apply some Direct\_modulation to test potential intervention to terminate the re-entry). Set beats to 0 as we don't want to apply a stimulus (we must still specify a BCL in order to read in the correct state file, which has the BCL in its filename).

./model\_tissue\_native Tissue\_model re-entry D1 0.25 dx 0.3 Dscale 0.75 BCL 300 Beats 0 Total\_time 500 Read\_state On State\_Reference\_read Re\_entry\_2D\_stable\_at\_3secs IKr\_scale 0.25 IKs\_scale 0.25 Reference Re\_entry\_example Results\_Reference Termination\_attempt

And create vtk files of the data:

./bin\_to\_vtk\_tissue Reference Re\_entry\_example Results\_Reference Termination\_attempt Tissue\_model re-entry start\_time 0 end\_time 500 interval 10

### 14. Inducing re-entry using the phase-distribution method

An alternative method to induce re-entry is to use the phase-distribution approach – where state files for a coupled cell are written throughout the duration of an AP (representing 0 -  $2\pi$ ) and then read in as initial-conditions applied to a phase map.

First, we must create the phase state files. This must be performed in 1D, with a BCL of 400 ms or longer. This is because the state files are output over an interval of 400 ms, hard coded in the model; you may change this in the appropriate main tissue file.

./model\_tissue\_native Tissue\_order 1D Tissue\_model re-entry Beats 2 BCL 600 Write\_state phase Reference Phase\_re-entry Results\_Reference phase\_write

And now we read in this phase file to a 2D or 3D tissue model (we are using Tissue\_mdoel re-entry, but this is not required), and ensure we set beats to 0.

./model\_tissue\_native Tissue\_order 3D Tissue\_model re-entry Beats 0 BCL 600 Read\_state phase Total\_time 500 Reference Phase\_re-entry Results\_Reference phase\_read Spatial\_output\_interval\_vtk 20

We can visualise the phase map itself in "Outputs\_tissue\_native\_Phase\_re-entry/Phase\_Map\_3D.vtk".

Note: we can impose the phase method on a heterogeneous tissue model; doing so requires the phase files to be created for every celltype in the tissue model (the code then automatically reads the correct files for each region).

### 6.3 Tissue model examples – anatomically detailed/complex tissue models

Functionality for anatomically detailed models is largely the same as idealised models, where now a geometry file must also be provided. A few different, previously published tissue models are available, as well as "functional\_model\_test" which has example implementations of all functionality. The primary difference here is that we now have the ability to read in maps (stimulus, diffusion tensor spatial non-uniformity, modulation and phase) from file, allowing more complex and continuous implementations than the simple maps created in the code for idealised models. Thus, you could also use these types of models to create semi-idealised models which need to implement complex gradient maps. This section outlines the primary differences and new functionality of these models – you can also follow idealised examples above using an anatomically detailed model for anything not directly listed here.

#### 1. Basic pacing with an anatomically detailed model

Simple example using an anatomically detailed model (**Tissue\_order geo**). We'll use **Human\_vent\_wedge** for this first illustration.

./model\_tissue\_native Tissue\_order geo Tissue\_model Human\_vent\_wedge Reference Human vent control Beats 1 BCL 500

We can view the geometry in "Outputs\_tissue\_native/Human\_vent\_control/Geometry\_anatomy.vtk", and visualise results spatial data (note now it is important PATH.txt is in the directory from which "./bin\_to\_vtk\_tissue" is being performed, as it now needs to be able to load the correct tissue geometry file):

./bin\_to\_vtk\_tissue Tissue\_order geo Tissue\_model Human\_vent\_wedge Reference Human\_vent\_control start\_time 0 end\_time 500 interval 20

#### 2. Spatial gradient map and model

Unlike idealised models, we can now also impose a spatial-gradient model. This may be apico-basal ventricular heterogeneity, or a gradual shortening of the AP with distance from SAN, or similar. i.e. a spatial gradient imposed on top of possible underlying cellular heterogeneity.

All we need is 1) a map file containing the spatial gradient (continuous 0-1; must be in PATH -> Tissue\_geometries) and 2) an electrophysiology gradient model to apply (we have two testing examples implemented, "apico\_basal\_example" and "SAN\_distance\_example", neither of which are based on real data or observations). Functional model test has an associated spatial-gradient file. Even though this

filename is set in the tissue model settings (in **lib/Tissue.cpp**), we will specify it at run-time as an example of how to do this (we could select between multiple available files this way) – note we just specify the file name, which is stored in PATH. In general, we do not need to pass in the filename directly; any default filenames set in the tissue model will be used, unless overwritten.

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Spatial\_gradient apico\_basal\_example Spatial\_gradient\_map\_file functional\_model\_test\_spatial\_gradient.dat BCL 500 Beats 1 Reference Spatial\_gradient\_example

We can then have a look at the spatial gradient map, as well as the geometry itself, in "Outputs../Map\_Spatial\_gradient.vtk" – note that you may have to rescale the colourmap to 0-1 (rather than scaling for empty space of -100). Note also that the geometry is heterogeneous, and the spatial gradient applies on top of that

./bin\_to\_vtk\_tissue Tissue\_order geo Tissue\_model functional\_model\_test Reference Spatial\_gradient\_example start\_time 0 end\_time 350 interval 10

And now we can see the effect of the spatial gradient and heterogeneity on repolarisation; the default D\_uniformity is also regional, so there is variation in conduction velocity also.

### 3. Specifying stimulus map files or coordinates

We can specify different files for stimulus (S1 or S2), or set the stimulus using coordinates (just as with the idealised tissue models).

Let's first see what happens under default settings for this model – we'll set total time to 0 as we are only interested in the stimulus locations, which we can see from the map files produced.

# ./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 Reference Default\_stimulus

You may notice the on-screen output during setup: "File loaded /.../MSCSF\_state\_and\_geometry\_files/Tissue\_geometries/functional\_model\_test\_stim.dat", which is the default file set in lib/Tissue.cpp, and we can inspect what this stimulus location will be in "Outputs../Default\_stimulus/Map\_S1.vtk". We can also pass an S2 argument to see what the default S2 stimulus file is and its location.

# ./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 S2 50 Reference Default\_stimulus\_S2

And we can see that it loads file "functional\_model\_test\_S2.dat", which is output in "../Map\_S2.vtk". There is also another S2 stimulus file available to us — "functional\_model\_test\_S2\_2.dat". Let's now set the S1 stimulus file to being the default S2 stimulus file, and the S2 file to be this alternative (there is nothing specific about S1 or S2 stimulus files — we can just name them as is most useful for us).

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 S2 50 Reference Different\_stimulus\_files stim\_file functional\_model\_test\_S2.dat S2\_stim\_file functional\_model\_test\_S2\_2.dat

And we now notice that "Map\_S1.vtk" looks like the previous S2 (as we would expect), while "Map\_S2.vtk" is clearly a new file.

We can also set either or both stimuli by coordinates by passing "{S2\_}Stimulus\_loc\_type coords". There are default coordinate settings in the tissue model, so in the first instance we don't need to speficy any coordinate parameters directly:

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 Stimulus\_location\_type coords S2\_Stimulus\_location\_type coords S2 50 Reference Default\_coords\_stimulus

And we can see that the S2 stimulus is perfectly setup for cross-field stimulation. We can also control any of the stimulus location parameters directly, just as with <u>example 4</u> for idealised models (referring to the direct location and size settings; we <u>cannot</u> call the pre-set **Stimulus\_location\_type** settings in anatomically detailed models). Let's adjust some S2 parameters:

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 Stimulus\_location\_type coords S2\_Stimulus\_location\_type coords S2\_50 S2\_shape cuboid S2\_y\_loc 25 S2\_x\_size 15 S2\_y\_size 5 S2\_z\_size 1 Reference run\_time\_S2\_coords\_stimulus

Note: if the tissue model does not have default settings for the stimulus coordinates, all parameters must be set at run-time if "coords" set.

#### 4. Setting D\_uniformity from map or regional\_map

The default setting for the **functional\_mode\_test** is for D to vary according to region/celltype – the same functionality as is available with idealised cell models (so long as the heterogeneity settings exist). A difference here, of course, is that our heterogeneity settings (tissue segmentation) is absorbed into the tissue geometry file – it either contains 1s and 0s only, or further numbers for segmentation – rather than having to set the segmentation properties as with an idealised model. So long as our tissue geometry file has multiple regions, we can impose electrical heterogeneity and/or D\_uniformity by region. However, with anatomically detailed tissue models, we can also impose D\_uniformity by a map, or by both a region and map (applied sequentially). The map multiples D1 and/or D\_AR by the map value for every cell (so can be used to impose a D spatial variability which does not depend on celltype and/or which varies continuously, or checkerboard etc – anything you can make with a map!). Remember, this is the baseline D1 and D\_AR associated with the model – not a remodelled region in which we want to change the diffusion parameters (which is controlled by Dscale, D\_AR\_scale, and Dscale\_mod\_map, D\_AR\_scale\_mod\_map – see next example) – and so is to correspond to different diffusion parameters around the tissue model as part of its control setup. When using a map file, we must provide a map file for both D1 and D\_AR – if we want only one to vary spatially, just create a map of all 1s for the one we don't want varied.

So let's compare our D1 and D2 maps under uniform, regional, map and regional\_map D\_uniformity. We'll again set Total\_time to 0 as we just need the maps for this illustration:

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 D\_uniformity\_uniform Reference D\_uniformity\_uniform

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 D uniformity regional Reference D uniformity regional

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 D\_uniformity map Reference D\_uniformity\_map

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 D\_uniformity regional\_map Reference D\_uniformity\_regional\_map

We notice that ".../Map\_{D1/D2}.vtk" for the uniform simulation are homogeneous (as we would hope!), whereas for the regional case, they clearly vary according to celltype (compare with the segmentation in "Geometry\_anatomy.vtk"). In the map simulation, we can see there are now two map files: "Map\_Duniformity.vtk" and "Map\_D\_AR\_uniformity.vtk", and we can easily see how these maps correlate with the actual values of D1 and D2: remember, D2 depends on both D1 map and D\_AR map, as D\_AR is relative to D1. Finally, we can see how applying the map and regional variation combine

sequentially in the regional\_map simulation example (seeing the smooth gradients in D1 in this last example may require rescaling between the ranges for each celltype, as the smooth gradient is imposed within discrete celltype variation.)

#### 5. Modulation and modulation map files

As with idealised tissue models, we can apply modulation (ISO, ACh, Remodelling, Mutation, Direct\_modulation, D\_scale\_mod, D\_AR\_scale\_mod) either homogeneous or by a map. We can set the map using coordinates, exactly as with the idealised model example 9, using map\_in\_type coords (at least one map has to be turned on for it to do anything!):

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 ISO 1 ISO\_map On map\_in\_type coords Reference ISO\_map\_coords

And we can explicitly set the map coordinates and sizes as in that previous example. However, this is limiting in two major ways:

- 1) we are limited to discrete maps (0 or 1 for off or on, multiplied by total amount of ISO);
- 2) all modulation must be subject to the same map (if map is set to on for that modulation we can still combine some by maps and others homogeneously).

To overcome these limitations, we can use map files – which we can create to contain any shape and continuity we like (note: Direct\_modulation maps must still be discrete, as continuous imposition of these modulations is not implemented). We can either apply all modulations by coordinates or files – we cannot combine coordinates and files for different modulation maps.

Map files can be named to indicate the modulation they are designed for, but, as with stimulus maps, the actual name of the map file does not limit where it can it can be used. The **functional\_model\_test** has example maps files for all modulations, and are defaulted in the tissue mode settings. So, let's first apply all modulations, set the modulation map to "file" and set all modulations to be applied by a map. We won't pass any map files (so it reads the default settings) and will set D\_uniformity to uniform (so we can easily interpret the D1 and D2 maps from the modulation). We need to pass some direct modulation in order for that map to have an effect. Note: the maps simply define the regions and proportion of maximum effect to which the modulation applies, so for ISO, ACh and Remodelling the maximum value of the map should be = 1, which will be the region where ISO, ACh or remodelling are applied according to their concentration/proportion variable (i.e. if ISO = 0.5, then the map region of 1 will apply ISO at a concentration of 0.5, and the map region 0.5 will apply concentration 0.25). So, passing different values of ISO, ACh and Remodelling\_prop will affect your simulation, but will not be reflected in the maps. Similarly, the D\_scale and D\_AR\_scale maps must also be between 0 and 1, where map=1 applies the full value of Dscale or D\_AR\_scale (which may be larger or smaller than 1). This is different to the baseline D1 and D\_AR maps (example 4), which are absolute scale factors to multiply the parameters D1 and D\_AR.

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 D\_uniformity uniform ISO 1 ISO\_map On ACh 0.5 ACh\_map On Remodelling test Remodelling\_map On Remodelling\_proportion 0.75 ICaL\_scale 0.5 IK1\_scale 2 Direct\_modulation\_map On Dscale 2 Dscale\_mod\_map On D\_AR\_scale 3 D\_AR\_scale\_mod\_map On map\_in\_type file Reference All\_mod\_maps\_by\_file

We can see on the run-time outputs that different map files are loaded for each modulation. We can now check all the map files, and that they are all different (note the Direct\_modulation map is not continuous) and that the D1 and D2 maps correlate with "Map\_Duniformity.vtk" and "Map\_D\_AR\_uniformity.vtk", as in the previous example (again, remember D2 depends on D1 map and D\_AR map).

Sometimes, we may want the same map to apply to multiple modulations – for example a remodelled region could be associated with electrical and diffusion dysfunction. We will use the functionality to set the map file at run-time in order to impose the same map on remodelling and Dscale:

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 0 Remodelling D uniformity uniform test Remodelling\_map On remod\_map\_file functional model test Dscale mod map.dat 0.5 Dscale mod map **Dscale** Dscale mod map file functional model test Dscale mod map.dat Reference Remodelling\_and\_Dscale\_same\_map\_file

We can of course combine D\_uniformity (by region or maps) with Dscale and D\_AR\_scale maps, in order to apply baseline variation in D, with a remodelled variation imposed on top.

#### 6. Multi-timed and site stimulus protocols

Using files rather than creating idealised stimulus regions easily allows for the stimulus to apply to multiple different locations. We can also apply a stimulus protocol where different regions are stimulated at different times (for example, simulating the Purkinje-fibre breakthrough sites in the ventricle during sinus rhythm). To do this, we need to ensure we have the right stimulus file and settings in **lib/Tissue.cpp** for this functionality (which just requires a stimulus file with different regions numbered sequentially in the order to apply the stimuli, and settings as to what the relative delay of each region is — see the functional\_model\_test setup for an example) and then to pass "**Multi\_stim On**". As multi\_stim is not the default for this tissue model, we also need to tell it to read the multi\_stim stimulus file rather than the standard one. In general, if a model requires multi-stim functionality, it will likely be for control and so set the default stimulus file to the multi-stim file.

./model\_tissue\_native Tissue\_order geo Tissue\_model functional\_model\_test Total\_time 100 Multi\_stim On stim\_file functional\_model\_test\_multi\_stim.dat Reference Multi\_stim

First, we can inspect "Map\_S1.vtk" and notice it now has 5 different regions (rather than just one), and applying the post-processing:

./bin\_to\_vtk\_tissue Tissue\_order geo Tissue\_model functional\_model\_test Reference Multi\_stim start\_time 0 end\_time 100 interval

We can clearly see the effect of the delayed stimulus points.

# II - Modifying the code

# Forward - general philosophy of the framework

Firstly, it should be clarified this is not a library, tool-set, scripting language or similar for cardiac cell and tissue modelling. Rather, this is a single implementation in C/C++ which contains all of the functionality for single cell (spatial and non-spatial) and tissue (idealised and anatomically detailed) simulations of cardiac electrical excitation which I use in my research<sup>1</sup>.

I personally prefer to develop my models in C/C++ with all functionality hard-coded and easily readable/modifiable. Over the course of my research so far, this has led to uncountable different project codes, implementing different cell and tissue models and with different conditions, functionality and protocols. Whereas this led to clean and efficient implementation for specific purposes, it became rather tedious to copy sections of code when implementing functionality to be applied to multiple models or projects; In particular, between single-cell and tissue implementations of the same model, or introducing new components to multiple models for model-independent studies.

This software represents a significant effort to contain everything I use in my research in one, functional and readable implementation such that once a new modification or cell model, tissue geometry and so on, has been developed, one has access to the full functionality without the need to double-up on code or use multiple projects etc. The motivation was firstly to facilitate my own research, and secondly to make the code and models easily accessible for my students and other researchers. Following this, and with the principals of openness, transparency and community support, there was also motivation to make the code as easy to interpret and modify as possible such that others may use and adapt the code with the same ease as myself. This documentation is designed to facilitate this purpose. I hope that this will be of assistance in the reader's own research.

# 1. Introduction

Because this code has been designed maintain significant functionality for running multiple different cell models and conditions, it is necessarily relatively large and consists of multiple files and variable structs; the structure and contents of the code are therefore detailed below and in the appendix, to assist in using and modifying the software. However, it should be easy to follow the code through using the algorithm schematic and reading the appropriate Main file (wherein the relevant files containing all called functions have been commented). The instructions below should be sufficient for most modifications; the appendix containing full file and function lists should only be required for specific reference or significant modifications.

Instructions on how to add new modifiers, such as celltype, remodelling, mutation, pharmacological agent, or isoprenaline, as well as a template file and instructions on how to add a <u>full new model</u> to the code, are given below. Whereas some tasks may be more involved than implementations in simple code, it (I hope!) will be more than worth it for long-term functionality.

The general philosophy of the code is simplicity to the extent of practicality. The code is written primarily in C to facilitate readability and following the inherently sequential nature of the simulations required. However, some additional functionality from C++ was used; Thus, whereas the code is compiled as C++, it retains the sequential nature of C and does not (primarily) utilise classes. Furthermore, the requirement for additional libraries (such as higher-order solvers) was avoided in order to maintain simplicity and facilitate portability and ease of installation.

<sup>&</sup>lt;sup>1</sup> Not all functionality may be present with specific code versions; all models are included in the global, parent code which does contain all functionality.

This software may be modified (see disclaimer at the start of this document). If you would like any modifications and additions to be shared as part of the framework (with appropriate credit given and citations added to the disclaimer) please feel free to send them to me. If deemed appropriate, the additions will be incorporated into the framework for future downloads.

For any new component you may add, please also add the relevant citations to the disclaimer output. In **lib/Outputs.cpp** go to output\_disclaimer\_citations(), simply add an entry here which prints the citation to screen if your new model/component is used.

# 2. Variable naming conventions

Where possible, variables have been named using a consistent convention.

For currents, gating variables, and variables which determine these, the convention used throughout is as such: " $I_{X\_type\_specifier}$ ". For example, the "voltage-activation" (va) gate for  $I_{to}$  is " $Ito\_va$ "; the "calciuminactivation" (ci) gate for  $I_{CaL}$  is " $ICaL\_ci$ "; the steady state (ss), time constant (tau) or alpha-transition rate (al) of the "voltage-inactivation" (vi) gate for  $I_{Kur}$  are: " $IKur\_vi\_ss$ ", " $IKur\_vi\_tau$ " or " $IKur\_vi\_al$ ". For maximal flux rates, for example for intracellular dynamics: " $I/J\_x\_bar/max$ " – for example, " $J\_rel\_max$ ", " $INCX\_bar$ ". For parameters and constants, in general denoted with " $I\_x\_kref$ " – example " $INCX\_kCai$ " would be the intracellular calcium constant associated with INCX whereas " $J\_SERCA\_kCaSR$ " is the SR-calcium constant associated with SERCA uptake.

## 3. Variable structs and contents

All model variables and parameters are contained within structs in order to allow access from multiple files and functions. All structs are defined in "lib/Structs.h", and consist of:

Struct	Contents
Argument_parameters	Variables which are used to control/modify model settings from the
	command line arguments (i.e. a variable associated with each option listed in
	the arguments). Argument variables are used for settings only.
Simulation_parameters	Global simulation settings: BCL, Total_time, Paced_time, NBeats, S2, NS2, dt,
	Vclamp, Read/Write_state.
Cell_parameters	Parameters which are not dynamically updated during simulation. Includes
	model conditions (Model, Celltype, Remodelling, ISO etc), constants (R, F, T),
	cell structure (C <sub>m</sub> , volumes, etc), stimulus parameters (stimduration,
	stimmag), ion-current parameters (conductance, maximal flux rate,
	saturation constant etc), ionic concentrations (initial or constant values),
	native calcium handling parameters (CICR model, buffering etc),
	modifier variables (scale factors, voltage shifts etc).
State_variables	Time-dependent variables which are integrated numerically. Includes $V_{\rm m}$ ,
	gating variables, ionic concentrations etc
Model_variables	Variables calculated dynamically during the simulation. Includes <b>stimulus</b>
	variables (Istim, stimflag etc), reversal potentials $(E_x)$ , ionic currents $(I_{tot},$
	$I_x$ ), intracellular fluxes ( $J_x$ ), transition rates and steady-states ( $a$ , $\beta$ , $\infty$ , $\tau$
	etc), <b>excitation properties</b> (APD, dv/dt, [Ca <sup>2+</sup> ] <sub>i_min</sub> /max etc).
Tissue_parameters	Parameters associated with setting up and running tissue models.
	Tissue model conditions (Tissue_model, Tissue_order, Tissue_type,
	Orientation_type etc), Stimulus location parameters, Tissue dimensions
	and diffusion parameters, map files and flags, Heterogeneity and
	anisotropy settings, Conduction velocity measurement variables
SC_variables	All variables and parameters for spatial diffusion and coupling (tissue and
	3D cell). Dimensions, space steps, geometry and map arrays, Diffusion
	coefficient and differential arrays, neighbour arrays and maps, local
	orientations, spatial Laplacian.

## 4. Adding new variables

You may need to add new variables to the code as part of any modification you are making; variables for most model components already exist, so first please to check **lib/Structs.h** for matching or suitably similar variable. If your variable does not already exist, then you will need to add it. This procedure depends on the type of variable you are adding:

- Local variables: if the variable is computed for the calculation of a current/flux/concentration, and is not required for use outside of its used function, create it locally. Otherwise:
- Parameters: Add the parameter to the appropriate location of Cell\_parameters struct. It is now ready to be used simply give it a value in the relevant set\_parameters\_native\_X() function in lib/Model\_X.cpp, or in set\_default\_parameters() in lib/Initialisation.c, if it applies to multiple models.
- Computed variables (e.g. steady state, transition rates, currents, fluxes): Simply add to the
  appropriate location of the Model\_variables struct. It is now ready to be accessed from any
  function which reads in Model\_variables.
- State variables (gating variables, concentrations and other time-dependent variables):
  - o Add to struct State\_variables.
  - Set the initial condition in initial\_conditions\_native\_X() in the relevant lib/Model\_X.cpp file.
  - o Finally, add it to read/write state functionality. In **lib/Read\_write\_state.c**, navigate to the first two functions {Write/Read}\_state\_variables\_native() and follow the instructions at the bottom of each function to add a new variable.
- Modifier variables (current/flux scaling; voltage shifts etc):
  - o Add to the appropriate location of Cell\_parameters struct (search "MODIFIERS").
  - O Set the default value in set\_modification\_defaults\_native() in lib/Initialisation.c (1 for scale; 0 for shift).
  - Note: shift applies by adding to V1/2 and thus subtracting from V.
- Tissue parameters: Add to Tissue\_parameters struct and default (if necessary) in set\_tissue\_model\_conditions() in lib/Tissue.cpp. Set either here or in relevant set tissue settings functions (set\_tissue\_settings\_idealised() or set\_tissue\_settings\_anatomical()).
- Variable/parameter to be controlled from command line arguments:
  - o First, add the variable itself as above (e.g. a current scale modifier); the following describes how to set and modify this variable from command line/settings\_file arguments; the variable itself must already be included and do what you want it to!
  - o In the Argument\_parameters struct (last one in the Structs.h file), add:
    - A copy of the variable you want to modify (e.g. a new current scale)
    - A boolean flag variable with the same name with "\_arg" appended.
  - O Default the "..\_arg" boolean to false in lib/Arguments.c -> set\_argument\_defaults().
  - Add a condition to the IF statements in function set\_arguments() in lib/Arguments.c, following the examples already present. Ensure to set the flag and increment arg\_counter within this conditional.
  - o Add your new argument and its options to screen outputs at the bottom of that function.
  - In lib/Initialisation.c, navigate to assign\_modification\_from\_arguments() and add a line
    which sets the model variable to the argument variable if the \_arg flag has been set to true
    (follow examples).
  - o This will ensure the argument value will be applied, but only if argument is passed.
  - o If it is a **Tissue parameter**, then you may also need to navigate to overwrite\_tissue\_properties\_from\_args() in lib/Tissue.cpp and add a clause there to overwrite/set the tissue parameter from your argument parameter.
  - o Finally, you can add it to screen settings outputs in output\_settings() in lib/Outputs.cpp.

# 5. Adding a new celltype or modulation model

The code has been presented with extensive variables to modify the equations of the ion currents (and basic variables to modify calcium handling properties – the **modifier variables** in the Cell\_parameters struct), and all included models have been implemented with these variables. Therefore, for the majority of modifications it is simple to implement a new modifier which affects all, some, or a specific cell model. Instructions are embedded in the relevant parts of the code; here, we outline what needs to be done and where. These instructions are intended to be read while the user is updating the code.

## 5.1. The modifier variables

Modifier variables, elements of Cell\_parameters, are grouped into different types:

- 1. Scale factors denoted **Gx** where x refers to the current or flux. These simply multiply the maximum conductance or flux rate. E.g. **GNa**, **Grel**. These are defaulted to 1.0.
- Voltage-shifts denoted Ix\_vy\_ss\_shift and Ix\_vy\_tau\_shift, where x denotes the current and y denotes the gating variable (activation, inactivation). These are subtracted from the voltage as used in the steady-state or time constant equations, i.e. equivalent to adding to the V<sub>1/2</sub>. E.g. Ito\_va\_ss\_shift, ICaL\_vi\_tau\_shift. Defaulted to 0.0.
- 3. Time constant scaling denoted **Ix\_vy\_tau\_scale** simply multiples the calculated time-constant of current x gating variable y. Defauled to 1.0.
- 4. Gradient scaling denoted **Ix\_vy\_ss\_kscale** scales the gradient parameter of regular sigmoidal functions for the steady state of current x and gate y. Defaulted to 1.0.

These can be accessed in all functions which read in Cell\_parameters, and should in general be used instead of setting parameters explicitly to apply modulation. In lib/Structs.h, search "MODIFIERS" for a full list.

Note on I<sub>CaL</sub> and J<sub>rel</sub> modifiers: There are two ways to scale these fluxes in the integrated cell models, but only one way in the native cell models. In the integrated cell models, the fluxes can be scaled by either changing the expression (N per dyad, corresponding to Cell\_parameters. {GCaL/Grel}) or by scaling the open transition rates (Cell\_parameters. {GLTCC\_kva1\_va2/GRyR\_kCO}). Both of these have the same effect in native models (Cell\_parameters. {GCaL/Grel} is simply set to GLTCC\_kva1\_va2/GRyR\_kCO if using native models) but do have different effects in the integrated models, which may not linearly correspond. So please think about what your modulation represents (change in channel expression or availability?) and use the appropriate variable for the correct integrated implementation, bearing in mind they both do the same for native models so either can be used.

# 5.2 Types of modulation

Modulation models are grouped as: **Celltype** – modifications for different celltypes within the same model i.e. regional heterogeneity; **Remodelling** – modifications for different remodelling conditions e.g. associated with atrial fibrillation or heat failure; **ISO/ACh** – models for sympathetic stimulation/isoprenaline and parasympathetic stimulation/acetylcholine, passed as 0-1 representing up to a saturating concentration; **Agent** – Name/specifier for pharmagological agents; **Mutation** – specific channel mutation; **Spatial\_gradient** – for continuous variation of parameters by a spatial map in tissue models.

Each of these types has its own specific function in which to place your new modifier. If your modifier fits within one of these categories, please follow the instructions below; adding a new modifier type is slightly more involved and requires more detailed understanding of the code (instructions may be added to this documentation in future). The code is set up such that each modifier can only have one option at a time (i.e. you cannot have two **Mutation** modifiers simultaneously), but may simultaneously run an option for each of the different modifiers (i.e. you can have **Celltype**, **Remodelling**, **ISO**, **Agent** and **Mutation** 

simultaneously) – the modifications will be applied sequentially, and so it is important to modify rather than set parameters unless explicitly intended. If you want to include models for multiple of the same type of modifier (e.g. AF and HF in **Remodelling**), then you must specify the combination as its own option (e.g. AF-HF).

An illustration of how to code modifiers is given in each relevant function as either "test" or "test\_global"; some real modifiers may also be already present in the relevant function. You can use lib/Model\_TEMPLATE.cpp as a guide if the function you need does not already exist.

The method of introducing new modifiers is the same whether they are model-specific, common to many models, or global – only the location and function in which the modifier is placed is determined by specificity.

## 5.3. Adding your new modulation; model-specific

Open the file associated with the model to which your modifier applies ("lib/Model\_X.cpp").

Navigate to the appropriate function:

- set\_celltype\_native\_X()
- update\_celltype\_integrated\_X()
- set\_modulation\_ISO\_native\_X()
- set\_modulation\_Agent\_native\_X()
- set\_modulation\_Remodelling\_native\_X()
- set\_modulation\_Mutation\_native\_X()
- set\_modulation\_ACh\_X()

And add a new condition of the IF statements with your new modulation identifier. If the function is not present in your selected cell model, copy the template function from lib/Model\_TEMPLATE.cpp and add the function call to set\_het\_mod\_X() and the function to lib/Model.h.

Now follow the in-code instructions for incorporating your model, using the modifier parameters described above. A few notes:

- Remember to modify (multiply/add) your modifier variables rather than explicitly set.
- For all modulation other than celltype and mutation, you can apply an amount to apply the modulation. For ISO and ACh models, this variable is Cell\_parameters.{ISO/ACh}; for Remodelling and Agent, this variable is Cell\_parameters.{Remodelling/Agent}\_prop. The variable will always be in the range 0-1 to specify the strength of the modulation. The convention in the code, to allow easy readability of the maximum effect of the modulation, is to write it as:
  - Cell\_parameters.[MODIFIER] \*= (1.0 + proportion \* (max\_effect 1)) [scale factor]
  - o Cell\_parameters.[MODIFIER] += proportion \* max\_effect [shift]
- For example, if the maximum effect of **ISO** on  $I_{Cal}$  is to increase the current by a factor 3 and to shift the voltage dependence of the activation gate by -5 mV, we would add:
  - $\circ$  Cell\_parameters.GCaL \*= (1.0 + ISO \* (3.0 1.0))
  - o Cell\_parameters.ICaL\_va\_ss\_shift += ISO \* -5.

## 5.4. Adding your new modulation; common or global

You may want to add a new modifier which applies to multiple cell models. This can be done by placing the modifier in **lib/Model.c**, without the requirement to repeat or copy code for multiple different models. In general, a modifier may be common or global if: (1) It is a pharmacological agent which affects different celltypes or species homogeneously; (2) There are multiple, independent models of the same cell (e.g. human atria, rabbit ventricle) to which heterogeneity, ISO etc apply; (3) It is a mutation which affects multiple celltypes or species homogeneously; or similar case.

First, in lib/Model.c, navigate to set\_heterogeneity\_and\_modulation\_native().

If a global/common function already exists which covers the new modulation you need to add, you simply need to place your modifier within this function following the same procedure as detailed above for model-specific. Global/common functions already present in the code: set\_global\_Agents() – for any drug which affects all models homogeneously; set\_celltype\_hAM() – regional celltypes for all human atrial cell models; set\_ISO\_hAM() – ISO models for human atrial cell models; set\_global\_remodelling() – remodelling models which apply to every cell model; set\_remodelling\_hAM() – AF remodelling (or others if added!) models for human atrial cell models; set\_mutation\_hAM() –  $I_{Kur}$  mutations (or others if added!) models for human atrial cell models; set\_ACh\_global() – any global model of parasympathetic activity.

If a global/common function does not already exist, you will need to create it. (1) define the function in "lib/Model.h" where the other global/common modifier functions are (near the start of the file) – a template function has been placed there called set\_MODIFIER\_X\_Y() so copy this and rename as appropriate (if global, call it "set\_global\_MODIFIER()", if species specific call it "set\_MODIFIER\_species()" and so on). Now, in "lib/Model.c" navigate to below the set\_heterogeneity\_and\_modulatioin\_native() function, where the global/common modifier functions are listed. An entry for the template is placed here, so you may also copy this and use it as a guide. [Note: ensure that the relevant tracking variable (p->MODIFIER\_set\_ref) is appropriately set to 1 and 0 as indicated in the template for proper error checking and selection]. Now, simply add your function call before the model specific selection IF statements in set\_heterogeneity\_and\_modulatioin\_native() in the relevant modifier type section. If your function applies to some but not all models, include an IF statement before the function call with a list of the suitable models.

## 5.5. Adding your new modulation; spatial tissue gradients

Adding a spatial gradient model, such as apico-basal ventricular heterogeneity gradients, is unique in that it is only implemented globally (as it will depend on geometry and species, but not specific cell models). Simply navigate to set\_spatial\_gradient() in lib/Model.c and add your model there, giving it an appropriate specific identifier. In tissue models, implementation will also require a spatial gradient map; in single cells, the gradient parameter can be controlled through the argument "Spatial\_gradient\_proportion [0-1]".

# 6. Adding a new tissue model

New idealised or anatomically detailed tissue models can be easily added in lib/Tissue.cpp.

Simply navigate to: set\_tissue\_settings\_idealised() for an idealised model or set\_tissue\_settings\_anatomical() for an anatomically detailed model. Create a new ELSE IF condition at the bottom of the list, following the examples given in "functional\_model\_test", which contains examples of all currently implemented functionality and instructions on file format etc. If adding an anatomical model, you will need to create all geo, stim and map files and put them in your PATH location in the directory "Tissue\_geometries", following file format instructions in the code.

At minimum, you must specify the spatial step (dx), diffusion parameters (D1, D\_AR and Diso) and spatial dimensions (NX, NY, NZ) for an idealised model, and the geometry and stimulus files for an anatomically detailed model. All other settings, such as heterogeneity, anisotropy and modulation maps are optional. You can also default whether these properties are turned on or off for your tissue model (which can be overwritten by run-time arguments). For example, you can provide settings for heterogeneity but default the tissue model to be homogeneous; you must provide settings for any of these options, independent of the default, if you want the functionality to be available when passing run-time arguments.

# 7. Adding a full new, or updated, cell model

Users are welcomed to incorporate further cell models into the framework (e.g. previously published or new work). A template file for a new cell model has been provided to assist in this task (lib/Model\_TEMPLATE.cpp) while automatically maintaining all functionality in your new model. Instructions have been embedded in that file – so you can just follow those; below is a summary of what must be done.

New models may be either entirely independent from the already implemented models, or may be an update of an already-included model and inherit functions from the baseline model, in which case, only those new components need to be added to the code (see lib/Model\_hAM\_MT.cpp as an example). These instructions are intended for use while the user is updating the code.

First, select a suitable **model identifier** (let's call it **X**) – this will be used for both file naming and for the conditional statements which select model-dependent functions: the convention implemented is "**speciesCELL\_MODEL**", e.g. **Human Atrial Myocyte Grandi-Bers** model is **hAM\_GB**. Now, copy the template to a new file with the name **lib/Model\_X.cpp** and search and replace all "\_**speciesCELL\_MODEL**" with "\_X"; similarly, copy all the "\_**speciesCELL\_MODEL**" functions in the header file (**lib/Model.h**) and rename them as appropriate. Add any new functions required following this convention.

The overall structure is that all model-specific functions are in **lib/Model\_X.cpp**, with calls to the model-specific functions placed in **lib/Model.c**. Process for adding the actual model formulations:

- 1. In all main files for which your model is relevant (single cell/tissue, native/integrated), navigate to the "Check Model is appropriate for this code version" section and add a line with your model identifier, so that it will be allowed to run for those implementations.
- 2. In lib/Model\_X.cpp, define all parameters used in the model in set\_parameters\_native\_X(), OR, if your model inherits from an already existing model (i.e. is an update of one already included), then you simply need to define all updated parameters in update\_parameters\_native\_X(). Add function calls to lib/Model.c -> set\_parameters\_native(). NOTE: All ionic concentrations must first be defined as a parameter here.
- 3. In lib/Model\_X.cpp, set an initial value for all state variables, including concentrations, in initial\_conditions\_native\_X() and add the function call to lib/Model.c -> initial\_conditions\_native(). NOTE: Ensure you set the initial value for all the concentration state variables from the equivalent parameter variable set in step 2. This must be performed even for concentration variables which are not updated dynamically in your model.
- 4. Now go through each current in turn and add the equations available parameters and variables have been listed in each function to help, and the format to include modulation has been demonstrated. Try to include the modifier parameters properly and fully wherever possible, so that modulation works properly!
  - Ion-channel currents controlled by gating variables have three associated functions: set\_Iy\_X\_rates(); update\_gates\_Iy\_X(); compute\_IY\_X(). Currents which do not depend on gating variables (i.e. time-independent) only have this last function (or possibly also a version of set\_Iy\_X\_rates() which sets a time-independent but voltage-dependent variable).
  - Ensure you have added function calls for each current to the whole-model call functions (in lib/Model\_X.cpp):
    - o set\_gate\_rates\_X\_native() (if the current has a set rates function)
    - o update\_gating\_variables\_X\_native() (if the current has an update gates function)
    - o compute\_Itot\_X\_native() (all currents).
    - O And ensure that the current itself is added to *Itot* in compute\_Itot\_X\_native().

- These three functions are called in compute\_model\_X\_native() and so you must add a call to this function in lib/Model.c -> compute\_model\_native().
- 5. Add a call to set\_gate\_rates\_X\_native() to the function lib/Model.c -> compute\_and\_output\_current\_functions(). This allows the Parameters outputs to work for your model.
- 6. Add the homeostasis calculations, including intracellular Ca<sup>2+</sup> handling, to the function comp\_homeostasis\_X().
- 7. Finally, add heterogeneity and modulation for all available/desired model-specific implementations. Follow the instructions above (and in the template) on how to do this, ensuring the specific functions are called in set\_het\_mod\_X(), and that this function is also called in lib/Model.c -> set\_heterogeneity\_and\_modulation\_native().

Re-compile the code, and your model is now ready to be selected by the run-time argument "Model X", where X is your model identifier.

<u>Suggestion</u>: When adding a new model, I tend to go through current by current (and then homeostasis), adding the formulations, parameters and initial conditions of state variables for each component in turn (rather than adding all parameters at once, then all state variables initial conditions at once, then all current formulations etc).

# 9. Adding a new current

If you need to add a new current to an existing model (or to a model you are adding), and the variables for the current don't already exist (i.e. the current isn't implemented in any of the packaged models), you simply need to add all the related variables (following the directions above; add the current itself and all computed variables to Model\_variables; the gating state variables to State\_variables, and related parameters to Cell\_Parameters (including the modifier variables) and ensure the parameters and state variable initial conditions are set in your model function) and then add your functions to the appropriate model, ensuring you add the current to the calculation of Itot and the function calls in the relevant compute and set functions. You do not need to update any settings for models which do not include the current. Finally, you may want to add the current (and its gating variables) to the Results outputs function in lib/Outputs.cpp.