


Pump 4-771

Schematic #	Part #	Description		Schematic #	Part #	Description
1	9751	Pump Foot Bracket		25	7362	Filler/Gooseneck Gasket
2	7550	Wrench		26	7355	Filler Body
3	7551	Screw		27	7353	Special Nut
4	7554	Wrench bracket		28	7350	Filler/Gooseneck O-ring
5	7364	Lock Nut		29	7168	S-Hook
6	9334	Pump Link		30	7358	Filler Cable
7	7553	Black Plastic Washer (Link)		31	7356	Discharge Tube
8	7555	Metal Link Washer		32	7321	Piston Rod
9	7363	1/4 -20 X 2 Hex head screw		33	7329	Valve Disc
10	7622	Small Release Pin		34	7359	Small Retainer
11	7622	Small Release Pin		35	7328	Piston Cup
12	7347	Ball		36	7327	Large Retainer
13	7128	Pump Ball Screw		37	7360	Lock Clip
14	7738	Pump Handle		38	7343	Lock Nut
15	7341	Bolt		39	7625	Small Screw
16	7342	Lock Washer		40	9623	Pump Latch
17	7633	Pump O-ring		41	9624	Pump Tube
18	9635	Pump Head		42	9916	Wing Nut
19	7324	U-Cup		43	7556	Metal Washer
20	7323	Brass Nut		44	7557	Foot Valve Spacer
21	7345	Brass Nut Bearing		45	7621	Long Release Pin
22	7325	Bolt		46	9330	Pump Tube Foot
23	7326	Nut		47	7558	Screw
24	7352	Stud Screw		48	9348	Screen

LEVEL 5



4-771 Pump