

Part Number	Description	Quantity Each
041050F	Threaded Insert	1
050027	Lock, Needle Holder	1
050031	Bushing, Gooser	1
050043F	Anvil	1
050068	Gooser & Cutter Chain Stop	1
050070F	Creaser Axle	1
050113F	Cutter Block Tube	1
050128F	Bushing, Chain Roller	2
050134	Chain Roller	2
050244	Spool	1
050405B	Keeper Axle, Black	1
050500	Brake Roller	1
050538	Creaser Spring Anchor	3
050556	Cutter Spring Stud	1
050572	Magnet	2
050573	Magnet Cap	1
050576	Brake Spring Mount	1
050577	Brake Torsion Spring	1
050594	Pivot Bushing, Short	1
050599	Main Shaft Washer	9
050700	Taper Head	1
050701	Left Side Plate	1
050702	Right Side Plate	1
050703	Spool Mount	1

Part Number	Description	Quantity Each
050707	Cover	1
050710	Tape Guide	1
050712	Main Tube End Plug	1
050713	Inner Mud Tube	1
050715	Link Bushing	3
050718	Creaser Spacer	1
050719	Main Tube Band Assy	1
050720	Control Arm Assy	1
050721A	Control Tube, Hard Black Anodized	1
050722	Control Tube Flange	3
050723	Flange for Control Arm	1
050725	Spool Mount Retaining Wire	1
050726	Spool Mount Retaining Wire Anchor	1
050727	Gooser	1
050728	Needle Holder	1
050729	Gooser Spring Mount	1
050730	Needle Disengager	1
050737	Creaser Axle, Threaded	1
050738	Creaser Axle	1
050742	Main Wheel Axle Screw	1
050743	Main Wheel Axle	1
050744	Side Plate Spacer	1
050745A	Main Tube, Hard Black Anodized	1
050748	Cutter Link Tube	1

Part Number	Description	Quantity Each		Part Number	Description	Quantity Each
050750	Creaser Connector	1		050787	Slider	1
050752	Gooser Guide Rod	1		050788	Creaser Connector Adjuster	1
050754	Control Arm Guide	1		050789	Creaser Connector Adjuster End	1
050757	Main Wheel Hub	2		050790	Creaser Cam Plate, Mirror	1
050758	Thumb Screw	1		050803	Creaser Trigger	1
050759	Creaser Frame Half	1		050804	Creaser Stop	2
050760	Creaser Frame Half, Mirror	1		050805	Trigger Stopper	1
050764	Swivel Retaining Ring	1		051094	Spool	1
050770	Cutter Frame	1		052404B	Keeper Yoke	1
050771	Creaser Tape Guide	1		053408	Spool Post, Slotted	1
050772	Keeper Half	2		056022	Gooser Spring	1
050773	Creaser Wheel	1		056093	Main Wheel	2
050774	Creaser Cam Plate	1		056133	Pyramid Blade, SST	1
050775	Cam Pivot Roller	2		056133	Pyramid Blade, SST	1
050776	Creaser Pivot Link	1		056135	Cutter Chain Assembly, SST.	1
050777	Push Tube	1		059014	Screw 4-40 X 3/16 Truss Hd. S.S	1
050778	Swash Plate	1		059020	Screw 6-32 X 3/8 Bind Hd.	8
050779	Cam Pivot Bar	1		059025	Cotter Pin. 5/64 X 1/2 S.S	1
050780	Connector	1		059037	Screw 4-40 X 1/4 Bind Hd. S.S	3
050781	Creaser Slider	2		059049	Needle, Gooser	1
050782	Cam Pivot Axle	1		059049	Needle, Gooser	1
050784	Gooser Body	1		059051	Screw 6-32 X 3/16 Fil. Hd. S.S	1
050785	Control Arm Guide Rod	1		059074	Stopnut, 8-32 Hex, Elas., S.S.	3
050786	Guide Bushing	1		059074	Stopnut, 8-32 Hex, Elas., S.S.	1

Part Number	Description	Quantity Each		Part Number	Description	Quantity Each
059092	Screw 8-32 X 1-1/2, Slotted Rd. Hd., S.S	1		059809	Spring, LEE LC067K10S	1
059102	Screw 4-40 X .225/.235 Fl.Hd.SST.	10		059810	Spacer, Creaser Pivot, McM 92320A691	1
059238	1/4-20 X 1/2 Screw Fl Hd Socket Cap	1		059811	Jam Nut 1/4-20	1
059264	4-40 X 7/16 Binding Head Screw	2		159027	Washer, #8, No 807, SST	2
059322	Screw, 4-40 X 7/8 Fl. Hd.	4		209042	#10 Brass Washer	1
059616	Screw, 4-40 x 1/2 Binding Hd, SST	1		209050	4-40 x 7/16 Slotted FL. Head, SS	3
059616	Screw, 4-40 x 1/2 Binding Hd, SST	1		219095	Washer	12
059620	Screw, 8-32 x 3/4 Hex Head, SST	2		499023	4-40 X 3/16 Flat Head Screw 18-8	12
059706	O-ring, 17.5mmID, 1.5mmwidth, Buna	1		509010	Screw: 4-40 X 5/16 Fl. Hd. S.S.	5
059709	O-ring, -033, Buna	1		609012	Stopnut 4-40 S.S	6
059763	Nyliner, 5L5F-642	2		609048	4-40X3/8 Flat Head S.S. Screw	1
059793	Screw, 1/4-20 x 1-1/8 FH Soc, SST	1		800856	Stud, Swivel	1
059794	Screw, 4-40 x 1-1/8 Fl Hd Slotted, SST	1		800857	Adapter, Swivel	1
059795	Screw, #4 x 1/4 Lg Thd Forming, SST	1		800858	Thrust Washer	1
059796	Spacer .188, SST, Ref McM-Carr 92320A689	4		809860	O-Ring, -013	1
059797	Spring, LEE LE045D13S	1		809861	O-Ring, -016	1
059798	E-Ring, Ext, .125/.127 Groove, SST	4		809862	O-Ring, -907	1
059799	Spacer .375, SST, Ref McM-Carr 92320A695	1				
059801	Screw, 4-40 x 9/16, Bind Hd, SST	1				
059802	ShoulderScr, 3/16 x 1", Slotted, SST	1				
059806	Trigger Attachment Pin	1				
059807	O-ring, Gooser Stop, -109 Buna	1				
059808	Spring, McM-Carr 9065K259	1				