# Flashing Firmware on Gemini

# Description:

This document provides guidance on how to flash the firmware on Gemini

# Preparation:

- 1. Mini USB cable with data transmission capability.
- 2. MicroSD card with SD card reader (File System: FAT32)
- 3. Software: Vysor or any other Android mirroring tool.




https://www.vysor.io/download/?return=https%3A%2F%2Fwww.vysor.io%2F


4. Firmware file

# Base Image Update Procedures:


1. Confirm the current firmware by checking the setting using Vysor.



2. You can see the region version and base version here.



- 3. Disconnect the power of Gemini. The update can only be initiated during the boot up process.
- 4. Read the SD card on PC and create a folder named "sdupdate".
- 5. Unzip and place the firmware files into the "sdupdate" folder.



- 6. Safely eject the SD card and insert it back to the Gemini.
- 7. Power on the device, LED will start blinking in green. This process takes about 3 5 minutes. Do not remove power until the update has been completed at this point.
- 8. When LED is in solid green remove the SD card.
- 9. LED changes into blue and will reboot for a few times. (roughly 3-5 minutes)
- 10. Confirm the version in setting using Vysor.

#### Region Image Update:

The procedures are the same. The only different is the LED status during the update.

- 1. LED blinks in green when device is powered on.
- 2. LED in solid blue then remove the SD card.
- 3. Device will reboot a few times to complete the update.
- 4. Confirm the version in setting using Vysor for Region image

# Troubleshoot

If you are not able to connect the device via Vysor, please check the Device Manger in Windows to ensure the device has been detected by the OS.

