

DANCE · CHAIRS & ARMCHAIRS

DANCE DINING CHAIR

ARM-09

Chair

W 50 x D 55 x H 79 cm

Ivory boucle seat and back; solid walnut frame

CARE

Dust with a soft dry cloth and use mats. Avoid direct sunlight, heat and standing water. Upholstered seats: professional cleaning only.

