## ARAB REPUBLIC OF EGYPT SUEZ CANAL AUTHORITY

www.suezeanal.gov.eg

Fax: 002 / 064 /3914784 / 3914785

Entail. Info@suezcanal.gov.eg

Telephone 064 /5396222 - 3395333 - 3397222 tumana



حمهورية مصر العربية هيشة تناة السويس

		Administration 24
Dept :	القوق المبرة	
No.		

2001/1/ delala

C.CC /5119

CONCRETE TESTET TESTET TESTET

-- +/- TI/ PELIFA - PELLAS 

(P)

+ Va

إشارة كتابية

ادارة التحركات إلى

مزكز البلبا

الإدارة الهندسية

بالإحالة إلى الشارقة فقم ٢٠٢٨/١٠ بتاريخ ٢٠٢٢/٢/١٥، والمعاينات التي تمت مع مندوبكم من قطاع الإسماعلية وبورسعيد لمحطات الإرشاد التي سيتم تطوير التغنية الكهربية بها بإستخدام الطاقة المتجددة (الرياح + الطاقة الشمسية) بناءاً على موافقة السيد الفريق/ رنيس الهيئة وحيث أنه جارى إستلام الأجهزة حالياً.

وطبقاً لما تع تنفيذه مسبقاً بمحطة زادار شرق الفردان يرجى التكرم بإتخاذ ما يلزم نحو 18

- حفر قواعد التربينات بابعاد ( ۱٫۹×۱٫۹٪ (۱٫۷٪) (طول × عرض × ارتفاع) طبقاً لنمر فق.
  - ربط القاعدة الخرسانية بمسارات المحطة المجاورة لها يعدد/ ٢ ماسورة ٤ بوصة.
  - مد ماسورة بالستيك مرنة بطول برج التربينة قطر ٣ بوصة وتثبيتها في حسم البرج.
- تركيب قاعدة التربينة بصورة صحيحة بحيث لا تؤثر على إستقامة يرج التربينة وصب الخرسانة عليها

مع الأخذ في الإعتبار أن جميع الأعمال السابقة مماثلة لما تم عمله مسبقاً في محطة رادار شرق الفردان.

ومندوبينا للتنسيق: د.م/محمود محمد عبداللا ت: ١٠٦٢٥٢٠ م: ٨٨١٠ ٢٥٦٢٠١٠

ت: ٢٦٥٢٦ ج: ٣٢٢٢٤٤١٠١١. م/مصنطقي الرافعي

وشكر م

مدس إداس ة التحركات

E me fales

قسم المراقبة الدلكترونية

صادر رقم : 679ه الستاريخ:30-08-2022

🗸 - المكتب القنص - مراقبة الكترونية

المتابعة - مراقبة إلكترونية

القوى أمراقبة الكترونية السا




## Procedure of tower installation E5



The installation must be carried out by authorized persons with certified knowledge in the field.

1


First step is to excavate the foundation for the tower base, using the excavator or similar, as shown on the Figure 1.



(Figure 1)




According to the specifications of Your particular installation, the dimensions of the excavation have the following minimum measurements, see Figure 2.



(Figure 2)


THE PROPERTY OF THE PARTY OF TH

Once the first step is completed it is necessary to ensure the correct levelling of the tower base. This part of the installation is the most important to achieve the verticality of the tower. See Figure 3.




PROPERTY AND PROPERTY OF

The third step is to pour the concrete into the prepared excavation, ensuring the correct position of the tower base. The concrete used should be at least HM 25, with minimum compression resistance, after setting, equal to or greater than 25N/mm2. See Figure 4.



(Figure 4)


It is recommended to leave the concrete above ground level (10 to 20 cm) to prevent the effect of humidity in the base of the tower and to facilitate the installation and maintenance, as shown in the Figure 5.



(Figure 5)

Setting the Advisor of the Setting

In the next step, the tower must be assembled (on the ground) as shown in the Figure 6. Special care must be taken not to confuse different lattice elements. All elements have marks according to the attached drawing in the annex A.




(Figure 6)

See the Table 1 for bolt specifications and tightening torque,



(Table 1)

The crane is used to lift the tower and place it on the concreted base. Special care must be taken not to exceed the capacity of the crane, see Figure 7.



(Figure 7)

Once the tower is placed, it must be fixed to the tower base with the tightening forque specified in the Table 1.

6

Before lifting and fixing the turbine, it is necessary to do the connection of the cables, and fix it to the tower toe, on the ground, as shown in the Figure 8 and Figure 9.