





NOTES

1 Use appropriate grip length of rivets to accommodate doubler and skid tube thickness.

2 Break all sharp edges on doubler.

212_MM_32_0005

Figure 32-5. Skid Tube (BHT 412-050-030/-034) Patch Repair