

Figure 97-36. Avionics master wiring diagram (S/N 30554 through 30596 except for S/N 30583, 30587, 30591, and 30592) (Sheet 1 of 5)




Figure 97-36. Avionics master wiring diagram (S/N 30554 through 30596 except for S/N 30583, 30587, 30591, and 30592) (Sheet 2)




Figure 97-36. Avionics master wiring diagram (S/N 30554 through 30596 except for S/N 30583, 30587, 30591, and 30592) (Sheet 3)




Figure 97-36. Avionics master wiring diagram (S/N 30554 through 30596 except for S/N 30583, 30587, 30591, and 30592) (Sheet 4)




Figure 97-36. Avionics master wiring diagram (S/N 30554 through 30596 except for S/N 30583, 30587, 30591, and 30592) (Sheet 5)

212-M-97-36-5

212-475-009C