Bell Helicopter
A Textron Company

GEARBOX
OIL FILLER
AND GAGE

PILLOW BLOCK OIL RESERVOIR

HUB GRIP OIL RESERVOIR

MAIN ROTOR HUB

GEARBOX
OIL FILLER
AND GAGE

TRANSMISSION OIL FILLER

HYDRAULIC
RESERVOIRS

COMBINING GEARBOX FILLER AND GAGE

HYDRAULIC
FILTERS

ENGINE FIRE EXTINGUISHER

R.H. ENGINE OIL FILTER AND GAGE

ROTOR
BRAKE

BATTERY

STEPS

FUEL TANK FILLER

TRANSMISSION OIL FILTER, GAGES, AND DRAIN

GROUNDING JACK

FUEL SUMP DRAINS (EACH SIDE)

STEPS

NOTE

STEP

EXTERNAL
POWER
RECEPTACLE

After compliance with
TB212-81-56, refer to lubrication
chart, figure 12-2.

ENGINE FIRE EXTINGUISHER

WALKWAY

L.H. ENGINE OIL FILLER AND GAGE

STEPS

GROUNDING JACK

HYDRAULIC TEST COUPLINGS

AUXILIARY FUEL TANK
CONNECTIONS (EACH SIDE)

TRANSMISSION OIL COOLER DRAIN VALVES

DEFUEL VALVE (EACH SIDE)

212-M-12-1

**Figure 12-1.   Servicing Points**