## **BHT-212-IPB**




Figure 99-18. Manual release installation