## **CONTENTS - IPB**

Figure	Figure Title	Chapter/Section	Page	
Number		Number	Number	
10-1	Loose equipment, installed and packaged	10-99-00	2	




Figure 10-1. Loose equipment, installed and packaged

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A - L	noc
		FIGURE: 10-1. Loose equipment, installed and packaged			
123 4556788	212-070-001-001 MS35207-259 212-030-044-001 CU934 212-070-450-019 SW4738-1 130-013-3 204-070-470-001 212-070-111-001 212-070-112-001 212-070-112-002	LOOSE EQUIPMENT, INSTALLED .SCREW .COVER, COLLECTIVE, CONTROL, LH .DOCUMENT CASE .LOOSE EQUIPMENT, PACKACED .TLE DOWN STRAP, TAIL ROTOR .TLE DOWN STRAP, TAIL ROTOR .TLE DOWN, MAIN ROTOR (REPLACED BY 130-013-3) .COVER ASSY, PITOT .COVER ASSY, ENGINE EJECTOR .SHIELD ASSY, ENGINE INLET .SHIELD ASSY, ENGINE INLET .SHIELD ASSY, ENGINE INLET	17111111211		