



- 1. Manual automatic fuel control interconnect linkage
- 2. Datum line
- 3. Acceleration adjuster
- 4. Automatic Fuel Control Unit (AFCU)
- 5. Manual Fuel Control Unit (MFCU)
- 6. Minimum stop screw
- 7. Stop arm

- 8 Stop
- 9. Maximum stop screw
- 10. Fuel control arm
- 11. Cotter pin
 12. Part power trim stop
- 13. Cotter pin
- 14. Maximum stop adjustment screw

212_M_76_3_c01

Figure 76-3. Manual and Automatic Fuel Control Adjustment