

- 1. This chart to be used for all configurations except when the following kits are installed.
 - 1. Auxiliary fuel 205-706-044
 - 2. Auxiliary fuel 205-706-045
 - 3. Auxiliary fuel 212-899-243
 - 4. Emergency flotation 212-706-021
 - 5. Floats 205-706-050
- 2. Use this chart when 212-706-032 or 212-706-042 float kit is installed.

212-M-8-3

Figure 8-3. Weight empty center of gravity