
CONTENTS - IPB

Figure Number	Figure Title	Chapter/Section Number	Page Number
28-1	Fuel system installation	28-99-00	2
28-2	Fuel system installation	28-99-00	10
28-3	Fuel system installation	28-99-00	14
28-4	Fuel system installation	28-99-00	20
28-5	Fuel system installation	28-99-00	26



212_IPB_28_0001

Figure 28-1. Fuel System Installation (Sheet 1 of 2)




Figure 28-1. Fuel system installation (Sheet 2)

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	4>4-L	200
		FIGURE: 28-1. Fuel system installation			
	212-060-600-003	FUEL SYSTEM INSTL (S/N 30504 THRU 30614) (SEE FIG 2,3,4,5 FOR BALANCE OF BREAKDOWN)	1		
	212-060-600-005	FUEL SYSTEM INSTL (S/N 30615 THRU 30729) (SEE FIG 2,3,4,5 FOR BALANCE OF BREAKDOWN)	1		
	212-060-600-009	FUEL SYSTEM INSTL (S/N 30730 THRU 31294) (SEE FIG 2,3,4,5 FOR BALANCE OF BREAKDOWN)	1		
	212-060-600-101	FUEL SYSTEM INSTL (S/N 31295 THRU 31311, 35001 THRU 35080) (SEE FIG. 2,3,4,5 FOR BALANCE OF BREAKDOWN)	1		
	212-060-600-103	FUEL SYSTEM INSTL (S/N 35081 THRU SUB) (SEE FIG. 2, . 3, 4, 5 FOR BALANCE OF BREAKDOWN)	1		
1	MS27039-1-12	.SCREW (S/N 31295 THRU SUB)	1		
2	AN960PD10L	.WASHER (S/N 31295 THRU SUB) (REPLACED BY AN960JD10L)	1		
2	AN960JD10L	.WASHER (S/N 31295 THRU SUB) (REPLACES	1		
3	MS21919DG9	.CLAMP (S/N 31295 THRU SUB) (REPLACED BY	1		
3	MS21919WDG9	.CLAMP (S/N 31295 THRU SUB) (REPLACES MS21919DG9)	1		
4	AN520-10R18	SCREW	1		
5	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1		
5	AN960JD10L	.WASHER (REPLACES AN960PD10L)	1		
6	NAS43DD3-48	.SPACER (REPLACED BY NAS43DD3-48N)	1	1	
6	NAS43DD3-48N	.SPACER (REPLACES NAS43DD3-48)	1		
7	MS21919DG9	.CLAMP (REPLACED BY MS21919WDG9)	1		
7	MS21919WDG9	.CLAMP (REPLACES MS21919DG9)	1		
8	AN520-10R7	SCREW (REPLACED BY MS35207-262)	1		
8	MS35207-262	SCREW (REPLACES AN520-10R7)	1		
9	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	ĺ	
9	AN960JD10L	.WASHER (REPLACES AN960PD10L)	1		
10	NAS43DD3-12	SPACER	1		
11	MS21919DG9	.CLAMP (REPLACED BY MS21919WDG9)	1		
12	MS21919WDG9 70-010H000V214	.CLAMP (REPLACES MS21919DG9)	1		
12	70-010H000V214 70-061H000V214A	.HOSE ASSY (REPLACES 70-010H000V214A)	1	1	
13	70-010H000V175	.HOSE ASSY (REPLACED BY 70-010H000175A,	1		
13	70-010H000V175A	.HOSE ASSY (REPLACES 70-010H000V175) (REPLACED BY . 70-010H000174 AND 70-061H000V174A)	1		
13	70-010H000V174	.HOSE ASSY (REPLACES 70-010H000175 AND	1		
13	70-061H000V174A	.HOSE ASSY (REPLACES 70-010H000V175,	1		
14	MS35489-17	.GROMMET	2		
15	AN929-6	.CAP	1		
16	AN815-8D	.UNION	1		
17	AN919-12D	REDUCER	3		
18	MS29512-08	.PACKING, PREFORMED	3		
19	110-144-8A	.SEAL (S/N 30730 THRU 31294)	2	1	
20	AN938D8	TEE	1		

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A A L	D00
		FIGURE: 28-1. Fuel system installation (Cont'd)			
21	AN520-10R10	.SCREW (REPLACED BY MS35207-264)	2		
21	MS35207-264	.SCREW (REPLACES AN520-10R10)	2		
22	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2		
22	AN960JD10L	.WASHER (REPLACES AN960PD10L)	2		
23	NAS43DD3-12 MS21919DG8	SPACER	2		
24	MS21919DG8 MS21919WDG8	.CLAMP (REPLACED BY MS21919WDG8)	2		
25	212-060-645-001	.CLAMP (REPLACES MS21919DG8)	2 1		
25	212-060-675-001	.TUBE ASSY (REPLACES 212-060-645-001)	1		
26	110-144-8A	SEAL (S/N 30730 THRU 31294)	1		
27	NAS679A3	NUT (REPLACED BY MS21042L3)	1		
27	MS21042L3	.NUT (REPLACES NAS679A3)	1		
28	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1		
28	AN960JD10L	.WASHER (REPLACES AN960PD10L)	1		
29	MS27039-1-42	.SCREW	1		
30	NAS43DD3-128	.SPACER	1		
31	MS21919DG8	.CLAMP (REPLACED BY MS21919WDG8)	1		
31	MS21919WDG8	.CLAMP (REPLACES MS21919DG8)	1		
32	MS21919DG10	.CLAMP (REPLACED BY MS21919WDG10)	1		
32	MS21919WDG10	.CLAMP (REPLACES MS21919DG10)	1		
33 34	212-060-644-001	TUBE ASSY	1		
35	110-144-8A NAS679A3	.SEAL (S/N 30730 THRU 31294)	1 1		
35	MS21042L3	.NUT (S/N 30730 THRU 31294) (REPLACES NAS679A3)	1		
36	AN960PD10L	.WASHER (S/N 30730 THRU 31294) (REPLACED BY	1		
36	AN960JD10L	.WASHER (S/N 30730 THRU 31294) (REPLACES AN960PD10L)	1		
37	MS27039-1-07	.SCREW (S/N 30730 THRU 31294)	1		į
38	MS21919DG10	.CLAMP (S/N 30730 THRU 31294) (REPLACED BY	1		
38	MS21919WDG10	.CLAMP (S/N 30730 THRU 31294) (REPLACES	1		
39	AN520-10R8	.SCREW (REPLACED BY MS35207-263)	1		
39	MS35207-263	.SCREW (REPLACES AN520-10R8)	1		
40	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1		
40	AN960JD10L	.WASHER (REPLACES AN960PD10L)	1		
41	MS21919DG10	.CLAMP (REPLACED BY MS21919WDG10)	2	1	İ
41	MS21919WDG10	.CLAMP (REPLACES MS21919DG10)	2		
42	NAS679A3	.NUT (REPLACED BY MS21042L3)	1		
42 43	MS21042L3	.NUT (REPLACES NAS679A3)	1		
43	AN960PD10L AN960JD10L	.WASHER (REPLACED BY AN960JD10L)	1		1
43	AN520-10R7	.WASHER (REPLACES AN960PD10L)	1 1		l
44	MS35207-262	SCREW (REPLACES AN520-10R7)	1		
45	MS21919DG6	.CLAMP (REPLACED BY MS21919WDG6)	1	-	
45	MS21919WDG6	.CLAMP (REPLACES MS21919DG6)	1	1	
46	MS21919DG10	.CLAMP (REPLACED BY MS21919WDG10)	1]	
			-		

BHT-212-IPB


(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	Å Å L	000
		FIGURE: 28-1. Fuel system installation (Cont'd)			
46	MS21919WDG10	.CLAMP (REPLACES MS21919DG10)	1		
47	212-060-631-001	.TUBE ASSY	1		
48	212-060-632-001	.TUBE ASSY	1		
49	AN821-8D	.ELBOW	1		
50	110-144-8A	.SEAL (S/N 30730 THRU 31294)	1		
51	869A10TT (018)	.VALVE (S/N 30504 THRU 31294) (REPLACED BY	2		
51	209-062-607-001	.VALVE (REPLACES 869A10TT(018))	2		
52	AN929-8	.CAP	1		
53	AN824-8D	TEE	1		
54	110-144-8A	.SEAL (S/N 30730 THRU 31294)	3		
55	NAS679A3	.NUT (REPLACED BY MS21042L3)	2		
55	MS21042L3	.NUT (REPLACES NAS679A3)	2		
56	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2		
56	AN960JD10L	.WASHER (REPLACES AN960PD10L)	2		
57	MS27039-1-07	.SCREW	1		
58	MS27039-1-08	.SCREW	1		
59	MS21919DG8	.CLAMP (REPLACED BY MS21919WDG8)	1		
59	MS21919WDG8	.CLAMP (REPLACES MS21919DG8)	1		
60	AN743-12	.BRACKET	1		
61	NAS679A3	.NUT (REPLACED BY MS21042L3)	2		
61	MS21042L3	.NUT (REPLACES NAS679A3)	2		
62	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2		
62	AN960JD10L	.WASHER (REPLACES AN960PD10L)	2		
63	AN520-10R7	SCREW (REPLACED BY MS35207-262)	2		
63 64	MS35207-262 MS21919DG8	SCREW (REPLACES AN520-10R7)	2		
64	MS21919WDG8	.CLAMP (REPLACED BY MS21919WDG8)	2		
65	MS21919WDG8 MS21919DG10	.CLAMP (REPLACES MS21919DG8)	2		.
65	MS21919WDG10	.CLAMP (REPLACED BY MS21919WDG10)	2		
66	NAS679A3	.NUT (REPLACED BY MS21042L3)	1		
66	MS21042L3	.NUT (REPLACES NAS679A3)	1		
67	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1		
67	AN960JD10L	.WASHER (REPLACES AN960PD10L)	1		
68	AN520-10R7	SCREW (REPLACED BY MS35207-262)	1		
68	MS35207-262	SCREW (REPLACES AN520-10R7)	1		
69	MS21919DG10	.CLAMP (REPLACED BY MS21919WDG10)	2		
69	MS21919WDG10	.CLAMP (REPLACES MS21919DG10)	2		
70	NAS679A3	.NUT (REPLACED BY MS21042L3)	1		
70	MS21042L3	.NUT (REPLACES NAS679A3)	1		
71	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	İ	
71	AN960JD10L	.WASHER (REPLACES AN960PD10L)	1		
72	AN520-10R22	.SCREW	1		
73	NAS43DD3-64	.SPACER	1		
74	MS21919DG10	.CLAMP (REPLACED BY MS21919WDG10)	2		
74	MS21919WDG10	.CLAMP (REPLACES MS21919DG10)	2		
75	212-060-618-001	.TUBE ASSY (S/N 30504 THRU 30614) (REPLACED BY	1		
75	212-060-674-001	212-060-674-001) .TUBE ASSY (REPLACES 212-060-618-001)	1		
					

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A	200
		FIGURE: 28-1. Fuel system installation (Cont'd)			
76	212-060-607-001	.TUBE ASSY (S/N 30504 THRU 31311, 35001 THRU	1		
76	212-060-221-101	.TUBE ASSY (REPLACES 212-060-607-001)	1		
77	212-060-608-001	.TUBE ASSY	1		
78	212-060-673-001	.TUBE ASSY	1		
79	AN815-8D	.UNION	1		
80	MS29512-08	.PACKING, PREFORMED	1		
81	AN929-8	.CAP	2		
82	AN815-8D	.UNION (S/N 31125 THRU 31206)	1		
82	AN837-8D	.ELBOW (S/N 31207 THRU SUB)	1		
83	AN924-8D	.NUT (S/N 31207 THRU SUB)	1		
84	MS29512-08	.PACKING, PREFORMED	1		
85	42C42604	.VALVE (S/N 30504 THRU 31294) (REPLACED BY 204-061-689-001)	2		
85	204-061-689-001	.VALVE (REPLACES 42C42604)	2		
86	MS29512-06	.PACKING, PREFORMED	2		l
87	AN893-12D	.BUSHING	2		l
88	MS29512-08	.PACKING, PREFORMED	2		
89	AN804D8	TEE	1	l	
90	AN924-8D	.NUT	1		
91	MS29512-08	.PACKING, PREFORMED	1		
92	AN937D8	.CROSS	1		-
93	AN938D8	.TEE	1		
94	MS29512-08	.PACKING, PREFORMED	2		
95	AN924-8D	.NUT	4		
96	AN960PD1216L	.WASHER (REPLACED BY AN960JD1216L)	2		
96	AN960JD1216L	.WASHER (REPLACES AN960PD1216L)	2	l	
97	AN832-8D	.ADAPTER	2		
98	MS29512-08	.PACKING, PREFORMED	2		
99	AN939D8	.ELBOW	2		
100	MS29512-08	.PACKING, PREFORMED	2		
101	AN815-8D	.UNION	2		
102	NAS679A3	.NUT (REPLACED BY MS21042L3)	2		
102	MS21042L3	.NUT (REPLACES NAS679A3)	2		
103	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2		
103	AN960JD10L	.WASHER (REPLACES AN960PD10L)	2		
104	AN520-10R7	SCREW (REPLACED BY MS35207-262)	2		1
104	MS35207-262	SCREW (REPLACES AN520-10R7)	2		
105	MS21919DG13	.CLAMP (REPLACED BY MS21919WDG13)	1]
105	MS21919WDG13	.CLAMP (REPLACES MS21919DG13)	1]
106	AN743-12	BRACKET	1		1
107 108	212-061-632-001	TUBE ASSY	1		
108	212-061-633-001 2662D10	TUBE ASSY	1		-
109	2662D10 110-089-6D	TEE (REPLACED BY 110-089-6D)	2		-
110	NAS679A3	REDUCER TEE (REPLACES 2662D10)	2		
110	MS21042L3	NUT (REPLACED BY MS21042L3)	4		
111	AN960PD10L	.NUT (REPLACES NAS679A3)	4		
111	AN960JD10L	.WASHER (REPLACED BY AN960JD10L)	4		
112	MS27039-1-34	· · · · · · · · · · · · · · · · · · ·	4		
112	13521055-1-34	SCREW	4		1

BHT-212-IPB

	(2)	(3)	(4)	(5) A	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A A L	000
		FIGURE: 28-1. Fuel system installation (Cont'd)			
113	212-061-629-001	.CONNECTOR	2		
114	AV24B1119B	.VALVE(ALTERNATE PART)	1		
114	233575	.VALVE	1		
115	MS29513-123	PACKING, PREFORMED (USBL ON AV24B1119B)	1		
115	M25988/1-122	PACKING, PREFORMED (USBL ON 233575)	1		
116	NAS679A3	.NUT (REPLACED BY MS21042L3)	2		
116	MS21042L3	.NUT (REPLACES NAS679A3)	2		
117	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2		
117	AN960JD10L	.WASHER (REPLACES AN960PD10L)	2		
118	AN520-10R16	.SCREW (REPLACED BY MS35207-267)	2		
118	MS35207-267	.SCREW (REPLACES AN520-10R16)	2		
119	NAS43DD3-28	.SPACER	2		
120	MS21919DG10	.CLAMP (REPLACED BY MS21919WDG10)	2		
120	MS21919WDG10	.CLAMP (REPLACES MS21919DG10)	2		
121	212-060-612-001	.TUBE ASSY	1		
122	212-060-611-001 AN815-10	.TUBE ASSY	1		
123		.UNION	2		
124	MS29512-10 MS27039-1-35	.PACKING, PREFORMED	2		
126	AN960PD10L	SCREW	8		
126	AN960JD10L	.WASHER (REPLACES AN9600DIOL)	8		
127	212-061-629-001	. CONNECTOR	2		
128	212-061-629-003	CONNECTOR	2		
129	205-060-612-003	.VALVE	2		
		(ALTERNATE PART)	ا ً		
129	233565	.VALVE	2		
130	MS29513-215	PACKING, PREFORMED (USBL ON 206-060-612-003)	2		
130	MS29513-121	PACKING, PREFORMED (USBL ON 233565)	2		
131	212-060-615-001	.TUBE ASSY	1	İ	
132	212-060-616-001	.TUBE ASSY	1	1	
133	212-060-665-001	.RESTRICTOR ASSY	2		
	MS29512-10	.PACKING, PREFORMED	2	l	
135	AN815-4	.UNION	2		
	MS29512-04	.PACKING, PREFORMED	2	1	
137	100-016-1	.PLUG	2		
138	MS29512-04	.PACKING, PREFORMED	2		
139	AN924-12C AN924-12J	.NUT (REPLACED BY AN924-12J)	2		
	AN960C1716	.NUT (REPLACES AN924-12C)	2		
141	209-062-608-001	.TRANSMITTER (REPLACED BY 130-020-1)	2 2		
141	130-020-1	TRANSMITTER (REPLACES 209-062-608-001)	2		
1	MS27039-1-05	SCREW	8		
143	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	8		
143	AN960JD10L	.WASHER (REPLACES AN960PD10L)	8		
144	205-061-686-001	BRACKET	2		
145	AN520-10R14	SCREW (REPLACED BY MS35207-266)	2		
145	MS35207-266	.SCREW (REPLACES AN520-10R14)	2		
	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2		
146					

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A L	n o c
		FIGURE: 28-1. Fuel system installation (Cont'd)			
147 148 148 149 150 151 153 154 155 156 157 158 159 161 162 163 164 165 168 169 171	NAS43DD3-28 MS21919DG10 MS21919WDG10 212-060-613-001 212-060-614-001 AN815-10 MS29512-10 AN938-10 AN938J10 212-060-646-001 212-060-654-101 212-060-656-101 MS35489-21 212-060-651-001 212-060-651-001 212-060-651-001 212-060-650-001 2662D12 110-089-7D AN815-12D MS29512-12 2559D8 110-091-3D AN919-19D MS29512-12 AN924-12D AN960PD1216L AN832-12D MS29512-12 AN937D12	SPACER CLAMP (REPLACED BY MS21919WDG10) CLAMP (REPLACES MS21919DG10) TUBE ASSY TUBE ASSY TUNION PACKING, PREFORMED TEE (REPLACED BY AN938J10) TUBE ASSY (S/N 30504 THRU 31294) TUBE ASSY (S/N 30504 THRU 31294) TUBE ASSY (S/N 31295 THRU SUB) GROMMET TUBE ASSY TUBE	2 2 2 1 1 4 2 2 2 1 1 1 1 2 1 1 1 1 1 1		



212-28-1002 C0001

Figure 28-2. Fuel system installation

(1)	(2)	(3)	(4)	(5) A	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	V A I L	0 C
		Figure 28-2. Fuel System Installation			
	212-060-600-003	FUEL SYSTEM INSTL (S/N 30504 THRU 30614) (SEE FIG. 1, 3, 4, 5 FOR BALANCE			
	212-060-600-005	OF BREAKDOWN)	REF	NP	
	212-060-600-009	OF BREAKDOWN) FUEL SYSTEM INSTL (S/N 30730 THRU 31294) (SEE FIG. 1, 3, 4, 5 FOR BALANCE	REF	NP	
	212-060-600-101	OF BREAKDOWN)	REF	NP	
	212-060-600-103	FOR BALANCE OF BREAKDOWN)	REF	NP	
		OF BREAKDOWN)	REF	NP	
1	AN924-6D	.NUT	2	SP	
2 2	AN960PD916L AN960JD916L	.WASHER (REPLACED BY AN960JD916L)	4	P	
		(REPLACED BY NAS1149D0916J)	4	P	
2	NAS1149D0916J	.WASHER (REPLACES AN960JD916L)	4	SP	
3 4	AN833-6 AN924-4D	.ELBOW	2 2	SP SP	
5	AN960PD716L	.WASHER (REPLACED BY AN960JD716L)	2	SP	
5	AN960JD716L	.WASHER (REPLACES AN960PD716L) (REPLACED BY NAS1149D0716J)	2	P	
5	NAS1149D0716J	WASHER (REPLACES AN960JD716L)	2	SP	
6	AN833-4	.ELBOW	2	SP	
7	212-060-623-001	.TUBE ASSY	1	SP	
8	212-060-624-001	.TUBE ASSY	1	SP	
9	458-4D1-6	.VALVE	2	SP	
10	MS29512-04	.PACKING, PREFORMED	2	SP	
11	212-060-621-001	.TUBE ASSY	1	SP	
12	212-060-620-001	TUBE ASSY	1	SP	
13 14	AN824-6D MS27039-1-07	.TEE	1	SP SP	
15	MS21919DG6	.CLAMP (REPLACED BY MS21919WDG6)	1	NP	
15	MS21919WDG6	.CLAMP (REPLACES MS21919DG6)	1	SP	
16	NAS679A3	.NUT (REPLACED BY MS21042L3)	1	P	
16	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	1	SP	
17	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	P	
17	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY NAS1149D0332J)	1	P	
17	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
18	AN520-10R7	.SCREW (REPLACED BY MS35207-262)	1	P	
18	MS35207-262	.SCREW (REPLACES AN520-10R7)	1	SP	
19	MS21919DG6	.CLAMP (REPLACED BY MS21919WDG6)	1	NP	
19	MS21919WDG6	.CLAMP (REPLACES MS21919DG6)	1	SP	
20	MS21919DG10	.CLAMP (REPLACED BY MS21919WDG10)	1	P	
20	MS21919WDG10 212-061-635-001	.CLAMP (REPLACES MS21919DG10)	1	SP SP	
21		- L. LUDB MAAI	· 1	SP.	i

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	J 0 C
		Figure 28-2. Fuel System Installation (Cont'd)			
22	NAS679A3	.NUT (REPLACED BY MS21042L3)	1	P	
22	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	1	SP	
23	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	P	
23	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
		(REPLACED BY NAS1149D0332J)	1	P	
23	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
24	AN520-10R10	.SCREW (REPLACED BY MS35207-264)	1	NP	
24	MS35207-264	.SCREW (REPLACES AN520-10R10)	1	SP	
25	MS21919DG12	.CLAMP (REPLACED BY MS21919WDG12)	2	P	
25	MS21919WDG12	.CLAMP (REPLACES MS21919DG12)	2	SP	
26	MS27039-1-24	.SCREW	1	SP	
27	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	P	
27	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
		(REPLACED BY NAS1149D0332J)	1	P	
27	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
28	NAS43DD3-70	.SPACER	1	SP	
29	MS21919DG12	.CLAMP (REPLACED BY MS21919WDG12)	1	P	
29	MS21919WDG12	.CLAMP (REPLACES MS21919DG12)	1	SP	
30	212-060-652-001	.TUBE ASSY	1	SP	
31	212-060-643-001	.TUBE ASSY	1	SP	
32	212-060-625-001	.TUBE ASSY	1	SP	
33	212-060-626-001	.TUBE ASSY	1	SP	
34	AN924-6D	.NUT	1	SP	
35	AN960PD916L	.WASHER (REPLACED BY AN960JD916L)	2	P	
35	AN960JD916L	.WASHER (REPLACES AN960PD916L)			
		(REPLACED BY NAS1149D0916J)	2	P	
35	NAS1149D0916J	.WASHER (REPLACES AN960JD916L)	2	SP	
36	AN832-6	.UNION (REPLACED BY AN832-6J)	2	P	
36	AN832-6J	.UNION (REPLACES AN832-6)	2	SP	
37	AN924-4D	NUT	1	SP	
38	AN960PD716L	.WASHER (REPLACED BY AN960JD716L)	1	SP	
38	AN960JD716L	.WASHER (REPLACES AN960PD716L)			
30	111,70002,101	(REPLACED BY NAS1149D0716J)	1	P	
38	NAS1149D0716J	.WASHER (REPLACES AN960JD716L)	1	SP	
39	AN804D4	TEE	1	SP	
40	AN924-4D	NUT	1	SP	
41	AN960PD716L	.WASHER (REPLACED BY AN960JD716L)	1	SP	
41	AN960JD716L	.WASHER (REPLACES AN960PD716L)			
	12.50005,101	(REPLACED BY NAS1149D0716J)	1	P	
41	NAS1149D0716J	.WASHER (REPLACES AN960JD716L)	1	SP	
42	AN832-4D	UNION	1	SP	
43	212-060-627-001	.TUBE ASSY	1	SP	
44	212-060-628-001	.TUBE ASSY	1	SP	
45	212-060-676-001	.CHECK VALVE	1	SP	
46	AN815-6D	UNION	2	SP	
47	MS29512-06	PACKING, PREFORMED	3	SP	
48	MS29512-06 AN938D6	TEE	1	SP	
		.NUT (REPLACED BY MS21042L3)	1	SP P	
49	NAS679A3	,	1	~	
49	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	_	SP	
50	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	P	

(1)	(2)	(3)	(4)	(5) A	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	V A I L	0 C
		Figure 28-2. Fuel System Installation (Cont'd)			
50	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
50	NAS1149D0332J	(REPLACED BY NAS1149D0332J)	1 1	P SP	
51	AN520-10R7	SCREW (REPLACED BY MS35207-262)	1	P	
51	MS35207-262	.SCREW (REPLACES AN520-10R7)	1	SP	
52	MS21919DG6	.CLAMP (REPLACED BY MS21919WDG6)	1	NP	
52	MS21919WDG6	.CLAMP (REPLACES MS21919DG6)	1	SP	
53	MS21919DG12	.CLAMP (REPLACED BY MS21919WDG12)	1	P	
53	MS21919WDG12	.CLAMP (REPLACES MS21919DG12)	1	SP	
54	212-060-629-001	.TUBE ASSY	1	SP	
55 56	212-060-676-001	.CHECK VALVE	1 3	SP	
56 57	AN815-6D MS29512-06	.UNION	4	SP SP	
57 58	MS29512-06 AN937D6	.CROSS	1	SP	
59	NAS679A3	.NUT (REPLACED BY MS21042L3)	1	P	
59	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	1	SP	
60	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	P	
60	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
		(REPLACED BY NAS1149D0332J)	1	P	
60	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
61	AN520-10R7	.SCREW (REPLACED BY MS35207-262)	1	P	
61	MS35207-262	SCREW (REPLACES AN520-10R7)	1	SP	
62	MS21919DG6	.CLAMP (REPLACED BY MS21919WDG6)	1	NP	
62 63	MS21919WDG6 MS21919DG12	.CLAMP (REPLACES MS21919DG6)	1 1	SP P	
63	MS21919DG12 MS21919WDG12	.CLAMP (REPLACES MS21919WDG12)	1	SP	
64	212-060-630-001	TUBE ASSY	1	SP	
65	AN815-12D	.UNION	2	SP	
66	NAS679A3	.NUT (REPLACED BY MS21042L3)	1	P	
66	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	1	SP	
67	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	P	
67	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
		(REPLACED BY NAS1149D0332J)	1	P	
67	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
68 69	AN520-10R8	SCREW (REPLACED BY MS35207-263)	1	P	
68 69	MS35207-263 MS21919DG12	SCREW (REPLACES AN520-10R8)	1 2	SP P	
69	MS21919DG12 MS21919WDG12	.CLAMP (REPLACES MS21919WDG12)	2	SP	
70	212-060-653-001	TUBE ASSY	1	SP	
71	212-060-642-001	.TUBE ASSY	1	SP	
72	MS35489-11	.GROMMET	2	SP	
73	MS35489-20	.GROMMET	1	SP	
74	MS35489-21	.GROMMET	1	SP	

(1)	(2)	(3)	(4)	(5) A	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	V A I L	U O C
		Figure 28-2. Fuel System Installation (Cont'd)			
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable See introduction on availability codes for additional information.			

THIS PAGE INTENTIONALLY LEFT BLANK




Figure 28-3. Fuel System Installation

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	200
		FIGURE: 28-3. Fuel system installation			
	212-060-600-003	FUEL SYSTEM INSTL (S/N 30504 THRU 30614) (SEE FIG 1,2,4,5 FOR BALANCE OF BREAKDOWN)	REF		
	212-060-600-005	FUEL SYSTEM INSTL (S/N 30615 THRU 30729) (SEE FIG 1,2,4,5 FOR BALANCE OF BREAKDOWN)	REF		
	212-060-600-009	FUEL SYSTEM INSTL (S/N 30730 THRU 31294) (SEE FIG 1,2,4,5 FOR BALANCE OF BREAKDOWN)	REF		
	212-060-600-101	FUEL SYSTEM INSTL (S/N 31295 THRU 31311, 35001 THRU 35080) (SEE FIG. 1,2,4,5 FOR BALANCE OF BREAKDOWN)	REF		
	212-060-600-103	FUEL SYSTEM INSTL (S/N 35081 THRU SUB) (SEE FIG. 1, 2, 4, 5 FOR BALANCE OF BREAKDOWN)	REF		
1	MS27039-1-06	SCREW	8		
2	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	8		
2	AN960JD10L	.WASHER (REPLACES AN960PD10L)	8		
3	212-061-631-001	.BRACKET	2		
4	70-061F086F090A	.HOSE ASSY, LH (S/N 31295 THRU 31311, 35001 THRU 35080)	1		
4	70-061F270Z092A	.HOSE ASSY, LH (S/N 35081 THRU SUB)	1		
5	70-061F280F094A	.HOSE ASSY, RH (S/N 31295 THRU 31311, 35001 THRU 35080)	1		
5	70-061F090Z090A	.HOSE ASSY, RH (S/N 35081 THRU SUB)	1		
6	110-089-13D	REDUCER TEE (S/N 31295 THRU SUB)	2		
7	60-003-2N16	.GROMMET (S/N 31295 THRU SUB)	4		
8	AN4-4A	.BOLT	12		
9	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	12		
9	AN960JD416L	.WASHER (REPLACES AN960PD416L)	12		
10 10	AN520-10R6 MS35207-261	SCREW (REPLACED BY MS35207-261)	12		
11	MS35207=261 AN960PD10L	SCREW (REPLACES AN520-10R6)	12		
11	AN960JD10L	.WASHER (REPLACES AN9600DIOL)	12		
12	MS20762D12-16	ELBOW	12 3		
13	4150-1-2	.VALVE VENT (S/N 30615 THRU SUB)	2		
14	205-060-640-001	PLATE	3		
15	MS29513-216	.PACKING, PREFORMED	3		
16	205-060-641-003	.BRACKET ASSY, LH	1		
16A	205-060-641-004	.BRACKET ASSY, RH	1		
17	205-061-629-001	.BRACKET ASSY	1		
18	NAS679A3	.NUT (REPLACED BY MS21042L3)	4		
18	MS21042L3	.NUT (REPLACES NAS679A3)	4		
19	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	4		
19	AN960JD10L	.WASHER (REPLACES AN960PD10L)	4		
20	MS27039-1-08	SCREW	4		
21 22	212-061-630-001 AN4-5A	BRACKET	1		
23	AN960PD416L	.BOLT	7		
23	AN960JD416L	.WASHER (REPLACES AN9600D416L)	7		
24	205-060-668-001	GROUND STRIP (S/N 30504 THRU 31294) (REPLACED BY	1		
24	120-055-2-3	BONDING STRIP (REPLACES 205-060-668-001)	1		
25	MS29513-243	.PACKING, PREFORMED	1		
	· · · · · · · · · · · · · · · · · · ·				

BHT-212-IPB

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	000
		FIGURE: 28-3. Fuel system installation (Cont'd)			
26	416-564	.FILLER CAP	1		
27	416-414	PACKING	1		
28	NAS679A4	.NUT (REPLACED BY MS21042L4)	8		l
28	MS21042L4	.NUT (REPLACES NAS679A4)	8		
29	AN960-416L	.WASHER	8		
30	MS27039-4-13 20-032-2	SCREW	8		
32	AN924-10D	.BRACKET	2		İ
32	AN960PD1416	.WASHER (REPLACED BY AN960JD1416)	2		
33	AN960JD1416	WASHER (REPLACES AN960PD1416)	2		
34	AN833-10D	.ELBOW	2		
35	NAS679A3	.NUT (REPLACED BY MS21042L3)	2		
35	MS21042L3	NUT (REPLACES NAS679A3)	2	į	
36	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2		
36	AN960JD10L	.WASHER (REPLACES AN960PD10L)	2		
37	AN3-4A	BOLT	1		
38	AN3-7A	BOLT	1		
39	NAS43DD3-28	SPACER	1		
40	MS21919DG13	.CLAMP (REPLACED BY MS21919WDG13)	1		
40	MS21919WDG13	.CLAMP (REPLACES MS21919DG13)	1		
41	20-032-1	.BRACKET	1		
42	120-067B25	.SLEEVE	1		.
43	70-010K000C185	.HOSE ASSY (REPLACED BY 70-010K000C186 AND	1		
43	70-010K000C186	.HOSE ASSY (REPLACES 70-010K000C185) (REPLACED BY . 70-061K000C186A)	1		
43	70-061K000C186A	.HOSE ASSY (REPLACES 70-010K000C185 AND	1		
44	NAS679A3	.NUT (REPLACED BY MS21042L3)	1		.
44	MS21042L3	.NUT (REPLACES NAS679A3)	1		.
45	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	Ì	
45	AN960JD10L	.WASHER (REPLACES AN960PD10L)	1		.
46	AN520-10R16	.SCREW (REPLACED BY MS35207-267)	1		.
46	MS35207-267	.SCREW (REPLACES AN520-10R16)	1		, 1
47	NAS43DD3-28	.SPACER	1		,
48	MS21919WDG13	.CLAMP	1		
49	NAS679A3	.NUT (REPLACED BY MS21042L3)	2		,
49	MS21042L3	NUT (REPLACES NAS679A3)	2		,
50	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2		
50	AN960JD10L	.WASHER (REPLACES AN960PD10L)	2		
51	AN3-4A	BOLT (S/N 31295 THRU SUB)	1		
52 53	AN3-7A	BOLT	1		
53	NAS43DD3-28 MS21919WDG13	.CLAMP	1		
55	AN743-12	BRACKET	1 1		
56	70-010K000C252	HOSE ASSY (REPLACED BY 70-061K000C252A,	1		
"	,5 01010000232	70-010K000C254 AND 70-061K000C254A)	1		
56	70-061K000C252A	.HOSE ASSY (REPLACES 70-010K000C252) (REPLACED BY .	1		
"		70-010K000C254 AND 70-061K000C254A)	-		
		The second secon			l

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A > A - L	υoc
		FIGURE: 28-3. Fuel system installation (Cont'd)			
56	70-010K000C254	.HOSE ASSY (REPLACES 70-010K000C252 AND	1		
56	70-061K000C254A	.HOSE ASSY (REPLACES 70-010K000C254,	1		
57	AN929-8	.CAP	1		
57A	AN929-8	.CAP (POST BHT-212-SI-86)	1		
58	110-144-8A	.SEAL (S/N 30730 THRU SUB)	1		
58A	MS29529-12	.VALVE (POST BHT-212-SI-86)	1		
58B	MS29512-12	.PACKING, PREFORMED (POST BHT-212-SI-86)	1		
59	AN4-5A	BOLT	12		
60	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)			
60	AN960JD416L	.WASHER (REPLACES AN960PD416L)	1		
61	MS29513-236	.PACKING, PREFORMED (S/N 30504 THRU 30729)	2		
61	MS29513-124	.PACKING, PREFORMED (S/N 30730 THRU SUB)	2		
62 63	4563-125 MS29513-220	CLAMP ASSY (S/N 30504 THRU 30729)	2		
64	MS29513-220 NAS679A4	.PACKING, PREFORMED (S/N 30504 THRU 30729)	8		
64	MS21042L4	.NUT (REPLACES NAS679A4)	8		
65	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	8		
65	AN960JD416L	.WASHER (REPLACES AN960PD416L)	8		
66	AN4-6A	BOLT	8		
67	MS29513-223	PACKING, PREFORMED	2		
68	AN4-4A	BOLT	4		
69	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	4		İ
69	AN960JD416L	.WASHER (REPLACES AN960PD416L)	4		
70	MS29513-216	.PACKING, PREFORMED	1		
71	205-061-631-011	.CROSSOVER ASSY (S/N 30504 THRU 30524) (REPLACED BY 205-061-631-013)	1		
71	205-061-631-013	.CROSSOVER ASSY (REPLACES 205-061-631-011)	1		
72	110-144-12A	.SEAL (S/N 30730 THRU 31294)	1		
73	300289-1	CROSSOVER ASSY (PRE BHT-212-SI-86) (S/N 30504 THRU 30729)	1		
73	300184-1	.CROSSOVER ASSY (POST BHT-212-SI-86) (S/N 30504 THRU 30729)	1		
73	300289-7	.CROSSOVER ASSY (PRE BHT-212-SI-86) (S/N 30730 THRU SUB)	1		
73	300184-9	.CROSSOVER ASSY (POST BHT-212-SI-86) (S/N 30730 THRU SUB)	1		
74	300184-3	.CROSSOVER ASSY (S/N 30504 THRU 30729)	1		
74	300184-11	.CROSSOVER ASSY (S/N 30730 THRU SUB)	1		
75	AN4-4A	.BOLT	8		
76	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	8		
76	AN960JD416L	.WASHER (REPLACES AN960PD416L)	8		1
77	MS29513-224	.PACKING, PREFORMED	2		l
78	205-061-631-005	CROSSOVER ASSY	1		
79	205-061-631-007	CROSSOVER ASSY	1		
80 81	AN4-4A AN960PD10T	.BOLT	4		
81	AN960PD10L AN960JD10L	.WASHER (REPLACES AN960JDIOL)	4		
82	MS29513-216	. PACKING, PREFORMED	1		
	111111111111111111111111111111111111111	The state of the s			

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A L	υοc
		FIGURE: 28-3. Fuel system installation (Cont'd)			
83 84	205-061-631-009 AN4-4A	.CROSSOVER ASSY	1 20		
85	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	20		
85	AN960JD416L	.WASHER (REPLACES AN960PD416L)	20		
86	NAS679A3	.NUT (REPLACED BY MS21042L3)	8		
86	MS21042L3	.NUT (REPLACES NAS679A3)	8		
87	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	8		
87	AN960JD10L	.WASHER (REPLACES AN960PD10L)	8		
88	800-515-100S	.LOCK-O-SEAL (REPLACED BY 120-068-13)	8		
88	120-068-13	.SEAL (REPLACES 800-515-100S)	8		
89	AN3-4A	.BOLT	5		
90	AN3H4	BOLT	3		
91	204-060-667-003	.PACKING, PREFORMED	1		
92	205-061-684-001	.NUT	1		
93 94	AN814-8D	PLUG	1		
94 95	MS29512-08 1-892-1	.PACKING, PREFORMED	1		
95 95	1-892-1 30-060-1A	.CONNECTOR (REPLACED BY 30-060-1A)	1		
96	1-890-1	CONNECTOR (REPLACED BY 30-060-1F)	1		
96	30-060-1F	CONNECTOR (REPLACES 1-890-1)	1		
97	205-061-642-009	DOOR ASSY	1		
98	205-061-684-001	.NUT	2		
99	MS29512-08	.PACKING, PREFORMED	2		
100	AN893-3D	BUSHING	2		
101	MS3367-1-9	.STRAP	2		
102	NAS679A08	.NUT (REPLACED BY MS21042L08)	4		
102	MS21042L08	.NUT (REPLACES NAS679A08)	4		
103	MS35206-242	.SCREW	4		
104	204-060-628-001	.CLIP (REPLACED BY 30-261-1)	2		
104	30-261-1	.CLIP (REPLACES 204-060-628-001)	2		
105	391046-200	.PROBE	1		
106	205-061-644-003	.BRACKET ASSY	1		
107	205-061-644-001	BRACKET ASSY	1		
108	AN4-13A	BOLT	8		
109 109	AN960PD416L AN960JD416L	.WASHER (REPLACED BY AN960JD416L)	8		
110	MS29513-240	.WASHER (REPLACES AN960PD416L)	8		
111	205-060-605-011	FUEL CELL, LH (S/N 30504 THRU 31311, 35001 THRU	1		
	210 000 000 011	35048) (REPLACED BY 212-360-602-101)	7		
111	212-360-602-101	.FUEL CELL, LH (REPLACES 205-060-605-011)	1		
112	205-060-605-005	.FUEL CELL, CENTER (S/N 30504 THRU 31311, 35001	1		
		THRU 35048) (REPLACED BY 212-360-603-101)	-		
112	212-360-603-101	.FUEL CELL, CENTER (REPLACES 205-060-605-005)	1		
113	205-060-605-013	.FUEL CELL, RH (S/N 30504 THRU 31311, 35001 THRU	1		
		35048) (REPLACED BY 212-360-602-102)			
113	212-360-602-102	.FUEL CELL, RH (REPLACES 205-060-605-013)	1		




Figure 28-4. Fuel system installation

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 28-4. Fuel System Installation			
	212-060-600-003	FUEL SYSTEM INSTL (S/N 30504 THRU 30614) (SEE FIG. 1, 2, 3, 5 FOR BALANCE			
	212-060-600-005	OF BREAKDOWN)	REF	NP	
	212-060-600-009	OF BREAKDOWN)	REF	NP	
	212-060-600-101	OF BREAKDOWN)	REF	NP	
	212-060-600-103	FOR BALANCE OF BREAKDOWN)	REF	NP	
		OF BREAKDOWN)	REF	NP	
1	MS27039-1-16	.SCREW	4	SP	
2	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	4	P	
2	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
_		(REPLACED BY NAS1149D0332J)	4	P	
2	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	4	SP	
3 4	MS29513-214	.PACKING, PREFORMED	1 2	SP	
5	AN3-5A AN960PD10L	.BOLT	2	SP P	
5	AN960JD10L	.WASHER (REPLACED BY AN9600DIOL) (REPLACED BY NAS1149D0332J)	2	P	
5	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	2	SP	
6	MS29513-120	.PACKING, PREFORMED	1	SP	
7	212-060-605-001	.CROSSOVER ASSY	1	SP	
8	MS35266-63	.SCREW	4	SP	
9 9	AN960PD10L AN960JD10L	.WASHER (REPLACED BY AN960JD10L)	4	P	
		(REPLACED BY NAS1149D0332J)	4	P	
9	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	4	SP	
10	300288-1	.CROSSOVER ASSY (REPLACED BY 300288-501)	1	NP	
10	300288-501	.CROSSOVER ASSY (REPLACES 300288-1)	1	SP	
11	NAS679A3	NUT (REPLACED BY MS21042L3)	4	P	
11	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	4	SP	
12 12	AN960PD10L AN960JD10L	.WASHER (REPLACED BY AN960JD10L) .WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY NAS1149D0332J)	4	P	
12	NAS1149D0332J	(REPLACED BY NASI149D0332J)	4	P SP	
13	MS27039-1-34	SCREW	4	SP	
14	AV24B1119B	.VALVE	1	SP	
		(ALTERNATE PART)			
14 15	233575 MS29513-123	PACKING, PREFORMED (USBL ON AV24B1119B)	1 2	NP SP	
15 16	MS29513-123 M25988/1-122	PACKING, PREFORMED (USBL ON AV24BILLIPB)	2	SP	
17	300286-1	CROSSOVER ASSY	1	SP	
18	AN4-4A	BOLT	2	SP	
19	AN960PD416	.WASHER (REPLACED BY AN960JD416)	2	NP	
		,			

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 28-4. Fuel System Installation (Cont'd)			
19	AN960JD416	.WASHER, FLAT (REPLACES AN960PD416)			
1.0		(REPLACED BY NAS1149D0463J)	2	P	
19	NAS1149D0463J	.WASHER (REPLACES AN960JD416)	2	SP	
20	AN924-6D	NUT	1	SP P	
21 21	AN960PD916L AN960JD916L	.WASHER (REPLACED BY AN960JD916L)		Р	
21	AN9600D916L	(REPLACED BY NAS1149D0916J)	1	P	
21	NAS1149D0916J	.WASHER (REPLACES AN960JD916L)	1	SP	
22	205-061-637-001	FITTING, FUEL TANK VENT	1	SP	
23	MS29513-213	.PACKING, PREFORMED	1	SP	
24	AN737TW46	.CLAMP	2	SP	
25	NAS679A3	.NUT (REPLACED BY MS21042L3)	3	P	
25	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	3	SP	
26	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	3	P	
26	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
		(REPLACED BY NAS1149D0332J)	3	P	
26	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	3	SP	
27	MS27039-1-10	.SCREW	3	SP	
28	AN814-4D	.PLUG (REPLACED BY AN814-4W)	1	P	
28	AN814-4W	.PLUG (REPLACES AN814-4D)	1	SP	
29	MS29512-04	.PACKING, PREFORMED	1	SP	
30	MS35489-23	.GROMMET	1	SP	
31	AV16E1217C	.VALVE(ALTERNATE PARTS)	1	P	
31	P164-395	(ALIERNATE PARTS)	1		
31	P191-395	VALVE	1	SP	
32	212-060-670-001	.TUBE ASSY	1	SP	
33	205-062-601-001	.HOSE	1	SP	
34	110-144-8A	.SEAL (USBL ON 212-060-600-009 AND -101)	2	SP	
35	AN4H35A	BOLT	1	SP	
36	AN960PD416	.WASHER (REPLACED BY AN960JD416)	1	NP	
36	AN960JD416	.WASHER, FLAT (REPLACES AN960PD416)			
		(REPLACED BY NAS1149D0463J)	1	P	
36	NAS1149D0463J	.WASHER (REPLACES AN960JD416)	1	SP	
37	MS29513-010	.PACKING, PREFORMED	1	SP	
38	MS29528-4	.VALVE	1	SP	
39	MS29512-04	.PACKING, PREFORMED	1	SP	
40	AN924-4D	.NUT	1	SP	
41	AN807-4D	.FITTING	1	SP	
42	MS29512-04	.PACKING, PREFORMED	1	SP	
43	AN4-6A	.BOLT	12	SP	
44	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	12	NP	
44	AN960JD416L	.WASHER (REPLACES AN960PD416L)		_	
		(REPLACED BY NAS1149D0416J)	12	P	
44	NAS1149D0416J	.WASHER (REPLACES AN960JD416L)	12	SP	
45	MS25083-1BC10	.JUMPER ASSY (REPLACED BY MS25083-7BC10)	1	NP	
45	MS25083-7BC10	JUMPER ASSY (REPLACES MS25083-1BC10)	1		
46	205-060-606-003	.PUMP ASSY (S/N 30504 THRU 31311, 35001 THRU	-	a n	
10	206 062 627 121	35034) (REPLACED BY 206-062-687-101)	1	SP	
46	206-062-687-101	.PUMP ASSY (REPLACES 205-060-606-003)	1	SP	

BUY BELL PARTS - BUY BELL VALUE


(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 28-4. Fuel System Installation (Cont'd)			
47	2C27-3	CARTRIDGE (USBL ON 206-062-687-101)	1	SP	
48	MS24694S46	.SCREW (REPLACED BY MS24694-S46)	2	P	
48	MS24694-S46	.SCREW (REPLACES MS24694S46)	2	SP	
49	475D12NN48LT32	.FLANGE (S/N 30504 THRU 30614)			
		(REPLACED BY 206-062-654-001)	1	NP	
49	206-062-654-001	.FLANGE (REPLACES 475D12NN48LT32)	1	SP	
50	204-060-604-001	.GASKET (REPLACED BY 60-011-1 AND 60-011-5)	2	NP	
50	60-011-1	.GASKET (REPLACES 204-060-604-001)	2	NTD	
50	60-011-5	(REPLACED BY 60-011-5)	2	NP	
		AND 60-011-1)	2	SP	
51	NAS679A3	.NUT (REPLACED BY MS21042L3)	2	P	
51	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP	
52	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2	P	
52	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
		(REPLACED BY NAS1149D0332J)	2	P	
52	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	2	SP	
53	MS24694S52	.SCREW (REPLACED BY MS24694-S52)	2	P	
53	MS24694-S52	.SCREW (REPLACES MS24694S52)	2	SP	
54	205-060-645-001	RETAINER	1	SP	
55	120-068-13	SEAL	1	SP	
56	205-062-613-001	NUT	1	SP	
57	AF11C9	.VALVE (REPLACED BY A280-2)	1	NP	
57	A280-2	.VALVE (REPLACES AF11C9)	1 1	SP	
58	MS29513-020	.PACKING, PREFORMED	1	SP	
59 60	NAS509-12 AN960PD1216L	.NUT	1	SP P	
60	AN960JD1216L	.WASHER (REPLACES AN9600D1216L)	1	Р	
00	ANGOODIZIOL	(REPLACED BY NAS1149D1216J)	1	P	
60	NAS1149D1216J	.WASHER (REPLACES AN960JD1216L)	1	SP	
61	204-060-654-007	SWITCH	1	SP	
62	MS29512-06	.PACKING, PREFORMED	1	SP	
63	212-060-602-001	SUPPORT	1	SP	
64	MS29512-08	.PACKING, PREFORMED	1	SP	
65	NAS509-9	NUT	1	SP	
66	AN960PD916L	.WASHER (REPLACED BY AN960JD916L)	1	P	
66	AN960JD916L	.WASHER (REPLACES AN960PD916L)			
		(REPLACED BY NAS1149D0916J)	1	P	
66	NAS1149D0916J	.WASHER (REPLACES AN960JD916L)	1	SP	
67	MS29513-018	.PACKING, PREFORMED	1	SP	
68	AN4-4A	.BOLT	12	SP	
69	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	12	NP	
69	AN960JD416L	.WASHER (REPLACES AN960PD416L)			
		(REPLACED BY NAS1149D0416J)	12	P	
69	NAS1149D0416J	.WASHER (REPLACES AN960JD416L)	12	SP	
70	AN924-16D	NUT	1	SP	
71	AN960PD2116L	.WASHER (REPLACED BY AN960JD2116L)	1	P	
71	AN960JD2116L	.WASHER (REPLACES AN960PD2116L)	_	_	
		(REPLACED BY NAS1149D2116J)	1	P	
71	NAS1149D2116J	.WASHER (REPLACES AN960JD2116L)	1	SP	

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 28-4. Fuel System Installation (Cont'd)			
72	375C16	.VALVE (REPLACED BY 375C-16)	1	NP	
72	375C-16	.VALVE (REPLACES 375C16)	1	SP	
73	MS29512-16	PACKING, PREFORMED	1	SP	
73A	MS29512-16	.PACKING, PREFORMED	1	SP	
74	1-890-1	CONNECTOR (REPLACED BY 30-060-1F)	1	NP	
74 74A	30-060-1F 1-713-1	CONNECTOR (REPLACES 1-890-1)	1	SP NP	
74A 74A	30-067-1F	ADAPTER (REPLACES 1-713-1)	1	SP	
74A 75	1-892-1	CONNECTOR (REPLACED BY 30-060-1A)	1	NP	
75 75	30-060-1A	CONNECTOR (REPLACES 1-892-1)	1	SP	
75A	5193-1	ADAPTER, TEE (REPLACED BY 30-067-1A)	1	NP	
75A	30-067-1A	ADAPTER (REPLACES 5193-1)	1	SP	
76	212-060-601-001	SUMP ASSY	1	SP	
77	NAS679A06	NUT (REPLACED BY MS21042L06)	5	P	
77	MS21042L06	NUT (REPLACES NAS679A06)	5	SP	
78	AN961-6	WASHER (REPLACED BY AN961-6T)	5	P	
78	AN961-6T	WASHER (REPLACES AN961-6)	5	SP	
79	MS27212-1-5	TERMINAL BOARD	1	SP	
80	MS29513-270	.PACKING, PREFORMED	1	SP	
81	70-010J000V110	.HOSE ASSY (REPLACED BY 70-061J000V110A)	1	NP	
81	70-061J000V110A	.HOSE ASSY (REPLACES 70-010J000V110)	1	SP	
82	S2490	.FITTING (S/N 30504 THRU 30614)			
		(REPLACED BY 50-040-3)	1	NP	
82	50-040-3	FITTING (REPLACES S2490)	1	SP	
83	AN960PD716	.WASHER, FLAT (REPLACED BY AN960JD716)	1	P	
83	AN960JD716	.WASHER (REPLACES AN960PD716) (REPLACED BY NAS1149D0763J)	1	Б	
83	NAS1149D0763J	WASHER (REPLACES AN960JD716)	1	P SP	
84	205-060-647-001	RETAINER	1	SP	
85	MS29513-113	.PACKING, PREFORMED	1	SP	
86	70-010H000A125	HOSE ASSY (REPLACED BY 70-061H000A125A)	1	NP	
86	70-061H000A125A	.HOSE ASSY (REPLACES 70-010H000A125)	1	SP	
87	488-6D1 1-4	.VALVE	1		
		(ALTERNATE PART)			
87	869A6TT2	.VALVE	1	NP	
88	205-061-635-003	.FLOW SWITCH	1	NP	
88	205-061-635-005	.FLOW SWITCH	1	SP	
89	AN815-6D	.UNION	1	SP	
90	MS29512-06	.PACKING, PREFORMED	2	SP	
91	70-010H000V065	.HOSE ASSY (S/N 30504 THRU 31311, 35001 THRU			
		35080) (REPLACED BY 70-061H000V066A)	1	NP	
91	70-061H000V066A	.HOSE ASSY (REPLACES 70-010H000V065)	1	SP	
92	AN924-6D	.NUT	1	SP	
93	AN832-6D	UNION	1	SP	
94	NAS679A4	.NUT (REPLACED BY MS21042L4)	2	P	
94	MS21042L4	NUT (REPLACES NAS679A4)	2	SP	
95	AN960PD416	.WASHER (REPLACED BY AN960JD416)	2	NP	
95	AN960JD416	.WASHER, FLAT (REPLACES AN960PD416) (REPLACED BY NAS1149D0463J)	2	T.	
		(KETHACED BI NASII43DU403U)	∠	P	

Figure 28-4. Fuel System Installation (Cont'd) Figure 28-4. Fuel System Installati	(1)	(2)	(3)	(4)	(5) A	(6)
NAS1149D0463J WASHER (REPLACES AN960JD416) 2 SP		PART NUMBER	ITEM NAME	PER	V A I	0
96 AN4-6A			Figure 28-4. Fuel System Installation (Cont'd)			
AN960D416	95	NAS1149D0463J	.WASHER (REPLACES AN960JD416)	_	SP	
AN960JD416	96	AN4-6A		_	SP	1
REPLACED BY NAS1149D0463J		AN960PD416	, , , , , , , , , , , , , , , , , , , ,	2	NP	1
97 NAS1149D0463J WASHER (REPLACES AN960JD416) 2 NP 98 AN960JD416L WASHER (REPLACED BY AN960JD416L) 2 NP 98 AN960JD416L WASHER (REPLACES AN960D416L) 2 P 98 NAS1149D0416J WASHER (REPLACES AN960D416L) 2 SP 99 NAS679A4 NDT (REPLACED BY MS21042L4) 1 P 100 AN960JD416 WASHER (REPLACES AN960JD416L) 1 NP 100 AN960JD416 WASHER (REPLACES DE AN960JD416) 1 NP 101 AN960JD416 WASHER (REPLACED BY AN960JD416) 1 NP 102 AN960JD416 WASHER (REPLACED BY AN960JD416) 1 NP 103 AN960JD416 WASHER (REPLACED BY AN960JD416) 1 NP 104 AN960JD416 WASHER (REPLACES AN960JD416) 1 NP 105 AN3-104 BOLT 1 SP 106 AN3-149D0463J WASHER (REPLACES AN960JD416) 1 SP 107 AN360JD416 WASHER (REPLACES AN960JD416) 1 SP 108 AN3-5A BOLT 1 SP 109 MC412-6D0280 HOSE ASSY 1 SP 100 466121-6D0280 HOSE ASSY 1 SP 101 AN3-5A BOLT 1 SP 102 205-061-666-001 VALVE 1 SP 103 205-061-666-001 WASHER (REPLACED BY AN960JD10L) 2 P 104 156R536-6D0280 HOSE ASSY 1 SP 105 AN3-10A BOLT 1 SP 106 AN3-16A BOLT 1 SP 107 AN960JD10L WASHER (REPLACED BY AN960JD10L) 2 P 108 AN345D3-40 SPACER (REPLACED BY AN960JD10L) 2 P 109 AN735D19 WASHER (REPLACED BY MS43DD3-40N) 2 P 108 NAS43DD3-40 SPACER (REPLACED BY NAS43DD3-40N) 2 P 108 NAS43DD3-40 SPACER (REPLACED BY MS21919WDF13) 1 SP 109 MS21919WDF13 CLAMP (REPLACED BY MS21919WDF13) 1 SP 100 MS21919WDF13 CLAMP (REPLACED BY MS21919WDF13) 1 P 110 MS21919WDF13 CLAMP (REPLACED BY NAS1149D0332J) 1 P 111 AN3-3A BOLT 1 SP 112 AN960P10L WASHER, FLAT (REPLACED BY AN960D10L) 1 SP 113 MS21919WDF13 CLAMP (REPLACED BY NAS1149D0332J) 1 P 114 AN960P10L WASHER, FLAT (REPLACED BY NAS1149D0332J) 1 P 115 AN3-3A BOLT 1 SP 116 AN924-6D NUT	97	AN960JD416	.WASHER, FLAT (REPLACES AN960PD416)			1
98 AN960PD416L			,		_	1
AN960JD416L	_		·	_		
REPLACED BY NAS1149D0416J 2 P			,	2	NP	
98 NAS149D0416J .WASHER (REPLACED BY MS21042L4) 1 p 99 NAS679A4 .NUT (REPLACED BY MS21042L4) 1 p 100 AN960PD416 .WASHER (REPLACED BY AN960JD416) 1 NP 100 AN960PD416 .WASHER (REPLACED BY AN960JD416) 1 NP 100 AN960J0416 .WASHER (REPLACES AN960JD416) 1 NP 100 ANS1149D0463J .WASHER (REPLACES AN960JD416) 1 SP 101 AN4-5A .BOLT 1 SP 102 205-061-643-003 .PLATE 2 SP 103 205-061-643-003 .PLATE 2 SP 104 466121-600280 .HOSE ASSY 1 SP 104 1568536-600280 .HOSE ASSY 1 SP 105 AN3-10A .BOLT 1 SP 107 AN960PD10L .WASHER (REPLACED BY AN960JD10L) 2 P 107 AN960PD10L .WASHER (REPLACED BY ANS1149D0332J) 2 P 108 NAS43DD3-40N .SPACER (REPLACED BY ANS10JD10L) 2	98	AN960JD416L	, ,		_	1
99 NAS679A4 .NUT (REPLACED BY MS21042L4) .1 p 99 MS21042L4 .NUT (REPLACES NAS679A4) .1 SP 100 AN960D416 .WASHER (REPLACES NAS679A4) .1 SP 100 AN960D416 .WASHER, FLAT (REPLACES AN960D416) .1 NP 100 AN960D416 .WASHER, FLAT (REPLACES AN960D416) .1 SP 101 NAS1149D0463J .WASHER, FLAT (REPLACES AN960D416) .1 SP 102 205-061-643-003 .PLATE .1 SP 103 205-060-666-001 .VALVE .1 SP 104 646121-6D0280 .HOSE ASSY .1 SP 105 AN3-10A .BOLT .1 SP 106 AN3-10A .BOLT .1 SP 107 AN960D10L .WASHER (REPLACED BY AN960J010L) .2 P 108 NAS1149D0332J .WASHER (REPLACES AN960J010L) .2 SP 108 NAS43DD3-40 .SPACER (REPLACES AN960J010L) .2 SP 109 AN735D19 .CLAMP (REPLACED BY MS43DD3-40N) .2 SP 100 MS21919DF13 .CLAMP (REPLACED BY MS43DD3-40) .2 SP 110 MS21919DF13 .CLAMP (REPLACED BY MS2191DWDF13) .1 SP 111 AN3-3A .BOLT .1 SP 112 AN960D10L .WASHER, FLAT (REPLACES AN960J010L) .2 SP 113 MS21919DF13 .CLAMP (REPLACED BY MS43DD3-40) .2 SP 114 AN3-3A .BOLT .1 SP 115 AN3-3A .BOLT .1 SP 116 MS2191DF13 .CLAMP (REPLACED BY MS43DD3-40) .2 SP 117 AN960D10L .WASHER, FLAT (REPLACES AN960J010L) .1 SP 118 AN3-3A .BOLT .1 SP 119 AN960D10L .WASHER, FLAT (REPLACES MS2191DWDF13) .1 SP 110 MS21919DF13 .CLAMP (REPLACED BY MS2191DWDF13) .1 SP 111 AN3-3A .BOLT .1 SP 112 AN960D10L .WASHER (REPLACED BY MS2191DWDF13) .1 SP 113 MS2191DF13 .CLAMP (REPLACED BY MS2191DWDF13) .1 SP 114 AN3-3A .BOLT .1 SP 115 AN3-3A .BOLT .1 SP 116 AN3-3A .BOLT .1 SP 117 MS2191DF13 .CLAMP (REPLACED BY MS2191DWDF13) .1 SP 118 MS2191DF13 .CLAMP (REPLACED BY MS2191DWDF13) .1 SP 119 AN960D10L .WASHER (REPLACED BY MS2191DWDF13) .1 SP 110 MS2191DF13 .CLAMP (REPLACED BY MS2191DWDF13) .1 SP 111 AN3-3A .BOLT .1 SP 112 AN960D10L .WASHER (REPLACED BY MS2191DWDF13) .1 SP 113 MS2191DF13 .CLAMP (REPLACES AN960D10L) .1 SP 114 AN3-3A .BOLT .1 SP 115 AN3-3A .BOLT .1 SP 116 AN3-3A .BOLT .1 SP 117 MS2191DF13 .CLAMP (REPLACED BY MS2191DWDF13) .1 SP 118 AN3-3A .BOLT .1 SP 119 AN960D10L .WASHER (REPLACED BY MS2191DWDF3) .1 SP 111 AN3-3A .BOLT .1 SP 112 AN960D10L .MASHER (REPLACED BY MS2191DWDF3) .1 SP 115 AN3-3A .BOLT .	0.0		,		_	1
MS2104214 NUT (REPLACES NAS679A4) 1 SP			·	_		
100			,	_	_	
NASHER, FLAT (REPLACES AN960PD416)			,	_		
(REPLACED BY NAS1149D0463J) 1 P 100 NAS1149D0463J WASHER (REPLACES AN960JD416) 1 SP 101 AN4-5A BOLT 1 SP 102 205-061-643-003 PLATE 2 SP 103 205-060-666-001 VALVE 1 SP 104 646121-6D0280 HOSE ASSY 1 T 105 AN3-10A BOLT 1 SP 106 AN3-16A BOLT 1 SP 107 AN960PD10L WASHER (REPLACED BY AN960JD10L) 2 P 107 AN960JD10L WASHER, FLAT (REPLACES AN960JD10L) 2 P 107 AN960JD10L WASHER, FLAT (REPLACES AN960JD10L) 2 SP 108 NAS43DD3-40 SPACER (REPLACED BY NAS149D0332J) 2 P 108 NAS43DD3-40N SPACER (REPLACED BY NAS43DD3-40N) 2 P 109 AN735D19 CLAMP 1 SP 100 MS21919WDF13 CLAMP (REPLACES MS21919WDF13) 1 SP 110 MS21919WDF13			,	1	NP	
100	100	AN9600D416		1	n.	
101	100	NAC1140D0462T	,	_	_	1
102			·	_		
103	-					
104	-			_		
CALTERNATE PART 1 SP				_	SP	
1	104	040121-000280				1
105	104	156R536-6D0280	,	1	SD	
106				_		
107 AN960PD10L				_		
107				_		
(REPLACED BY NAS1149D0332J) 2 P 107 NAS1149D0332J .WASHER, FLAT (REPLACES AN960JD10L) 2 SP 108 NAS43DD3-40 .SPACER (REPLACED BY NAS43DD3-40N) 2 P 108 NAS43DD3-40N .SPACER (REPLACES NAS43DD3-40N) 2 SP 109 AN735D19 .CLAMP 1 SP 110 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 110 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 111 AN3-3A .BOLT 1 SP 112 AN960JD10L .WASHER (REPLACED BY AN960JD10L) 1 P 112 AN960JD10L .WASHER, FLAT (REPLACES AN960PD10L) 1 P 113 MS21919DF13 .CLAMP (REPLACED BY NAS1149D0332J) 1 P 114 NS2149D0332J .WASHER, FLAT (REPLACES AN960JD10L) 1 SP 113 MS21919WDF13 .CLAMP (REPLACED BY MS21919WDF13) 1 SP 114 70-010K000V336 .CLAMP (REPLACES MS21919DF13) 1 SP 114 70-061K000V334A .HOSE ASSY (S/N 30504 THRU 30614) 1 NP 115 AN833-6D .ELBOW 1 SP 116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT			,	_	_	1
108 NAS43DD3-40 .SPACER (REPLACED BY NAS43DD3-40N) 2 P 108 NAS43DD3-40N .SPACER (REPLACES NAS43DD3-40) 2 SP 109 AN735D19 .CLAMP 1 SP 110 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 110 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 111 AN3-3A .BOLT 1 SP 112 AN960PD10L .WASHER (REPLACED BY AN960JD10L) 1 P 112 AN960JD10L .WASHER, FLAT (REPLACES AN960PD10L) 1 P 112 NAS1149D0332J .WASHER, FLAT (REPLACES AN960JD10L) 1 SP 113 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 113 MS21919WDF13 .CLAMP (REPLACED BY MS21919DF13) 1 P 114 70-010K000V336 .HOSE ASSY (S/N 30504 THRU 30614) R R 12 AN933-6D .ELBOW 1 SP 115 AN933-6D .ELBOW 1 SP 116 A				2	P	
108 NAS43DD3-40N .SPACER (REPLACES NAS43DD3-40) 2 SP 109 AN735D19 .CLAMP 1 SP 110 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 110 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 111 AN3-3A .BOLT 1 SP 112 AN960PD10L .WASHER (REPLACED BY AN960JD10L) 1 P 112 AN960JD10L .WASHER, FLAT (REPLACES AN960JD10L) 1 P 112 NAS1149D0332J .WASHER, FLAT (REPLACES AN960JD10L) 1 SP 113 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 113 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 114 70-010K000V336 .HOSE ASSY (S/N 30504 THRU 30614) REPLACED BY 70-061K000V334A 1 NP 115 AN833-6D .ELBOW 1 SP 116 AN924-6D	107	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	2	SP	1
109 AN735D19 .CLAMP	108	NAS43DD3-40	.SPACER (REPLACED BY NAS43DD3-40N)	2	P	
110 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P	108	NAS43DD3-40N	.SPACER (REPLACES NAS43DD3-40)	2	SP	
110 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 111 AN3-3A .BOLT 1 SP 112 AN960PD10L .WASHER (REPLACED BY AN960JD10L) 1 P 112 AN960JD10L .WASHER, FLAT (REPLACES AN960PD10L) 1 P 112 NAS1149D0332J .WASHER, FLAT (REPLACES AN960JD10L) 1 SP 113 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 113 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 114 70-010K000V336 .HOSE ASSY (S/N 30504 THRU 30614) REPLACED BY 70-061K000V334A) 1 NP 114 70-061K000V334A .HOSE ASSY (REPLACES 70-010K000V336) 1 SP 115 AN833-6D .ELBOW 1 SP 116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 AN960-10 .WASHER (REPLACES AN960-10) 2 SP	109	AN735D19	.CLAMP	1	SP	
111 AN3-3A .BOLT 1 SP 112 AN960PD10L .WASHER (REPLACED BY AN960JD10L) 1 P 112 AN960JD10L .WASHER, FLAT (REPLACES AN960PD10L) 1 P 112 NAS1149D0332J .WASHER, FLAT (REPLACES AN960JD10L) 1 SP 113 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 113 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 114 70-010K000V336 .HOSE ASSY (S/N 30504 THRU 30614) REPLACED BY 70-061K000V334A 1 NP 114 70-061K000V334A .HOSE ASSY (REPLACES 70-010K000V336) 1 SP 115 AN833-6D .ELBOW 1 SP 116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 AN960-10 .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP	110	MS21919DF13	.CLAMP (REPLACED BY MS21919WDF13)	1	P	
112	110	MS21919WDF13	.CLAMP (REPLACES MS21919DF13)	1	SP	1
112 AN960JD10L .WASHER, FLAT (REPLACES AN960PD10L) 1 P 112 NAS1149D0332J .WASHER, FLAT (REPLACES AN960JD10L) 1 SP 113 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 113 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 114 70-010K000V336 .HOSE ASSY (S/N 30504 THRU 30614) 1 NP 114 70-061K000V334A .HOSE ASSY (REPLACES 70-010K000V334A) 1 NP 115 AN833-6D .ELBOW 1 SP 116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 AN960-10 .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP	111	AN3-3A		1	SP	ł
REPLACED BY NAS1149D0332J				1	P	
112 NAS1149D0332J .WASHER, FLAT (REPLACES AN960JD10L) 1 SP 113 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 113 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 114 70-010K000V336 .HOSE ASSY (S/N 30504 THRU 30614) 1 NP 114 70-061K000V334A .HOSE ASSY (REPLACES 70-010K000V334A) 1 SP 115 AN833-6D .ELBOW 1 SP 116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 NAS1149F0363P .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP	112	AN960JD10L				1
113 MS21919DF13 .CLAMP (REPLACED BY MS21919WDF13) 1 P 113 MS21919WDF13 .CLAMP (REPLACES MS21919DF13) 1 SP 114 70-010K000V336 .HOSE ASSY (S/N 30504 THRU 30614) 1 NP 114 70-061K000V334A .HOSE ASSY (REPLACES 70-010K000V334A) 1 SP 115 AN833-6D .ELBOW 1 SP 116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 AN960-10 .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP			· ·	_	_	ĺ
MS21919WDF13			· · · · · · · · · · · · · · · · · · ·	_		ł
114			,	_	_	ł
(REPLACED BY 70-061K000V334A) 1 NP 114 70-061K000V334A .HOSE ASSY (REPLACES 70-010K000V336) 1 SP 115 AN833-6D .ELBOW 1 SP 116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 AN960-10 .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP				1	SP	ł
114 70-061K000V334A .HOSE ASSY (REPLACES 70-010K000V336) 1 SP 115 AN833-6D .ELBOW 1 SP 116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 AN960-10 .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP	114	70-010K000V336				
115 AN833-6D .ELBOW 1 SP 116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 AN960-10 .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP	114	70 061#000***	,			ĺ
116 AN924-6D .NUT 1 SP 117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 AN960-10 .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP			,	_		ł
117 MS29512-06 .PACKING, PREFORMED 1 SP 118 AN3-15A .BOLT 2 SP 119 AN960-10 .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP	_			_		ł
118 AN3-15A .BOLT				_		
119 AN960-10 .WASHER (REPLACED BY NAS1149F0363P) 2 P 119 NAS1149F0363P .WASHER (REPLACES AN960-10) 2 SP				_		1
119 NAS1149F0363P .WASHER (REPLACES AN960-10)	_					1
					_	ł
120 203 001 034 001 1 SF				_		ł
	120	200 001-001-001	TOTAL		SP	

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 28-4. Fuel System Installation (Cont'd)			
121	205-062-604-001	.NUT	1	SP	
122	AN960PD1216L	.WASHER (REPLACED BY AN960JD1216L)	1	P	
122	AN960JD1216L	.WASHER (REPLACES AN960PD1216L)	1	F	
122	NAS1149D1216J	(REPLACED BY NAS1149D1216J)	1	P SP	
123	MS29512-08	.PACKING, PREFORMED	1	SP	
124	205-061-641-001	FITTING	1	SP	
125	AN4-4A	.BOLT	4	SP	
126	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	4	NP	
126	AN960JD416L	.WASHER (REPLACES AN960PD416L)			
		(REPLACED BY NAS1149D0416J)	4	P	
126	NAS1149D0416J	.WASHER (REPLACES AN960JD416L)	4	SP	
127	205-061-679-001	.VALVEPACKING, PREFORMED	1	SP	
128 129	MS29513-020 205-061-640-001	.PACKING, PREFORMED	1	SP SP	
130	MS29513-223	.PACKING, PREFORMED	1	SP	
131	AN3-3A	BOLT	1	SP	
132	AN3-10A	BOLT	1	SP	
133	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2	P	
133	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
		(REPLACED BY NAS1149D0332J)	2	P	
133	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	2	SP	
134	AN742D18	.CLAMP	1	SP	
135	391046-199	.PROBE	1	SP	
136	AN3-10A	BOLT	2	SP	
137	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	2	P	
137	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY NAS1149D0332J)	2	P	
137	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	2	SP	
138	AN3-3A	BOLT	1	SP	
139	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	P	
139	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L)			
		(REPLACED BY NAS1149D0332J)	1	P	
139	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
140	NAS43DD3-40	.SPACER (REPLACED BY NAS43DD3-40N)	1	P	
140	NAS43DD3-40N	.SPACER (REPLACES NAS43DD3-40)	1	SP	
141	AN735D19	.CLAMP	1	SP	
142 143	AN3-3A AN960PD10L	BOLT	1	SP P	
143	AN960PDIOL AN960JD10L	.WASHER (REPLACED BY AN9600D10L)	1	P	
143	דו או או או איז איז איז איז איז איז איז איז איז איז	(REPLACED BY NAS1149D0332J)	1	P	
143	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
144	AN742D18	.CLAMP	1	SP	
145	391046-197	.PROBE	1	SP	
146	FCE53917	.FUEL CELL, LH (S/N 30504 THRU 31311, 35001 THRU 35048) (REPLACED BY 212-360-601-101)	1	NP	
146	212-360-601-101	.FUEL CELL, LH (REPLACES FCE53917)	1	SP	
147	AN4H-5A	BOLT	12		
148	AN960D416L	WASHER (REPLACED BY NAS1149D0416H)	12	P	
148	NAS1149D0416H	WASHER (REPLACES AN960D416L)	12	SP	

(1)	(2)	(3)	(4)	(5)	(6)	1
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	0 C	
		Figure 28-4. Fuel System Installation (Cont'd)				
149 150	FCD46182 FCD41993 RK30S RK30	BAR, OUTER ACCESS (USBL ON FCE53917) BAR, INNER ACCESS (USBL ON FCE53917) REPAIR KIT (REPLACED BY RK30) REPAIR KIT (REPLACES RK30S)	1 1 1	P P NP P		
		AVAIL CODE DEFINITION				
		P Procurable NP Non Procurable SP Normal Stock/Procurable See introduction on availability codes for additional information.				







Figure 28-5. Fuel System Installation (Sheet 1 of 2)

28-99-00 Page 26





212_IPB_28_0005b

Figure 28-5. Fuel System Installation (Sheet 2 of 2)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 28-5. Fuel System Installation			
	212-060-600-003	FUEL SYSTEM INSTL (S/N 30504 THRU 30614) (SEE FIG. 28-1, 28-2, 28-3, 28-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-600-005	FUEL SYSTEM INSTL (S/N 30615 THRU 30729) (SEE FIG. 28-1, 28-2, 28-3, 28-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-600-009	FUEL SYSTEM INSTL (S/N 30730 THRU 31294) (SEE FIG. 28-1, 28-2, 28-3, 28-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-600-101	FUEL SYSTEM INSTL (S/N 31295 THRU 31311, 35001 THRU 35080) (SEE FIG. 28-1, 28-2, 28-3, 28-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-600-103	FUEL SYSTEM INSTL (S/N 35081 THRU SUB) (SEE FIG. 28-1, 28-2, 28-3, 28-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
1	MS27039-1-16	SCREW	4	SP	
2	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	4	NP	
2	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	4	NP	
2	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	4	SP	
3	MS29513-214	. PACKING, PREFORMED	1	SP	
4	AN3-5A	BOLT	2	SP	
5	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	2	NP	
5	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (RÉPLACED BY NAS1149D0316J)	2	NP	
5	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	2	SP	
6	MS29513-120	. PACKING, PREFORMED	1	SP	
7	212-060-605-001	. CROSSOVER ASSY	1	SP	
8	300287-1	. CROSSOVER ASSY	1	SP	
9	MS35266-63	. SCREW	4	SP	
10 10	AN960PD10L AN960JD10LL	. WASHER (REPLACED BY AN960JD10LL)	4	NP NP	
		NAS1149D0316J)			
10	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	4	SP	
11	300288-1	. CROSSOVER ASSY (REPLACED BY 300288-501)	1	NP	
11	300288-501	. CROSSOVER ASSY (REPLACES 300288-1)	1	SP	
12	AN4-4A AN960PD416	BOLT	2	SP	
13 13	AN960JD416	. WASHER (REPLACED BY AN960JD416)	2	P P	
13	NA 91140D0462 I	NAS1149D0463J)	2	SP	
13	NAS1149D0463J AN924-6D	WASHER (REPLACES AN960JD416)	1	P	
14	AS5178D06	NUT (REPLACED BY AS5178D06)	1	SP	
15	AN960PD916L	. WASHER (REPLACED BY AN960JD916L)	1	Р	
15	AN960JD916L	. WASHER (REPLACED BY AN9603D916L)	1	P	
15	NAS1149D0916J	. WASHER (REPLACES AN960JD916L)	1	SP	
16	205-061-637-001	FITTING, FUEL TANK VENT	1	SP	
17	MS29513-213	. PACKING, PREFORMED.	1	SP	
18	AN737TW46	CLAMP	2	SP	
19	205-062-601-001	HOSE	1	SP	
19A	205-062-601-003	. HOSE	1	SP	
20	70-010J000A067	. HOSE ASSY (REPLACED BY 70-061J000A067A)	1	NP	
20	70-061J000A067A	. HOSE ASSY (REPLACES 70-010J000A067)	1	SP	
21	AN815-8D	. UNION (REPLACED BY AS5174D0808)	1	Р	
21	AS5174D0808	. UNION (REPLACES AN815-8D) (REPLACED BY AS5174W0808).	1	Р	
21	AS5174W0808	. FITTING (REPLACES AS5174D0808)	1	SP	
22 23	205-062-602-001 110-144-8A	. TUBE ASSY	1 4	SP NP	
		AS4824A08)			
23 24	AS4824A08 AN4H35A	. SEAL (REPLAĆES 110-144-8A)	4	SP SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 28-5. Fuel System Installation (Cont'd)			
25 25	AN960PD416 AN960JD416	. WASHER (REPLACED BY AN960JD416)	1	P P	
25	NAS1149D0463J	NAS1149D0463J)	1	SP	
26	MS29513-010	. PACKING, PREFORMED	1	SP	
27 28	MS29528-4 MS29512-04	VALVEPACKING, PREFORMED	1	SP SP	
29	AN924-4D	NUT (REPLACED BY AS5178D04)	1	NP	
29	AS5178D04	NUT (REPLACES AN924-4D)	1	SP	
30	AN807-4D	FITTING (REPLACED BY AS5180D04)	1	NP	
30	AS5180D04	. FITTING (REPLACES AN807-4D)	1	SP	
31	MS29512-04	. PACKING, PREFORMED	1	SP	
32	AN4-6A	. BOLT	12	SP	
33	AN960PD416L	. WASHER (REPLACED BY AN960JD416L)	12	NP	
33	AN960JD416L	. WASHER (REPLACES AN960PD416L) (REPLACED BY	12	NP	
33	NAS1149D0416J	NAS1149D0416J)	12	SP	
34	MS25083-1BC10	J. WASHER (REPLACES AN960JD416L)	1	NP	
34	MS25083-7BC10	. JUMPER ASSY (REPLACES MS25083-1BC10) (REPLACED BY	1	NP	
34	M83413/8-C010BC	M83413/8-C010BC)	1	SP	
35	205-060-606-003	. PUMP ASSY (S/N 30504 THRU 31311, 35001 THRU 35034)	1	SP	
35	206-062-687-101	(REPLACED BY 206-062-687-101)	1	SP	
36	2C27-3	. PUMP ASSY (REPLACES 205-060-606-003)	1	SP	
37	MS24694S46	SCREW (REPLACED BY MS24694-S46)	2	NP	
37	MS24694-S46	SCREW (REPLACES MS24694S46)	2	SP	
38	475D12NN48LT32	. FLANGE (S/N 30504 THRU 30614) (REPLACED BY 206-062-654-001)	1	NP	
38	206-062-654-001	. FLANGE (REPLACES 475D12NN48LT32)	1	SP	
39	204-060-604-001	. GASKET	2	NP	
40	NAS679A3	. NUT (REPLACED BY MS21042L3)	2	NP	
40	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP	
41	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	2	NP	
41	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	2	NP	
41	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	2	SP	
42	MS24694S52	. SCREW (REPLACED BY MS24694-S52)	2	NP	
42	MS24694-S52	. SCREW (REPLACES MS24694S52)	2	SP	
43	205-060-645-001	RETAINER	1	SP	
44 45	120-068-13 205-062-613-001	SEAL	2	SP SP	
45 46	AF11C9	NUT	1	NP	
46	AF11C-9	VALVE (REPLACES AF11C-9)	1	NP	
46	A280-2	. VALVE (REPLACES AF11C-9)	1	SP	
47	MS29513-020	. PACKING, PREFORMED	1	SP	
48	NAS509-12	NUT	1	SP	
49	AN960PD1216L	. WASHER (REPLACED BY AN960JD1216L)	1	NP	
49	AN960JD1216L	WASHER (REPLACES AN960PD1216L) (REPLACED BY NAS1149D1216J)	1	Р	
49	NAS1149D1216J	. WASHER (REPLACES AN960JD1216L)	1	SP	
50	204-060-654-007	SWITCH	1	SP	
51	MS29512-06	. PACKING, PREFORMED	1	SP	
52	212-060-602-001	. SUPPORT	1	SP	
53	MS29512-08	. PACKING, PREFORMED	1	SP	
54	NAS509-9	. NUT	1	SP	
55 55	AN960PD916L	. WASHER (REPLACED BY AN960JD916L)	1	P P	
ວວ	AN960JD916L	. WASHER (REPLACES AN960PD916L) (REPLACED BY	'	-	
	1	NAS1149D0916J)			1



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	0 C
		Figure 28-5. Fuel System Installation (Cont'd)			
55	NAS1149D0916J	. WASHER (REPLACES AN960JD916L)	1	SP	
56	MS29513-018	. PACKING, PREFORMED	1	SP	
57	AN4-4A	BOLT	12	SP	
58 58	AN960PD416L AN960JD416L	. WASHER (REPLACED BY AN960JD416L)	12 12	NP NP	
58	NAS1149D0416J	. WASHER (REPLACES AN960JD416L)	12	SP	
59	AN924-16D	. NUT (REPLACED BY AS5178D16)	1	NP	
59	AS5178D16	. NUT (REPLACES AN924-16D)	1	SP	
60	AN960PD2116L	. WASHER (REPLACED BY AN960JD2116L)	1	NP	
60	AN960JD2116L	. WASHER (REPLACES AN960PD2116L) (REPLACED BY	1	Р	
60	NAS1149D2116J	NAS1149D2116J)	1	SP	
60 61	375C16	. WASHER (REPLACES AN960JD2116L)		NP	
61	375C-16	. VALVE (REPLACED BY 3/3C-16)	1	SP	
62	MS29512-16	. PACKING, PREFORMED	i	SP	
63	MS29512-16	. PACKING, PREFORMED.	1	SP	
64	1-713-1	. ADAPTER (REPLACED BY 30-067-1F)	1	NP	
64	30-067-1F	. ADAPTER (REPLACES 1-713-1)	1	SP	
65	1-890-1	. CONNECTOR (REPLACED BY 30-060-1F)	1	NP	
65 66	30-060-1F	. CONNECTOR (REPLACES 1-890-1)	1	SP	
66 66	5193-1	. ADAPTER, TEE (REPLACED BY 30-067-1A)	1	NP SP	
67	30-067-1A 1-892-1	. ADAPTER (REPLACES 5193-1)		P	
67	30-060-1A	CONNECTOR (REPLACES 1-892-1)	1	SP	
68	212-060-601-005	SUMP ASSY, RH	1	SP	
69	NAS679A06	NUT (REPLACED BY MS21042L06)	5	SP	
69	MS21042L06	NUT (REPLACES NAS679A06)	5	SP	
70	AN961-6	WASHER (REPLACED BY AN961-6T)	5	NP	
70	AN961-6T	WASHER (REPLACES AN961-6)	5 1	SP	
71 72	MS27212-1-5 MS29513-270	TERMINAL BOARD		SP SP	
73	70-010J000V110	. HOSE ASSY (REPLACED BY 70-061J000V110A)	1	NP	
73	70-061J000V110A	. HOSE ASSY (REPLACES 70-010J000V110)	i	SP	
74	S2490	. FITTING (S/N 30504 THRU 30614) (REPLACED BY 50-040-3)	1	NP	
74	50-040-3	FITTING (REPLACES S2490)	1	SP	
75	AN960PD716	. WASHER, FLAT (REPLACED BY AN960JD716)	1	NP	
75	AN960JD716	. WASHER (REPLACES AN960PD716) (REPLACED BY	1	Р	
75	NIA C11 40 D0 762 I	NAS1149D0763J)	1	SP	
75 76	NAS1149D0763J 205-060-647-001	. WASHER (REPLACÉS AN960JD716)	1	SP	
77	MS29513-113	PACKING, PREFORMED	1	SP	
78	70-010H000A125	. HOSE ASSY (REPLACED BY 70-061H000A125A)	1	NP	
78	70-061H000A125A	. HOSE ASSY (REPLACES 70-010H000A125)	1	SP	
79	488-6D1 1-4	. VALVE (ALTERNATE PART)	1	NP	
79	869A6TT2	. VALVE (REPLACED BY 869A-6TT-2)	1	NP	
79	869A-6TT-2	. VALVE (REPLACES 869A6TT2)	1	SP	
80	205-061-635-003	. FLOW SWITCH	1	NP	
		(ALTERNATE PART)			
80	205-061-635-005	. FLOW SWITCH	1	SP	
81 01	AN815-6D	. UNION (REPLACED BY AS5174D0606)	1	NP P	
81 81	AS5174D0606 AS5174W0606	. UNION (REPLACES AN815-6D) (REPLACED BY AS5174W0606).	1	SP	
82	MS29512-06	. UNION (REPLACES AS5174D0606)	2	SP	
83	70-010H000V066	. HOSE ASSY (REPLACED BY 70-061H000V066A)	1	NP	
83	70-061H000V066A	. HOSE ASSY (REPLACES 70-010H000V066)	1	SP	
84	AN924-6D	NUT (REPLACED BY AS5178D06)	1	Р	
84	AS5178D06	. NUT (REPLACES AN924-6D)	1	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME		A V A I L	U 0 C
		Figure 28-5. Fuel System Installation (Cont'd)			
85 85 85 86 86 87 87	AN832-6D AS5406D06 AS5406W06 NAS679A4 MS21042L4 AN960PD416 AN960JD416	. UNION (REPLACED BY AS5406D06)	1 1 1 2 2 2 2	NP NP SP NP SP P	
87 88 89 89	NAS1149D0463J AN4-6A AN960PD416 AN960JD416	NAS1149D0463J)	2 2 1 1	SP SP P	
89 90 90	NAS1149D0463J AN960PD416L AN960JD416L	NAS1149D0463J)	1 1 1	SP NP NP	
90 91 91 92 92	NAS1149D0416J NAS679A4 MS21042L4 AN960PD416 AN960JD416	WASHER (REPLACES AN960JD416L) NUT (REPLACED BY MS21042L4) NUT (REPLACES NAS679A4) WASHER (REPLACED BY AN960JD416) WASHER (REPLACES AN960PD416) (REPLACED BY	1 1 1 1	SP NP SP P	
92 93 94 95 96	NAS1149D0463J AN4-5A 205-061-643-003 205-060-666-001 646121-6D0280	NAS1149D0463J)	1 1 2 1	SP SP SP SP NP	
96 97 98 99	56R536-6D0280 AN3-10A AN3-16A AN960PD10L AN960JD10LL	(ALTERNATE PART) . HOSE ASSY	1 1 1 1	NP SP SP NP NP	
99 100 100 101 102 102 103 104	NAS1149D0316J NAS43DD3-40 NAS43DD3-40N AN735D19 MS21919DF13 MS21919WDF13 AN3-3A AN960PD10L AN960JD10LL	NAS1149D0316J)	1 2 2 1 1 1 1 1	SP NP SP SP NP SP SP NP NP	
104 105 105 106 106 107 107 107 108 108 109 110 111	NAS1149D0316J MS21919DF13 MS21919WDF13 70-010K000V3366 70-061K000V336A AN833-6D AS1038D0606 AS1038W0606 AN924-6D AS5178D06 MS29512-06 AN3-15A AN960-10 NAS1149F0363P	NAS1149D0316J)	1 1 1 1 1 1 1 1 1 1 2 2	SP NP SP NP SP SP SP SP SP SP SP	



(1) (2)		(6)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 28-5. Fuel System Installation (Cont'd)			
112	205-061-634-001	. PUMP	1	SP	
113	205-062-604-001	. NUT	1	SP	
114	AN960PD1216L	. WASHER (REPLACED BY AN960JD1216L)	1	NP	
114	AN960JD1216L	. WASHER (REPLACES AN960PD1216L) (REPLACED BY NAS1149D1216J)	1	Р	
114	NAS1149D1216J	. WASHER (REPLACES AN960JD1216L)	1	SP	
115	MS29512-08	. PACKING, PREFORMED	1	SP	
116	205-061-641-001	FITTING	1	SP	
117	AN4-4A	BOLT	4	SP	
118	AN960PD416L	. WASHER (REPLACED BY AN960JD416L)	4	NP	
118	AN960JD416L	. WASHER (REPLACES AN960PD416L) (REPLACED BY	4	NP	
	7.1.100002 1.102	NAS1149D0416J)	•		
118	NAS1149D0416J	. WASHER (REPLACES AN960JD416L)	4	SP	
119	205-061-679-001	. VALVE	1	SP	
120	MS29513-020	PACKING, PREFORMED	1	SP	
121	205-061-640-001	PLATE	1	SP	
122	MS29513-223	PACKING, PREFORMED	1	SP	
123	AN3-3A	POLT	1	SP	
123	AN3-3A AN3-10A	BOLT	1	SP	
124	MS51964-57	BOLT (REPLACED BY MS51964-57)	1	SP	
125	AN960PD10L	. SETSCREW (REPLACES AN3-10A)	2	NP	
_		. WASHER (REPLACED BY AN960JD10LL)	2		
125	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY		NP	
405	NA 04440 DOO40 I	NAS1149D0316J)		0.0	
125	NAS1149D0316J	. WASHER (REPLACÉS AN960JD10LL)	2	SP	
126	AN742D18	. CLAMP (REPLACED BY AS5587D18)	1	NP	
126	AS5587D18	. CLAMP (REPLACES AN742D18)	1	SP	
127	391046-199	. PROBE	1	SP	
128	AN3-10A	. BOLT (REPLACED BY MS51964-57)	2	SP	
128	MS51964-57	. SETSCREW (REPLACES AN3-10A)	2	SP	
129	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	2	NP	
129	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY	2	NP	
		NAS1149D0316J)			
129	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	2	SP	
130	AN3-3A	BOLT	1	SP	
131	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	1	NP	
131	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY	1	NP	
		NAS1149D0316J)			
131	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	1	SP	
132	NAS43DD3-40	. SPACER (REPLACED BY NAS43DD3-40N)	1	NP	
132	NAS43DD3-40N	SPACER (REPLACES NAS43DD3-40)	1	SP	
133	AN735D19	CLAMP	1	SP	
134	AN3-3A	BOLT	1	SP	
135	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	1	NP	
135	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY	1	NP	
100	7.1100002 1022	, ,			
135	NAS1149D0316J	NAS1149D0316J)	1	SP	
136	AN742D18	CLAMP (REPLACED BY AS5587D18)	1	NP	
136	AS5587D18		1	SP	
137	391046-197	. CLAMP (REPLACES AN742D18)	1	SP	
138	205-061-632-002	PROBE		NP	
130	200-001-032-002	. FUEL CELL, RH (S/N 30504 THRU 31294) (REPLACED BY	'	INF	
400	242 260 604 400	212-360-601-102)		C C	
138	212-360-601-102	. FUEL CELL, RH (RÉPLACES 205-061-632-002)	1	SP	
139	AN4-5A	BOLT	12	SP	
140	AN960PD416L	. WASHER (REPLACED BY AN960JD416L)	12	NP	
140	AN960JD416L	. WASHER (REPLACES AN960PD416L) (REPLACED BY	12	NP	
		NAS1149D0416J)			
140	NAS1149D0416J	. WASHER (REPLACES AN960JD416L)	12	SP	
1 40		,			



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME			U 0 C
		Figure 28-5. Fuel System Installation (Cont'd)			
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			