

COLUMN 1	2	3	4	5	6
ITEM	Starter/ Generator Installed		Sling. Hole Number	Cables (See Diagram 'A')	Attachment Points (See Diagram 'B')
Rail System, Removal/Installation					
Complete Engine	YES	YES	6	1, 2, 4, 6,	3, 6, 7, 9
Complete Engine	YES	NO	7	1, 2, 4, 6,	3, 6, 7, 9,
Complete Engine	NO	YES	4	1, 2, 4, 6,	3, 6, 7, 9,
Complete Engine	NO	NO	5	1, 2, 4, 6,	3, 6, 7, 9,
Rail System, Removal/Installation					
Complete Power Section L.H.	YES		10	1, 4,	5, 9,
Complete Power Section R.H.	YES		10	1, 4,	4, 8,
Complete Power Section L.H.	NO		9	1, 4,	5, 9,
Complete Power Section R.H.	NO		9	1, 4,	4, 8,
Rail System, Removal/Installation					
Reduction Gearbox			11	3, 5,	1, 2,
					212-M-71-11

Figure 71-11. Engine sling SWE 13833 and rail system handling stand