

- 1. Tachometer generator
- 2. Tachometer generator
- 3. Hose fuel pump drain
- 4. Hose fuel pump drain
- 5. Oil drain valve
- 6. Oil drain valve
- 7. Cross fitting
- 8. Cross fitting
- 9. Drain tube starter-generator

- 10. Drain tube starter-generator
- 11. Tube seal drain
- 12. Tube seal drain
- 13. Starter-generator
- 14. Starter-generator
- 15. Mount fitting
- 16. Oil tank drain hose
- 17. Fuel inlet hose
- 18. Fuel inlet hose

212-M-71-13 212-062-005

Figure 71-13. Accessory gearbox lines