

212-M-52-3-1

Figure 52-3. Interior cabin access doors, covers, and panels (sheet 1 of 2)

ITEM	NOMENCLATURE	ACCESSES	DIMENSIONS (INCHES)	RETAINER	
				TYPE	QTY
1	Door	No. 2 Engine Accessory Gearbox	13 x 14	Screw	12
2	Door	No. 1 Engine Accessory Gearbox	13 x 14	Screw	12
3	Door Assembly	Hydraulic Components, Lift Beam Link and Cargo Hook	15 x 28	Sleeve Bolt	37
4	Door Assembly	Cyclic Hydraulic Servos and Cargo Hook	11 x 28	Screw	38
5	Door Assembly	Pilot Cyclic Controls	17 x 29	Screw	6
6	Door Assembly	Collective Jackshaft	15 x 27	Screw	7
7	Door Assembly	Cyclic Mixing Bellcrank	29 x 29	Bolt	14
8	Door Assembly	Cyclic/Collective Controls	21 x 29	Bolt	6
9	Panel Assembly	General Inspection Area	14 x 54	Screw	104
10	Cover	Auxiliary Fuel Connections	8 x 13	Screw	17
11	Panel Assembly	Forward Fuel Cell	24 x 54	Screw	106
12	Panel Assembly	Fuel Cell Interconnect	12 x 32	Screw	30
13	Panel Assembly	Fuel Cell Interconnect	12 x 32	Screw	30
14	Panel Assembly	Forward Fuel Cell	24 x 54	Screw	106
15	Cover	Auxiliary Fuel Connection	8 x 13	Screw	17
16	Panel Assembly	General Inspection Area	14 x 54	Screw	104
17	Door Assembly	Copilot Cyclic Controls	17 x 29	Screw	6
18	Door	Copilot Cyclic Controls	7.7 x 9.7	Screw	6
19	Door	Copilot Cyclic Controls	3 x 4	Screw	4

212-M-52-3-2

Figure 52-3. Interior cabin access doors, covers, and panels (sheet 2)