


- 1. Starter generator duct
- 2. Air valve electrical plug
- 3. Rear mount bolts
- 4. Jackshaft
- 5. Governor RPM actuator
- 6. Electrical plug
- 7. Bleed air valve
- 8. Combustion chamber drain
- 9. Fuel manifold drain
- 10. Fitting
- 11. Ignition exciter
- 12. Forward engine mount tube

- 13. Idle stop solenoid
- 14. Accessory gearbox drain hose
- 15. Governor bleed hose
- 16. Oil filler
- 17. Fuel inlet hose
- 18. Starter electrical plug
- 19. Fuel control link
- 20. Clamp
- 21. Bracket and clamp
- 22. Bleed air elbow
- 23. Bleed air tube
- 24. Bleed air adapter

212-M-71-9-1

Figure 71-9. Engine assembly (sheet 1 of 2)






Figure 71-9. Engine assembly (sheet 2)