



## **CAUTION**

Ensure pressure tester is serviced with same oil as used in combining gearbox.

212\_M\_76\_6\_c01

Figure 76-6. Pressure Tester