


CHAPTER 71 — POWER PLANT

CONTENTS — ILLUSTRATED PARTS BREAKDOWN

Figure Number		Chapter/Section Number	Page Number
71-1	Power Plant Installation	. 71-99-00	2
71-2	Power Plant Installation	. 71-99-00	14
71-3	Firewall Assembly and Power Plant Installation	. 71-99-00	20
71-4	Firewall Assembly, Centerline	. 71-99-00	26
71-5	Firewall Assembly, Middle		30
71-6	Cowling Installation		34
71-7	Cowling Installation	. 71-99-00	40
71-8	Cowling Installation	. 71-99-00	46
71-9	Cowling Installation		50
71-10	Oil Cooler Support Cowling Assembly	. 71-99-00	56
71-11	Fairing Assembly, Air Inlet	. 71-99-00	60
71-12	Engine Mount Installation	. 71-99-00	66
71-13	Air Management System Installation		70
71-14	Baffle Assembly, Induction		78
71-15	Valve Assembly		84
71-16	Engine Assembly	. 71-99-00	86
71-17	Engine Assembly		98
71-18	Engine Assembly, Rear		102
71-19	Starter Generator (209-060-221)	. 71-99-00	108
71-20	Starter Generator (200SG119Q-1)	. 71-99-00	112
71-21	Ejector and Ejector/Deflector Assemblies	. 71-99-00	116






Figure 71-1. Power Plant Installation (Sheet 1 of 2)

71-99-00 Page 2

Rev. 8 30 APR 2010






Figure 71-1. Power Plant Installation (Sheet 2 of 2)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-1. Power Plant Installation			
	212-062-001-001	POWER PLANT INSTL (S/N 30504 THRU 30530) (SEE FIG. 71-2,	1	NP	
	212-062-001-005	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-001-007	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-001-011	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-001-009	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 30597 THRU 30603, 30611 THRU 30614) (SEE FIG. 71-2, 71-3, 71-4, 71-5 FOR BALANCE OF	1	NP	
	212-062-001-013	BREAKDOWN)	1	NP	
	212-062-001-015	POWER PLANT INSTL (S/N 30615 THRU 30729) (SEE FIG. 71-2,	1	NP	
	212-062-001-023	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 30730 THRU 30849) (SEE FIG. 71-2,	1	NP	
	212-062-001-027	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-001-101	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-001-103	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-001-115	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 31295 THRU 31311, 35001 THRU 35068) (SEE FIG. 71-2, 71-3, 71-4, 71-5 FOR BALANCE OF	1	NP	
	212-062-001-119	POWER PLANT INSTL (S/N 35069 THRU 35080) (SEE FIG. 71-2,	1	NP	
	212-062-001-123	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-001-125	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 35102 THRU SUB) (SEE FIG. 71-2, 71-3,	1	NP	
1	212-060-900-181	71-4, 71-5 FOR BALANCE OF BREAKDOWN)	1	Р	
1	212-060-900-287	THRU 30610) (SEE FIG. 71-3 FOR BREAKDOWN)	1	NP	
1	212-060-900-299	BREAKDOWN) (REPLACED BY 212-060-900-299)	1	SP	
2 3	MS21042L3 AN960C10L	71-3 FOR BREAKDOWN) (REPLACES 212-060-900-287) NUT, SELF-LOCKING (S/N 30597 THRU 30603, 30611 THRU SUB) . WASHER (S/N 30597 THRU 30603, 30611 THRU SUB) (REPLACED	6 6	SP P	
3	NAS1149C0332R	BY NAS1149C0332R)	6	SP	
4 5	MS27039C1-07 17343-771-310	AN960C10L)	6 2	SP SP	
6 7	MS27039C1-10 AN960C10L	. SCREW (S/N 30597 THRU 30603, 30611 THRU SUB)	2 2	SP P	
7	NAS1149C0332R	BY NAS1149C0332R)	2	SP	
8 9	212-062-011-001 212-061-903-003	AN960C10L)	1	SP NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-1. Power Plant Installation (Cont'd)			
9	212-061-903-141	. FIREWALL ASSY, CENTERLINE (S/N 30531 THRU 30877) (SEE FIG. 71-4 FOR BREAKDOWN) (REPLACES 212-061-903-003)	1	NP	
9	212-061-903-151	(REPLACED BY 212-061-903-151 AND -175)	1	NP	
9	212-061-903-175	(REPLACED BY 212-061-903-175)	1	Р	
10	212-060-901-115	212-061-903-003, -141 AND -151)	1	Р	
10	212-060-901-161	. FIREWALL ASSY, MIDDLE (S/N 30554 THRU 31124) (SEE FIG. 71-5	1	Р	
10	212-060-901-179	FOR BREAKDOWN)	1	NP	
10	212-060-901-189	. FIREWALL ASSY, MIDDLE (S/N 31295 THRU 31310, 35001) (SEE	1	NP	
10	212-060-901-203	FIG. 71-5 FOR BREAKDOWN)	1	NP	
10	212-060-901-219	. FIREWALL ASSY, MIDDLE (S/N 35084 THRU 35099) (SEE FIG. 71-5	1	Р	
10	212-060-901-237	FOR BREAKDOWN)	1	NP	
11	212-061-902-161	FOR BREAKDOWN)	1	NP	
11	212-061-902-171	-171, -177 AND -187)	1	NP	
11	212-061-902-177	BY 212-061-902-177, -187, -203 AND -207)	1	Р	
11	212-061-902-187	(REPLACED BY 212-061-902-187, -203 AND -207)	1	NP	
11	212-061-902-203	212-061-902-203 AND -207)	1	Р	
11	212-061-902-207	212-061-902-207)	1	Р	
11	212-061-902-217	AND -203)	1	SP	
11	212-061-902-233	FOR BREAKDOWN)	1	Р	
	212-060-905-011	FIRE DETECTION INSTL	1	NP	
12	207865	NUT	8	SP	
13	251987	CLAMP (REPLACED BY 30-024-1)	30	NP	
13	30-024-1	CLAMP (REPLACES 251987)	30	SP	
14	245284	GROMMET (REPLACED BY 30-024-2)	30	NP	
14	30-024-2	GROMMET (REPLACES 245284)	30	SP	
15	212-060-923-003	SENSING ELEMENT	2	SP SP	
16	212-060-923-005	SENSING ELEMENT	-	32	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-1. Power Plant Installation (Cont'd)			
17	872203	FLEX CABLE	2	SP	
18	NAS679A3	. NUT (REPLACED BY MS21042L3)	8	NP	
18	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	8	SP	
19	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	16	Р	
19	NAS1149C0332R	WASHER (REPLACES AN960C10L)	16	SP	
20	MS35207-268	SCREW	8	SP	
21 22	209-062-519-001 MS29512-04	BOOT, OIL COOLER BLOWER	2 4	SP SP	
23	AN815-4	PACKING, PREFORMED	2	NP	
23	AN815-4J	UNION (REPLACED BY AN815-4J)	2	SP	
23	AS5174J0404	UNION (REPLACES ANS15-4) (REPLACED BY ASS17430404)	2	SP	
24	AN919-3	REDUCER (REPLACED BY AN919-3J)	2	NP	
24	AN919-3J	REDUCER (REPLACES AN919-3) (REPLACED BY AS5174J0504)	2	NP	
24	AS5174J0504	REDUCER (REPLACES AN919-3J)	2	SP	
25	NAS679A3	. NUT (REPLACED BY MS21042L3)	8	NP	
25	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	8	SP	
26	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	8	Р	
26	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	8	SP	
27	MS27039C1-07	. SCREW	8	SP	
28	NAS43HT3-12	. SPACER	8	SP	
29	42D218	. SWITCH, PRESSURE (REF. DES. S100, S101) (REPLACED BY	2	SP	
29	42D399	42D399)	2	SP	
	212-061-904-001	BRACKET ASSY, LH.	1	Р	
	212-061-904-002	BRACKET ASSY, RH	li	P	
30	212-061-904-003	BRACKET ASSY	1	Р	
31	212-061-904-005	BRACKET	2	Р	
32	212-061-904-007	SUPPORT	1	Р	
33	212-061-904-009	STIFFENER, LH	1	Р	
33	212-061-904-010	STIFFENER, RH	1	Р	
34	212-061-906-101	LABEL (INSTALL CAUTION)	1	SP	
35 35	NAS679A3 MS21042L3	NUT (REPLACED BY MS21042L3)	4	NP SP	
36	AN960C10L	NUT, SELF-LOCKING (REPLACES NAS679A3)	4	P	
36	NAS1149C0332R	. WASHER (REPLACED BY NAS1149C0332R)	4	SP	
37	MS27039-1-09	SCREW	4	SP	
38	AN735-48	CLAMP	4	SP	
39	DELETED		NA		
40	NAS1375A12SH082	. HOSE (S/N 30504 THRU 31294) (REPLACED BY 70-051-12R082G)	2	NP	
40	70-051-12R082G	. HOSE (REPLACES NAS1375A12SH082) (REPLACED BY NAS1377A12SH082)	2	NP	
40	NAS1377A12SH082	. HOSE (REPLACES 70-051-12R082G, NAS1375A12SH082)	2	SP	
41 42	AN3CH4A AN960C10L	. BOLT (S/N 30504 THRU 30553)	4	SP P	
40	NA 044 40 00000	NAS1149C0332R)	4	C L	
42 43	NAS1149C0332R	. WASHER (S/N 30504 THRU 30553) (REPLACES AN960C10L)	4 2	SP NP	
43 43	NAS679A3 MS21042L3	NUT (S/N 30504 THRU 30553) (REPLACED BY MS21042L3)	2	SP	
40	WOLIUTLLU	NUT, SELF-LOCKING (S/N 30504 THRU 30553) (REPLACES NAS679A3)	_	Ji-	
44	AN960C10L	NAS6/9A3)	2	Р	
44	NAS1149C0332R	. WASHER (S/N 30504 THRU 30553) (REPLACES AN960C10L)	2	SP	
45	MS27039-1-08	SCREW (S/N 30504 THRU 30553)	2	SP	
46	MS21919H16	CLAMP (S/N 30504 THRU 30553) (REPLACED BY MS21919WCH16)	2	Р	
46	MS21919WCH16	. CLAMP (S/N 30504 THRU 30553) (REPLACES MS21919H16)	2	SP	
47	20-032-1	. BRACKET (S/N 30504 THRU 30553)	2	SP	
48	212-060-532-001	. TUBE ASSY, LH (S/N 30504 THRU 30553)	1	SP	Ī



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-1. Power Plant Installation (Cont'd)			
49	212-060-532-003	. TUBE ASSY, RH (S/N 30504 THRU 30553)	1	SP	
50	212-060-532-005	GASKET	1	SP	
51 51	MS29561-022 M83248/1-022	. PACKING, PREFORMED (REPLACED BY M83248/1-022) PACKING, PREFORMED (REPLACES MS29561-022) (REPLACED	2	NP SP	
51	AS3209-022	BY AS3209-022)	2	SP	
52	MS35489-24	GROMMET	2	SP	
53	AN815-4S	. UNION (REPLACED BY AN815-4J)	2	NP	
53	AN815-4J	. UNION (REPLACES AN815-4S) (REPLACED BY AS5174J0404) .	2	SP	
53	AS5174J0404	. UNION (REPLACES AN815-4J)	2	SP	
54	NAS679A3	. NUT (REPLACED BY MS21042L3)	2	NP	
54	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP	
55	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	2	Р	
55	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	2	SP	
56 57	MS27039-1-08 MS21919H4	SCREW	2	SP P	
57 57	MS21919H4 MS21919WCH4	CLAMP (REPLACED BY MS21919WCH4)	2	SP	
5 <i>1</i>	MS21919WCH4	CLAMP (REPLACES MS21919H4)	2	NP	
58	MS21919WCH10	CLAMP (REPLACES MS21919WCH10)	2	SP	
59	212-060-635-001	. TUBE ASSY, LH	1	SP	
60	212-060-636-001	. TUBE ASSY, RH	i i	SP	
61	475C61NSX	. VALVE (REPLACED BY 475C-61NSX)	2	NP	
61	475C-61NSX	. VALVE (REPLACES 475C61NSX)	2	SP	
62	212-060-659-001	. TUBE ASSY, LH	1	SP	
63	212-060-660-001	. TUBE ASSY, RH	1	SP	
64	AN919-6S	. REDUCER (REPLACED BY AN919-6J)	2	NP	
64	AN919-6J	. REDUCER (REPLACES AN919-6S) (REPLACED BY AS5174J0604)	2	NP	
64	AS5174J0604	. REDUCER (REPLACES AN919-6J)	2	SP	
65	AN938S6	. TEE (REPLACED BY AN938J6)	2	NP	
65 65	AN938J6 AS5192J06	TEE (REPLACES AN938S6) (REPLACED BY AS5192J06)	2	SP SP	
66	AN815-6S	TEE (REPLACES AN938J6)	2	NP	
66	AN815-6J	. UNION (REPLACED BY AN815-6J)	2	NP	
66	AS5174J0606	UNION (REPLACES ANS 15-63) (REPLACED BY ASS 17430000)	2	SP	
67	MS29512-06	. PACKING, PREFORMED	6	SP	
68	212-060-676-001	. CHECK VALVE	2	SP	
69	212-060-637-001	. TUBE ASSY, LH	1	SP	
70	212-060-638-001	. TUBE ASSY, RH	1	SP	
71	NAS679A3	. NUT (REPLACED BY MS21042L3)	4	NP	
71	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	4	SP	
72	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	4	Р	
72 72	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	4	SP	
73 74	MS27039-1-08	SCREW	4	SP	
74 74	MS21919H7 MS21919WCH7	CLAMP (REPLACED BY MS21919WCH7)	4	P SP	
74 75	NAS679A3	CLAMP (REPLACES MS21919H7)	2	NP	
75 75	MS21042L3	NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP	
76	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	2	P	
76	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	2	SP	
77	MS27039-1-08	. SCREW	2	SP	
78	MS21919H7	. CLAMP (REPLACED BY MS21919WCH7)	4	Р	
78	MS21919WCH7	. CLAMP (REPLACES MS21919H7)	4	SP	
79	NAS679A3	. NUT (REPLACED BY MS21042L3)	1	NP	
79	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	1	SP	
80	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	1	Р	
80	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY	1	Р	
80	NAS1149D0316J	NAS1149D0316J)	1	SP	
81	MS27039-1-07	SCREW		SP	
0 1	527000 1 07	. OOINE VV	'	01	l



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A L	U 0 C
		Figure 71-1. Power Plant Installation (Cont'd)			
82	MS21919H7	. CLAMP (REPLACED BY MS21919WCH7)	1	Р	
82	MS21919WCH7	. CLAMP (REPLACES MS21919H7)	1	SP	
83	MS21919H10	. CLAMP (REPLACED BY MS21919WCH10)	1	NP	
83	MS21919WCH10	. CLAMP (REPLACES MS21919H10)	1	SP	
84 84	MS21919H7 MS21919WCH7	CLAMP (REPLACED BY MS21919WCH7)	1	P SP	
85	MS21919WCH7 MS21042L3	. CLAMP (REPLACES MS21919H7)	1	SP	
86	AN960PD10L	NUT, SELF-LOCKING	1	P	
86	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (RÉPLACED BY	1	P	
86	NAS1149D0316J	NAS1149D0316J)	1	SP	
87	MS27039-1-07	SCREW		SP	
88	MS21919H4	. CLAMP (REPLACED BY MS21919WCH4)	1	P	
88	MS21919WCH4	. CLAMP (REPLACES MS21919H4)	1	SP	
89	MS21919H7	. CLAMP (REPLACED BY MS21919WCH7)	1	Р	
89	MS21919WCH7	. CLAMP (REPLACES MS21919H7)	1	SP	
90	MS21042L3	. NUT, SELF-LOCKING	1	SP	
91	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	1	Р	
91	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	1	Р	
91	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	1	SP	
92	MS27039-1-07	. SCREW	1	SP	
93	MS21919H7	. CLAMP (REPLACED BY MS21919WCH7)	1	Р	
93	MS21919WCH7	. CLAMP (REPLACES MS21919H7)	1	SP	
94	MS21919H10	. CLAMP (REPLACED BY MS21919WCH10)	1	NP	
94	MS21919WCH10	. CLAMP (REPLACES MS21919H10)	1	SP	
95 95	NAS679A3 MS21042L3	NUT (REPLACED BY MS21042L3)	1	NP SP	
95 96	AN960C10L	NUT, SELF-LOCKING (REPLACES NAS679A3)	1	P	
96	NAS1149C0332R	. WASHER (REPLACED BY NAS1149C0332R)	1	SP	
97	MS27039-1-19	SCREW	1	SP	
98	NAS43HT3-54	SPACER	1	SP	
99	20-032-1	. BRACKET	1	SP	
100	MS21919H16	. CLAMP (REPLACED BY MS21919WCH16)	1	Р	
100	MS21919WCH16	. CLAMP (REPLACES MS21919H16)	1	SP	
101	NAS679A3	. NUT (REPLACED BY MS21042L3)	2	NP	
101	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP P	
102 102	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	2	SP	
102	NAS1149C0332R MS27039-1-08	. WASHER (REPLACES AN960C10L)	1	SP	
103	MS27039-1-08 MS27039-1-19	SCREW	1	SP	
105	20-032-1	BRACKET	1	SP	
106	NAS43HT3-54	SPACER	1	SP	
107	MS21919H5	. CLAMP (REPLACED BY MS21919WCH5)	1	Р	
107	MS21919WCH5	. CLAMP (REPLACES MS21919H5)	1	SP	
108	MS21919H16	. CLAMP (REPLACED BY MS21919WCH16)	1	Р	
108	MS21919WCH16	. CLAMP (REPLACES MS21919H16)	1	SP	
109	212-060-004-001	. TUBE, LH	1	SP	
110 111	212-060-009-001 212-061-013-001	TUBE, RH	1 2	SP NP	
111	212-061-013-003	. ADAPTER ASSY, BLEED AIR (REPLACED BY 212-061-013-003) ADAPTER ASSY, BLEED AIR (NOTE 1) (REPLACES	2	SP	
	3766B18T16A	212-061-013-001)	REF	Р	
112	M83248/2-214	PACKING, PREFORMED	1	SP	
112A	3601-16-19	WASHER	2	P	
	BC515-16A	ADAPTER ASSY, BLEED AIR (HYDRAFLOW)	REF	P	
112B	12W36-16A	WASHER	1	Р	
	CD004 CA 044	PACKING, PREFORMED	1	Р	l
112C 112D	SD001-SA-214 WR001-16A	FACKING, FREFORMED	1	P	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-1. Power Plant Installation (Cont'd)			
113 113 114	AN837-6J AS1040J0606 AN924-6J	. ELBOW (REPLACED BY AS1040J0606)	2 2 2	SP SP SP	
114	AN924-6J	31294) (REPLACED BY AS5178J06)	1	SP	
114	AS5178J06	SUB) (REPLACED BY AS5178J06)	2	SP	
114	AS5178J06	31294) (REPLACES AN924-6J)	1	SP	
115	AN919-6S	SUB) (REPLACES AN924-6J)	2	NP	
115	AN919-6J	THRU 31294) (REPLACED BY AN919-6J)	2	NP	
115	AS5174J0604	AS5174J0604)	2	SP	
115A	AN814-6J	THRU 31294) (REPLACES AN919-6J)	2	NP	
115A	AS5169J06	THRU 31294) (REPLACED BY AS5169J06)	2	SP	
116	AN938S6	THRU 31294) (REPLACES AN814-6J)	2	NP	
116	AN938J6	AN938J6)	2	SP	
116	AS5192J06	AN938S6) (REPLACED BY AS5192J06)	2	SP	
117	MS29512-06	AN938J6)PACKING, PREFORMED	6	SP	
118	NAS679A3	. NUT (REPLACED BY MS21042L3)	1	NP	
118	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	1	SP	
119	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	1	Р	
119	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (RÉPLACED BY NAS1149D0316J)	1	Р	
119	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	1	SP	
120	MS27039-1-08	SCREW	1	SP	
121	MS21919WDG4	. CLAMP	1	SP	
122	MS21919WDG16	. CLAMP	1	SP	
123	MS21042L3	. NUT, SELF-LOCKING	1	SP	
124	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	1	Р	
124	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY	1	Р	
404	NIA 044 40 D004 6 I	NAS1149D0316J)	١,	0.0	
124	NAS1149D0316J	. WASHER (REPLACÉS AN960JD10LL)	1	SP	
125 126	MS27039-1-12 NAS43DD3-32	SCREW	1	SP P	
126	NAS43DD3-32 NAS43DD3-32N	SPACER (REPLACED BY NAS43DD3-32N)	1	SP	
126	MS21919DG4	SPACER (REPLACES NAS43DD3-32)	1	NP	
127	MS21919DG4	CLAMP (REPLACED BY MS21919WDG4)		SP	
128	AN815-4	UNION (REPLACES MS21919DG4)	2	NP	
128	AN815-4J	UNION (REPLACED BY ANS15-4)	2	SP	
128	AS5174J0404	UNION (REPLACES ANS15-4) (REFEACED BY ASS17430404)	2	SP	
129	NAS679A3	NUT (REPLACED BY MS21042L3)	2	NP	
129	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP	
130	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	2	P	
130	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	2	SP	
131	MS27039-1-08	SCREW	2	SP	
132	MS21919WDG4	. CLAMP	2	SP	
133	212-062-013-001	. TUBE ASSY, LH	1	SP	
134	212-061-642-001	. TUBE ASSY, RH	1	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-1. Power Plant Installation (Cont'd)			
135 136 137 138 138 139 140 140 141	212-060-639-001 212-061-638-001 MS27039C1-08 AN960C10L NAS1149C0332R AN893-4D 67121-65-225 67121-65-239 NAS617-12 M83248/1-912	. TUBE ASSY, LH	1 1 24 24 24 1 1 1 1	SP SP SP SP NP SP SP SP	
141 142 142	AS3208-12 NAS617-4 M83248/1-904	AS3208-12)	1 1 1	SP P SP	
142 143 143 144 144	AS3208-04 NAS679A3 MS21042L3 AN960PD10L AN960JD10LL	AS3208-04)	1 1 1 1	SP NP SP P	
144 145 146 146 147 148 149	NAS1149D0316J MS27039-1-23 NAS43DD3-64 NAS43DD3-64N MS21919WDG15 MS27039-1-09 AN960PD10L AN960JD10LL	WASHER (REPLACES AN960JD10LL) SCREW SPACER (REPLACED BY NAS43DD3-64N) SPACER (REPLACES NAS43DD3-64) CLAMP SCREW WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACES AN960PD10L) (REPLACED BY	1 1 1 2 4 4	SP SP SP SP P P	
149 150	NAS1149D0316J 212-062-502-005	NAS1149D0316J)	4 1	SP NP	
150 151 152 153 153	212-062-504-001 M25988/1-222 MS21042L3 AN960PD10L AN960JD10LL	BY 212-062-504-001) CAP AND ADAPTER ASSY (REPLACES 212-062-502-005) PACKING, PREFORMED NUT, SELF-LOCKING WASHER (REPLACED BY AN960JD10LL) . WASHER (REPLACES AN960PD10L) (REPLACED BY	1 1 2 2 2	SP SP SP P	
153 154 155 156 157 158 158	NAS1149D0316J MS27039-1-08 MS21919WDG7 MS21919WDG15 MS21042L3 AN960PD10L AN960JD10LL	NAS1149D0316J) WASHER (REPLACES AN960JD10LL) SCREW CLAMP CLAMP NUT, SELF-LOCKING WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACES AN960PD10L) (REPLACED BY	2 2 2 2 1 1	SP SP SP SP P	
158 159 160 161 161 162 162 163 163A 164	NAS1149D0316J MS27039-1-08 MS21919WDG7 70-010L000A240 70-061L000A240A 70-010F180Z444 70-061F180Z444A 212-062-503-001 4017-16 NAS617-20 M83248/1-920	NAS1149D0316J) WASHER (REPLACES AN960JD10LL) SCREW CLAMP HOSE ASSY (REPLACED BY 70-061L000A240A) HOSE ASSY (REPLACES 70-010L000A240) HOSE ASSY (REPLACED BY 70-061F180Z444A) HOSE ASSY (REPLACES 70-010F180Z444A) VALVE SEAL PACKING, PREFORMED (REPLACED BY M83248/1-920) PACKING, PREFORMED (REPLACES NAS617-20) (REPLACED BY AS3208-20)	1 1 2 1 1 1 1 1 1	SP S	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-1. Power Plant Installation (Cont'd)			
164	A\$3208-20	. PACKING, PREFORMED (REPLACES M83248/1-920)	1	SP	
165	MS21042L3	. NUT, SELF-LOCKING	1	SP	
166 166	AN960PD10L AN960JD10LL	. WASHER (REPLACED BY AN960JD10LL)	1 1	P P	
166	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	1	SP	
167	MS27039-1-08	. SCREW	1	SP	
168	MS21919WDG7	. CLAMP	1	SP	
169	MS21919WDG16	. CLAMP	1	SP	
170 171	MS21043-3 AN960PD10L	. NUT (S/N 30504 THRU 30530)	8 8	SP P	
171	AN960JD10LL	. WASHER (S/N 30504 THRU 30530) (REPLACED BY AN960JD10LL) . WASHER (REPLACES AN960PD10L) (REPLACED BY	8	P	
171	NAS1149D0316J	NAS1149D0316J)	8	SP	
172	MS27039-1-08	SCREW (S/N 30504 THRU 30530)	8	SP	
173	212-060-821-001	. COVER (S/N 30504 THRU 30530)	1	SP	
174	209-062-533-001	. FITTING, RH (S/N 30554 THRU 31311, 35001 THRU SUB)	1	P	
174	212-062-507-001	. FITTING, LH (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACED BY 212-062-507-007)	1	NP	
174	212-062-507-007	. FITTING, LH (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACES 212-062-507-001)	1	SP	
175	209-062-540-001	GASKET (S/N 30554 THRU 31311, 35001 THRU SUB)	2	SP	
176	70-009L000V210	. HOSE ASSY (S/N 30554 THRU 31311, 35001 THRU SUB)	2	NP	
176	70-009L000V210A	(REPLACED BY 70-009L000V210A)	2	SP	
177	AN924-12	(REPLACES 70-009L000V210)	2	NP	
177	AS5178-12	AS5178-12)	2	SP	
178	AN960-1716L	. WASHER (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACED	4	P	
178	NAS1149F1732P	BY NAS1149F1732P)	4	SP	
179	AN833-12	ELBOW (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACED BY AN833-12J)	2	NP	
179	AN833-12J	. ELBOW (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACES	2	SP	
179	AS1038J1212	AN833-12) (REPLACED BY AS1038J1212)	2	SP	
180	212-062-505-001	. TUBE ASSY (S/N 30554 THRU 31311, 35001 THRU SUB)	2	SP	
181	AN924-12	. NUT (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACED BY AS5178-12)	2	NP	
181	AS5178-12	NUT (REPLACES AN924-12)	2	SP	
182	AN960-1716L	. WASHER (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACED	4	P	
182	NAS1149F1732P	BY NAS1149F1732P)	4	SP	
183	AN832-12	AN960-1716L)	2	NP	
183	AN832-12J	BY AN832-12J)	2	SP	
184	MS21042L3	. NUT, SELF-LOCKING (S/N 30554 THRU 31311, 35001 THRU SUB)	1	SP	
185	AN960PD10L	. WASHER (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACED	1	Р	
185	AN960JD10LL	BY AN960JD10LL)	1	Р	
185	NAS1149D0316J	NAS1149D0316J)	1	SP	
186	MS35207-264	. WASHER (REPLACES AN960JD10LL)	1	SP	
187	MS21919WDG9	. CLAMP (S/N 30554 THRU 31311, 35001 THRU SUB)	1	SP	
188	MS21919WDG15	. CLAMP (S/N 30554 THRU 31311, 35001 THRU SUB)	i i	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	4 > 4 _ L	U O C
		Figure 71-1. Power Plant Installation (Cont'd)			
189	70-009L000A154	. HOSE ASSY (S/N 30554 THRU 31311, 35001 THRU SUB)	2	NP	
189	70-009L000A154A	(REPLACED BY 70-009L000A154A)	2	SP	
190 191	212-062-506-001 AN960-1716L	(REPLACES 70-009L000A154)	2 4	SP P	
191	NAS1149F1732P	BY NAS1149F1732P)	4	SP	
192 193	MS9201-12 AN815-12D	AN960-1716L)	1 2	SP SP	
193 193 194 195 196 197	AS5174D1212 AS5174W1212 209-062-534-003 AN939D12 MS21042L3 AN960PD10L	BY AS5174D1212)	2 2 2 2 1 1	SP SP SP NP SP P	
197	AN960JD10LL	BY AN960JD10LL)	1	Р	
197 198 199 200 201 202	NAS1149D0316J MS35207-264 MS21919WDG9 MS21919WDG15 MS21042L3 AN960PD10L	NAS1149D0316J)	1 1 1 1 1	SP SP SP SP P	
202	AN960JD10LL	BY AN960JD10LL)	1	Р	
202 203 204 205 206	NAS1149D0316J MS35207-264 AN743-12 MS21919WDG9 70-010H000V300	NAS1149D0316J)	1 1 1 1 1	SP SP SP SP NP	
206	70-061H000V300A 212-061-032-001	. HOSE ASSY (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACES 70-010H000V300)	1	SP SP	
208	AN960-916L NAS1149F0932P	. WASHER (S/N 30554 THRU 31311, 35001 THRU SUB) (REPLACED BY NAS1149F0932P)	2	NP SP	
209 210 211	209-062-534-001 NAS424-6 MS29512-06	AN960-916L)	1 2 4	SP SP SP	
212	MS21919WDG9	SUB)	4	SP	
212	MS21919WDG7	BY MS21919WDG7)	5	SP	
212A 213 214 214A 215	MS21919WDG8 70-061F000D280A 70-061F000D244A 70-061F000D100A AN924-4J	MS21919WDG9) . CLAMP (S/N 35081 THRU 35103)	2 1 1 2 2 2	SP SP SP SP	
215	AS5178J04	. NUT (REPLACES AN924-4J)	2	SP	ł



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-1. Power Plant Installation (Cont'd)			
216	AN960JD716	. WASHER (S/N 31295 THRU 31311, 35001 THRU SUB) (REPLACED	4	Р	
216	NAS1149D0763J	BY NAS1149D0763J)	4	SP	
217 218	AN833-4J AN924-4J	AN960JD716)	2 2	SP SP	
218 219	AS5178J04 AN960JD716L	NUT (REPLACES AN924-4J) WASHER (S/N 31295 THRU 31311, 35001 THRU SUB) (REPLACED BY NAS1149D0716J)	2 2	SP SP	
219	NAS1149D0716J	. WASHER (S/N 31295 THRU 31311, 35001 THRU SUB) (REPLACES AN960JD716L)	2	SP	
220	AN960JD716	. WASHER (S/N 31295 THRU 31311, 35001 THRU SUB) (REPLACED	2	Р	
220	NAS1149D0763J	BY NAS1149D0763J)	2	SP	
221	AN833-4J	AN960JD716)	2	SP	
		HYDRAFLOW. FOR SEALING THE BLEED AIR TUBES 212-060-004-001, 212-060-009-001, WIGGINS USES ONE PACKING AND TWO WASHERS AND HYDRAFLOW USES ONE PACKING AND ONE WASHER. REFER TO FIGURE AND PART LIST FOR APPLICABLE PART NUMBERS. AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			





Figure 71-2. Power Plant Installation (Sheet 1 of 2)

71-99-00 Page 14

Rev. 8 30 APR 2010





POST TB 212-01-187

212_IPB_71_0002b

Figure 71-2. Power Plant Installation (Sheet 2 of 2)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-2. Power Plant Installation			
	212-062-001-001	POWER PLANT INSTL (S/N 30504 THRU 30530) (SEE FIG. 71-1,	REF	NP	
	212-062-001-005	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-007	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
		71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)			
	212-062-001-011	POWER PLANT INSTL (S/N 30579 THRU 30596) (SEE FIG. 71-1, 71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-009	POWER PLANT INSTL (S/N 30597 THRU 30603, 30611 THRU 30614) (SEE FIG. 71-1, 71-3, 71-4, 71-5 FOR BALANCE OF	REF	NP	
	212-062-001-013	BREAKDOWN)	REF	NP	
	212-062-001-015	POWER PLANT INSTL (S/N 30615 THRU 30729) (SEE FIG. 71-1,	REF	NP	
	212-062-001-023	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-027	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 30850 THRU 31124, 32101 THRU 32142) (SEE FIG. 71-1, 71-3, 71-4, 71-5 FOR BALANCE OF	REF	NP	
	212-062-001-101	BREAKDOWN)	REF	NP	
	212-062-001-103	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 31282 THRU 31294) (SEE FIG. 71-1,	REF	NP	
	212-062-001-115	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 31295 THRU 31311, 35001 THRU 35068) (SEE FIG. 71-1, 71-3, 71-4, 71-5 FOR BALANCE OF	REF	NP	
	212-062-001-119	BREAKDOWN)	REF	NP	
	212-062-001-123	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-125	71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 35102 THRU 35103) (SEE FIG. 71-1, 71-3, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
1	212-060-779-001	SPRING	1	SP	
2	212-060-780-001	. CLIP (S/N 30504 THRU 31281) (REPLACED BY 212-060-780-101)	1	NP	1
2	212-060-780-101	. CLIP (REPLACES 212-060-780-001)	1	SP	1
	33-001-219-1	. SUPPORT INSTL (S/N 31125 THRU 31311, 35001 THRU 35103) .	1	NP	1
3	MS21042L3	NUT, SELF-LOCKING	1	SP	
4	AN960JD10L	WASHER, FLAT (REPLACED BY NAS1149D0332J)	1	Р	1
4	NAS1149D0332J	WASHER, FLAT (REPLACES AN960JD10L)	1	SP	ł
5	MS27039-1-08	SCREW	1	SP	
6	MS21919WDG7	. CLAMP (S/N 31125 THRU 31311, 35001 THRU 35103)	2	SP	1
7 8	MS21919WDG7	. CLAMP (S/N 31125 THRU 31311, 35001 THRU 35103)	1	SP SP	
	MS21919WDG15	. CLAMP (S/N 31125 THRU 31311, 35001 THRU 35103)	_		ł
9 10	MS21042L3 AN960PD10L	NUT, SELF-LOCKING (S/N 31125 THRU 31311, 35001 THRU 35103) WASHER (S/N 31125 THRU 31311, 35001 THRU SUB) (REPLACED BY AN960JD10LL)	3	SP P	
10	AN960JD10LL	. WASHER (S/N 31125 THRU 31311, 35001 THRU SUB) (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	3	Р	
10	NAS1149D0316J	. WASHER (S/N 31125 THRU 31311, 35001 THRU SUB) (REPLACES AN960JD10LL)	3	SP	
11	MS27039-1-09	. SCREW (S/N 31125 THRU 31311, 35001 THRU 35103)	1	SP	
12	MS27039-1-06	SCREW	2	SP	
13	MS21919DG2	. CLAMP (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACED BY MS21919WDG2)	1	NP	
13	MS21919WDG2	. CLAMP (S/N 31125 THRU 31311, 35001 THRU SUB) (REPLACES MS21919DG2)	1	SP	
	i				



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-2. Power Plant Installation (Cont'd)			
14 15 16	MS21919WDG7 MS21919WCH4 70-061F000Y424	. CLAMP (S/N 31125 THRU 31311, 35001 THRU 35103)	4 2 1	SP SP NP	
16	70-061F000Y424A	(REPLACED BY 70-061F000Y424A)	1	SP	
17	70-061F000Y370	(REPLACES 70-061F000Y424)	1	NP	
17	70-061F000Y370A	. HOSE ASSY (S/N 31125 THRU 31311, 35001 THRU 35103)	1	SP	
18 19	204-060-670-001 NAS617-12	(REPLACES 70-061F000Y370)	2	SP P	
19	M83248/1-912	35103) (REPLACED BY M83248/1-912)	1	SP	
19	AS3208-12	. PACKING, PREFORMED (S/N 31125 THRU 31311, 35001 THRU	1	SP	
20 21	AN893-4D NAS617-4	35103) (REPLACES M83248/1-912)	1	NP P	
21	M83248/1-904	35103) (REPLACED BY M83248/1-904)	1	SP	
21	AS3208-04	. PACKING, PREFORMED (S/N 31125 THRU 31311, 35001 THRU	1	SP	
22	AN815-4	35103) (REPLACES M83248/1-904)	1	NP	
22	AN815-4J	. UNION (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACES	1	SP	
22	AS5174J0404	AN815-4) (REPLACED BY AS5174J0404)	1	SP	
23	NAS617-4	. PACKING, PREFORMED (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACED BY M83248/1-904)	1	Р	
23	M83248/1-904	. PACKING, PREFORMED (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACES NAS617-4) (REPLACED BY AS3208-04) .	1	SP	
23	AS3208-04	. PACKING, PREFORMED (S/N 31125 THRU 31311, 35001 THRÚ 35103) (REPLACES M83248/1-904)	1	SP	
24	AN815-4	. UNION (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACED BY AN815-4J)	1	NP	
24	AN815-4J	. UNION (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACES AN815-4) (REPLACED BY AS5174J0404)	1	SP	
24	AS5174J0404	. UNION (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACES AN815-4J)	1	SP	
25	MS29512-04	PACKING, PREFORMED (S/N 31125 THRU 31311, 35001 THRU 35103)	1	SP	
26	AN924-4C	NUT (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACED BY AN924-4J)	1	NP	
26	AN924-4J	NUT (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACES AN924-4C) (REPLACED BY AS5178J04)	1	SP	
26	AS5178J04	NUT (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACES AN924-4J)	1	SP	
27 28	AN833-4J MS29512-04	. ELBOW (S/N 31125 THRU 31311, 35001 THRU 35103)	1 2	SP SP	
29	AN924-12C	35103)	1	NP	
29	AN924-12J	. NUT (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACES AN924-12C) (REPLACED BY AS5178J12)	1	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-2. Power Plant Installation (Cont'd)			
29	AS5178J12	. NUT (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACES	1	SP	
30	AN960C1716	AN924-12J)	1	Р	
30	NAS1149C1790R	(REPLACED BY NAS1149C1790R)	1	SP	
31	412-075-205-101	(REPLACES AN960C1716)	2	Р	
32 33	MS21042L3 AN960PD10L	. NUT, SELF-LOCKING (S/N 31125 THRU 31311, 35001 THRU 35103) . WASHER (S/N 31125 THRU 31311, 35001 THRU 35103)	8 8	SP P	
33	AN960JD10LL	(REPLACED BY AN960JD10LL)	8	Р	
33	NAS1149D0316J	(REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J) . WASHER (S/N 31125 THRU 31311, 35001 THRU 35103) (REPLACES AN960JD10LL)	8	SP	
34 35	NAS6203-2 205-061-686-001	. BOLT (S/N 31125 THRU 31311, 35001 THRU 35103)	8 2	SP NP	
36 37 38	205-061-686-101 MS21074-3K 800-0001	35103)	2 4 2	NP SP P	
39 40 41 42 43 43 43 44 45 46 47 48	102-0075D 24-0001-2 201-0001 MS21042L3 AN960PD10 AN960JD10 NAS1149D0363J AN3-4A MS21042L3 AN960JD10L MS27039-1-09 MS21919WDG3	212-01-187) (REPLACES 412-075-205-101) TRANSDUCER, PRESSURE (POST TB 212-01-187) CABLE, INTERFACE (POST TB 212-01-187) TORQUE CONVERTER (POST TB 212-01-187) NUT, SELF-LOCKING (POST TB 212-01-187) WASHER (POST TB 212-01-187) (REPLACED BY AN960JD10) WASHER (POST TB 212-01-187) (REPLACES AN960PD10) (REPLACED BY NAS1149D0363J) WASHER (POST TB 212-01-187) (REPLACES AN960JD10) BOLT (POST TB 212-01-187) NUT, SELF-LOCKING WASHER, FLAT SCREW CLAMP	1 1 1 4 8 8 8 4 REF REF REF	P SP SP SP SP SP SP SP SP	
49	MS21919WDG8	AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.	REF	SP	






Figure 71-3. Firewall Assembly and Power Plant Installation

212_IPB_71_0003

71-99-00 Page 20

Rev. 8 30 APR 2010



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-3. Firewall Assembly and Power Plant Installation			
	212-060-900-181	FIREWALL ASSY, FWD (S/N 30504 THRU 30596, 30604 THRU 30610) (SEE FIG. 71-1 FOR NHA)	REF	Р	
	212-060-900-287	FIREWALL ASSY, FWD (S/N 30597 THRU 30603, 30611 THRU 31311, 35001 THRU 35037) (SEE FIG. 71-1 FOR NHA)	REF	NP	
	212-060-900-299	FIREWALL ASSY, FWD (S/N 31312 THRU SUB, 35038 THRU SUB) (SEE FIG. 71-1 FOR NHA)	REF	SP	
1	MS27039-1-05	SCREW	8	SP	
2	212-060-900-195	. FIREWALL ASSY (S/N 30504 THRU 30596, 30604 THRU 30610) .	1	P	
2	212-060-900-289	. FIREWALL ASSY (S/N 30597 THRU 30603, 30611 THRU 31311,	1	NP	
_	212 000 000 200	35001 THRU 35037)			
2	212-060-900-303	FIREWALL ASSY (S/N 35038 THRU SUB)	1	Р	
3	212-060-900-077	GASKET		SP	
4	212-060-900-079	GASKET		SP	
5	212-060-900-081	GASKET		SP	
3	212-060-900-183	FIREWALL ASSY, UPPER FORWARD, LH (S/N 30504 THRU 31311,	1	NP	
	212 000 000 100	35001 THRU 35040, 35046 THRU 35051) (SEE FIG. 71-11 FOR	'	141	
	0.4.0.000.000.004	NHA) (REPLACED BY 212-060-900-301)		0.0	
	212-060-900-301	FIREWALL ASSY, UPPER FORWARD, LH (S/N 35041 THRU 35045,	1	SP	
		35052 THRU SUB) (SEE FIG. 71-11 FOR NHA) (REPLACES			
		212-060-900-183)			
	212-060-900-184	FIREWALL ASSY, UPPER FORWARD, RH (S/N 30504 THRU 31311,	1	NP	
		35001 THRU 35040, 35046 THRU 35051) (SEE FIG. 71-11 FOR			
		NHA) (REPLACED BY 212-060-900-302)			
	212-060-900-302	FIREWALL ASSY, UPPER FORWARD, RH (S/N 35041 THRU 35045,	1	SP	
	: : :	35052 THRU SUB) (SEE FIG. 71-11 FOR NHA) (REPLACES			
6	212-060-900-237	212-060-900-184)	1	SP	
7	120-104-1-0600		1	NP	
8	212-060-900-247	SEAL (MAKE EDOM 120 104 1)	1	SP	
8	120-104-1	SEAL (MAKE FROM 120-104-1)	AR	SP	
8A	212-060-900-235	SEAL (38.0 INCHES)	1	SP	
8A	212-060-900-233	RETAINER, LH (USBL ON 212-060-900-183)		SP	
_		RETAINER. LH (USBL ON 212-060-900-301)		SP	
8A	212-060-900-236	RETAINER, RH (USBL ON 212-060-900-184)	1	P	
8A 9	212-060-900-310	. RETAINER, RH (USBL ON 212-060-900-302)	1	NP	
-	120-104-1-0600	. SEAL (MAKE FROM 120-104-1)			
9	120-104-1	SEAL (6.0 INCHES)	AR	SP	
10	120-104-1-0600	. SEAL (MAKE FROM 120-104-1)	1	NP	
10	120-104-1	SEAL (6.0 INCHES)	AR	SP	
11	120-104-1-0600	. SEAL (MAKE FROM 120-104-1)	1	NP	
11	120-104-1 120-104-1-0600	SEAL (6.0 INCHES)	AR	SP	
12		. SEAL (MAKE FROM 120-104-1)	1	NP	
12	120-104-1 MS24042L08	SEAL (6.0 INCHES)	AR	SP	
13	MS21042L08	NUT	6	SP	
14	AN960-8L	. WASHER (REPLACED BY NAS1149FN816P)	6	NP	
14	NAS1149FN816P	. WASHER (REPLACES AN960-8L)	6	SP	
15 15	MS24693C49 MS24693-C49	SCREW (REPLACED BY MS24693-C49)	6 6	NP SP	
16	212-060-900-263	SCREW (REPLACES MS24693C49)	1	SP	
17	212-060-900-263	STRIP, LH		SP	
18	MS21052-3K	STRIP, RH	2	SP	
		NUTPLATE			
19	MS21048-3K	NUTPLATE (REPLACED BY NAS1770C3K)	15	NP SP	
19 20	NAS1770C3K MS21061L3K	NUTPLATE (REPLACES MS21048-3K)	15	SP	
_ ∠∪		NUTPLATE	1		
	212-061-902-161	FIREWALL ASSY, AFT (S/N 30504 THRU 30530) (SEE FIG. 71-1 FOR	REF	NP	
		NHA) (REPLACED BY 212-061-902-171, -177, -187, -203 AND			
		-207)			

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-3. Firewall Assembly and Power Plant Installation (Cont'd)			
	212-061-902-171	FIREWALL ASSY, AFT (S/N 30504 THRU 30553) (SEE FIG. 71-1 FOR NHA) (REPLACES 212-061-902-161) (REPLACED BY	REF	NP	
	212-061-902-177	212-061-902-177, -187, -203 AND -207)	REF	Р	
	212-061-902-187	212-061-902-187, -203 AND -207)	REF	NP	
	212-061-902-203	AND -177) (REPLACED BY 212-061-902-203 AND -207) FIREWALL ASSY, AFT (S/N 30504 THRU 31311, 35001 THRU 35065) (SEE FIG. 71-1 FOR NHA) (REPLACES 212-061-902-161, -171,	REF	Р	
	212-061-902-207	-177 AND -187) (REPLACED BY 212-061-902-207) FIREWALL ASSY, AFT (S/N 35066 THRU 35096) (SEE FIG. 71-1 FOR	REF	Р	
	212-061-902-217	NHA) (REPLACES 212-061-902-161, -171, -177, -187 AND -203) FIREWALL ASSY, AFT (S/N 35097 THRU 35103) (SEE FIG. 71-1 FOR NHA)	REF	SP	
	212-061-902-233	FIREWALL ASSY, AFT (S/N 35104 THRU SUB) (SEE FIG. 71-1 FOR NHA)	REF	Р	
21 21 22 23 23 24 25 26 26	MS24694C48 MS24694-C48 MS27039C1-09 AN960C10L NAS1149C0332R MS27039-1-06 MS27039-1-07 AN960PD10L AN960JD10LL	NHA) . SCREW (REPLACED BY MS24694-C48) . SCREW (REPLACES MS24694C48) . SCREW . WASHER (REPLACED BY NAS1149C0332R) . WASHER (REPLACES AN960C10L) . SCREW . SCREW . WASHER, FLAT (REPLACED BY AN960JD10LL) . WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY	4 4 6 6 6 4 12 22 22	PPSPSPSPP	
26 27 28 28 29 30 30 31 32 33 34 35 36 37 38	NAS1149D0332J MS27039C1-08 AN960C10L NAS1149C0332R MS27039C1-10 AN960C10L NAS1149C0332R 212-061-902-007 212-061-902-008 212-061-902-008 212-061-902-010 212-061-902-113 212-061-902-114 212-061-902-114 212-061-902-011 212-061-902-011 212-061-902-015 212-061-902-173	NAS1149D0332J). WASHER, FLAT (REPLACES AN960JD10LL). SCREW. WASHER (REPLACED BY NAS1149C0332R). WASHER (REPLACES AN960C10L). SCREW. WASHER (REPLACED BY NAS1149C0332R). WASHER (REPLACES AN960C10L). STIFFENER ASSY, LH. STIFFENER ASSY, LH. STIFFENER ASSY, RH. STIFFENER ASSY, RH. STIFFENER ASSY, RH. STIFFENER ASSY, LH. STIFFENER ASSY, LH. STIFFENER ASSY, LH. STIFFENER ASSY, RH. SEAL ASSY, LH. SEAL ASSY, CH. SPLICE ASSY. FIREWALL ASSY (USBL ON 212-061-902-161). FIREWALL ASSY (USBL ON 212-061-902-171, -177, -187, -203 AND	22 36 36 36 4 4 1 1 1 1 1 1	\$\$P\$\$P\$\$P\$\$\$\$\$P\$ PP	
38 39	212-061-902-223 212-061-902-006	-207) (REPLACES 212-061-902-005)	1	P P	
39	212-061-902-174	212-061-902-174)	1	Р	
39	212-061-902-224	. FIREWÁLL ASSY (USBL ON 212-061-902-217 AND -233)	1	Р	
40	212-061-902-073	SEAL (MAKE FROM 120-104-7)	1	SP	
40 41	120-104-7 212-061-902-081	SEAL	1 2	SP SP	
41	MS27039C1-08	SEAL	2	SP	
43	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	2	Р	
43	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	2	SP	




INDEX NUMBER					
	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-3. Firewall Assembly and Power Plant Installation (Cont'd)			
44	MS21060-3K	. NUTPLATE	2	SP	
	212-061-902-013	. FIREWALL ASSY	1	NP	
	MS27039-1-11	. SCREW	4	SP	
47 48	204-060-927-001 MS21047-3	WASHER	4	SP P	
-	MS21047-3 MS21047L3	NUTPLATE (REPLACED BY MS21047L3)	4	SP	
	NAS1770-3	NUTPLATE (REPLACES MS21047-3) (REPLACED BY NAST770-3)	4	SP	
	MS27039-1-10	SCREW	16	SP	
	AN960PD10L	. WASHER, FLAT (REPLACED BY AN960JD10LL)	16	Р	
50	AN960JD10LL	. WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY NAS1149D0332J)	16	Р	
50	NAS1149D0332J	. WASHER, FLAT (REPLACES AN960JD10LL)	16	SP	
	MS21059-3	. NUTPLATE (REPLACED BY MS21059L3)	16	Р	
	MS21059L3	. NUTPLATE (REPLACES MS21059-3)	16	SP	
	MS27039-1-08 MS21059-3K	SCREW	8 o	SP NP	
	MS21059-3K MS21059L3K	NUTPLATE (REPLACED BY MS21059L3K)	8 8	NP SP	
54	MS17160-25	CLIP (REPLACED BY M24066/2-325)	2	NP	
54	M24066/2-325	. CLIP (REPLACES MS17160-25)	2	SP	
55	212-061-902-179	. FIREWALL ASSY, AFT (S/N 30504 THRU 31124)	1	Р	
55	212-061-902-185	. FIREWALL ASSY, AFT (S/N 31125 THRU 31311, 35001 THRU	1	Р	
55	212-061-902-201	35037)	1	Р	
55	212-061-902-205	. FIREWALL ASSY, AFT (S/N 35066 THRU 35096)	1	Р	
55	212-061-902-221	. FIREWALL ASSY, AFT (S/N 35097 THRU 35103)	1	NP	
	212-061-902-235	. FIREWALL ASSY, AFT (S/N 35104 THRU SUB)	1	Р	
	212-061-902-035	CAP, LH	1	NP	
55B 56	212-061-902-036 212-061-902-059	CAP, RH	1 2	NP SP	
57	212-061-902-061	SEAL	2	SP	
58	212-061-902-147	SEAL	4	SP	
	212-061-902-055	SEAL (S/N 30504 THRU 31311, 35001 THRU 35037)	1	SP	
59	212-061-902-189	SEAL (S/N 35038 THRU SUB)	1	SP	
60	212-061-902-111	SEAL	1	SP	
61	212-060-906-003	FITTING, LH (S/N 30504 THRU 31311, 35001 THRU 35080)	1	SP	
61 62	412-061-003-101 212-060-907-001	FITTING, LH (S/N 35081 THRU SUB)	1	P SP	
63	212-060-907-001	FITTING, RH (S/N 30504 THRU 31311, 35001 THRU 35080)	1	SP	
	412-061-003-102	FITTING, RH (S/N 35081 THRU SUB)	1	P	
64	212-060-907-002	PLATE	1	SP	
	212-060-908-001	FITTING	4	SP	
66	50-008RF2	RECEPTACLE	7	SP	
67	MS21059L3	NUTPLATE	7	SP	
68 69	212-061-902-057 212-061-902-058	RETAINER, LH	1	SP P	
	212-061-902-056	RETAINER, RH	1	SP	
71	212-061-902-076	CLIP, RH	1	SP	
72	212-061-902-155	CLIP, LH	1	SP	
73	212-061-902-156	CLIP, RH	1	SP	
74	212-061-902-183	BRACKET, LH	1	NP	
75 70	212-061-902-184	BRACKET, RH	1	NP	
76 77	212-061-902-181	BRACKET, LH	1	NP	
77	212-061-902-182 212-062-001-001	BRACKET, RH	REF	NP NP	
		POWER PLANT INSTL (S/N 30504 THRU 30530) (SEE FIG. 71-1, 71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)			
	212-062-001-005	POWER PLANT INSTL (S/N 30531 THRU 30553) (SEE FIG. 71-1, 71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-3. Firewall Assembly and Power Plant Installation (Cont'd)			
	212-062-001-007	POWER PLANT INSTL (S/N 30554 THRU 30578) (SEE FIG. 71-1,	REF	NP	
	212-062-001-011	71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-009	71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-013	POWER PLANT INSTL (S/N 30604 THRU 30610) (SEE FIG. 71-1,	REF	NP	
	212-062-001-015	71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-023	71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-027	71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-101	71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-103	71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-115	71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-119	POWER PLANT INSTL (S/N 35069 THRU 35080) (SEE FIG. 71-1,	REF	NP	
	212-062-001-123	71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-125	POWER PLANT INSTL (S/N 35102 THRU SUB) (SEE FIG. 71-1, 71-2, 71-4, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
78 79 80 81 82 83	MS27039C1-08 MS27039C1-06 MS27039C1-12 MS27039C1-10 AN3C-4A AN960C10L NAS1149C0332R	SCREW	22 15 4 1 2 44 44	SP SP SP SP NP P SP	
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			





212_IPB_71_0004

Figure 71-4. Firewall Assembly, Centerline



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	4 > 4 _ L	500
		Figure 71-4. Firewall Assembly, Centerline			
	212-061-903-003	FIREWALL ASSY, CENTERLINE (S/N 30504 THRU 30530) (SEE FIG.	REF	NP	
	212-061-903-141	71-1 FOR NHA) (REPLACED BY 212-061-903-141, -151 AND -175) FIREWALL ASSY, CENTERLINE (S/N 30504 THRU 30877) (SEE FIG. 71-1 FOR NHA) (REPLACES 212-061-903-003) (REPLACED BY 212-061-903-151 AND -175)	REF	NP	
	212-061-903-151	FIREWALL ASSY, CENTERLINE (S/N 30878 THRU 31311, 35001 THRU 35037, 35039 THRU 35040) (SEE FIG. 71-1 FOR NHA) (REPLACES 212-061-903-003 AND -141) (REPLACED BY 212-061-903-175)	REF	NP	
	212-061-903-175	FIREWALL ASSY, CENTERLINE (S/N 31312 THRU SUB, 35038, 35041 THRU SUB) (SEE FIG. 71-1 FOR NHA) (REPLACES 212-061-903-003, -141 AND -151)	REF	Р	
1	MS27039C1-06	SCREW	23	SP	
2 3	NAS1149C0332R 212-061-903-013	. WASHER (S/N 31312 THRU SUB, 35091 THRU SUB)	23 1	SP NP	
3	212-061-903-159	212-061-903-159)	1	SP	
	040 004 000 405	(REPLACES 212-061-903-013)		0.0	
3 4	212-061-903-185 212-061-903-117	. COVER ASSY, FWD (S/N 31312 THRU SUB, 35038 THRU SUB) .	1 2	SP SP	
5	212-061-903-117	GASKET	1	SP	
6	212-061-903-115	GASKETGASKET	1	SP	
7	212-061-903-123	GASKET		SP	
8	212-061-903-123	PLATE	1	SP	
9	MS21052-3K	NUTPLATE	2	SP	
10	MS21074-3K	NUTPLATE (S/N 30504 THRU 31311, 35001 THRU 35037)	6	SP	
10	MS21070-3K	NUTPLATE (S/N 30304 THRO 31311, 35007 THRO 35037)	6	SP	
11	NAS1149C0332R	. WASHER (S/N 31312 THRU SUB, 35091 THRU SUB)	6	SP	
12	MS27039C1-06	SCREW	6	SP	
13	212-061-903-011	. COVER ASSY (S/N 30504 THRU 31311, 35001 THRU 35037)	1	SP	
14	212-061-903-009	. COVER ASSY, LOWER (S/N 31312 THRU SUB, 35038 THRU SUB)	1	Р	
15	212-061-903-075	GASKET (S/N 30504 THRU SUB, 35001 THRU SUB)	1	SP	
16	212-061-903-079	GASKET (S/N 30504 THRU 31311, 35001 THRU 35040)	1	SP	
17	MS21074-3K	NUTPLATE (S/N 30504 THRU 31311, 35001 THRU 35040)	2	SP	
18	MS21048-3K	NUTPLATE (S/N 31312 THRU SUB, 35038 THRU SUB) (REPLACED BY NAS1770C3K)	4	NP	
18	NAS1770C3K	NÚTPLATE (S/N 31312 THRU SÚB, 35038 THRU SUB) (REPLACES MS21048-3K)	4	SP	
19	212-061-903-007	. WEB ASSY, UPPER (S/N 30504 THRU 31311, 35001 THRU 35037)	1	Р	
19	212-061-903-177	. WEB ASSY, UPPER (S/N 35038 THRU 35101) (REPLACED BY 212-061-903-199)	1	NP	
19	212-061-903-199	. WEB ASSY, UPPER (S/N 35102 THRU 35103) (REPLACES 212-061-903-177)	1	NP	
20	212-061-903-077	GASKET	2	SP	
21	212-061-903-127	GASKET	1	SP	
22	212-061-903-129	GASKET	1	SP	
23	212-061-903-119	GASKET	1	SP	
24	212-061-903-051	SEAL	1	Р	
25	212-061-903-052	SEAL	1	SP	
26	RF3 1-2	RECEPTACLE (REPLACED BY 50-008RF2)	12	NP SP	
26 27	50-008RF2 MS21060-3K	RECEPTACLE (REPLACES RF3 1-2)	12 16	SP	
28	MS21060-3K MS21052-3K	NUTPLATE	2	SP	
28 29	MS21052-3K MS21053-L3K	NUTPLATE	2	NP	
30	MS24694-C48	NUTPLATE	2	SP	
31	MS21054-3K	NUTPLATE	2	SP	
32	MS21034-3K MS21048-3K	NUTPLATE (REPLACED BY NAS1770C3K)	6	NP	
32	NAS1770C3K	NUTPLATE (REPLACES MS21048-3K)	6	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-4. Firewall Assembly, Centerline (Cont'd)			
33 A 34 35 36 37 38 39 40 41 41 42 43 44 45 46 47 48 49 51 51 52 354 55 56	MS21071L3K MS21058-3K MS21059L3K MS27039C0806 NAS1149CN832R 212-061-903-133 212-061-903-135 MS27039C1-06 NAS1149C0332R 212-061-903-005 212-061-903-143 212-061-903-179 212-061-903-067 212-061-903-065 212-061-903-065 212-061-903-085 212-061-903-085 212-061-903-085 212-061-903-085 212-061-903-085 212-061-903-085 212-061-903-085 X122-061-903-085 X122-061-903-085 X121-061-903-085 X121-061-903-085 X121-061-903-085 X121-061-903-085 X121-061-903-085 X121-061-903-085 X121-061-903-085 X121-061-903-095 X121-061-903-085 X1	. NUTPLATE . NUTPLATE . NUTPLATE . NUTPLATE (S/N 31312 THRU SUB, 35038 THRU SUB) . SCREW . WASHER (S/N 31312 THRU SUB, 35091 THRU SUB) . RETAINER . GASKET . SCREW . WASHER (S/N 31312 THRU SUB, 35091 THRU SUB) . WEB ASSY, LOWER (S/N 30504 THRU 30530) . WEB ASSY, LOWER (S/N 30531 THRU 31311, 35001 THRU 35037) . WEB ASSY, LOWER (S/N 31312 THRU SUB, 35038 THRU SUB) . GASKET . GASKET . GASKET . GASKET . GASKET . GASKET . SEAL . GASKET . SEAL . GASKET . SEAL . NUTPLATE (REPLACED BY NAS1770C3K) . NUTPLATE	2 2 8 4 4 1 1 22 22 1 1 1 1 2 2 2 1 1 1 4 52 52 14 1 4 2 2	$^\circ$	
	212-062-001-001 212-062-001-005	POWER PLANT INSTL (S/N 30504 THRU 30530) (SEE FIG. 71-1, 71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP NP	
	212-062-001-007	71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-011	71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-009	71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 30597 THRU 30603, 30611 THRU 30614) (SEE FIG. 71-1, 71-2, 71-3, 71-5 FOR BALANCE OF	REF	NP	
	212-062-001-013 212-062-001-015	BREAKDOWN)	REF REF	NP NP	
	212-062-001-023	71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-027	71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-101	71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 31125 THRU 31281) (SEE FIG. 71-1,	REF	NP	
	212-062-001-103	71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-115	71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 31295 THRU 31311, 35001 THRU 35068) (SEE FIG. 71-1, 71-2, 71-3, 71-5 FOR BALANCE OF	REF	NP	
	212-062-001-119	POWER PLANT INSTL (S/N 35069 THRU 35080) (SEE FIG. 71-1,	REF	NP	
	212-062-001-123	71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN) POWER PLANT INSTL (S/N 35081 THRU 35101) (SEE FIG. 71-1, 71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN)	REF	NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
57 58 59 60 60	212-062-001-125 MS27039C1-12 MS27039C1-10 MS27039C1-08 AN960C10 NAS1149C0363R	Figure 71-4. Firewall Assembly, Centerline (Cont'd) POWER PLANT INSTL (S/N 31312 THRU SUB, 35102 THRU SUB) (SEE FIG. 71-1, 71-2, 71-3, 71-5 FOR BALANCE OF BREAKDOWN) . SCREW . SCREW . SCREW . WASHER (REPLACED BY NAS1149C0363R) . WASHER (REPLACES AN960C10)	9 6 32 47 47	% 4 % % % A % A % A % A % A % A % A % A	
		AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 71-5. Firewall Assembly, Middle



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-5. Firewall Assembly, Middle			
	212-060-901-115	FIREWALL ASSY, MIDDLE (S/N 30504 THRU 30553) (SEE FIG. 71-1	REF	Р	
	212-060-901-161	FOR NHA)	REF	Р	
	212-060-901-179	FOR NHA) FIREWALL ASSY, MIDDLE (S/N 31125 THRU 31294) (SEE FIG. 71-1	REF	NP	
	212-060-901-189	FOR NHA) FIREWALL ASSY, MIDDLE (S/N 31295 THRU 31310, 35001) (SEE	REF	NP	
	212-060-901-203	FIG. 71-1 FOR NHA)	REF	NP	
	212-060-901-219	FIG. 71-1 FOR NHA)	REF	Р	
	212-060-901-237	FOR NHA)	REF	NP	
1 2	MS27039C1-06 MS27039C1-05	SUB) (SEE FIG. 71-1 FOR NHA)	36 2	SP SP	
3	AN121657	SCREW	2	NP	
3	MS20392-2S19	. PIN (REPLACED BY MS20392-2S19)	2	SP	
4	AN960C10L	PIN (REPLACES AN121657)	4	Р	
4	NAS1149C0332R	WASHER (REPLACED BY NAS1149C0332R)	4	SP	
		. WASHER (REPLACES AN960C10L)	4	_	
5	NAS43DD3-8	. SPACER (REPLACED BY NAS43DD3-8N)	•	Р	
5	NAS43DD3-8N	. SPACER (REPLACES NAS43DD3-8)	4	SP	
6	MS21043-3	. NUT	2	SP	
7	AN960JD10L	. WASHER, FLAT (REPLACED BY NAS1149D0332J)	2	Р	
7	NAS1149D0332J	. WASHER, FLAT (REPLACES AN960JD10L)	2	SP	
8 9	AN970-3 AN345-10	. WASHER (S/N 31312 THRU SUB, 35081 THRU SUB)	2	SP NP	
9	MS35650-302	MS35650-302)	2	SP	
10	AN42B5A	AN345-10)	2	NP	
10	AN42B-5A	(REPLACED BY AN42B-5A)	2	SP	
		(REPLACES AN42B5A)	_		
10	BH42-01	. EYÈBOLT (S/N 31312 THŔU SUB, 35081 THRU SUB)	2	NP	
11	205-060-802-003	BRACE ASSY	2	SP	
12	212-060-901-121	. FIREWALL ASSY, LH (S/N 30504 THRU 30553)	1	NP	
12	212-060-901-163	FIREWALL ASSY, LH (S/N 30554 THRU 31310, 35001)	1	NP	
12	212-060-901-209	FIREWALL ASSY, LH (S/N 31311, 35002 THRU 35083)	1	Р	
12	212-060-901-221	FIREWALL ASSY, LH (S/N 35084 THRU 35099)	1	Р	
12	212-060-901-235	. FIREWALL ASSY, LH (S/N 31312 THRU SUB, 35100 THRU SUB)	1	SP P	
13 13	212-060-901-122	FIREWALL ASSY, RH (S/N 30504 THRU 30553)	1	NP	
13	212-060-901-164	FIREWALL ASSY, RH (S/N 30554 THRU 31310, 35001)	1	NP P	
13	212-060-901-210 212-060-901-223	FIREWALL ASSY, RH (S/N 31311, 35002 THRU 35083)	1	P	
13	212-060-901-223	FIREWALL ASSY, RH (S/N 35084 THRU 35099)	1	P	
_	212-060-901-236	. FIREWALL ASSY, RH (S/N 31312 THRU SUB, 35100 THRU SUB)	1	P	
14 15		PAD	1	NP	
15 15	212-060-901-051	SEAL (MAKE FROM 120-104-1) (REPLACED BY 120-104-1)	-	SP	
_	120-104-1	SEAL (57 INCHES REQUIRED) (REPLACES 212-060-901-051) .	1		
16	212-060-901-053	GASKET	1	SP	
17	212-060-901-055	SEAL	1	SP	
18	212-060-901-081	SEAL	1	SP	
19	MS21060L3K	NUTPLATE	8	SP	
20	MS21061L3K	NUTPLATE	4	SP	
21	MS21070L3K	NUTPLATE	2	SP	
22	MS21071L3K	NUTPLATE	3	SP	
23	MS21072L3K	NUTPLATE	2	SP	
24	212-060-901-061	RETAINER, LH	1 1	NP	i



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-5. Firewall Assembly, Middle (Cont'd)			
24	212-060-901-062	RETAINER, RH	1	NP	
25	212-060-901-117	. FIREWALL ASSY, LH (S/N 30504 THRU 31124)	1	SP	
25	212-060-901-181	. FIREWALL ASSY, LH (S/N 31125 THRU 31294)	1	Р	
25 25	212-060-901-191	. FIREWALL ASSY, LH (S/N 31295 THRU 31310, 35001)	1	NP P	
26	212-060-901-215 212-060-901-119	FIREWALL ASSY, LH (S/N 31311 THRU SUB, 35002 THRU SUB)	1	SP	
26	212-060-901-119	. FIREWALL ASSY, RH (S/N 30504 THRU 31124)	1	P	
26	212-060-901-193	. FIREWALL ASSY, RH (S/N 31295 THRU 31310, 35001)	1	NP	
26	212-060-901-217	. FIREWALL ASSY, RH (S/N 31311 THRU SUB, 35002 THRU SUB)	1	Р	
27	7C1-10W	CLAMP (REPLACED BY 30-056-10W)	1	NP	
27	30-056-10W	CLAMP (REPLACES 7C1-10W)	1	SP	
28	212-060-901-029	SEAL	1	SP SP	
29 30	212-060-901-027 212-060-901-023	GASKET	1	SP	
31	212-060-901-023	GASKET	1	SP	
32	212-060-901-069	GASKET, LH	1	SP	
32	212-060-901-073	GASKET, RH	1	SP	
32	212-060-901-075	GASKET, RH	1	SP	
33	MS21060L3K	NUTPLATE	2	SP	
34 35	MS21076L3K 212-060-901-123	NUTPLATE	1	NP SP	
35	212-060-901-123	. FIREWALL ASSY, LH (S/N 30504 THRU 31310, 35001)	1	SP	
36	212-060-901-125	FIREWALL ASSY, RH (S/N 30504 THRU 31310, 35001)	1	SP	
36	212-060-901-207	. FIREWALL ASSY, RH (S/N 31311 THRU SUB, 35002 THRU SUB)	1	SP	
37	212-060-901-025	SEAL	1	SP	
38	212-060-901-067	SEAL	1	SP	
39	212-060-901-047	RETAINER, LH	1	NP	
39	212-060-901-048 212-062-001-001	RETAINER, RH	1 REF	NP NP	
	212-002-001-001	POWER PLANT INSTL (S/N 30504 THRU 30530) (SEE FIG. 71-1, 71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)	IXLI	INF	
	212-062-001-005	POWER PLANT INSTL (S/N 30531 THRU 30553) (SEE FIG. 71-1,	REF	NP	
	212-062-001-007	71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
		71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)			
	212-062-001-011	POWER PLANT INSTL (S/N 30579 THRU 30596) (SEE FIG. 71-1, 71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-009	POWER PLANT INSTL (S/N 30597 THRU 30603, 30611 THRU 30614)	REF	NP	
		(SEE FIG. 71-1, 71-2, 71-3, 71-4 FOR BALANCE OF			
	212-062-001-013	BREAKDOWN)	REF	NP	
		71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)			
	212-062-001-015	POWER PLANT INSTL (S/N 30615 THRU 30729) (SEE FIG. 71-1, 71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-023	POWER PLANT INSTL (S/N 30730 THRU 30849) (SEE FIG. 71-1,	REF	NP	
	212-062-001-027	71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
		71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)			
	212-062-001-101	POWER PLANT INSTL (S/N 31125 THRU 31281) (SEE FIG. 71-1, 71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-103	POWER PLANT INSTL (S/N 31282 THRU 31294) (SEE FIG. 71-1,	REF	NP	
	212-062-001-115	71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
		(SEE FIG. 71-1, 71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)			
	212-062-001-119	POWER PLANT INSTL (S/N 35069 THRU 35080) (SEE FIG. 71-1,	REF	NP	
	212-062-001-122	71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-001-123	POWER PLANT INSTL (S/N 35081 THRU 35101) (SEE FIG. 71-1, 71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN)	INEF	INF	
		112, 110, 11 TI ON BALANOL OF BINLANDOWN)			



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
40 40 41 42 43 44 45 46 47	212-062-001-125 AN960C10L NAS1149C0332R MS27039C1-08 MS27039C1-06 MS21042L3 MS27039C1-09 MS27039C1-10 MS27039C1-12 MS27039C1-14	Figure 71-5. Firewall Assembly, Middle (Cont'd) POWER PLANT INSTL (S/N 31312 THRU SUB, 35102 THRU SUB) (SEE FIG. 71-1, 71-2, 71-3, 71-4 FOR BALANCE OF BREAKDOWN) WASHER (REPLACED BY NAS1149C0332R) WASHER (REPLACES AN960C10L) SCREW SCREW NUT, SELF-LOCKING SCREW SCREW SCREW SCREW	REF 44 44 6 22 8 8 2 4 2	P P P P P P P P P P P P P P P P P P P	
		AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 71-6. Cowling Installation

71-99-00 Page 34

Rev. 8 30 APR 2010



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-6. Cowling Installation			
	212-060-800-005	COWLING INSTL (S/N 30504 THRU 30553) (SEE FIG. 71-7, 71-8,	1	NP	
	212-060-800-009	71-9 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-060-800-017	71-9 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-060-800-021	71-9 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-060-800-015	71-9 FOR BALANCE OF BREAKDOWN)	1	NP	
	212-060-800-101	71-9 FOR BALANCE OF BREAKDOWN)	1	NP	
1	MS27039C1-04	SCREW	9	SP	
2	212-060-801-001	. FAIRING ASSY, TRANSMISSION	1	NP	
3	212-060-801-003	FAIRING ASSY	1	NP	
4	NAS679A3 MS21042L3	NUT (REPLACED BY MS21042L3)	8 8	NP SP	
5	NAS1197-10	NUT, SELF-LOCKING (REPLACES NAS679A3)	16	SP	
6	MS27039-1-14	SCREW	8	SP	
7	212-060-801-009	SCREEN ASSY	1	NP	
8	212-060-801-045	RETAINER	2	Р	
9	212-060-801-043	SCREEN (REPLACED BY 212-060-801-009)	1	NP	
9	212-060-801-009	SCREEN ASSY (REPLACES 212-060-801-043)	1	NP	
10	212-060-801-057	PLATE, LH	1	NP	
11	212-060-801-058	PLATE, RH	1	Р	
12	212-060-801-037	FRAME	1	Р	
13 14	212-060-801-031 212-060-801-053	SHIM	2	P SP	
15	212-060-801-053	SHIM	1	SP	
16	212-060-801-047	ANGLE, LH ANGLE, RH	1	SP	
17	212-060-801-019	RETAINER, LH	1	SP	
18	212-060-801-020	RETAINER, RH	1	SP	
19	212-060-801-027	SEAL (30 INCHES) (MAKE FROM 110-004-8)	2	Р	
19	110-004-8	SEAL (30 INCHES)	2	SP	
20	212-060-801-023	RETAINER, LH	1	SP	
21	212-060-801-024	LRETAINER.RH	1	SP	
22	212-060-801-025	SEAL (27 INCHES) (MAKE FROM 110-004-1-270) (NOTE 2)	2	SP	
22	110-004-1-270	SEAL (27 INCHES) (NOTE 2)	2	NP	
23 23	MS20392-2-35 MS20392-2C35	PIN (REPLACED BY MS20392-2C35)	2	NP P	
25	WO20002 2000	MS20392-2S35)	_	'	
23	MS20392-2S35	MS20392-2535)	2	SP	
24	AN960PD10L	WASHER (REPLACED BY AN960JD10LL)	2	P	
24	AN960JD10LL	WASHER (REPLACES AN960PD10L) (RÉPLACED BY NAS1149D0316J)	2	P	
24	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	2	SP	
25	H287-1	LATCH (REPLACED BY 90-029-1)	2	NP	
25	90-029-1	LATCH (REPLACES H287-1)	2	SP	
26	212-060-801-021 212-060-801-022	SUPPORT, LH	1	NP	
27 28	212-060-801-022 212-060-801-005	SUPPORT, RH	1	NP NP	
28 29	NAS679A3	FAIRING ASSY	2	NP NP	
29	MS21042L3	NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP	
30	AN960-10	WASHER (REPLACED BY NAS1149F0363P)	8	P	
30	NAS1149F0363P	WASHER (REPLACES AN960-10)	8	SP	
31	MS27039-1-19	SCREW	2	SP	
32	NAS43DD3-14	SPACER (REPLACED BY NAS43DD3-14N)	4	NP	
		, , , , , , , , , , , , , , , , , , ,			




	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A L	0 C
		Figure 71-6. Cowling Installation (Cont'd)			
32	NAS43DD3-14N	SPACER (REPLACES NAS43DD3-14)	4	SP	
33	212-060-815-001	HINGE HALF, LH (REPLACED BY 212-060-815-003)	1	NP	
33	212-060-815-003	HINGE HALF, LH (REPLACES 212-060-815-001)	1	SP	
34	212-060-815-002	HINGE HALF, RH (REPLACED BY 212-060-815-004)	1	NP	
34	212-060-815-004	HINGE HALF, RH (REPLACES 212-060-815-002)	1	SP	
35 36	212-060-801-007 MS27039-1-06	FAIRING ASSY, NOSE	4	NP SP	
36A	212-060-801-033	SCREWNOSE FAIRING	1	NP	
37	212-060-801-033	SUPPORT ASSY	1	P	
38	MS21075L3	NUTPLATE (REPLACED BY MS21075L3N)	2	NP	
38	MS21075L3N	NUTPLATE (REPLACES MS21075L3)	2	SP	
39	MS21059L3	NUTPLATE	2	SP	
40	212-060-801-055	SUPPORT, LH	1	SP	
41	212-060-801-056	SUPPORT, RH	1	SP	
42	212-060-801-011	ANGLE ASSY	1	NP	
43	MS21059L3K	NUTPLATE	3	SP	
44	205-060-802-015	BRACE ASSY	1	SP	
45	AN121657	PIN (REPLACED BY MS20392-2C19)	1	NP	
45	MS20392-2C19	PIN (REPLACES AN121657) (REPLACED BY MS20392-2S19).	1	Р	
45	MS20392-2S19	PIN (REPLACES MS20392-2C19)	1 2	SP P	
46 46	AN960C10L NAS1149C0332R	WASHER (REPLACED BY NAS1149C0332R)	2	SP	
46 47	NAS1149C0332R NAS43DD3-8	WASHER (REPLACES AN960C10L)	2	P	
47	NAS43DD3-8N	SPACER (REPLACED BY NAS43DD3-6N)	2	SP	
48	MS20253P2-275	PIN (REPLACED BY MS20253P2-7200)	1	SP	
48	MS20253P2-7200	PIN, HINGE (REPLACES MS20253P2-275)	l i	SP	
49	205-060-802-011	HINGE	1	SP	
50	205-060-802-021	FITTING	2	Р	
51	205-060-802-017	BRACE ASSY	1	SP	
52	AN121606	PIN (REPLACED BY MS20392-1-17)	1	Р	
52	MS20392-1-17	PIN (REPLACES AN121606) (REPLACED BY MS20392-1C17)	1	NP	
52	MS20392-1C17	PIN (REPLACES MS20392-1-17) (REPLACED BY	1	Р	
		MS20392-1S17)			
52	MS20392-1S17	PIN (REPLACES MS20392-1C17)	1	SP	
53 53	AN960C4L NAS1149CN416R	WASHER (REPLACED BY NAS1149CN416R)	2	SP SP	
53 54	205-060-802-007	WASHER (REPLACES AN960C4L)	1	P	
55	205-060-802-007	LATCH		SP	
56	205-060-802-009	BRACE	1	P	
57	NAS679A3	NUT (REPLACED BY MS21042L3)	1	NP	
57	MS21042L3	NUT, SELF-LOCKING (REPLACES NAS679A3)	1	SP	
58	AN960PD10L	WASHER (REPLACED BY AN960JD10LL)	2	Р	
58	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY	2	Р	
		NAS1149D0316J)			
58	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	2	SP	
59	MS27039-1-06	SCREW	1	SP	
60	7C1-10W	CLAMP (REPLACED BY 30-056-10W)	1	NP	
60 61	30-056-10W 212-060-801-059	CLAMP (REPLACES 7C1-10W)	1 1	SP P	
62	MS20392-2-31	SUPPORTPIN (REPLACED BY MS20392-2C31)		NP	
62	MS20392-2-31	PIN (REPLACED BY MS20392-2-31) (REPLACED BY MS20392-2-S31)	1	NP	
62	MS20392-2S31	PIN (REPLACES MS20392-2C31)	1	SP	
63	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	1	P	
63	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY	1	Р	
		NAS1149D0316J)			
63	NAS1149D0316J	. WASHER (REPLACÉS AN960JD10LL)	1	SP	
64	MS21042L4 AN960PD416L	NUT	1	SP	
65		. WASHER (REPLACED BY AN960JD416L)	1 1	NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-6. Cowling Installation (Cont'd)			
65	AN960JD416L	. WASHER (REPLACES AN960PD416L) (REPLACED BY	1	Р	
65	NAS1149D0416J	NAS1149D0416J)	1	SP	
66	205-060-863-001	. FITTING (S/N 30504 THRU 30553)	1	SP	
66	205-060-863-003	. FITTING (S/N 30554 THRU SUB, 35001 THRU SUB)	1	SP	
67	AN4-3A	BOLT	4	SP	
68	AN960PD416L	. WASHER (REPLACED BY AN960JD416L)	4	NP	
68	AN960JD416L	. WASHER (REPLACES AN960PD416L) (REPLACED BY NAS1149D0416J)	4	Р	
68	NAS1149D0416J	. WASHER (REPLACES AN960JD416L)	4	SP	
69	AN4-3A	BOLT (NOTE 1)	4	SP	
70	AN960PD416L	. WASHER (REPLACED BY AN960JD416L)	4	NP	
70	AN960JD416L	. WASHER (REPLACES AN960PD416L) (REPLACED BY NAS1149D0416J)	4	Р	
70	NAS1149D0416J	. WASHER (REPLACES AN960JD416L)	4	SP	
71	AN960PD416	. WASHER (NOTE 1) (REPLACED BY ÁN960JD416)	4	NP	
71	AN960JD416	. WASHER (NOTE 1) (REPLACES AN960PD416) (REPLACED BY NAS1149D0463J)	4	Р	
71	NAS1149D0463J	. WASHER (NOTE 1) (REPLACES AN960JD416)	4	SP	
72	AN970-4	. WASHER `	4	SP	
73	212-060-810-001	LATCH FITTING	4	SP	
74	212-060-802-097	. FAIRING ASSY, ENGINE AIR INLET, LH (SEE FIG. 71-11 FOR BREAKDOWN) (USBL ON 212-060-800-005, -009, -015, -017	1	NP	
74	212-060-802-155	AND -021)	1	NP	
74	212-060-802-163	. FAIRING ASSY, ENGINE AIR OUTLET, LH (SEE FIG. 71-11 FOR	1	Р	
75	212-060-802-098	BREAKDOWN) (USBL ON 212-060-800-101)	1	NP	
75	212-060-802-156	. FAIRING ASSY, ENGINE AIR INLET, RH (SEE FIG. 71-11 FOR BREAKDOWN) (USBL ON 212-060-800-101)	1	NP	
75	212-060-802-164	FAIRING ASSY, ENGINE AIR INLET, RH (SEE FIG. 71-11 FOR BREAKDOWN) (USBL ON 212-060-800-101)	1	Р	
76	NAS1189-3P18	SCREW	2	SP	
77	212-060-826-001	LOCATOR ASSY, FAIRING, LH (REPLACED BY 212-060-828-101)	1	P	
77	212-060-828-101	LOCATOR PLATE, FAIRING, LH (REPLACES 212-060-826-001)	1	SP	
78	212-060-826-002	LOCATOR ASSY, FAIRING, RH (REPLACED BY 212-060-828-102)	1	SP	
78	212-060-828-102	LOCATOR PLATE, FAIRING, RH (REPLACES 212-060-826-002)	1	SP	
79	212-060-826-007	LOCKPLATE, LH	1	SP	
80	212-060-826-008	LOCKPLATE, RH	1	SP	
		NOTE 1: USE AS REQUIRED TO ADJUST FOR PROPER COWL LATCH ENGAGEMENT. ATTACHING BOLT LENGTH TO BE CHANGED TO ACCOMMODATE ADDITIONAL WASHERS.			
		NOTE 2: BELL HELICOPTER WILL NO LONGER STOCK THE SEAL 110-004-1. PLACE ORDERS FOR DARK CHARCOAL GRAY SEAL 110-004-2 OR WHTIE SEAL 110-004-3.			



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A L	U 0 C
		Figure 71-6. Cowling Installation (Cont'd)			
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			




71-99-00 Page 40

Rev. 8 30 APR 2010

ECCN EAR99





212_IPB_71_0007b

Figure 71-7. Cowling Installation (Sheet 2 of 2)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	4 > 4 _ L	U O C
		Figure 71-7. Cowling Installation			
	212-060-800-005	COWLING INSTL (S/N 30504 THRU 30553) (SEE FIG. 71-6, 71-8,	REF	NP	
	212-060-800-009	71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-017	71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-021	71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-015	71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-101	35001 THRU 35040, 35046 THRU 35051) (SEE FIG. 71-6, 71-8, 71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
1 1 2 3	MS24693C49 MS24693-C49 MS27039C1-04 212-060-803-097	BREAKDOWN)	30 30 2 1	NP SP SP NP	
3	212-060-803-119	212-060-803-119)	1	Р	
3	212-060-803-133	212-060-803-097)	1	NP	
3	212-060-803-163	THRU 35051) (REPLACED BY 212-060-803-163)	1	NP	
4	212-060-803-099	(REPLACES 212-060-803-133)	1	NP	
4	212-060-803-125	212-060-803-125)	1	Р	
4	212-060-803-135	212-060-803-099)	1	NP	
4	212-060-803-165	THRU 35051) (REPLACED BY 212-060-803-165)	1	NP	
4A 4A 4B 4B 4C 4D 5 6 7 8	212-060-803-087 212-060-803-169 212-060-803-085 212-060-803-167 50-009-2 50-007A15 212-060-803-105 212-060-803-095 212-060-816-001 212-060-803-015 212-060-823-001	(REPLACES 212-060-803-135) . FRAME (REPLACED BY 212-060-803-169) FRAME (REPLACES 212-060-803-087) . FRAME (REPLACED BY 212-060-803-167) FRAME (REPLACES 212-060-803-085) . GROMMET . STUD . SKIN . DUCT ASSY . FAIRING (S/N 30504 THRU 30553) . LOUVER . BAFFLE ASSY (S/N 30504 THRU 31206) (REPLACED BY	1 1 1 1 24 24 1 1 1 1	NP SP P SP SP P NP	
9	212-060-823-101	212-060-823-101)	1	NP	
9	212-060-823-105	212-060-823-001)	1	SP	
9 9A 10 10 11 12 13	212-060-823-107 212-060-823-103 AN960C6 NAS1149CN632R MS21060L08K MS21061L08K NAS1766-3 90-070-3-2	(REPLACED BY 212-060-823-107) . BAFFLE ASSY (REPLACES 212-060-823-105) . RETAINER . WASHER (REPLACED BY NAS1149CN632R) WASHER (REPLACES AN960C6) NUTPLATE . NUTPLATE . NUTPLATE . NUTPLATE . NUTPLATE	1 4 32 32 9 3 2	SP SP SP SP SP SP	



14A 21 15 21 16 MS 16 MS	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A	U
15 21 16 MS 16 MS				L	O C
18	12-060-803-127 12-060-822-001 \$20253P2-275 \$20253P2-7200 05-030-353-001 20-128-1 12-060-822-013 12-060-822-013 12-060-822-009 12-060-804-009 12-060-804-119 12-060-804-110 12-060-804-110 12-060-804-120 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808 \$27039-0808	Figure 71-7. Cowling Installation (Cont'd) STIFFENER DOOR ASSY (USBL ON 212-060-803-097, -119, -133 AND -163) PIN (REPLACED BY MS20253P2-2200) PIN, HINGE (REPLACES MS20253P2-275) SPRING (MAKE FROM 120-128-1) (REPLACED BY 120-128-1) SPRING (REPLACES 205-030-353-001) HINGE HALF STOP COWL ASSY, ENGINE, UPPER, LH (S/N 30504 THRU 31311, 35001 THRU 35080) (REPLACED BY 212-060-804-119) COWL ASSY, ENGINE, UPPER, LH (S/N 31312 THRU SUB, 35081 THRU 35080) (REPLACED BY 212-060-804-109) COWL ASSY, ENGINE, UPPER, RH (S/N 30504 THRU 31311, 35001 THRU 35080) (REPLACED BY 212-060-804-120) COWL ASSY, ENGINE, UPPER, RH (S/N 30504 THRU 31311, 35001 THRU 35080) (REPLACED BY 212-060-804-120) COWL ASSY, ENGINE, UPPER, RH (S/N 31312 THRU SUB, 35081 THRU SUB) SCREW (S/N 31312 THRU SUB, 35081 THRU SUB) LATCH (S/N 30504 THRU 31311, 35001 THRU 35080) SCREW (S/N 31312 THRU SUB, 35081 THRU SUB) SCREW (S/N 31312 THRU SUB, 35081 THRU SUB) SCREW (S/N 31312 THRU SUB, 35081 THRU SUB) LATCH (S/N 30504 THRU 31311, 35001 THRU 35080) LATCH (S/N 30504 THRU 31311, 35001 THRU 35080) LATCH (S/N 30504 THRU 31311, 35001 THRU SUB) SCREW (S/N 31312 THRU SUB, 35081	11111111 1 1 1 66116611111111111 1 1 1	- £\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$	
39 21 40 21 40 21 40 MS 41 MS 42 MS 43 AN	12-060-804-037 12-060-804-081 12-060-804-079 12-060-804-117 S35822-11C S27039-1-09 S27039-1-08 N960PD10L N960JD10LL	SEAL HINGE HALF (REPLACED BY 212-060-804-117) HINGE HALF (REPLACED BY 212-060-804-117) HINGE (MAKE FROM MS35822-11C) (REPLACES 212-060-804-079 AND -081) HINGE (REPLACES 212-060-804-079 AND -081) .SCREW .SCREW .WASHER (REPLACED BY AN960JD10LL) .WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	1 1 1 1 6 6 12 12	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-7. Cowling Installation (Cont'd)			
43	NAS1149D0316J 212-060-817-005	. WASHER (REPLACES AN960JD10LL)	12 1	SP NP	
	212-060-817-101	(REPLACED BY 212-060-817-101)	1	NP	
	212-060-817-006	. PILLAR INSTL, RH (S/N 30504 THRU 31311, 35001 THRU 35080) (REPLACED BY 212-060-817-102)	1	NP	
	212-060-817-102	. PILLAR INSTL, RH (S/N 31312 THRU SUB, 35081 THRU SUB) (REPLACES 212-060-817-006)	1	NP	
44	MS27039-1-10	SCREW	4	SP	
45	MS27039-1-10	SCREW (S/N 30504 THRU 31311, 35001 THRU 35063)	2	SP	
46	AN960PD10L		4	P	
46	AN960JD10LL	WASHER (REPLACED BY AN960JD10LL)	4	P	
46	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	4	SP	
47	AN960PD10L	WASHER (REPLACES AN9603DT0LL) WASHER (S/N 30504 THRU 31311, 35001 THRU 35063) (REPLACED BY AN9603D10LL)	2	Р	
47	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	2	Р	
47	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	2	SP	
48	MS27039-1-11	SCREW	5	SP	
49	AN960PD10L	WASHER (REPLACED BY AN960JD10LL)	5	P	
49	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	5	P	
49	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	5	SP	
50	212-060-817-081	SHIM	1	SP	
51	212-060-817-083	SHIM	1	SP	
52	212-060-817-085	SHIM	1	NP	
53	212-060-817-007	PILLAR ASSY, LH (S/N 30504 THRU 31311, 35001 THRU 35080)	1	SP	
53	212-060-817-103	PILLAR ASSY, LH (S/N 31312 THRU SUB, 35081 THRU SUB)	1	Р	
53	212-060-817-008	PILLAR ASSY, RH (S/N 30504 THRU 31311, 35001 THRU 35080)	1	P	
53	212-060-817-104	PILLAR ASSY, RH (S/N 31312 THRU SUB, 35081 THRU SUB)	1	P	
54	MS27039-1-08	SCREW	9	SP	
55	AN960PD10L	WASHER (REPLACED BY AN960JD10LL)	9	P.	
55	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	9	P	
55	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	9	SP	
56	MS27039-1-09	SCREW (S/N 30504 THRU 31311, 35001 THRU 35063)	1	SP	
56	MS27039-1-08	SCREW (S/N 31312 THRU SUB, 35064 THRU SUB)	1	SP	
57	AN960PD10L	WASHER (REPLACED BY AN960JD10LL)	1	Р	
57	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	1	P	
57	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	1	SP	
58	MS27039-1-10	SCREW (S/N 30504 THRU 31311, 35001 THRU 35063)	1	SP	
58	MS27039-1-08	SCREW (S/N 31312 THRU SUB, 35064 THRU SUB)	1	SP	
59	AN960PD10L	WASHER (REPLACED BY AN960JD10LL)	1	P	
59	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	1	P	
59	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	1	SP	
60	212-060-817-045	SHIM, LH	1	Р	
60	212-060-817-046	SHIM, RH	1	P	
61	212-060-817-047	CHAFE STRIP, LH (S/N 30504 THRU 31311, 35001 THRU 35080)	1	SP	
61	212-060-817-109	CHAFE STRIP, LH (S/N 31312 THRU SUB, 35081 THRU SUB).	1	P	
61	212-060-817-048	CHAFE STRIP, RH (S/N 30504 THRU 31311, 35001 THRU 35080)	1	SP	
61	212-060-817-110	CHAFE STRIP, RH (S/N 30304 THRU S1311, 35001 THRU S080)	1	P	
-	212-060-817-110	SUPPORT, LH	1	NP	
h/	- · - 000 0 1 1 001		•		
62 62	212-060-817-058	SUPPORT RH	1	ישוו	
62 63	212-060-817-058 212-060-817-079	SUPPORT, RH FRAME, LH	1 1	NP NP	



NIDEX NUMBER Figure 71-7. Cowling Installation (Cont'd)	(1)	(2)	(3)	(4)	(5)	(6)
63 212-060-817-080		PART NUMBER	ITEM NAME	PER	V A I	ō
codes as well as general use of the Illustrated Parts Breakdown Manual.	63 64 64 65 65 66 67 70 70 70 70 71 71 71 71 72 73 73 73 74 74 75 76 77 78 78	212-060-817-080 212-060-817-067 212-060-817-068 212-060-817-025 212-060-817-026 20-042-8-10 20-042-2-8 20-042-1-8 MS21075L3 MS21075L3N 212-060-817-087 212-060-817-089 212-060-817-015 212-060-817-016 212-060-817-106 MS27039-1-12 AN960PD10L AN960JD10LL NAS1149D0316J 209-062-802-001 209-062-802-001 209-062-817-001 209-062-817-001 209-062-817-003 MS21069L3 MS21075L3 MS21075L3N	Figure 71-7. Cowling Installation (Cont'd) FRAME, RH FRAME ASSY, LH FRAME ASSY, LH FRAME ASSY, RH FRAME, LH FRAME, LH RADIUS BLOCK RADIUS BLOCK RADIUS BLOCK RADIUS BLOCK NUTPLATE NUTPLATE (REPLACED BY MS21075L3N). NUTPLATE (REPLACED BY MS21075L3N). PLATE, WEAR (STAINLESS). PLATE, WEAR (STAINLESS). PLATE, WEAR (STAINLESS). FRAME ASSY, LH (S/N 30504 THRU 31311, 35001 THRU 35080). FRAME ASSY, LH (S/N 31312 THRU SUB, 35081 THRU SUB). FRAME ASSY, RH (S/N 31312 THRU SUB, 35081 THRU SUB). SCREW WASHER (REPLACED BY AN960JD10LL). WASHER (REPLACED BY AN960JD10LL). FITTING (REPLACES AN960JD10LL). FITTING (REPLACES AN960JD10LL). FITTING (REPLACES AN960JD10LL). FITTING (REPLACES 209-062-802-003). FITTING (REPLACES 209-062-802-001). PLATE NUTPLATE NUTPLATE NUTPLATE NUTPLATE (REPLACED BY MS21075L3N). NUTPLATE (REPLACED BY MS21075L3N). NUTPLATE (REPLACES MS21075L3). WASHER AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts	UNIT PER ASSY 1 1 1 1 1 2 2 2 2 1 1 1 1 2 2 2 2 1 1 1 1 2 2 4 4	AVALL SPP PPP PPPPPPPPPPPPPPPPPPPPPPPPPPPP	U






Figure 71-8. Cowling Installation



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	4 > 4 _ L	U 0 C
		Figure 71-8. Cowling Installation			
	212-060-800-005	COWLING INSTL (S/N 30504 THRU 30553) (SEE FIG. 71-6, 71-7, 71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-009	COWLING INSTL (S/N 30554 THRU 30578) (SEE FIG. 71-6, 71-7, 71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-017	COWLING INSTL (S/N 30579 THRU 30596) (SEE FIG. 71-6, 71-7, 71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-021	COWLING INSTL (S/N 30604 THRU 30610) (SEE FIG. 71-6, 71-7, 71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-015	COWLING INSTL (S/N 30597 THRU 30603, 30611 THRU 31311, 35001 THRU 35040, 35046 THRU 35051) (SEE FIG. 71-6, 71-7,	REF	NP	
	212-060-800-101	71-9 FOR BALANCE OF BREAKDOWN)	REF	NP	
1	MS27039C1-09	BREAKDOWN)	4	SP	
2	AN960C10	. WASHER (REPLACED BY NAS1149C0363R)	4	P	
2	NAS1149C0363R	. WASHER (REPLACES AN960C10)	4	SP	
3	205-060-821-005	. FITTING (S/N 30504 THRU 30679) (REPLACED BY 212-060-825-003 AND -007)	2	NP	
3	212-060-825-003	. FITTING (S/N 30504 THRU 30897) (REPLACES 205-060-821-005) (REPLACED BY 212-060-825-007)	2	NP	
3	212-060-825-007	. FITTING (REPLACES 205-060-821-005, 212-060-825-003)	2	SP	
4	AN320-4	. NUT	4	SP	
5 5	AN960PD416L AN960JD416L	. WASHER (REPLACED BY AN960JD416L)	4	NP P	
		NAS1149D0416J)			
5	NAS1149D0416J	. WASHER (REPLACES AN960JD416L)	4	SP	
6	AN4-17	. BOLT	4	SP	
7 7	AN960-416	. WASHER (REPLACED BY NAS1149F0463P)	16	NP SP	
8	NAS1149F0463P AN960-416L	. WASHER (REPLACES AN960-416)	16 24	P	
8	NAS1149F0432P	. WASHER (REPLACED BY NAS1149F0432P)	24	SP	
9	NAS1354DS7S15	PIN (REPLACED BY NAS1354DS7S15D)	4	P	
9	NAS1354DS7S15D	PIN (REPLACES NAS1354DS7S15)	4	SP	
10	NAS1455A00-6	. CHAIN	4	SP	
11	212-060-813-001	. HINGE ASSY	2	SP	
	212-060-813-003	FRAME ASSY	1	NP	1
12	22-006B15-32-16	BUSHING	4	SP	1
13	AN316-9R	NUT	2	SP	1
14 15	TCL001SEB9 212-060-805-009	ROD END	2	SP NP	1
13	212-000-003-009	THRU 35040, 35046 THRU 35051) (REPLACED BY 212-060-805-015)	'	INF	
15	212-060-805-015	. COWL ASSY, ENGINE, LOWER, LH (S/N 30504 THRU 31311, 35001 THRU 35097) (REPLACES 212-060-805-009)	1	NP	
15	212-060-805-115	. COWL ASSY, ENGINE, LOWER, LH (S/N 31312 THRU SUB, 35098 THRU SUB)	1	NP	
16	212-060-805-010	. COWL ASSY, ENGINE, LOWER RH (S/N 30504 THRU 31311, 35001 THRU 35040, 35046 THRU 35051) (REPLACED BY	1	NP	
16	212-060-805-016	212-060-805-016)	1	NP	
16	212-060-805-116	THRU 35097) (REPLACES 212-060-805-010)	1	NP	
17	MS27039C0806	THRU SUB)	12	SP	1
17	AN525-832R6	SCREW (5/N 30504 THRU 31311, 35001 THRU 35097)	12	Р	1
18	H38-K1161	LATCH (USBL ON 212-060-805-009 AND -010)	2	NP	1
		, ,			<u> </u>



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	0 C
		Figure 71-8. Cowling Installation (Cont'd)			
19	H38-K1161	LATCH (USBL ON 212-060-805-015 AND -016)	1	NP	i
20	H38-K1490	LATCH (USBL ON 212-060-805-015 AND -016)	1	NP	İ
20A	50-007A33C	STUD (POST ASB 212-95-99)	2	SP	İ
20B 20C	50-008RF2C 50-009C2	RECEPTACLE (POST ASB 212-95-99)	2	SP SP	
20C 20D	412-060-015-101	GROMMET (POST ASB 212-95-99)	2	SP	
200	MS27039-1-10	SCREW	8	SP	
22	205-060-855-001	SUPPORT HINGE, LH	1	SP	
22	205-060-855-002	SUPPORT HINGE, RH	1	SP	
23	205-060-856-001	SUPPORT HINGE, LH	1	SP	
23	205-060-856-002	SUPPORT HINGE, RH	1	SP	
24	212-060-805-011	COWL ASSY, LH (USBL ON 212-060-805-009) (REPLACED BY	1	NP	
24	212-060-805-013	212-060-805-013)	1	NP	
24	212-060-805-109	COWL ASSY, LH (USBL ON 212-060-805-115)	1	NP	
24	212-060-805-012	COWL ASSY, RH (USBL ON 212-060-805-010) (REPLACED BY	1	NP	
24	212-060-805-014	212-060-805-014)	1	NP	
24	212-060-805-110	(REPLACES 212-060-805-012)	1	NP	
25	NAS1330S3K116	NUT	8	SP	
26	212-060-814-001	SUPPORT ASSY, LH (USBL ON 212-060-805-011) (REPLACED	1	NP	
26	212-060-814-011	BY 212-060-814-011)	1	SP	
26	212-060-814-002	SUPPORT ASSY, RH (USBL ON 212-060-805-012) (REPLACED	1	NP	
26	212-060-814-012	BY 212-060-814-012)	1	SP	
26A	212-060-805-031	DOUBLER, LH (INSIDE)	1	P	
26A	212-060-805-032	DOUBLER, RH (INSIDE)	1	P	
26B	212-060-805-027	DOUBLER, LH (INSIDE)	1	Р	
26B	212-060-805-028	DOUBLER, RH (INSIDE)	1	Р	
26C	212-060-805-033	DOUBLER, LH (INSIDE)	1	NP	
26C	212-060-805-034	DOUBLER, RH (INSIDE)	1	NP	
27	NAS679A06	NUT (REPLACED BY MS21042L06)	2	SP	
27 28	MS21042L06 AN960PD6	NUT (REPLACES NAS679A06)	2	SP P	
28	AN960JD6	WASHER (REPLACED BY AN960JD6)	2	P	
		NAS1149DN632J)			
28	NAS1149DN632J	WASHER (REPLACES AN960JD6)	2	SP	1
29	P116-499-10-24A	STUD (REPLACED BY P116-499-10-495)	2	NP	1
29	P116-499-10-495	STUD (REPLACES P116-499-10-24A)	2	SP	
30	212-060-814-003	SUPPORT ASSY, LH (USBL ON 212-060-814-001)	1	NP	
30 30	212-060-814-013 212-060-814-004	SUPPORT ASSY, LH (USBL ON 212-060-814-011)	1 1	NP NP	
30	212-060-814-004	SUPPORT ASSY, RH (USBL ON 212-060-814-002)		NP	
31	212-060-814-017	BRACKETBRACKET	1	NP	1
32	MS20253P2-244	PIN	2	SP	1
33	212-060-814-021	HINGE HALF (MAKE FROM MS20257XP4-275)	2	SP	1
33	MS20257XP4-275	HINGE HALF	2	NP	1
34	212-060-814-023	HINGE HALF (MAKE FROM MS20257YP4-275)	2	SP	İ
34	MS20257YP4-275	HINGE HALF	2	NP	1
35	A1663-022-24A	SPRING LATCH (REPLACED BY 50-031-1)	1	NP	1
35 36	50-031-1 212-060-805-043	FASTENER (REPLACES A1663-022-24A)	1 1	SP SP	İ
36 37	212-060-805-043	GASKETGASKET	1	SP	1
38	212-060-805-045	SEAL		SP	İ
39	212-060-822-015	DOOR ASSY	1	SP	1
40	MS20253P3-275	PIN	1	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
41 41 42 42 43 44 45 46 47 48 49	212-060-822-021 MS20257-XC3-400 205-030-353-001 120-128-1 212-060-822-023 MS20257-YC3-400 212-060-822-009 MS27039C1-09 AN960C10 NAS1149C0363R 204-060-927-001 212-060-909-003 204-060-936-001	Figure 71-8. Cowling Installation (Cont'd) HINGE HALF (MAKE FROM MS20257-XC3-400) HINGE HALF SPRING (REPLACED BY 120-128-1) SPRING (REPLACES 205-030-353-001) HINGE HALF (MAKE FROM MS20257-YC3-400) HINGE HALF STOP SCREW WASHER (REPLACED BY NAS1149C0363R) WASHER (REPLACES AN960C10) WASHER FITTING PLATE AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.	1 1 1 1 1 8 8 8 8 2 2	L PPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPP	







Figure 71-9. Cowling Installation (Sheet 1 of 2)

212_IPB_71_0009a





212-71-1009-2 C0000

Figure 71-9. Cowling Installation (Sheet 2 of 2)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-9. Cowling Installation			
	212-060-800-005	COWLING INSTL (S/N 30504 THRU 30553) (SEE FIG. 71-6, 71-7,	REF	NP	
	212-060-800-009	71-8 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-017	71-8 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-021	71-8 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-015	71-8 FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-060-800-101	71-8 FOR BALANCE OF BREAKDOWN)	REF	NP	
1 2	MS27039-1-07 212-061-807-001	SCREW	8 1	SP P	
2	212-061-807-011	30604 THRU 30610)	1	SP	
3 4	MS27039C1-07 212-061-808-003	30611 THRU 31311, 35001 THRU 35103)	19 1	SP NP	
5	212-061-808-004	. COWL ASSY, TWIN GEARBOX, TOP RH	1	NP	
6	MS21042L3	NUT, SELF-LOCKING	4	SP	
7 7	AN960PD10L AN960JD10LL	WASHER (REPLACED BY AN960JD10LL)	4 4	P P	
7	NAS1149D0316J	NAS1149D0316J)	4	SP	
8	MS27039-1-10	SCREW	4	SP	
9	MS27039-1-11	SCREW	2	SP	
10 10	AN960PD10L AN960JD10LL	WASHER (REPLACED BY AN960JD10LL)	2 2	P P	
4.0	NA 044 40 B0040 I	NAS1149D0316J)		0.0	
10	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	2	SP	
11 11	AN960PD10 AN960JD10	WASHER (REPLACED BY AN960JD10)	2	SP P	
11	NAS1149D0363J	NAS1149D0363J)	2	SP	l
12	NAS1330S3K116	NUT	2	SP	
13	212-061-816-001	HINGE HALF	2	NP	
14	212-061-808-015	SHIM	2	SP	
15	MS27039-1-07	SCREW	36	SP	
16	212-061-812-009	. COWL ASSY, TWIN GEARBOX, LH SIDE (S/N 30504 THRU 30578)	1	SP	
16	212-061-812-103	. COWL ASSY, TWIN GEARBOX, EIT SIDE (S/N 30504 THING 30576) . COWL ASSY, TWIN GEARBOX, LH SIDE (S/N 30579 THRU 31311, 35001 THRU 35101) (REPLACED BY 212-061-812-109)	1	NP	
16	212-061-812-109	COWL ASSY, TWIN GEARBOX, LH SIDE (COMPOSITE) (S/N 35102 THRU 35103) (REPLACES 212-061-812-103)	1	SP	
17 17	212-061-812-010 212-061-812-104	COWL ASSY, TWIN GEARBOX, RH SIDE (S/N 30504 THRU 30578) COWL ASSY, TWIN GEARBOX, RH SIDE (S/N 30579 THRU 31311,	1 1	SP NP	
17	212-061-812-110	35001 THRU 35101) (REPLACED BY 212-061-812-110) COWL ASSY, TWIN GEARBOX, RH SIDE (COMPOSITE) (S/N 35102 THRU 35103) (REPLACES 212-061-812-104)	1	SP	
18	212-061-812-101	DOOR ASSY, LH (USBL ON 212-061-812-009 AND -103)	1	NP	
18	212-061-812-111	DOOR ASSY, LH (OSBE ON 212-001-612-009 AND -103)		NP	
18	212-061-812-111	DOOR ASSY, RH (USBL ON 212-061-812-009)	1	NP	
18	212-061-812-102	DOOR ASSY, RH (USBL ON 212-061-612-010 AND -104)	1	NP	
19	90-030-05A5	LATCH	2	SP	
20	H6099A025A	HINGE ASSY (REFERENCE ASB 212-10-136) (USBL ON 212-061-812-101 AND -102)	1	SP	



PART NUMBER Figure 71-9. Cowling Installation (Cont'd)	(1)	(2)	(3)	(4)	(5)	(6)
MS20257C4-415		PART NUMBER	ITEM NAME	PER	V A I	U 0 C
212-061-812-011			Figure 71-9. Cowling Installation (Cont'd)			
212-061-812-011	20	MS20257C4-415		1	NP	
212-061-812-113	21	212-061-812-011	FRAME ASSY, LH (USBL ON 212-061-812-009) (REPLACED BY	1	NP	
21	21	212-061-812-105	212-061-812-105)	1	NP	
212-061-812-012	0.4	040 004 040 440	212-061-812-011)		0.0	
212-061-812-106						
212-061-812-106	21	212-061-812-012	FRAME ASSY, RH (USBL ON 212-061-812-010) (REPLACED BY	1	NP	
21 212-061-812-014	21	212-061-812-106	FRAME ASSY, RH (USBL ON 212-061-812-104) (REPLACES	1	NP	
22 212-061-812-022 P.LATE, LH. (USBL ON 212-061-812-012 AND -105).	24	242 004 042 444	212-061-812-012)		CD	
22 212-061-812-022					_	
23				-		
232 212-061-812-107						
23	-			-		
212-061-812-108			SPLICE, LH (USBL ON 212-061-812-105)			
212-061-812-083	-		SPLICE, RH (USBL ON 212-061-812-012)			
24	-			-		
25				-		
212-061-812-068				-		
26 NAS679A3 NUT (REPLACED BY MS21042L3) 2 NP 26 MS21042L3 NUT, SELF-LOCKING (REPLACED SY AN960JD10LL) 2 SP 27 AN960D10L WASHER (REPLACED BY AN960JD10LL) 2 P 27 AN960J10LL WASHER (REPLACES AN960DD10L) (REPLACED BY 2 P 28 MS27039-1-11 SCREW 2 SP 29 209-062-822-001 STRUT 2 SP 30 NAS679A3 NUT (REPLACED BY MS21042L3) 4 NP 30 MS21042L3 NUT, SELF-LOCKING (REPLACES NAS679A3) 4 SP 31 AN960JD10LL WASHER (REPLACED BY MS60JD10LL) 32 P 31 AN960JD10LL WASHER (REPLACED BY AN960JD10LL) 32 P 31 NAS1149D0316J WASHER (REPLACES AN960DD10LL) 32 P 32 MS27039-1-21 SCREW. 4 SP 33 212-061-814-001 SCOOP ASSY, OIL COOLER, LH (S/N 30504 THRU 30578) 1 NP 34 212-061-814-102 </td <td>_</td> <td></td> <td></td> <td>-</td> <td></td> <td></td>	_			-		
26 MS21042L3 NNT, SELF-LOCKING (REPLACES NAS679A3) 2 SP 27 AN960PD10L WASHER (REPLACED SY AN960JD10LL) 2 P 27 AN960JD10LL WASHER (REPLACES AN960PD10L) (REPLACED BY 2 P 28 MS27039-1-11 SCREW. 2 SP 29 209-062-822-001 STRUT. 2 SP 30 NAS679A3 NUT (REPLACED BY MS21042L3) 4 NP 30 MS21042L3 NUT, SELF-LOCKING (REPLACES NAS679A3) 4 SP 31 AN960PD10L WASHER (REPLACED BY AN960JD10LL) 32 P 31 AN960PD10L WASHER (REPLACES AN960JD10LL) 32 P 31 AN960JD10LL WASHER (REPLACES AN960JD10LL) 32 P 32 MS27039-1-21 SCOOP ASSY, OIL COOLER, LH (S/N 30504 THRU 30578) 1 SP 33 212-061-814-101 SCOOP ASSY, OIL COOLER, LH (S/N 30579 THRU 30578) 1 NP 34 212-061-814-102 SCOOP ASSY, OIL COOLER, LH (S/N 30592 THRU 35103) 1 NP				-		
27 AN960PD10L	26	NAS679A3	NUT (REPLACED BY MS21042L3)			
AN960JD10LL	26	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)		SP	
AN960JD10LL	27	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	2	Р	
27 NAS1149D0316J WASHER (REPLACÉS AN960JD10LL) 2 SP 28 MS27039-1-11 SCREW 2 SP 30 NAS679A3 NUT (REPLACED BY MS21042L3) 4 NP 30 MS21042L3 NUT (REPLACED BY MS2104L3) 4 NP 31 AN960PD10L WASHER (REPLACED BY AN960JD10LL) 32 P 31 AN960JD10LL WASHER (REPLACES AN960JD10LL) 32 P 31 NAS1149D0316J WASHER (REPLACES AN960JD10LL) 32 P 32 MS27039-1-21 SCREW 32 SCREW 4 SP 33 212-061-814-001 SCCOP ASSY, OIL COOLER, LH (S/N 30504 THRU 30578) 1 SP 33 212-061-814-101 SCOOP ASSY, OIL COOLER, LH (S/N 35092 THRU 35103) 1 NP 34 212-061-814-102 SCOOP ASSY, OIL COOLER, RH (S/N 305094 THRU 30578) 1 NP 34 212-061-814-100 SCOOP ASSY, OIL COOLER, RH (S/N 305094 THRU 35103) 1 NP 34 212-061-814-100 SCOOP ASSY, OIL COOLER, RH (S/N	27	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY	2	Р	
28 MS27039-1-11 SCREW 2 SP 29 209-062-822-001 STRUT 2 SP 30 NAS679A3 NUT (REPLACED BY MS21042L3) 4 NP 30 MS21042L3 NUT, SELF-LOCKING (REPLACES NAS679A3) 4 SP 31 AN960JD10L WASHER (REPLACES AN960D10LL) 32 P 31 AN960JD10LL WASHER (REPLACES AN960D10LL) (REPLACED BY 32 P 31 NAS1149D0316J WASHER (REPLACES AN960D10LL) 32 SP 32 MS27039-1-21 SCOOP ASSY, OIL COOLER, LH (S/N 30504 THRU 30578) 1 SP 33 212-061-814-101 SCOOP ASSY, OIL COOLER, LH (S/N 30597 THRU 31311, 35001 1 NP 34 212-061-814-139 SCOOP ASSY, OIL COOLER, RH (S/N 30592 THRU 35103) 1 NP 34 212-061-814-102 SCOOP ASSY, OIL COOLER, RH (S/N 30597 THRU 31311, 35001 1 NP 34 212-061-814-100 SCOOP ASSY, OIL COOLER, RH (S/N 30597 THRU 35103) 1 NP 35 MS27039-1-12 SCEW SCOO	27	NAS11/10D0316 I	MASTI49D03T00)	2	SD	
29 209-062-822-001 STRUT 2 SP 30 NAS679A3 NUT (REPLACED BY MS21042L3) 4 NP 30 MS21042L3 4 NP 31 AN960PD10L WASHER (REPLACED BY AN960JD10LL) 32 P 31 AN960JD10LL WASHER (REPLACES AN960PD10L) (REPLACED BY AN960JD10LL) 32 P 31 NAS1149D0316J WASHER (REPLACES AN960JD10LL) 32 SP 32 MS27039-1-21 SCREW 4 SP 33 212-061-814-001 SCOOP ASSY, OIL COOLER, LH (S/N 30594 THRU 30578) 1 SP 33 212-061-814-139 SCOOP ASSY, OIL COOLER, LH (S/N 30592 THRU 35103) 1 NP 34 212-061-814-109 SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 30578) 1 NP 34 212-061-814-102 SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 30578) 1 NP 34 212-061-814-102 SCOOP ASSY, OIL COOLER, RH (S/N 30592 THRU 31311, 35001 1 NP 35 MS27039-1-12 SCCOP ASSY, OIL COOLER, RH (S/N 30592 THRU 31311, 35001			. WASHER (REPLACES ANSOUJDTULL)			
NAS679A3					_	
MS21042L3						
AN960PD10L			NUT (REPLACED BY MS21042L3)			
NAS1149D0316J WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J) SP NAS1149D0316J SCREW SCOOP ASSY, OIL COOLER, LH (S/N 30504 THRU 30578) 1 NP THRU 35091) (REPLACED BY 212-061-814-139) SCOOP ASSY, OIL COOLER, LH (S/N 30579 THRU 31311, 35001 NP THRU 35091) (REPLACED BY 212-061-814-139) SCOOP ASSY, OIL COOLER, LH (S/N 30579 THRU 31311, 35001 NP THRU 35091) (REPLACED BY 212-061-814-139) SCOOP ASSY, OIL COOLER, LH (S/N 30502 THRU 35103) 1 NP (REPLACES 212-061-814-101) SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 30578) 1 NP (REPLACES 212-061-814-101) SCOOP ASSY, OIL COOLER, RH (S/N 30579 THRU 31311, 35001 1 NP THRU 35091) (REPLACED BY 212-061-814-140) SCOOP ASSY, OIL COOLER, RH (S/N 30579 THRU 31311, 35001 1 NP (REPLACES 212-061-814-102) SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCRE				-	_	
NAS1149D0316J WASHER (REPLACES AN960JD10LL) 32 SP						
32 MS27039-1-21 SCREW			NAS1149D0316J)			
32 MS27039-1-21 SCREW. 4 SP 33 212-061-814-001 SCOOP ASSY, OIL COOLER, LH (S/N 30504 THRU 30578) 1 SP 33 212-061-814-101 SCOOP ASSY, OIL COOLER, LH (S/N 30579 THRU 31311, 35001 1 NP 33 212-061-814-139 SCOOP ASSY, OIL COOLER, LH (S/N 35092 THRU 35103) 1 NP 34 212-061-814-002 SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 30578) 1 P 34 212-061-814-102 SCOOP ASSY, OIL COOLER, RH (S/N 30579 THRU 31311, 35001 1 NP 34 212-061-814-102 SCOOP ASSY, OIL COOLER, RH (S/N 30592 THRU 35103) 1 NP 34 212-061-814-102 SCOOP ASSY, OIL COOLER, RH (S/N 30579 THRU 35103) 1 NP 34 212-061-814-140 SCOOP ASSY, OIL COOLER, RH (S/N 30592 THRU 35103) 1 NP 35 MS27039-1-12 SCCEW. SCOOP ASSY, OIL COOLER, RH (S/N 30592 THRU 35103) 1 NP 36 AN960PD10L WASHER (REPLACED BY AN960JD10LL) 6 P 36 AN960JD10LL WASHER (REPLACES AN960JD10LL) 6 P 37 212-061-817-001 WASHER (REPLAC						
33 212-061-814-001 .SCOOP ASSY, OIL COOLER, LH (S/N 30504 THRU 30578)	-		. SCREW			
THRU 35091) (REPLACED BY 212-061-814-139) SCOOP ASSY, OIL COOLER, LH (S/N 35092 THRU 35103) 1 NP (REPLACES 212-061-814-101) SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 30578) 1 P SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 31311, 35001 1 NP THRU 35091) (REPLACED BY 212-061-814-140) THRU 35091) (REPLACED BY 212-061-814-140) SCOOP ASSY, OIL COOLER, RH (S/N 30579 THRU 31311, 35001 1 NP (REPLACES 212-061-814-140) SCOOP ASSY, OIL COOLER, RH (S/N 35092 THRU 35103) 1 NP (REPLACES 212-061-814-102) SCREW						
33 212-061-814-139 . SCOOP ASSY, OIL COOLER, LH (S/N 35092 THRU 35103) 1 NP 34 212-061-814-002 . SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 30578) 1 P 34 212-061-814-102 . SCOOP ASSY, OIL COOLER, RH (S/N 30579 THRU 31311, 35001 1 NP 34 212-061-814-140 . SCOOP ASSY, OIL COOLER, RH (S/N 35092 THRU 35103) 1 NP 35 MS27039-1-12 . SCOOP ASSY, OIL COOLER, RH (S/N 35092 THRU 35103) 1 NP 36 AN960PD10L . SCREW. 6 SP 36 AN960JD10LL . WASHER (REPLACED BY AN960JD10LL) 6 P 36 NAS1149D0316J . WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J) 6 P 37 212-061-817-001 . FITTING (REPLACES AN960JD10LL) 6 SP 37 212-061-817-005 . FITTING (REPLACES 212-061-817-005) 2 NP 38 212-061-814-037 . SHIM . SHIM 2 SP 39 212-061-814-003 . FAIRING ASSY, LH (S/N 30579 THRU 31311, 35001 THRU 35091) 1 P	33	212-061-814-101	. SCOOP ASSY, OIL COOLER, LH (S/N 30579 THRU 31311, 35001	1	NP	
34 212-061-814-002 . SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 30578)	33	212-061-814-139	. SCOOP ASSY, ÓIL COOLER, LH (S/N 35092 THRÚ 35103)	1	NP	
34 212-061-814-002 . SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 30578)			(REPLACES 212-061-814-101)			
34 212-061-814-102 . SCOOP ASSY, OIL COOLER, RH (S/N 30579 THRU 31311, 35001 THRU 35091) (REPLACED BY 212-061-814-140)	34	212-061-814-002	. SCOOP ASSY, OIL COOLER, RH (S/N 30504 THRU 30578)	1	Р	
34 212-061-814-140 . SCOOP ASSY, ÓIL COOLER, RH (S/N 35092 THRÚ 35103) 1 NP 35 MS27039-1-12 . SCREW. . SCREW. . WASHER (REPLACED BY AN960JD10LL) 6 P 36 AN960JD10LL . WASHER (REPLACES AN960JD10LL) 6 P 36 NAS1149D0316J . WASHER (REPLACES AN960JD10LL) 6 SP 37 212-061-817-001 . FITTING (REPLACED BY 212-061-817-005) 2 NP 37 212-061-814-037 . FITTING (REPLACES 212-061-817-001) 2 SP 38 212-061-814-033 . SHIM. 2 SP 39 212-061-814-103 . FAIRING ASSY, LH (S/N 30579 THRU 31311, 35001 THRU 35091) 1 P	34	212-061-814-102	. SCOOP ASSY, OIL COOLER, RH (S/N 30579 THRU 31311, 35001	1	NP	
35 MS27039-1-12 SCREW	34	212-061-814-140	. SCOOP ASSY, ÓIL COOLER, RH (S/N 35092 THRÚ 35103)	1	NP	
36 AN960PD10L WASHER (REPLACED BY AN960JD10LL) 6 P 36 AN960JD10LL WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J) 6 P 37 212-061-817-001 WASHER (REPLACES AN960JD10LL) 6 SP 37 212-061-817-005 FITTING (REPLACED BY 212-061-817-005) 2 NP 38 212-061-814-037 FITTING (REPLACES 212-061-817-001) 2 SP 39 212-061-814-003 FAIRING ASSY, LH (S/N 30504 THRU 30578) 1 SP 39 212-061-814-103 FAIRING ASSY, LH (S/N 30579 THRU 31311, 35001 THRU 35091) 1 P	35	MS27039-1-12		6	SP	
36 AN960JD10LL WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)				-	_	
36 NAS1149D0316J WASHER (REPLACES AN960JD10LL) 6 SP 37 212-061-817-001 FITTING (REPLACED BY 212-061-817-005) 2 NP 38 212-061-814-037 FITTING (REPLACES 212-061-817-001) 2 SP 39 212-061-814-003 FAIRING ASSY, LH (S/N 30504 THRU 30578) 1 SP 39 212-061-814-103 FAIRING ASSY, LH (S/N 30579 THRU 31311, 35001 THRU 35091) 1 P			WASHER (REPLACES AN960PD10L) (RÉPLACED BY	-	-	
37 212-061-817-001 FITTING (REPLACED BY 212-061-817-005) 2 NP 37 212-061-817-005 FITTING (REPLACES 212-061-817-001) 2 SP 38 212-061-814-037 SHIM	36	NAS1149D03161	WASHER (REDIACES ANGEOID1011)	6	SP	
37 212-061-817-005 FITTING (REPLACES 212-061-817-001) 2 SP 38 212-061-814-037 SHIM				-	_	
38 212-061-814-037 SHIM	-					
39					_	
39 212-061-814-103 FAIRING ASSY, LH (S/N 30579 THRU 31311, 35001 THRU 35091) 1 P					_	
				-		
(11001 021040 004 044 404)	39	212-001-014-103		'	Г	
(USBL ON 212-061-814-101)			(USBL ON 212-061-814-101)			



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-9. Cowling Installation (Cont'd)			
39	212-061-814-141	FAIRING ASSY, LH (S/N 35092 THRU 35103) (USBL ON 212-061-814-139)	1	Р	
39 39	212-061-814-004 212-061-814-104	. FAIRING ASSY, RH (S/N 30504 THRU 30578)	1 1	P NP	
39	212-061-814-142	(USBL ON 212-061-814-102)	1	Р	
39A	212-061-814-023	212-061-814-140)	1	NP	
		RAMP (USBL ON 212-061-814-103 AND -141)	-		
39A	212-061-814-024	RAMP (USBL ON 212-061-814-104 AND -142)	1	NP	
39B	212-061-814-127	DOUBLER (USBL ON 212-061-814-103 AND -141)	1	NP	
39B	212-061-814-128	DOUBLER (USBL ON 212-061-814-104 AND -142)	1	NP	
40	MS21075L3	NUTPLATE (REPLACED BY MS21075L3N)	5	NP	
_	MS21075L3N		5	SP	
40		NUTPLATE (REPLACES MS21075L3)	5	_	
41	MS21075L3	NUTPLATE (S/N 30504 THRU 31311, 35001 THRU 35055) (REPLACED BY MS21075L3N)	1	NP	
41	MS21075L3N	NUTPLATE (S/N 30504 THRU 31311, 35001 THRU 35055) (REPLACES MS21075L3)	1	SP	
4.4	00 070 0 0			O.D.	
41 42	90-070-3-2 H605S063A279	NÚTPLATE (S/N 35056 THRU SUB)	1 1	SP NP	
42	90-056-188-376	30578)	1	SP	
43	H605S063A279	31311, 35001 THRU SUB) LATCH ASSY, UPPER (PRE TB 212-96-158) (S/N 30504 THRU	1	NP	
40	110051/0000	30578)		0.0	
43 44	H605K3262 H605S063A104	LATCH ASSY, UPPER (POST TB 212-96-158)	1 1	SP SP	
44	90-056-130-376	30578)	1	NP	
	00 050 400 404	31311, 35001 THRU 35103)		0.0	
44	90-056-130-194	LATCH ASSY, AFT (S/N 30579 THRU 31311, 35001 THRU 35103)	1	SP	
44A	212-061-814-129	DOUBLER	1	NP	
44A	212-061-814-130	DOUBLER	1	NP	
45	140-001-3		4	SP	
-		WASHER	•		
46	212-061-814-045	CHAFE STRIP	1	SP	
47	212-061-814-137	DOUBLER ASSY, LH	1	NP	
47	212-061-814-138	DOUBLER ASSY, RH	1	NP	
48	212-061-814-047	DOUBLER (PRE TB 212-96-158)	2	NP	
-					
48	212-061-814-143	DOUBLER ASSY (POST TB 212-96-158)	2	NP	
49	NAS679A3	. NUT (REPLACED BY MS21042L3)	2	NP	
49	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP	
50	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	8	Р	
50	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	8	Р	
50	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	8	SP	
			-		
51	NAS43DD3-28	. SPACER (REPLACED BY NAS43DD3-28N)	2	SP	
51	NAS43DD3-28N	. SPACER (REPLACES NAS43DD3-28)	2	SP	
52	AN42B10A	. EYEBOLT (REPLACED BY AN42B-10A)	2	NP	
52	AN42B-10A	EYEBOLT (REPLACES AN42B10A)	2	SP	
53	212-061-811-007	. COWL ASSY, OIL COOLER SUPPORT (S/N 30504 THRU 30553)	1	NP	
53	212-061-811-009	(SEE FIG. 71-10 FOR BREAKDOWN)	1	NP	
53	212-061-811-013	35001 THRU 35016) (SEE FIG. 71-10 FOR BREAKDOWN) (REPLACED BY 212-061-811-013)	1	NP	
		(REPLACES 212-061-811-009)			
	212-061-813-013	. FAIRING ASSY, OIL COOLER	1	NP	
54	MS27039-1-08	SCREW	13	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	0 C
		Figure 71-9. Cowling Installation (Cont'd)			
55 55 56 57 57	AN960-10L NAS1149F0332P 212-061-813-011 212-061-813-055 212-061-813-071	WASHER (REPLACED BY NAS1149F0332P) WASHER (REPLACES AN960-10L) FAIRING ASSY SEAL (REPLACED BY 212-061-813-071, 110-004-11-0050) SEAL (REPLACES 212-061-813-055) (REPLACED BY 110-004-11-0050, 110-004-11)	13 13 1 1 1	P SP NP NP NP	
57 58 58	110-004-11-0050 212-061-813-056 212-061-813-072	SEAL (REPLACES 212-061-813-055 AND -071)	1 1 1	NP NP NP	
58 59 59	110-004-11-0050 212-061-813-057 212-061-813-073	SEAL (REPLACES 212-061-813-056 AND -072)	1 1 1	NP NP NP	
59 60 61 62 63 64 65 66 67 68	110-004-11-0170 212-061-813-021 212-061-813-017 212-061-813-039 212-061-813-040 212-061-813-019 212-061-813-029 212-061-813-032 212-061-813-031 MS35489-11	SEAL (REPLACES 212-061-813-057 AND -073) SKIN (REPLACED BY 212-061-813-119) SKIN (REPLACES 212-061-813-021) SKIN CAP CAP STIFFENER RETAINER STIFFENER STIFFENER GROMMET	1 1 1 1 1 1 1 1 1 1 1 1 1	P N P P P P P P P P P P P P P P P P P P	
	212-061-902-161 212-061-902-171	FIREWALL ASSY, AFT (S/N 30504 THRU 30530) (SEE FIG. 71-1 FOR NHA) (REPLACED BY 212-061-902-171, -177, -187 AND -203) . FIREWALL ASSY, AFT (S/N 30504 THRU 30553) (SEE FIG. 71-1 FOR NHA) (REPLACES 212-061-902-161) (REPLACED BY	REF REF	NP NP	
	212-061-902-177	212-061-902-177, -187 AND -203) FIREWALL ASSY, AFT (S/N 30504 THRU 31124) (SEE FIG. 71-1 FOR NHA) (REPLACES 212-061-902-161 AND -171) (REPLACED BY	REF	Р	
	212-061-902-187	212-061-902-187 AND -203)	REF	NP	
	212-061-902-203	FIREWALL ASSY, AFT (S/N 30504 THRU 31311, 35001 THRU 35065) (SEE FIG. 71-1 FOR NHA) (REPLACES 212-061-902-161, -171,	REF	Р	
	212-061-902-207	-177 AND -187)	REF	Р	
69 69	212-061-902-217 MS17160-25 M24066/2-325	FIREWALL ASSY, AFT (S/N 35097 THRU 35103) (SEE FIG. 71-1 FOR NHA)	REF REF REF	SP NP SP	
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			




Figure 71-10. Oil Cooler Support Cowling Assembly



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-10. Oil Cooler Support Cowling Assembly			
	212-061-811-007	COWL ASSY, OIL COOLER SUPPORT (S/N 30504 THRU 30553)	REF	NP	
	212-061-811-009	(SEE FIG. 71-9 FOR NHA)	REF	NP	
	212-061-811-013	212-061-811-013)	REF	NP	
1 2 2 3 4 5 5 6 6 7 8	MS27039-1-18 AN960-10L NAS1149F0332P MS21059L3 212-061-818-003 212-061-818-004 205-060-772-003 212-061-811-109 20-042-11-30 MS27039C1-07 AN960C10L	212-061-811-009) . SCREW WASHER (REPLACED BY NAS1149F0332P) . WASHER (REPLACES AN960-10L) NUTPLATE . HOOK, L/H . HOOK, R/H . BASE . SHIM . RADIUS BLOCK . SCREW (S/N 30554 THRU SUB, 35001 THRU SUB) . WASHER (S/N 30554 THRU SUB, 35001 THRU SUB) (REPLACED	4 12 12 4 1 1 2 6 2 4	SP P SP SP SP SP SP P	
8	NAS1149C0332R	BY NAS1149C0332R)	4	SP	
9 10 11	MS21059L3K MS27039C0807 AN960C8L	NUTPLATE (S/N 30554 THRU SUB, 35001 THRU SUB)	4 4 4	SP SP SP	
11	NAS1149CN816R	BY NAS1149CN816R)	4	SP	
12 13 14	MS21059L08K 212-061-819-001 212-060-822-001	. NUTPLATE (S/N 30554 THRU SUB, 35001 THRU SUB)	4 4 1	SP P SP	
15 15 16 16 17 18 19 20 20A 21 21 22 23 24 25 26 27 27A 27A 28A	MS20253P2 MS20253P2-7200 205-030-353-001 120-128-1 212-060-822-011 212-060-822-013 212-060-829-101 212-060-829-102 212-060-829-103 212-060-829-104 212-060-829-104 212-060-829-105 212-060-829-105 212-060-829-105 212-061-811-129 212-061-811-123 212-061-811-130 212-061-811-044	. PIN (REPLACED BY MS20253P2-7200) . PIN, HINGE (REPLACES MS20253P2) . SPRING (REPLACED BY 120-128-1) . SPRING (REPLACES 205-030-353-001) . HINGE HALF . HINGE HALF . STOP . ACCESS PANEL, LH (POST TB 212-91-135) . ACCESS PANEL, RH (POST TB 212-91-135) . DOOR ASSY, LH . DOOR ASSY, RH . ATTACHMENT . HINGE . STUD . GROMMET . FRAME ASSY, LH . FRAME ASSY, LH . RECEPTACLE . SKIN, LH (S/N 30504 THRU 31311, 35001 THRU 35016) . SKIN, LH (S/N 30504 THRU 31311, 35001 THRU SUB) . SKIN, RH (S/N 30504 THRU 31311, 35001 THRU 35016) . SKIN, RH (S/N 30504 THRU SUB, 35017 THRU SUB) . SKIN, RH (S/N 31312 THRU SUB, 35017 THRU SUB) . SKIN, RH (S/N 31312 THRU SUB, 35017 THRU SUB) . SKIN, RH (S/N 31312 THRU SUB, 35017 THRU SUB)	1 1 1 1 1 1 1 1 2 1 2 1 1 1 1 1 1 1 1 1	P	
28A 29	212-061-811-044 MS21042L3	. SKIN, RH	1	NP SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-10. Oil Cooler Support Cowling Assembly (Cont'd)			
30 30	AN960PD10L AN960JD10LL	. WASHER (REPLACED BY AN960JD10LL)	1 1	P P	
30 31 32 33 34 35 36 37 38 39 40 41 42 42 43 44 45 46 47 48 49 49 49 50 50 51 52 52 53 54 56 56 56	AN960JD10LL NAS1149D0316J MS35207-261 AN743-12 MS27039-1-06 AN960C10L NAS1149C0332R MS21059L3K MS21073L3K 212-061-811-081 212-061-811-077 212-061-811-078 212-061-811-040 212-061-811-040 212-061-811-095 212-061-811-033 212-061-811-033 212-061-811-089 212-061-811-089 212-061-811-089 212-061-811-089 212-061-811-025 212-061-811-025 212-061-811-025 212-061-811-026 212-061-811-025 212-061-811-025 212-061-811-025 212-061-811-025 212-061-811-025 212-061-811-025 212-061-811-025 212-061-811-025 212-061-811-025 212-061-811-051 212-061-811-051 212-061-811-051 212-061-811-052 212-061-811-052 212-061-811-052 212-061-811-052 212-061-811-052 212-061-811-052 212-061-811-052 212-061-811-052 212-061-811-052 212-061-811-052 212-061-811-052 212-061-811-099 212-061-811-099 212-061-811-048	WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J). WASHER (REPLACES AN960JD10LL) SCREW. BRACKET SCREW. WASHER (REPLACED BY NAS1149C0332R). WASHER (REPLACES AN960C10L). NUTPLATE NUTPLATE FRAME CHANNEL, LH. CHANNEL, RH BRACKET, LH. BRACKET, LH. SUPPORT SUPPORT, SUPPORT, LH. SUPPORT, RH BRACKET, LH. BRACKET, LH. BRACKET, LH. BRACKET, LH. BRACKET, LH. BRACKET, LH. BRACKET, LH. BRACKET, LH. GUSSET, LH. GUSSET, RH. SUPPORT, RH BRACKET, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, LH. SUPPORT, SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOM SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOMON SOM SOMON SOMON SOM SOMON SOM SOM SOM SOM SOM SOM SOM SOM SOM SOM	1 1 1 1 5 5 5 2 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	P	
		NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 71-11. Fairing Assembly, Air Inlet



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	4 > 4 _ L	500
		Figure 71-11. Fairing Assembly, Air Inlet			
	212-060-802-097	FAIRING ASSY, AIR INLET, LH (S/N 30504 THRU 31311, 35001 THRU 35040, 35046 THRU 35051) (SEE FIG. 71-6 FOR NHA)	REF	NP	
	212-060-802-155	FAIRING ASSY, AIR INLET, LH (S/N 35041 THRU 35045, 35052	REF	NP	
	212-060-802-163	THRU 35102) (SEE FIG. 71-6 FOR NHA)	REF	Р	
	212-060-802-098	71-6 FOR NHA) FAIRING ASSY, AIR INLET, RH (S/N 30504 THRU 31311, 35001	REF	NP	
	212-060-802-156	THRU 35040, 35046 THRU 35051) (SEE FIG. 71-6 FOR NHA) FAIRING ASSY, AIR INLET, RH (S/N 35041 THRU 35045, 35052	REF	NP	
	212-060-802-164	THRU 35102) (SEE FIG. 71-6 FOR NHA) FAIRING ASSY, AIR INLET, RH (S/N 35103 THRU SUB) (SEE FIG.	REF	Р	
1	MS27039C1-07	71-6 FOR NHA)SCREW	18	SP	
2 2	AN960PD10L AN960JD10LL	. WASHER (REPLACED BY AN960JD10LL)	18 18	P P	
_		. WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)		•	
2 2A	NAS1149D0316J MS27039C1-06	. WASHER (REPLACES AN960JD10LL)	18 19	SP SP	
2B	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	19	P	
2B	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	19	SP	
3	212-060-802-057	. FAIRING ASSY, LH (S/N 30504 THŔU 31311, 35001 THRU 35102)	1	NP	
3	212-060-802-167	. FAIRING ASSY, LH (S/N 35103 THRU SUB)	1	Р	
3	212-060-802-058 212-060-802-168	. FAIRING ASSY, RH (S/N 30504 THRU 31311, 35001 THRU 35102)	1	NP P	
4	MS27039C1-06	. FAIRING ASSY, RH (S/N 35103 THRU SUB)	2	SP	
5	AN960C10L	WASHER (REPLACED BY NAS1149C0332R)	2	P	
5	NAS1149C0332R	WASHER (REPLACES AN960C10L)	2	SP	
6	212-060-802-113	BRACKET	1	SP	
7 7	MS20392-2C35 MS20392-2S35	PIN (REPLACED BY MS20392-2S35)	1	P SP	
8	AN960PD10L	PIN (REPLACES MS20392-2C35)		P	
8	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY	1	P	
8	NAS1149D0316J	NAS1149D0316J)	1	SP	
9	H287-1	LATCH (REPLACED BY 90-029-1)	1	NP	
9	90-029-1	. LATCH (REPLACES H287-1)	1	SP	
10	NAS1297-3-1	BOLT	2	SP	
11 11	AN960PD416L AN960JD416L	WASHER (REPLACED BY AN960JD416L)	2 2	NP P	
		NAS1149D0416J)			
11	NAS1149D0416J	WASHER (REPLACES AN960JD416L)	2	SP	
12 12	212-060-802-089 212-060-802-090	RETAINER, LH	1	NP SP	
13	212-060-802-090	RETAINER, RH		NP	
13	110-004-23-0310	SEAL (MAKE FROM 110-004-23) (REPLACES 212-060-802-087)	1	NP	
13	110-004-23	SEAL (31 INCHES)	AR	SP	
14	212-060-802-035	SEAL, SUPPORT, LH	1	SP	
14	212-060-802-036	SEAL, SUPPORT, RH	1	SP	
15 15	212-060-802-015 212-060-802-016	SKIN, OUTER DH	1	NP NP	
16	212-060-802-016	SKIN, OUTER RH		P	
16	212-060-802-012	SKIN, INNER RH.	1	P	
17	212-060-802-009	. SKIN, LOWER LH	1	SP	
17	212-060-802-010	SKIN, LOWER RH	1	Р	
18	212-060-802-013	SKIN, UPPER LH	1	Р	
18	212-060-802-014	SKIN, UPPER RH	1	Р	
19 19	212-060-802-085 212-060-802-086	SKIN, LH	1 1	P P	
19	212-000-002-000	SKIN, RH	'		



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-11. Fairing Assembly, Air Inlet (Cont'd)			
20	212-060-802-063	FORMER, LH	1	Р	
20	212-060-802-064	FORMER, RH	1	Р	ł
21	212-060-802-065	FORMER, LH	1	Р	ł
21	212-060-802-066	FORMER, RH	1	Р	ł
22 22	212-060-802-095	FORMER, LH	1	NP NP	ł
23	212-060-802-096 212-060-802-091	FORMER, RH	1	NP	ł
23	212-060-802-091	DOUBLER, LH	1	SP	
24	212-060-802-103	DOUBLER, LH	1	NP	
24	212-060-802-104	DOUBLER, RH	1	NP	l
25	212-060-802-115	SHIM	1	Р	ĺ
26	212-060-802-019	ANGLE, LH (REPLACED BY 212-060-802-107)	1	Р	ł
26	212-060-802-107	ANGLE, LH (REPLACES 212-060-802-019)	1	NP	ĺ
26	212-060-802-020	ANGLE, RH (REPLACED BY 212-060-802-108)	1	Р	ĺ
26	212-060-802-108	ANGLE, RH (REPLACES 212-060-802-020)	1	NP	ĺ
27	212-060-802-021	ANGLE, LH (REPLACED BY 212-060-802-109)	1	Р	ł
27 27	212-060-802-109 212-060-802-022	ANGLE, LH (REPLACES 212-060-802-021)	1	NP P	ł
27	212-060-802-022	ANGLE, RH (REPLACED BY 212-060-802-110)	1	NP	ĺ
28	212-060-802-110	CHANNEL, LH	1	NP	l
28	212-060-802-026	. CHANNEL, RH	1	NP	l
29	212-060-802-073	SUPPORT, LH.	1	NP	ľ
29	212-060-802-074	SUPPORT, RH	1	SP	l
30	212-060-802-105	GUSSET, LH	1	NP	l
30	212-060-802-106	GUSSET, RH	1	NP	ĺ
31	212-060-802-067	INTERCOSTAL, LH	1	Р	ĺ
31	212-060-802-068	INTERCOSTAL, RH	1	Р	ł
32	212-060-802-059	LIP ASSY, LH	1	NP	ĺ
32 33	212-060-802-060 212-060-802-055	LIP ASSY, RH	1	NP NP	ĺ
33	212-060-802-056	DOUBLERDOUBLER	1	NP	ĺ
33A	MS21048-3K	NUTPLATE (REPLACED BY NAS1770C3K)	19	NP	ĺ
33A	NAS1770C3K	NUTPLATE (REPLACES MS21048-3K)	19	SP	ĺ
33B	212-060-802-099	SUPPORT, LH.	1	NP	ĺ
33B	212-060-802-100	SUPPORT, RH	1	NP	ĺ
34	212-060-818-005	COWLING ASSY, ENGINE ACCESSORY GEARBOX, LH (S/N 30504 THRU 31311, 35001 THRU 35040, 35046 THRU 35051)	1	Р	
34	212-060-818-107	. COWLING ASSY, ENGINE ACCESSORY GEARBOX, LH (S/N 35041	1	Р	
34	212-060-818-111	THRU 35045, 35052 THRU 35080)	1	Р	
34	212 060 919 006	THRU SUB, 35081 THRU SUB)	4	SP	
34	212-060-818-006	COWLING ASSY, ENGINE ACCESSORY GEARBOX, RH (S/N 30504 THRU 31311, 35001 THRU 35040, 35046 THRU 35051)	1	SP	
34	212-060-818-108	. COWLING ASSÝ, ENGINE ACCESSORY GEARBOX, RH (Ś/N 35041 THRU 35045, 35052 THRU 35080)	1	Р	
34	212-060-818-112	. COWLING ASSY, ENGINE ACCESSORY GEARBOX, RH (S/N 31312	1	Р	
25	MC24042L2	THRU SUB, 35081 THRU SUB)		60	
35 36	MS21042L3 AN960PD10L	NUT, SELF-LOCKING	6 6	SP P	
36	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY	6	P	
36	NAS1149D0316J	NAS1149D0316J)	6	SP	
37	MS27039-1-08	SCREW	6	SP	
38	MS27039-1-08	SCREW	2	SP	
39	AN960PD10L	WASHER (REPLACED BY AN960JD10LL)	2	Р	
39	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	2	Р	
39	NAS1149D0316J	WASHER (REPLACES AN960JD10LL)	2	SP	
40	MS21061L3	NUTPLATE	2	SP	ł



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-11. Fairing Assembly, Air Inlet (Cont'd)			
41	MS21042L3	NUT, SELF-LOCKING	1	SP	
42	AN960PD10L	WASHER (REPLACED BY AN960JD10LL)	1	Р	
42	AN960JD10LL	WASHER (REPLACES AN960PD10L) (REPLACED BY	1	Р	
42	NAS1149D0316J	NAS1149D0316J)	1	SP	
42	AN3-4A	BOLT		SP	
44	212-060-819-001	FITTING (S/N 30504 THRU 30755) (REPLACED BY 212-060-819-003 AND -005)	2	NP	
44A	212-060-819-003	FITTING (S/N 30504 THRU 30755) (REPLACES 212-060-819-001)	1	NP	
44B	212-060-819-005	(REPLACED BY 212-060-819-005)	3	SP	
45	212-060-818-067	SHIM	5	SP	
	212-060-818-007	COWLING ASSY, LH (S/N 30504 THRU 31311, 35001 THRU 35040, 35046 THRU 35051)	1	NP	
	212-060-818-109	COWLING ASSY, LH (S/N 31312 THRU SUB, 35041 THRU 35045, 35052 THRU SUB)	1	NP	
	212-060-818-008	COWLING ASSY, RH (S/N 30504 THRU 31311, 35001 THRU 35040, 35046 THRU 35051)	1	NP	
	212-060-818-110	COWLING ASSY, RH (S/N 31312 THRU SUB, 35041 THRU 35045,	1	NP	
46	212-060-818-069	35052 THRU SUB)	1	NP	
46	110-004-8	SEAL (REPLACES 212-060-818-069)	Ιi	SP	
47	212-060-900-183	FIREWALL ASSY, LH (S/N 30504 THRU 31311, 35001 THRU 35040, 35046 THRU 35051) (SEE FIG. 71-3 FOR	1	NP	
47	212-060-900-301	BREAKDOWN) (REPLACED BY 212-060-900-301) FIREWALL ASSY, LH (SEE FIG. 71-3 FOR BREAKDOWN)	1	SP	
47	212-060-900-184	(REPLACES 212-060-900-183)	1	NP	
		BREAKDOWN) (REPLACED BY 212-060-900-302)			
47	212-060-900-302	FIREWALL ASSY, RH (SEE FIG. 71-3 FOR BREAKDOWN) (REPLACES 212-060-900-184)	1	SP	
48	212-060-818-061	STRAP, LH	1	Р	
48	212-060-818-062	STRAP, RH	1	NP	
49	212-060-818-019	FRAME, LH	1	NP	
49	212-060-818-020	FRAME, RH	1	NP	
50	212-060-818-021	FRAME, LH	1	NP	
50	212-060-818-022	FRAME, RH	1	Р	
51 51	212-060-818-023 212-060-818-024	FRAME, LH	1	NP NP	
51 52	212-060-818-024	FRAME, RH	1	NP P	
52 52	212-060-818-028	GUSSET, LH		NP	
52	212-060-818-028S	GUSSET, RH (REPLACES 212-060-818-028)	1	SP	
53	212-060-818-043	BRACKET, LH	1	P	
53	212-060-818-044	BRACKET, RH.	1	Р	
54	212-060-818-045	BRACKET, LH	1	P	
54	212-060-818-046	BRACKET, RH	1	Р	
54A	212-060-818-025	BEAM, LH	1	NP	
54A	212-060-818-026	BEAM, RH	1	NP	
55	212-061-210-001	. DUCT ASSY, FWD, LH	1	SP	
55	212-061-210-002	. DUCT ASSY, FWD, RH	1	SP	
56 57	212-061-210-031	SEAL	1	NP	
57 50	212-061-210-037	GASKET	1	SP	
58 59	212-061-208-001	PETAINED III	1 1	SP NP	
59 59	212-061-210-023 212-061-210-024	RETAINER, LH	1	NP NP	
60	212-061-210-024	RETAINER, RH		NP	
60	212-061-210-025	RETAINER, LH	1	NP	
		THE PARTY INTO THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF THE PROPERTY OF			



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
	212-061-210-039 212-061-210-040 MS21048-3 212-060-817-007 212-060-817-008 212-060-817-087 212-060-817-087 212-060-817-089	Figure 71-11. Fairing Assembly, Air Inlet (Cont'd) FRAME, LH FRAME, RH NUTPLATE PILLAR ASSY, LH (S/N 30504 THRU 31311, 35001 THRU 35080) (SEE FIG. 71-7 FOR NHA) PILLAR ASSY, RH (S/N 30504 THRU SUB) (SEE FIG. 71-7 FOR NHA) PILLAR ASSY, RH (S/N 30504 THRU 31311, 35001 THRU 35080) (SEE FIG. 71-7 FOR NHA) PILLAR ASSY, RH (S/N 35081 THRU SUB) (SEE FIG. 71-7 FOR NHA) PLATE, WEAR PLATE, WEAR AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.	1 1 3 REF REF	1	






Figure 71-12. Engine Mount Installation



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-12 Engine Mount Installation			
1 1A 1A 2 2 3 3 4 4 4 5 5 6 6 6 A 6 A 7 8 8 9 10 11 22 13 14 15 16	212-061-100-003 212-061-100-005 212-061-100-101 MS24665-306 NAS1022A8 MS17826-8 MS14145L8 AN960-816 NAS1149F0863P NAS464P8A25 NAS464P8-25 MS21042L6 MS17826-6 MS14145L6 AN960-616L NAS1149F0632P NAS464P6-25 MS24665-153 MS24665-155 MS21042L6 AN960-616 NAS1149F0663P MS20002C6 MS20006-22 MS21042L5 AN960-516 NAS1149F0563P MS20002C5 MS20005-20 212-061-115-007	Figure 71-12. Engine Mount Installation	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	PPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPPP	
16	212-061-115-002	(ALTERNATE PART) . FITTING, RH	1	Р	
17 18	212-061-109-003 212-061-109-004	SHIM, LH (S/N 30504 THRU 30614) (REPLACED BY 212-061-109-011)	1	P NP	
19 20 21 21A 21A 22 22 23 23 24 24 24A 25 26 26 27 28	212-061-109-004 212-061-109-011 212-061-109-005 212-061-109-006 MS24665-153 MS24665-155 MS21042L6 MS14145L6 AN960-616L NAS1149F0632P NAS464P6A17 NAS464P6-17 MS24665-153 MS24665-155 MS21042L5 AN960-516 NAS1149F0563P MS20002C5 MS20005-16 MS20005-18	212-061-109-011) . SHIM (REPLACES 212-061-109-003 AND -004) . SHIM, LH . SHIM, RH . PIN, COTTER (REPLACED BY MS24665-155) . PIN, COTTER (REPLACES MS24665-153) . NUT (S/N 30504 THRU 31124) . NUT (S/N 31125 THRU SUB) . WASHER (REPLACED BY NAS1149F0632P) . WASHER (REPLACES AN960-616L) . BOLT (S/N 30504 THRU 31124) . BOLT (S/N 31125 THRU SUB) . PIN, COTTER (REPLACED BY NAS1149F0632P) . WASHER (REPLACES AN960-616L) . BOLT (S/N 31125 THRU SUB) . PIN, COTTER (REPLACED BY MS24665-155) . PIN, COTTER (REPLACED BY MS24665-153) . NUT, SELF-LOCKING . WASHER (REPLACED BY NAS1149F0563P) . WASHER (REPLACES AN960-516) . WASHER . BOLT (S/N 30504 THRU 30849) . BOLT (S/N 30850 THRU SUB)	2 1 1 1 2 2 2 2 1 1 2 3 3 2 2 2	S S S S S S S S S S S S S S S S S S S	



(1)	(2)	(3)	(4)	(5) A	(6
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A	0 C
		Figure 71-12. Engine Mount Installation (Cont'd)			
29	MS21042L4	NUT	2	SP	
30	AN960-416	. WASHER (REPLACED BY AN960C416, NAS1149F0463P)	1	NP	
30	NAS1149F0463P	. WASHER (REPLACES AN960-416)	1	SP	
30	AN960C416	. WASHER, FLAT (REPLACES AN960-416) (REPLACED BY	1	Р	
0.0	NA 044 40 00 400 B	NAS1149C0463R)		0.0	
30 31	NAS1149C0463R MS20002C4	. WASHER (REPLACES AN960C416)	1 2	SP SP	
32	MS20002C4 MS20004-14	. WASHER	2	SP	
33	212-061-103-001	FITTING, LH	1	SP	
34	212-061-103-002	FITTING, RH	1	SP	
35	212-061-109-001	SHIM	2	SP	
36	212-061-108-001	. BI-POD ASSY (REPLACED BY 212-061-108-003)	1	NP	
36	212-061-108-003	. BI-POD ASSY (REPLACES 212-061-108-001)	1	SP	
37	209-062-109-001	BEARING	2	SP	
38	212-061-106-001	FITTING (S/N 30504 THRU 30614) (REPLACED BY	1	NP	
38	212-061-106-003	212-061-106-003)	1	SP	
38A	MS24665-306	FITTING (REPLACÉS 212-061-106-001)		SP	
39	NAS1022A8	. NUT (S/N 30504 THRU 31124)	1	NP	
39	MS17826-8	. NUT (S/N 31125 THRU SUB) (REPLACED BY MS14145L8)	l i	NP	
39	MS14145L8	. NUT (S/N 31125 THRU SUB) (REPLACES MS17826-8)	1	SP	
40	AN960-816	. WASHER (REPLACED BY NAS1149F0863P)	1	Р	
40	NAS1149F0863P	. WASHER (REPLACES AN960-816)	1	SP	
41	NAS464P8A27	. BOLT (S/N 30504 THRU 31124)	1	SP	
41 41A	NAS464P8-27 MS24665-153	BOLT (S/N 31125 THRU SUB)	1	SP NP	
41A 41A	MS24665-155	PIN, COTTER (REPLACED BY MS24665-155)		SP	
42	MS21042L6	NUT (S/N 30504 THRU 31124)	1	SP	
42	MS17826-6	. NUT (S/N 31125 THRU SUB) (REPLACED BY MS14145L6)	1	NP	
42	MS14145L6	. NUT (S/N 31125 THRU SUB) (REPLACES MS17826-6)	1	SP	
43	AN960-616L	. WASHER (REPLACED BY NAS1149F0632P)	1	Р	
43	NAS1149F0632P	. WASHER (REPLACES AN960-616L)	1	SP	
44	NAS464P6A17	. BOLT (S/N 30504 THRU 31124)	1	SP	
44 45	NAS464P6-17 MS21042L5	BOLT (S/N 31125 THRU SUB)	1	SP SP	
45 46	AN960-516	NUT, SELF-LOCKING		P	
46	NAS1149F0563P	. WASHER (REPLACES AN960-516)	1	SP	
47	MS20002C5	WASHER	1	SP	
48	MS20005-16	. BOLT (S/N 30504 THRU 30849)	2	SP	
48	MS20005-18	. BOLT (S/N 30850 THRU SUB)	2	SP	
49	MS21042L4	. NUT	2	SP	
50 50	AN960-416 NAS1149F0463P	. WASHER (REPLACED BY AN960C416, NAS1149F0463P)	3	NP SP	
50 50	AN960C416	. WASHER (REPLACES AN960-416)	3	P	
00	71143333413	NAS1149C0463R)		•	
50	NAS1149C0463R	. WASHER (REPLACES AN960C416)	3	SP	
51	MS20002C4	WASHER	2	SP	
52	MS20004-10	. BOLT	2	SP	
53	212-061-109-007	. SHIM (S/N 30504 THRU 30614) (REPLACED BY 212-061-109-013)	1	NP	
53	212-061-109-013	. SHIM (REPLACES 212-061-109-007)	1	SP	
54 55	212-061-109-009	SHIM	1	SP SP	
56	212-061-102-001 212-061-107-001	. FITTING		NP	
56	212-061-107-003	TRI-POD ASSY (REPLACED BY 212-061-107-003)	1	SP	
57	209-062-109-001	BEARING	3	SP	
58	212-061-105-001	. FITTING	1	SP	
58A	MS24665-153	. PIN, COTTER (REPLACED BY MS24665-155)	2	NP	
58A	MS24665-155	PIN, COTTER (REPLACES MS24665-153)	2	SP	
59	AN320C4	. NUT (S/N 30504 THRU 31124)	2	SP	ĺ



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-12. Engine Mount Installation (Cont'd)			
59 60 61 61 62 63 63 64 64 64 65 66 67 68 68 69 69 70 71 72 73 74 75 76 77 78 79	MS14145L4 AN960C416L NAS1149C0432R AN174-13 NAS464-4-15 AN310C4 MS14144L4 AN960C416L NAS1149C0432R AN174-13 NAS464-4-15 MS24665-153 MS24665-155 AN320C4 MS14145L4 AN960C416L NAS1149C0432R NAS464-4-15 212-061-117-001 209-062-105-001 AN320C4 AN310-4 MS14144L4 AN960C416L NAS1149C0432R AN174-23 20-057-4-32D MS21043-3 AN960C10L NAS1149C0332R AN173C23A 212-060-115-001 212-061-113-001 212-061-113-001 212-061-113-001 212-061-113-001 209-062-104-001 209-062-105-001	NUT (S/N 31125 THRU SUB). WASHER (REPLACES AN960C416L). BOLT (S/N 30504 THRU 30614) BOLT (S/N 30504 THRU 30614). BOLT (S/N 30504 THRU 31124). NUT (S/N 31125 THRU SUB). NUT (S/N 31125 THRU SUB). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACES AN960C416L). BOLT (S/N 30504 THRU 30614) BOLT (S/N 30504 THRU 30614). BOLT (S/N 30615 THRU SUB). PIN, COTTER (REPLACED BY MS24665-155). PIN, COTTER (REPLACES MS24665-153). NUT (S/N 30504 THRU 31124). NUT (S/N 30504 THRU SUB). WASHER (REPLACED BY MS214665-153). NUT (S/N 30504 THRU SUB). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0432R). WASHER (REPLACED BY NAS1149C0332R).	24422224422442222244412488422 2212	\circ \circ \circ \circ \circ \circ \circ \circ \circ \circ	







Figure 71-13. Air Management System Installation (Sheet 1 of 2)

71-99-00 Page 70

Rev. 8 30 APR 2010

ECCN EAR99





212_IPB_71_0002b

Figure 71-13. Air Management System Installation (Sheet 2 of 2)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-13. Air Management System Installation			
1 1 2 2 2 3 4 5 5 5 6 7	212-061-200-005 212-061-200-011 212-061-200-015 212-061-200-019 212-061-200-021 212-061-200-021 212-061-200-012 212-061-200-016 212-061-200-020 212-061-200-022 212-061-200-022 212-061-200-022 212-061-200-102 NAS679A3 MS21042L3 AN960PD10L AN960JD10LL NAS1149D0316J AN3-6A MS27039-1-09 AN960PD10L AN960JD10LL NAS1149D0316J 212-061-205-001 212-061-205-002		REF REF REF REF REF REF REF REF REF REF	22222 2 22222 2 2800 B 8600 B 860	
7 8 9 10 11 11 12 13 13 14 15 16 16 17 17 18 18 19 20 20 21	212-061-203-002 212-061-203-001 212-061-203-002 NAS679C3 MS21043-3 AN960C10L NAS1149C0332R AN3C6A AN960C516L NAS1149C0532R NAS43HT3-17 212-061-204-005 AAL-061-210-001 212-061-209-005 212-061-209-001 212-061-209-005 212-061-209-005 212-061-209-006 MS27039C1-08 AN960PD10L AN960JD10LL NAS1149D0316J 212-061-201-005	BRACKET, RH BRACKET, RH NUT (REPLACED BY MS21043-3) NUT (REPLACES NAS679C3) WASHER (REPLACES AN960C10L) BOLT WASHER (REPLACED BY NAS1149C0532R) WASHER (REPLACES AN960C516L) SPACER LINK (NOTE 1) (S/N 30504 THRU 31311, 35001 THRU 35103) LINK (NOTE 1) LINK (NOTE 1) SHANKET (S/N 30504 THRU 30553) BLANKET (S/N 30504 THRU 30553) BLANKET (S/N 30504 THRU 30553) BLANKET (S/N 30504 THRU 30596, 30604 THRU 30610) BLANKET (S/N 30504 THRU 30596, 30604 THRU 30610) BLANKET (S/N 30504 THRU 30596, 30604 THRU 30610) BLANKET (S/N 30504 THRU 30596, 30604 THRU 30610) SCREW WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACES AN960JD10LL) EJECTOR ASSY, EXHAUST, LH (NOTE 2) (S/N 30504 THRU 30553) (SEE FIG. 71-21 FOR BREAKDOWN) (REPLACED BY AAL-061-204-001)	1 1 2 2 4 4 3 4 4 2 1 1 1 1 1 1 23 23 23 23 1	55855666666666666666666666666666666666	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-13. Air Management System Installation (Cont'd)			
21	212-061-201-009	. EJECTOR ASSY, EXHAUST, LH (NOTE 2) (S/N 30554 THRU 30596, 30604 THRU 30610) (SEE FIG. 71-21 FOR BREAKDOWN)	1	SP	
21	212-061-201-011	(REPLACED BY 212-061-201-011, AAL-061-204-001) EJECTOR ASSY, EXHAUST, LH (NOTE 2) (S/N 30597 THRU 30603, 30611 THRU 31311, 32101 THRU 32142, 35001 THRU 35103) (SEE FIG. 71-21 FOR BREAKDOWN) (REPLACES 212-061-201-009) (REPLACED BY AAL-061-204-001) (ALTERNATE PART)	1	NP	
21	212-061-216-101	. EJECTOR ASSY, EXHAUST, LH (NOTE 2) (S/N 30597 THRU 30603, 30611 THRU 31311, 35001 THRU 35103) (SEE FIG. 71-21 FOR	1	NP	
21	AAL-061-204-001	BREAKDOWN) (REPLACED BY AAL-061-204-001) EJECTOR ASSY, EXHAUST, LH (NOTE 2) (SEE FIG. 71-21 FOR BREAKDOWN) (REPLACES 212-061-201-005, -009 AND -011,	1	Р	
22	212-061-201-006	212-061-216-101)	1	SP	
22	212-061-201-010	AAL-061-204-002)	1	SP	
22	212-061-201-012	(REPLACED BY 212-061-201-012, AAL-061-204-002) EJECTOR ASSY, EXHAUST, RH (NOTE 2) (S/N 30597 THRU 30603, 30611 THRU 31311, 32101 THRU 32142, 35001 THRU 35103) (SEE FIG. 71-21 FOR BREAKDOWN) (REPLACES 212-061-201-010) (REPLACED BY AAL-061-204-002)	1	NP	
22	212-061-216-102	(ALTERNATE PART) . EJECTOR ASSY, EXHAUST, RH (NOTE 2) (S/N 30597 THRU 30603, 30611 THRU 31311, 35001 THRU 35103) (SEE FIG. 71-21 FOR	1	NP	
22	AAL-061-204-002	BREAKDOWN) (REPLACED BY AAL-061-204-002)	1	Р	
23 24 24	MS27039-1-08 AN960PD10L AN960JD10LL	212-061-216-102)	4 4 4	SP P P	
24 25 26 26	NAS1149D0316J MS27039-1-06 AN960PD10L AN960JD10LL	NAS1149D0316J)	4 17 17 17	SP SP P	
26 27 28 29 30 31	NAS1149D0316J 212-060-204-001 212-060-204-002 212-060-204-029 MS20500-428 AN960C416L	NAS1149D0316J)	17 1 1 1 14 28	SP SP SP SP SP NP	
31 32 33 33	NAS1149C0432R MS20034-1 212-061-202-005 212-061-202-007	NAS1149C0432R)	28 14 1 1	SP SP SP NP	
34 34	212-061-202-006 212-061-202-008	212-061-202-009)	1	SP NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-13. Air Management System Installation (Cont'd)			
35	MS20500-428	. NUT	28	SP	
36	AN960C416L	. WASHER	56	NP	
36	NAS1149C0432R	. WASHER	56	SP	
37 38	MS20034-1	BOLT	28	SP SP	
38	212-061-202-009	DUCT ASSY, LH (NOTE 3) (S/N 30554 THRU 31311, 35001 THRU 35103) (REPLACES 212-061-202-007) (REPLACED BY AAL-061-301-009)	1	25	
38	AAL-061-301-009	DUCT ASSY, LH (NOTE 3) (REPLACES 212-061-202-009)	1	SP	
39	212-061-202-010	DUCT ASSY, RH (NOTE 3) (S/N 30554 THRU 31311, 35001 THRU 35103) (REPLACES 212-061-202-008) (REPLACED BY AAL-061-301-010)	1	NP	
39	AAL-061-301-010	. DUCT ASSY, LH (NOTE 3) (REPLACES 212-061-202-010)	1	SP	
40	MS27039-1-10	. SCREW	9	SP	
41	AN960-10L	. WASHER (REPLACED BY NAS1149F0332P)	9	Р	
41	NAS1149F0332P	. WASHER (REPLACES AN960-10L)	9	SP	
42	MS27039-1-08	. SCREW	61	SP	
43	AN960-10L	. WASHER (REPLACED BY NAS1149F0332P)	61	Р	
43 44	NAS1149F0332P MS27039-1-06	. WASHER (REPLACES AN960-10L)	61 7	SP SP	
45	AN960-10L	SCREW	7	P	
45	NAS1149F0332P	. WASHER (REPLACES AN960-10L)	7	SP	
46	212-060-203-001	. VALVE ASSY (SEE FIG. 15 FOR BREAKDOWN)	1	P	
47	212-061-207-005	BAFFLE ASSY, INDUCTION, LH (S/N 30504 THRU 30530) (SEE FIG. 14 FOR BREAKDOWN) (REPLACED BY 212-061-207-245)	1	NP	
47	212-061-207-245	. BAFFLE ASSY, INDUCTION, LH (S/N 30531 THRU 31310, 35001) (SEE FIG. 14 FOR BREAKDOWN) (REPLACES	1	NP	
47	212-061-207-293	212-061-207-005) (REPLACED BY 212-061-207-293) BAFFLE ASSY, INDUCTION, LH (S/N 31311, 35002 THRU 35103) (SEE FIG. 14 FOR BREAKDOWN) (REPLACES	1	SP	
47	212-061-207-367	212-061-207-245) (REPLACED BY 212-061-207-367)	1	NP	
48	212-061-207-307	BAFFLE ASSY, INDUCTION, LH (REPLACES 212-061-207-293) . BAFFLE ASSY, INDUCTION, RH (S/N 30504 THRU 30530) (SEE	1	NP	
40	212-001-201-001	FIG. 14 FOR BREAKDOWN) (REPLACED BY 212-061-207-247)	' '	INI	
48	212-061-207-247	BAFFLE ASSY, INDUCTION, RH (S/N 30531 THRU 31310, 35001) (SEE FIG. 14 FOR BREAKDOWN) (REPLACES	1	NP	
48	212-061-207-295	212-061-207-007) (REPLACED BY 212-061-207-295)	1	SP	
		(SEE FIG. 14 FOR BREAKDOWN) (REPLACES	1		
48	212-061-207-369	212-061-207-247) (REPLACED BY 212-061-207-369)	1	NP	
46 49	MS24665-134	BAFFLE ASSY, INDUCTION, RH (REPLACES 212-061-207-295). PIN, COTTER (REPLACED BY MS24665-136)	1	SP	
49	MS24665-136	PIN, COTTER (REPLACED BY MS24605-136)	1	SP	
49A	AN320C4	. NUT	1	SP	
50	AN960-416L	. WASHER (NOTE 4) (REPLACED BY NAS1149F0432P)	3	P	
50	NAS1149F0432P	. WASHER (NOTE 4) (REPLACES AN960-416L)	3	SP	
50A	AN960-416L	. WASHER (REPLACED BY NAS1149F0432P)	2	Р	
50A	NAS1149F0432P	. WASHER (REPLACES AN960-416L)	2	SP	
51	AN174-11	BOLT	1	SP	
52 52	MS24665-134	PIN, COTTER (REPLACED BY MS24665-136)	1	SP	
52 52 A	MS24665-136	PIN (REPLACES MS24665-134)	1 1	SP	
52A 53	AN320C4 AN960-416	. NUT	3	SP NP	
53 53	NAS1149F0463P	. WASHER (NOTE 4) (REPLACED BY NAS1149F0463P)	3	SP	
53A	AN960-416L	. WASHER (REPLACES AN960-416)	2	P	
53A	NAS1149F0432P	. WASHER (REPLACES AN960-416L).	2	SP	
	AN174-10	BOLT	1 4 '	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-13. Air Management System Installation (Cont'd)			
55	209-062-214-001	. ACTUATOR (S/N 30504 THRU 31311, 35001 THRU 35075) (REPLACED BY 209-062-214-101)	1	NP	
55	209-062-214-003	(ALTERNATE PART) . ACTUATOR (S/N 30504 THRU 31311, 35001 THRU 35075)	1	NP	
55	209-062-214-101	(REPLACED BY 209-062-214-101)	1	SP	
56 57 58 59 60	212-060-208-001 212-060-214-003 212-060-214-001 MS27039-1-06 AN960PD10L AN960JD10LL	209-062-214-001 AND -003) . FITTING . SHIM . SHIM . SCREW . WASHER (REPLACED BY AN960JD10LL) . WASHER (REPLACES AN960PD10L) (REPLACED BY	1 1 1 10 10	SP SP SP SP P	
60 61 62 62	NAS1149D0316J MS27039-1-08 AN960PD10L AN960JD10LL	NAS1149D0316J)	10 7 7 7	SP SP P	
62 63 64 64	NAS1149D0316J MS27039-1-10 AN960PD10L AN960JD10LL	NAS1149D0316J)	7 2 2 2	SP SP P	
64 65 66 67 68 69 70	NAS1149D0316J 212-061-210-003 212-061-210-004 212-061-210-051 212-061-210-055 MS21062-3K MS21060-3K RS203-040	NAS1149D0316J) . WASHER (REPLACES AN960JD10LL) . DUCT ASSY . DUCT ASSY . GASKET . GASKET . NUTPLATE . NUTPLATE . CHAIN ASSY (S/N 30531 THRU SUB, 35001 THRU 35103)	2 1 1 1 2 4 8	SP SP SP SP SP SP SP NP	
71 72 73 74 74 74 75	RS-203-40 AN929A6J AN924-6 AN960C916L NAS1149C0932R 140-009B37S58 AN832-6	(ALTERNATE PART) . CHAIN ASSY (S/N 30531 THRU SUB, 35001 THRU 35103)	1 1 1 1 1 1	SP SP SP SP SP SP	
75 76 77 77 78 78	AN832-6J CYRB288 212-061-201-117 212-061-201-118 212-061-201-107 212-061-201-106	(ALTERNATE PART) . UNION (S/N 30531 THRU 31311, 35001 THRU 35103)	1 1 1 1 1	SP SP P P SP	
		ONLY WITH EJECTOR ASSEMBLIES AAL-061-204-001 AND AAL-061-204-002.			



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-13. Air Management System Installation (Cont'd)			
		NOTE 2: USE EJECTOR/DEFLECTOR ASSEMBLY LH AAL-061-204-001 AND EJECTOR/DEFLECTOR ASSEMBLY RH AAL-061-204-002 AS A SET. EACH EJECTOR/DEFLECTOR ASSEMBLY MUST BE INSTALLED WITH LINK AAL-061-210-001 AND LINK AAL-061-210-003.			
		NOTE 3: USE RETAINING RING AAL-061-300-101 AND BOLT MS20034-2 ONLY WITH DUCT ASSEMBLIES AAL-061-202-101 AND AAL-061-202-102.			
		NOTE 4: MAXIMUM QUANTITY SHOWN, ACTUAL QUANTITY IS DETERMINED ON INSTALLATION, REFER TO BHT-212-MM.			
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			







Figure 71-14. Baffle Assembly, Induction (Sheet 1 of 2)

71-99-00 Page 78

Rev. 8 30 APR 2010

ECCN EAR99





212_IPB_71_0014b

Figure 71-14. Baffle Assembly, Induction (Sheet 2 of 2)



21 21 21 21 21 21 21 21 21 21 21 21 21 2	12-061-207-005 12-061-207-245 12-061-207-293 12-061-207-293 12-061-207-007 12-061-207-247 12-061-207-295 1827039-1-06 N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL	Figure 71-14. Baffle Assembly, Induction BAFFLE ASSY, INDUCTION, LH (S/N 30504 THRU 30530) (SEE FIG. 71-13 FOR NHA). BAFFLE ASSY, INDUCTION, LH (S/N 30531 THRU 31310, 35001) (SEE FIG. 71-13 FOR NHA). BAFFLE ASSY, INDUCTION, LH (S/N 31311, 35002 THRU SUB) (SEE FIG. 71-13 FOR NHA). BAFFLE ASSY, INDUCTION, RH (S/N 30504 THRU 30530) (SEE FIG. 71-13 FOR NHA). BAFFLE ASSY, INDUCTION, RH (S/N 30531 THRU 31310, 35001) (SEE FIG. 71-13 FOR NHA). BAFFLE ASSY, INDUCTION, RH (S/N 30531 THRU 31310, 35001) (SEE FIG. 71-13 FOR NHA). BAFFLE ASSY, INDUCTION, RH (S/N 31311, 35002 THRU SUB) (SEE FIG. 71-13 FOR NHA). SCREW	REF REF REF REF REF 21 21 21 9	NP SP NP SP SP P SP	ООС
21 21 21 21 21 21 21 21 21 21 21 21 21 2	12-061-207-245 12-061-207-293 12-061-207-007 12-061-207-247 12-061-207-295 IS27039-1-06 N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL AS1149D0316J	BAFFLE ASSY, INDUCTION, LH (S/N 30504 THRU 30530) (SEE FIG. 71-13 FOR NHA)	REF REF REF REF 21 21 9	NP SP NP SP SP P SP	
21 21 21 21 21 21 21 21 21 21 21 21 21 2	12-061-207-245 12-061-207-293 12-061-207-007 12-061-207-247 12-061-207-295 IS27039-1-06 N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL AS1149D0316J	71-13 FOR NHA)	REF REF REF REF 21 21 9	NP SP NP SP SP P SP	
21 21 21 21 21 21 21 21 21 21 21 21 21 2	12-061-207-293 12-061-207-007 12-061-207-247 12-061-207-295 IS27039-1-06 N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL AS1149D0316J	BAFFLE ASSY, INDUCTION, LH (S/N 30531 THRU 31310, 35001) (SEE FIG. 71-13 FOR NHA) BAFFLE ASSY, INDUCTION, LH (S/N 31311, 35002 THRU SUB) (SEE FIG. 71-13 FOR NHA) BAFFLE ASSY, INDUCTION, RH (S/N 30504 THRU 30530) (SEE FIG. 71-13 FOR NHA) BAFFLE ASSY, INDUCTION, RH (S/N 30531 THRU 31310, 35001) (SEE FIG. 71-13 FOR NHA) BAFFLE ASSY, INDUCTION, RH (S/N 31311, 35002 THRU SUB) (SEE FIG. 71-13 FOR NHA) SCREW WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J) WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACED BY AN960JD10LL)	REF REF REF 8 21 21 21 9	SP NP NP SP P SP	
21 21 21 1 M3 2 AN 2 AN 2 AN 4 AN 4 AN 4 AN 5 21 5 21 6 21 7 21 8 21 9 21 10 M3 11 AN 11 AN 11 NA 11 NA 11 NA	12-061-207-007 12-061-207-247 12-061-207-295 IS27039-1-06 N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL AS1149D0316J	BAFFLE ASSY, INDUCTION, LH (S/N 31311, 35002 THRU SUB) (SEE FIG. 71-13 FOR NHA) BAFFLE ASSY, INDUCTION, RH (S/N 30504 THRU 30530) (SEE FIG. 71-13 FOR NHA) BAFFLE ASSY, INDUCTION, RH (S/N 30531 THRU 31310, 35001) (SEE FIG. 71-13 FOR NHA) BAFFLE ASSY, INDUCTION, RH (S/N 31311, 35002 THRU SUB) (SEE FIG. 71-13 FOR NHA) SCREW WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACES AN960JD10LL) (REPLACED BY NAS1149D0316J) WASHER (REPLACES AN960JD10LL) BOLT WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACES AN960PD10L) (REPLACED BY	REF REF 8 21 21 21 9	NP NP SP SP P SP	
21 1 M3 2 AN 2 AN 2 AN 3 AN 4 AN 4 AN 5 21 5 21 6 21 7 21 8 21 9 21 10 M3 11 AN 11 NA 11 NA 11 NA 11 NA	12-061-207-247 12-061-207-295 IS27039-1-06 N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL AS1149D0316J	71-13 FOR NHA)	REF REF 8 21 21 21 9	NP SP SP P SP	
21 1 M3 2 AN 2 AN 2 AN 3 AN 4 AN 4 AN 5 21 5 21 6 21 7 21 8 21 9 21 10 M3 11 AN 11 AN 11 NA 11 NA 11 NA	12-061-207-295 IS27039-1-06 N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL	71-13 FOR NHA)	REF 8 21 21 21 9	SP SP P SP	
1 M3 2 AM 2 AM 3 AM 4 AM 4 AM 5 21 5 21 6 21 7 21 8 21 9 21 10 M3 11 AM 11 AM 11 NA 11 NA 11 NA	IS27039-1-06 N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL	(SEE FIG. 71-13 FOR NHA) BAFFLE ASSY, INDUCTION, RH (S/N 31311, 35002 THRU SUB) (SEE FIG. 71-13 FOR NHA) SCREW WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J) WASHER (REPLACES AN960JD10LL) BOLT WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACED BY AN960PD10L) (REPLACED BY	8 21 21 21	SP P P	
2 AN 2 AN 3 AN 4 AN 4 AN 5 21 5 21 6 21 7 21 8 21 10 M3 11 AN 11 AN 11 NA 11 NA 11 NA	N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL AS1149D0316J	(SEE FIG. 71-13 FOR NHA) . SCREW . WASHER (REPLACED BY AN960JD10LL) . WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J) . WASHER (REPLACES AN960JD10LL) . BOLT . WASHER (REPLACED BY AN960JD10LL) . WASHER (REPLACED BY AN960PD10L) (REPLACED BY	21 21 21 9	P P SP	
2 AN 2 AN 3 AN 4 AN 4 AN 5 21 5 21 6 21 7 21 8 21 10 M3 11 AN 11 AN 11 NA 11 NA 11 NA	N960PD10L N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL AS1149D0316J	. WASHER (REPLACED BY AN960JD10LL)	21 21 21 9	P P SP	
2 NA 3 AN 4 AN 4 AN 5 21 5 21 6 21 7 21 8 21 10 M3 11 AN 11 AN 11 NA 11 NA 11 NA	N960JD10LL AS1149D0316J N3-3A N960PD10L N960JD10LL AS1149D0316J	WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	21 21 9	P	1
3 AN AN AN AN AN AN AN AN AN AN AN AN AN	N3-3A N960PD10L N960JD10LL AS1149D0316J	. WASHER (REPLACES AN960JD10LL)	9		ì
3 AN AN AN AN AN AN AN AN AN AN AN AN AN	N3-3A N960PD10L N960JD10LL AS1149D0316J	BOLT	9		ı
4 AN AN AN AN AN AN AN AN AN AN AN AN AN	N960PD10L N960JD10LL AS1149D0316J	. WASHER (REPLACED BY AN960JD10LL)	_	SP	ı
4 AN AN AN AN AN AN AN AN AN AN AN AN AN	N960JD10LL AS1149D0316J	. WASHER (REPLACES AN960PD10L) (REPLACED BY	1 1/	Р	1
5 21 5 21 6 21 7 21 8 21 9 21 10 M3 11 AN 11 AN 11 NA 11 NA			17	P	ī
5 21 5 21 6 21 7 21 8 21 9 21 10 M3 11 AN 11 AN 11 NA 11 NA		. WASHER (REPLACES AN960JD10LL)	17	SP	
5 21 6 21 7 21 8 21 9 21 10 M3 11 AN 11 AN 11 NA 11 NA 11 NA	12-061-207-149	SKIN ASSY, LH.	1	P	i
6 21 7 21 8 21 9 21 10 M3 10 M3 11 AN 11 AN 11 NA 11 NA 11 NA	12-061-207-150	SKIN ASSY, RH	1	NP	
8 21 9 21 10 M3 10 M3 11 AN 11 AN 11 NA 11 NA 12 21	12-061-207-229	GASKET	1	SP	
9 21 10 M3 10 M3 11 AN 11 AN 11 NA 11 NA 12 21	12-061-207-209	GASKET	1	SP	
10 M3 10 M3 11 AN 11 AN 11 NA 11 NA 12 21	12-061-207-231	GASKET	1	SP	i
10 M3 11 AN 11 AN 11 NA 11 NA 11 NA	12-061-207-205	GASKET	1	SP	i
11 AN 11 AN 11 NA 11 NA 12 21	IS27039-1-05	. SCREW (PRE TB 212-04-196)	4	SP	
11 AN 11 NA 11 NA 12 21	IS27039C1-06	. SCREW (POST TB 212-04-196)	4	SP	
11 NA 12 21	N960PD10L N960JD10LL	. WASHER (PRE TB 212-04-196) (REPLACED BY AN960JD10LL) . WASHER (PRE TB 212-04-196) (REPLACES AN960PD10L)	4	P P	İ
11 NA 12 21	A 044 40 D 004 C I	(REPLACED BY NAS1149D0316J)		0.0	1
12 21	AS1149D0316J AS1149C0332R	. WASHER (PRE TB 212-04-196) (REPLACES AN960JD10LL)	4	SP SP	
	12-061-207-035	. WASHER (POST TB 212-04-196)	1 1	SP	1
	12-061-207-035	SCREEN ASSY (PRE 18 212-04-196)		SP	1
	12-061-207-349	. SCREEN		NP	1
	12-061-207-061	GASKET		NP	ı
-	IS21062L3	NUTPLATE (POST TB 212-04-196)	2	SP	
-	IS21061L3	NUTPLATE (USBL ON 212-061-207-349)	2	SP	
	IS21060L3	NUTPLATE (POST TB 212-04-196)	9	SP	1
13B M	IS21059L3	NUTPLATE (USBL ON 212-061-207-349)	9	SP	1
13C 21	12-061-207-351	RETAINER, LH (POST TB 212-04-196) (USBL ON 212-061-207-349)	1	NP	ı
13D 21	12-061-207-352	RETAINER, RH (POST TB 212-04-196) (USBL ON 212-061-207-349)	1	NP	ı
13E 21	12-061-207-353	RETAINER (POST TB 212-04-196) (USBL ON 212-061-207-349)	2	NP	i
_	12-061-207-355	RETAINER (POST TB 212-04-196) (USBL ON 212-061-207-349)	1	NP	ı
	IS27039-1-06	SCREW	7	SP	i,
	N960PD10L	. WASHER (REPLACED BY AN960JD10LL)	7	P	ı
	N960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	7	P	ı
15 NA	AS1149D0316J	. WASHER (REPLACES AN960JD10LL)	7	SP	1
		SKIN ASSY (S/N 30504 THRU 30530) (REPLACED BY 212-061-207-249)	1	NP	1
16 21	12-061-207-145	- LIC UUI"とUI"とすび1	1	SP	1



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	4 V 4 I L	U 0 C
		Figure 71-14. Baffle Assembly, Induction (Cont'd)			
16	212-061-207-146	. SKIN ASSY (S/N 30504 THRU 30530) (REPLACED BY	1	NP	
16	212-061-207-250	212-061-207-250)	1	NP	
17	212-061-207-201	GASKET	1	SP	
18	212-061-207-207	GASKET	1	SP	
19	212-061-207-221	GASKET	1	SP	
20	212-061-207-199	GASKET	1	SP	
21	MS27039-1-06	. SCREW	7	SP	
22 22	AN960PD10L AN960JD10LL	. WASHER (REPLACED BY AN960JD10LL)	7 7	P P	
22	NAS1149D0316J	NAS1149D0316J)	7	SP	
23	212-061-207-159	. SKIN ASSY, LH	1	Р	
23	212-061-207-161	. SKIN ASSY, RH	1	Р	
24	212-061-207-201	GASKET	1	SP	
25	212-061-207-213	GASKET, LH	1	SP	
25	212-061-207-211	GASKET, RH	1	SP	
26	212-061-207-217	GASKET	1	SP	
27	212-061-207-235	GASKET	1	SP	
28 29	AN3-3A AN960PD10L	BOLT	4	SP P	
29 29	AN960JD10LL	. WASHER (REPLACED BY AN960JD10LL)	4	P	
29	NAS1149D0316J	NAS1149D0316J)	4	SP	
30	212-061-207-147	. SKIN ASSY, LH	1	Р	
30	212-061-207-148	. SKIN ASSY, RH	1	Р	
31	212-061-207-233	GASKET	1	SP	
32	212-061-207-225	GASKET	1	SP	
33	212-061-207-223	GASKET	1	SP	
34	MS27039-1-06	. SCREW	7	SP	
35	212-061-207-023	. FAIRING ASSY, LH	1	SP	
35	212-061-207-025	. FAIRING ASSY, RH	1	SP	
36	212-061-207-065	SEAL (MAKE FROM 120-104-1)	2	NP	
36 36A	120-104-1 212-061-207-123	SEAL (19 INCHES)	AR 1	SP P	
36A	212-061-207-123	RETAINER, LH		P	
36A 37	AN3-3A	RETAINER, RH	4	SP	
38	AN960PD10L	BOLT	4	P	
38	AN960JD10LL	. WASHER (REPLACED BY AN960JDTULL) . WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	4	P	
38	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	4	SP	
39	212-061-207-151	. WEB ASSY, LH (S/N 30504 THRU 31310, 35001)	1	NP	
39	212-061-207-285	. WEB ASSY, LH (S/N 31311, 35002 THRU SUB)	1	NP	
39	212-061-207-157	. WEB ASSY, RH (S/N 30504 THRU 31310)	1	NP	
39	212-061-207-291	. WEB ASSY, RH (S/N 31311, 35002 THRU SUB)	1	NP	
40	212-061-207-193	SEAL (MAKE FROM 120-104-2)	1	NP	
40	120-104-2	SEAL, TADPOLE, HIGH TEMP (32 INCHES) (REPLACED BY 120-104-2-0600)	AR	NP	
40	120-104-2-0600	SEAL, TADPOLE, HIGH TEMP (32 INCHES) (REPLACES 120-104-2)	AR	SP	
41	212-061-207-203	GASKET	1	SP	
42	212-061-207-215	GASKET	1	SP	
43	212-061-207-219	GASKET	1	SP	
44	212-061-207-155	. WEB ASSY, LH (S/N 30504 THRU 31310, 35001)	1	NP	
44	212-061-207-289	. WEB ASSY, LH (S/N 31311, 35002 THRU SUB)	1	SP	
44	212-061-207-156	. WEB ASSY, RH (S/N 30504 THRU 31310, 35001)	1	NP	
44	212-061-207-290	. WEB ASSY, RH (S/N 31311, 35002 THRU SUB)	1	SP	
45 45	212-061-207-197	SEAL (MAKE FROM 120-104-1)	1 ^ D	NP SP	
45	120-104-1	SEAL (24 INCHES)	AR	32	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-14. Baffle Assembly, Induction (Cont'd)			
46 46 46 46 47 47	212-061-207-153 212-061-207-287 212-061-207-154 212-061-207-288 212-061-207-195 120-104-2	. WEB ASSY, LH (S/N 30504 THRU 31310, 35001)	1 1 1 1 1 AR	NP SP NP SP NP NP	
48 48	212-061-207-051 120-104-2	120-104-2)	1 AR	NP NP	
48	120-104-2-0600	120-104-2-0600)	AR	SP	
49	212-061-207-227	120-104-2)	1	SP	
		AVAIL CODE DEFINITION			
		P Non Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			




Figure 71-15. Valve Assembly



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
1 2 3 3 4 5 6 7 8 8 9 10 11 12 13 14 15 16 17 18 19 19 19 19 19 20 21 22	212-060-203-001 MS27039C1-06 MS27039C1-09 AN960C10L NAS1149C0332R 212-060-203-027 212-060-203-027 212-060-203-041 212-060-203-039 NAS679C3 MS21043-3 AN960C10L NAS1149C0332R AN173-10A 212-060-203-005 212-060-203-005 212-060-203-005 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-057 212-060-203-059 212-060-203-051 3120-012-3A MS21069L3 MS21059L3K MS21061L3K	Figure 71-15. Valve Assembly VALVE ASSY (SEE FIG. 71-13 FOR NHA). SCREW. SCREW. WASHER (REPLACED BY NAS1149C0332R). WASHER (REPLACES AN960C10L). SEAL. COVER. SEAL. SEAL. NUT (REPLACED BY MS21043-3). NUT (REPLACES NAS679C3). WASHER (REPLACED BY NAS1149C0332R). WASHER (REPLACED BY NAS11149C0332R). BOLT. DOOR ASSY. SEAL. FITTING FITTING FITTING FITTING STOP STOP STOP STOP STOP STOP STOP STOP	REF 10 4 14 1 1 1 1 2 2 4 4 2 1 1 1 2 2 2 1 1 1 8 2 2 2 1 1 1 1 1 1	P	
		AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 71-16. Engine Assembly (Sheet 1 of 3)

71-99-00 Page 86

Rev. 8 30 APR 2010

ECCN EAR99







Figure 71-16. Engine Assembly (Sheet 2 of 3)





212_IPB_71_0016c

Figure 71-16. Engine Assembly (Sheet 3 of 3)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-16. Engine Assembly			
	212-062-005-001	ENGINE ASSY (S/N 30504 THRU 30530) (SEE FIG. 71-17, 71-18	1	NP	
	212-062-005-003	FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-005-005	FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-005-103	FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-005-105	FOR BALANCE OF BREAKDOWN)	1	NP	
	212-062-005-107	212-062-005-107)	1	NP	
	212-062-005-113	212-062-005-105)	1	NP	
	212-062-005-119	ENGINE ASSY (S/N 35081 THRU 35102) (SEE FIG. 71-17, 71-18	1	Р	
	212-062-005-131	FOR BALANCE OF BREAKDOWN)	1	Р	
1 1	AN176H6A NAS6606H3	OF BREAKDOWN)	6 6	SP SP	
2	AN960C616	. WASHER (REPLACED BY NAS1149C0663R)	6	P	
2	NAS1149C0663R		6	SP	
3	212-060-109-001	. WASHER (REPLACES AN960C616)	1	NP	
3	212-061-110-001	212-061-110-001, 212-061-111-001)	1	NP	
3	212-061-111-001	FITTING, LH (REPLACES 212-060-109-001, 212-061-110-001)	1	SP	
4	212-060-109-002	. FITTING, RH (S/N 30504 THRU 31124) (REPLACED BY	1	NP	
4	212-061-110-002	212-061-111-002, 212-061-110-002)	1	NP	
4	212-061-111-002	212-060-109-002) (REPLACED BY 212-061-111-002)	1	SP	
5	70-010H000T200	. FITTING, RH (REPLACES 212-060-109-002, 212-061-110-002)	2	NP	
		. HOSE ASSY (REPLACED BY 70-061H000T200A)			
5	70-061H000T200A	. HOSE ASSY (REPLACES 70-010H000T200)	2	SP	
6	AN924-8J	NUT (REPLACED BY AS5178J08)	2	SP	
6	AS5178J08	NUT (REPLACES AN924-8J)	2	SP	
7	M25988/1-115	PACKING, PREFORMED	2	SP	
8	209-062-028-001	. FITTING (S/N 30504 THRU 31306) (REPLACED BY 412-062-674-101)	2	NP	
8	412-062-674-101	. FITTING (REPLACES 209-062-028-001)	2	SP	
9	209-062-010-001	. VALVE, OIL DRAIN	2	SP	
10	AN924-8J	. NUT (REPLACED BY AS5178J08)	2	SP	
10	AS5178J08	. NUT (REPLACES AN924-8J)	2	SP	
11	AN919-12D	REDUCER (S/N 30504 THRU 31311, 35001 THRU 35042)	2	NP	
12	AN919-10D	REDUCER (S/N 30504 THRU 31311, 35001 THRU 35042)	2	SP	
12A	AN919-12D	REDUCER (S/N 35044 THRU 35101)	2	NP	
12B	AN919-10D	REDUCER, RH (POST TB 212-99-181) (S/N 35043 THRU 35102).	1	SP	
12B	AN919-10D	REDUCER, RH (S/N 35103)	1	SP	
13	AN832-8D	. ADAPTER, UNION-FLARED (S/N 30504 THRU 31311, 35001 THRU	2	SP	
13A	AN893-3D	35042)	2	NP	
13A 14	AS5172D0408L AN919-8D	BUSHING (S/N 35043 THRU 35103) (REPLACES AN893-3D) REDUCER (S/N 30504 THRU 31311, 35001 THRU 35042)	2	P SP	



NOBER PART NUMBER ITEM NAME PART NUMBER Figure 71-16. Engine Assembly (Cont'd)	(1)	(2)	(3)	(4)	(5)	(6)
14A AN815-4D		PART NUMBER	ITEM NAME	PER	Ā	ō
(REPLACED BY AS517400404) 14A AS5174D0404 14A AS5174W0404 14A AS5174W0404 14A AS5174W0404 14A AS5174W0404 14A AS5174W0404 14B AN915-4D 14A AS5174D0404 14B AN919-8D 14B AN919-8D 14B AN919-8D 14B AN919-8D 14C AN919-1D 14C AN919-1D 14D AN919-1D 15D 16D 17D 18D 18D 18D 18D 18D 18D 18			Figure 71-16. Engine Assembly (Cont'd)			
14A AS517400404	14A	AN815-4D		1	SP	
14A	14A	AS5174D0404	. UNION, LH (POST TB 212-99-181) (S/N 35043 THRU 35102)	1	SP	
14A ANS15-4D	14A	AS5174W0404	. UNION, LH (POST TB 212-99-181) (S/N 35043 THRU 35102)	1	SP	
AS5174D0404	14A	AN815-4D	(REPLACES AS5174D0404)	1	SP	
AS5174W04044	14A	AS5174D0404	. UNION, LH (S/N 35103) (REPLACES AN815-4D) (REPLACED BY	1	SP	
AM919-8D	14A	AS5174W0404	LINION TH (S/N 35103) (REPLACES AS5174D0404)	1	SP	
ANS19-8D			REDUCER 1H (POST TR 212-99-181) (S/N 35043 THRU 35102)	-	_	
ANS19-1D REDUCER, RH (FOST TB 212-99-181) (S/N 35043 THRU 35102) 1 NP NAS19-1D REDUCER, RH (S/N 35103) 2 SP NAS919-8D REDUCER (PRE TB 212-99-181) (S/N 30503 THRU 31311, 35001 2 SP THRU 35042) REDUCER (PRE TB 212-99-181) (S/N 30503 THRU 31311, 35001 2 SP THRU 35042) REDUCER (PRE TB 212-99-181) (S/N 30503 THRU 31311, 35001 2 SP THRU 35042) REDUCER (PRE TB 212-99-181) (S/N 30503 THRU 31311, 35001 2 SP THRU 35042) REDUCER (PRE TB 212-99-181) (S/N 30503 THRU 31311, 35001 2 SP ANS178D08 NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACED BY AS178D08) NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES AN924-4D NUT (S/N 30504 THRU 35103) (REPLACES AN924-4D NUT (S/N 30504 THRU 35103) (REPLACES AN924-4D NUT (S/N 30504 THRU 35103) (REPLACES AN924-4D NUT (S/N 30504 THRU 35103) (REPLACED BY AS3208-08) PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU 14 P NAS617-8 PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU 14 P NAS617-8 PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU 15 P NAS617-8 PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU 15 P NAS617-8 PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU 14 SP NAS617-8 PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU 15 P M83248/1-908 PACKING, PREFORMED (S/N 30504 THRU 31310) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (REPLACED BY AS3042) (RE					_	
ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS ANS			. REDUCER, LH (3/N 33103)	-		
AN919-8D				-		
THRU 35042 REDUCER (POST TB 212-99-181) (S/N 30503 THRU 31311, 35001 2 SP	_		. REDUCER, RH (5/N 35103)	-		
THRU 35042). NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACED BY AS5178D08). NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACED BY AS5178D08). NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES 2 SP AN924-8D). 15A AN924-4D			THRU 35042)	_		
NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACED BY AS5178D08). NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES SP AS5178D08) NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES SP AS5178D04 NUT (S/N 30504 THRU 35103) (REPLACED BY AS5178D04). 2 SP NUT (S/N 35043 THRU 35103) (REPLACES AN924-4D). 2 SP NUT (S/N 35043 THRU 35103) (REPLACES AN924-4D). 2 SP NUT (S/N 35043 THRU 35103) (REPLACES AN924-4D). 2 SP NUT (S/N 35043 THRU 35103) (REPLACES AN924-4D). 2 SP NUT (S/N 35043 THRU 35103) (REPLACES AN924-4D). 2 SP NUT (S/N 35043 THRU 35103) (REPLACED BY MS3248/1-908). PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU 14 SP 35042) (REPLACES NAS617-8) (REPLACED BY AS3208-08). PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU 14 SP 35042) (REPLACES NAS617-8) (REPLACED BY AS3208-08). PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU 14 SP 35042) (REPLACES NAS617-8) (REPLACED BY AS3248/1-908). PACKING, PREFORMED (S/N 35043 THRU 35103) (REPLACED BY MS3248/1-908). PACKING, PREFORMED (S/N 35043 THRU 35103) (REPLACES 2 SP NAS617-8) (REPLACED BY AS3208-08). PACKING, PREFORMED (S/N 35043 THRU 35103) (REPLACED BY MS3248/1-904). PACKING, PREFORMED (S/N 35043 THRU 35103) (REPLACED BY NAS617-4) (REPLACED BY AS3208-04). PACKING, PREFORMED (S/N 35043 THRU 35103) (REPLACED BY NAS617-4) (REPLACED BY AS3208-04). PACKING, PREFORMED (S/N 35043 THRU 35103) (REPLACES 4 SP NAS617-4) (REPLACED BY AS3208-04). PACKING, PREFORMED (S/N 35043 THRU 35103) (REPLACED BY AS5192W08) TEE (S/N 35043 THRU 35103) (REPLACED BY AS5192W08) TEE (S/N 35043 THRU 35103) (REPLACED BY AS5192W08) TEE (S/N 35043 THRU 35103) (REPLACED BY AS5192W08) TEE (S/N 35043 THRU 35103) (REPLACED BY AS5192W08) TEE (S/N 35043 THRU 35103) (REPLACED BY AS5192W08) TEE (S/N 35043 THRU 35103) (REPLACED BY AS1031W040404) PACKING, PREFORMED (S/N 35043 THRU 35003 (REPLACED BY AS1031W040404) PACKING, PREFORMED (S/N 35043 THRU 35003) (REPLACED BY AS1031W040404) PACKING, PREFORMED (S/N 35043 THRU	14D	AN919-10D		2	SP	
AS5178D08	15	AN924-8D	. NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACED BY	2	SP	
15A	15	AS5178D08	. NUT (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES	2	SP	
15A	15A	AN924-4D	NIIT (S/N 350/3 THDII 35/03) (PEDI ACED BY AS5/78D0/)	2	SP	
16					_	
35042) (REPLACED BY M83248/1-908) 35042) (REPLACED BY M83248/1-908) 14 SP 35042) (REPLACES NAS617-8) (REPLACED BY AS3208-08) 2 PACKING, PREFORMED (S/N 30504 THRU 31311, 35001 THRU	_			_	_	
16	10	NA3017-6		14	Г	
16	16	M83248/1-908		14	SP	
17 NAS617-8	16	AS3208-08		14	SP	
M83248/1-908	17	NAS617-8		2	Р	
NAS617-8) (REPLACED BY AS3208-08)	17	M83248/1-908	M83248/1-908)	2	SP	
M83248/1-908	17		NAS617-8) (REPLACED BY AS3208-08)	2	SP	
18 M83248/1-904			M83248/1-908)			
NAS617-4) (REPLACED BY AS3208-04) NAS617-4) (REPLACED BY AS3208-04) PACKING, PREFORMED (S/N 35043 THRU 35103) (REPLACES 4 SP			M83248/1-904)	•	•	
M83248/1-904) TEE (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACED BY AS5192W08) TEE (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES BY AS5192W08) TEE (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES BY AN938D8) TEE (S/N 35043 THRU 35103) (REPLACED BY AS1031W040404) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (REPLACES AN783D4) ZEE (S/N 35043 THRU 35103) (R	18			4	SP	
19 AN938D8 . TEE (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACED BY AS5192W08) . TEE (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES AN938D8) . TEE (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES AN938D8) . TEE (S/N 35043 THRU 35103) (REPLACED BY AS1031W040404) 2 NP 19A AS1031W040404 . TEE (S/N 35043 THRU 35103) (REPLACES AN783D4) . 2 20 AN937D8 . CROSS, FITTING . 2 21 MS21224-3 . NUT . SCREW 22 MS35276-264 . SCREW . 2 23 NAS679A3 . NUT (REPLACED BY MS21042L3) . 1 NP 23 MS21042L3 . NUT, SELF-LOCKING (REPLACES NAS679A3) . 1 SP 24 AN960C10L . WASHER (REPLACED BY NAS1149C0332R) . 1 P 25 MS27039-1-08 . SCREW . 1 SP	18	AS3208-04		4	SP	
19 AS5192W08 . TEE (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES AN938D8)	19	AN938D8	. TEE (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACED BY	2	NP	
19A AN783D4 . TEE (S/N 35043 THRU 35103) (REPLACED BY AS1031W0404040) 2 NP 19A AS1031W040404 . TEE (S/N 35043 THRU 35103) (REPLACES AN783D4) . 2 2 20 AN937D8 . CROSS, FITTING . 2 SP 21 MS21224-3 . NUT . 2 P 22 MS35276-264 . SCREW . 2 SP 23 NAS679A3 . NUT (REPLACED BY MS21042L3) . 1 NP 23 MS21042L3 . NUT, SELF-LOCKING (REPLACES NAS679A3) . 1 SP 24 AN960C10L . WASHER (REPLACED BY NAS1149C0332R) . 1 P 24 NAS1149C0332R . WASHER (REPLACES AN960C10L) . 1 SP 25 MS27039-1-08 . SCREW . 1 SP	19	AS5192W08	. TEE (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES	2	SP	
19A AS1031W040404 . TEE (S/N 35043 THRU 35103) (REPLACES AN783D4). 2 20 AN937D8 . CROSS, FITTING. 2 21 MS21224-3 . NUT 2 22 MS35276-264 . SCREW. 2 SP 23 NAS679A3 . NUT (REPLACED BY MS21042L3). 1 NP 23 MS21042L3 . NUT, SELF-LOCKING (REPLACES NAS679A3) 1 SP 24 AN960C10L . WASHER (REPLACED BY NAS1149C0332R) 1 P 24 NAS1149C0332R . WASHER (REPLACES AN960C10L) 1 SP 25 MS27039-1-08 . SCREW 1 SP	19A	AN783D4		2	NP	
20 AN937D8 . CROSS, FITTING 2 SP 21 MS21224-3 . NUT 2 P 22 MS35276-264 . SCREW 2 SP 23 NAS679A3 . NUT (REPLACED BY MS21042L3) 1 NP 23 MS21042L3 . NUT, SELF-LOCKING (REPLACES NAS679A3) 1 SP 24 AN960C10L . WASHER (REPLACED BY NAS1149C0332R) 1 P 24 NAS1149C0332R . WASHER (REPLACES AN960C10L) 1 SP 25 MS27039-1-08 . SCREW 1 SP	_				. *'	
21 MS21224-3 . NUT	-				QD	
22 MS35276-264 .SCREW .2 SP 23 NAS679A3 .NUT (REPLACED BY MS21042L3) .1 NP 23 MS21042L3 .NUT, SELF-LOCKING (REPLACES NAS679A3) .1 SP 24 AN960C10L .WASHER (REPLACED BY NAS1149C0332R) .1 P 24 NAS1149C0332R .WASHER (REPLACES AN960C10L) .1 SP 25 MS27039-1-08 .SCREW .1 SP						
23 NAS679A3 . NUT (REPLACED BY MS21042L3) 1 NP 23 MS21042L3 . NUT, SELF-LOCKING (REPLACES NAS679A3) 1 SP 24 AN960C10L . WASHER (REPLACED BY NAS1149C0332R) 1 P 24 NAS1149C0332R . WASHER (REPLACES AN960C10L) 1 SP 25 MS27039-1-08 . SCREW 1 SP				_	-	
23 MS21042L3 . NUT, SELF-LOCKING (REPLACES NAS679A3) 1 SP 24 AN960C10L . WASHER (REPLACED BY NAS1149C0332R) 1 P 24 NAS1149C0332R . WASHER (REPLACES AN960C10L) 1 SP 25 MS27039-1-08 . SCREW 1 SP				_	_	
24 AN960C10L . WASHER (REPLACED BY NAS1149C0332R) 1 P 24 NAS1149C0332R . WASHER (REPLACES AN960C10L) 1 SP 25 MS27039-1-08 . SCREW 1 SP	_			-		
24 NAS1149C0332R . WASHER (REPLACES AN960C10L) 1 SP 25 MS27039-1-08 . SCREW 1 SP	_				_	
24 NAS1149C0332R . WASHER (REPLACES AN960C10L) 1 SP 25 MS27039-1-08 . SCREW 1 SP				-	-	
25 MS27039-1-08 . SCREW			. WASHER (REPLACES AN960C10L)	1		
	_		. SCREW	1	_	
	26	MS21919WDG6	. CLAMP	1	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-16. Engine Assembly (Cont'd)			
27	MS21919DG4	. CLAMP (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACED	1	NP	
27	MS21919WDG4	BY MS21919WDG4)	1	SP	
28	NAS679A3	MS21919DG4)	1	NP	
28	MS21042L3	MS21042L3)	1	SP	
29	AN960C10L	35042) (REPLACES NAS679A3)	1	Р	
29	NAS1149C0332R	(REPLACED BY NAS1149C0332R)	1	SP	
30 31	MS27039-1-08 MS21919DG4	(REPLACES AN960C10L)	1 2	SP NP	
31	MS21919WDG4	BY MS21919WDG4)	2	SP	
32	AN833-4D	MS21919DG4)	2	SP	
33	AN924-4D	. NUT (REPLACED BY AS5178D04)	2	SP	
33	AS5178D04	. NUT (REPLACES AN924-4D)	2	SP	
34 34	NAS617-4 M83248/1-904	. PACKING, PREFORMED (REPLACED BY M83248/1-904)	2	P SP	
34	AS3208-04	AS3208-04)	2	SP	
35	212-062-010-001	BRACKET	2	SP	
36	212-062-009-001	. TUBE ASSY, LH (S/N 30504 THRU 31311, 35001 THRU 35042)	1	SP	
36	212-062-018-101	. TUBE ASSY, LH (S/N 35043 THRU SUB)	1	SP	
37 37	212-062-008-001 212-062-017-101	TUBE ASSY, RH (S/N 30504 THRU 31311, 35001 THRU 35042)	1	SP SP	
38	NAS679A3	. TUBE ASSY, RH (S/N 35043 THRU SUB)	2	NP	
38	MS21042L3	NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP	
39	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	2	Р	
39	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	2	SP	
40	MS27039-1-08 MS21919WDG2	SCREW	2	SP	
41 42	MS21919WDG2 MS21919DG4	CLAMP	1	SP NP	
42	MS21919WDG4	CLAMP (REPLACES MS21919DG4)	1	SP	
	212-062-006-001	. BRACKET INSTL (S/N 30504 THRU 31124)	1	NP	
	212-062-006-101	. BRACKET INSTL (S/N 31125 THRU 31311, 35001 THRU 35042) .	1	NP	
40	212-062-006-105	BRACKET INSTL (S/N 35043 THRU SUB)	1	NP	
43 44	MS21042L3 AN960PD10L	NUT, SELF-LOCKING (S/N 30504 THRU 31124)	1	SP P	
44	AN960JD10LL	AN960JD10LL)	1	Р	
44	NAS1149D0316J	WASHER (S/N 30504 THRU 31124) (REPLACES AN960JD10LL)	1	SP	
45 46	MS27039-1-05	SCREW (S/N 30504 THRU 31124)	1 7	SP SP	
46 47	MS9592-008 MS9592-008	BRACKET (S/N 30504 THRU 31124)	3	SP SP	
48	MS9592-004	BRACKET (S/N 30123 THRU 31311, 35001 THRU 50B)	4	SP	
49	MS9592-024	BRACKET	7	SP	
50	MS9592-010	BRACKET (S/N 30504 THRU 31311, 35001 THRU 35042)	14	SP	
51	MS9592-010	BRACKET (S/N 35043 THRU SUB)	12	SP	
52 53	MS9592-014 MS9592-050	BRACKET (S/N 35043 THRU SUB)	1 4	SP SP	
54	MS9592-050 MS9592-138	BRACKET	4	SP	
55	MS9592-138	BRACKET (S/N 31125 THRU 31311, 35001 THRU SUB)	9	SP	
56	MS9592-183	BRACKET	1	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-16. Engine Assembly (Cont'd)			
57	20-032-1	BRACKET	1	SP	
58	MS9592-005	BRACKET (S/N 30504 THRU 31124)	2	SP	
59	NAS679A3	. NUT (REPLACED BY MS21042L3)	2	NP	
59	MS21042L3	. NUT, SELF-LOCKING (REPLACES NAS679A3)	2	SP	
60	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	2	Р	
60 61	NAS1149C0332R MS27039-1-08	. WASHER (REPLACES AN960C10L)	2	SP SP	
62	MS21919DG4	SCREW	2	NP	
02	M321919D34		2	INI	
62	MS21919WDG4	BY MS21919WDG4)	2	SP	
02	M021010WB04	MS21919DG4)	_	0,	
63	MS21919DG2	. CLAMP (PRE TB 212-99-181) (S/N 30504 THRU 31311, 35001	2	NP	
00		THRU 35042) (REPLACED BY MS21919WDG2)	_		
63	MS21919WDG2	. CLAMP (PRE TB 212-99-181) (S/N 30504 THRU 31311, 35001	2	SP	
		THRU 35042) (REPLACES MS21919DG2)	_		
63	MS21919WDG4	. CLAMP (POST TB 212-99-181) (S/N 30504 THRU 31311, 35001	2	SP	
		THRU 35042)			
64	AN815-2D	. UNION (REPLACED BY AS5174W0202)	2	NP	
64	AS5174W0202	. UNION (REPLACES AN815-2D)	2	Р	
65	NAS617-2	. PACKING, PREFORMED (REPLACED BY M83248/1-902)	2	NP	
65	M83248/1-902	. PACKING, PREFORMED (REPLACES NAS617-2) (REPLACED BY	2	SP	
		AS3208-02)	_		
65	A\$3208-02	. PACKING, PREFORMED (REPLACES M83248/1-902)	2	SP	
66	212-060-013-001	. TUBE ASSY, LH (S/N 30504 THRU 31311, 35001 THRU 35042)	1	SP	
66 66	212-062-022-101	. TUBE ASSY, LH (S/N 35043 THRU 35080)	1 1	NP SP	
66 67	212-062-023-101 MS21042L3	. TUBE ASSY, LH (S/N 35081 THRU SUB)	1	SP	
68	AN960JD10L	NUT, SELF-LOCKING	1	Р	
68	NAS1149D0332J	. WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
69	MS27039-1-19	SCREW	1	SP	
70	NAS43DD3-48	. SPACER (REPLACED BY NAS43DD3-48N)	1	Р	
70	NAS43DD3-48N	. SPACER (REPLACES NAS43DD3-48)	1	SP	
71	MS21919WDG2	. CLAMP	1	SP	
72	212-060-014-001	. TUBE ASSY, RH (PRE TB 212-99-181) (S/N 30504 THRU 31311,	1	SP	
		35001 THRU 35042)			
72	212-062-027-101	. TUBE ASSY, RH (POST TB 212-99-181) (S/N 30504 THRU 31311,	1	SP	
		35001 THRU 35042)			
72 70	212-062-021-101	. TUBE ASSY, RH (PRE TB 212-99-181) (S/N 35043 THRU 35102).	1	SP	
72 72	212-062-024-101	. TUBE ASSY, RH (POST TB 212-99-181) (S/N 35043 THRU 35102)	1	SP	
72 73	212-062-024-101 MS21042L3	. TUBE ASSY, RH (S/N 35103)	1 1	SP SP	
73 74	MS21042L3 MS21042L3	NUT, SELF-LOCKING	2	SP	
7 4 75	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	1	Р	
75	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY	1	P	
-	· · · · · · · · · · · · · · · · · · ·	NAS1149D0316J)			
75	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	1	SP	
76	AN960JD10L	. WASHER, FLAT (REPLACED BY NAS1149D0332J)	2	Р	
76	NAS1149D0332J	. WASHER, FLAT (REPLACES AN960JD10L)	2	SP	
77	MS27039-1-08	. SCREW	1	SP	
78 70	MS27039-1-07	. SCREW	2	SP	
79	MS21919DG2	. CLAMP (PRE TB 212-99-181) (S/N 30504 THRU 31311, 35001	1	NP	
70	MCO4040WDCO	THRU 35042) (REPLACED BY MS21919WDG2)	_	C D	
79	MS21919WDG2	. CLAMP (PRE TB 212-99-181) (S/N 30504 THRU 31311, 35001	1	SP	
70	MS21010WDG4	THRU 35042) (REPLACES MS21919DG2)	1	6D	
79	MS21919WDG4	. CLAMP (POST TB 212-99-181) (S/N 30504 THRU 31311, 35001	I	SP	
80	MS21919WDG6	THRU 35042)	2	SP	
80 81	MS21919WDG6 MS21919DG6	CLAMP	1	NP	
٥.		Control (INCLIDED INVOCATION OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE CONTROL OF THE	•		



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-16. Engine Assembly (Cont'd)			
81	MS21919WDG6	. CLAMP (REPLACES MS21919DG6)	1	SP	
82	MS21919WDG2	. CLAMP (PRE TB 212-99-181) (S/N 35043 THRU 35102)	2	SP	
82	MS21919WDG4	. CLAMP (POST TB 212-99-181) (S/N 35043 THRU 35102)	2	SP	
82 83	MS21919WDG4 MS21042L3	CLAMP (S/N 35103)	2	SP SP	
84	AN960PD10L	NUT, SELF-LOCKING	1	P	
84	AN960JD10LL	. WASHER (REPLACED BY AN9603D10LL) . WASHER (REPLACES AN960PD10L) (REPLACED BY NAS1149D0316J)	1	P	
84	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	1	SP	
85	MS27039-1-08	. SCREW	1	SP	
86	MS21919DG2	. CLAMP (REPLACED BY MS21919WDG2)	1	NP	
86	MS21919WDG2	. CLAMP (REPLACES MS21919DG2)	1	SP	
87	MS21042L3	. NUT, SELF-LOCKING	1	SP	
88	AN960PD10L	. WASHER (REPLACED BY AN960JD10LL)	1	Р	
88	AN960JD10LL	. WASHER (REPLACES AN960PD10L) (REPLACED BY	1	Р	
0.0	NA C11 40 D004 0 1	NAS1149D0316J)	4	en.	
88	NAS1149D0316J	. WASHER (REPLACES AN960JD10LL)	1 1	SP	
89 90	MS27039-1-08 MS21919DG2	SCREW	1	SP NP	
90	MS21919DG2 MS21919WDG2	CLAMP (REPLACES MS21919WDG2)	1	SP	
91	MS21919DG4	. CLAMP (REPLACES MISZ1919DG2)	1	NP	
٠.	W621616B61	BY MS21919WDG4)			
91	MS21919WDG4	. CLAMP (S/N 30504 THRU 31311, 35001 THRU 35042) (REPLACES MS21919DG4)	1	SP	
92	212-060-015-001	. TUBE ASSY, LH (PRE TB 212-99-181) (S/N 30504 THRU 31311,	1	SP	
92	212-062-026-101	35001 THRU 35042)	1	SP	
		35001 THRU 35042)			
92	212-062-020-101	. TUBE ASSY, LH (PRE TB 212-99-181) (S/N 35043 THRU 35102) .	1	SP	
92	212-062-025-101	. TUBE ASSY, LH (POST TB 212-99-181) (S/N 35043 THRU 35102)	1	SP	
92 93	212-062-025-101 212-060-016-001	TUBE ASSY, LH (S/N 35103)	1	SP SP	
93	212-000-010-001	. TUBE ASSY, RH (S/N 30504 THRU 31311, 35001 THRU 35042)	'	SF	
93	212-060-017-001	(REPLACED BY 212-060-017-001)	1	SP	
93	212-062-019-101	(REPLACES 212-060-016-001)	1	SP	
94	AN815-2D	. UNION (PRE TB 212-99-181) (S/N 30504 THRU 31311, 35001 THRU 35102) (REPLACED BY AS5174W0202)	2	NP	
94	AS5174W0202	. UNION (PRE TB 212-99-181) (S/N 30504 THRU 31311, 35001 THRU	2	Р	
94	AN919-2D	35102) (REPLACES AN815-2D)	2	NP	
94	AN919-2D	REDUCER (S/N 53103)	2	NP	
95	MS29512-02	. PACKING, PREFORMÉD (PRE TB 212-99-181) (S/N 30504 THRU	2	SP	
95	MS29512-03	31311, 35001 THRU 35102)	2	SP	
		31311, 35001 THRU 35102)			
95	MS29512-03	. PACKING, PREFORMED (S/N 53103)	2	SP	
96	AN815-4J	. UNION (REPLACED BY AS5174J0404)	2	SP	
96	AS5174J0404	. UNION (REPLACES AN815-4J)	2	SP	
97	MS29512-04	PACKING, PREFORMED	2	SP SP	
98 98	70-009F000Y294A 70-009F000X253A	HOSE ASSY, LH (S/N 30504 THRU 31124)	1	SP SP	
98 98	70-009F000X253A 70-009F000X280	HOSE ASSY, LH (S/N 31125 THRU 31306)	1	NP	
30	10-0091 000AZ00	. HOSE ASSY, LH (S/N 31307 THRU 31311, 35001 THRU SUB)	'	INF	
98	70-009F000X280A	(REPLACED BY 70-009F000X280A)	1	SP	
		(REPLACES 70-009F000X280)			

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-16. Engine Assembly (Cont'd)			
99	70-009F000Y287A	. HOSE ASSY, RH (S/N 31125 THRU 31311, 35000 THRU SUB)	1	SP	
100	AN924-4J	. NUT (REPLACED BY AS5178J04)	2	SP	
100 101	AS5178J04 AN833-4J	. NUT (REPLACES AN924-4J)	2 2	SP SP	
101	MS29512-04	PACKING, PREFORMED	2	SP	
103	70-009F000X200	. HOSE ASSY, LH (REPLACED BY 70-009F000X200A)	1	NP	
103	70-009F000X200A	. HOSE ASSY, LH (REPLACES 70-009F000X200)	1	SP	
104	70-009F000Y300	. HOSE ASSY, RH (REPLACED BY 70-009F000Y300A)	1	NP	
104	70-009F000Y300A	. HOSE ASSY, RH (REPLACES 70-009F000Y300)	1	SP	
105	212-060-663-001	BOLT	2	SP	
106 107	212-060-662-001 204-060-031-005	. FITTING ASSY	2	SP SP	
107	MS29512-05	PACKING, PREFORMED	2	SP	
109	MS29512-04	PACKING, PREFORMED.	2	SP	
110	MS21042L3	. NUT, SELF-LOCKING (S/N 30561 THRU 31311, 35001 THRU SUB)	1	SP	
111	AN960JD10L	. WASHER, FLAT (S/N 30561 THRU 31311, 35001 THRU SUB)	1	Р	
		(REPLACED BY NAS1149D0332J)			
111	NAS1149D0332J	. WASHER, FLAT (S/N 30561 THRU 31311, 35001 THRU SUB)	1	SP	
440	M007000 4 00	(REPLACES AN960JD10L)		C D	
112	MS27039-1-08	. SCREW (S/N 30561 THRU 31311, 35001 THRU SUB)	1	SP SP	
113 114	MS21919WDG10 MS21919WDG4	CLAMP (S/N 30561 THRU 31311, 35001 THRU SUB)	1	SP	
115	70-009F180F114A	. HOSE ASSY, LH (S/N 30504 THRU 30560)	1	SP	
115	70-009F180F122A	. HOSE ASSY, LH (S/N 30504 THRU 30500)	1	SP	
116	70-009F180F174A	. HOSE ASSY, RH	1	SP	
117	MS21919H18	. CLAMP (REPLACED BY MS21919WCH18)	2	NP	
117	MS21919WCH18	. CLAMP (REPLACES MS21919H18)	2	SP	
118	MS21042L3	. NUT, SELF-LOCKING (S/N 35081 THRU SUB)	1	SP	
119 120	NAS1149C0332R MS27039-1-09	. WASHER (S/N 35081 THRU SUB)	1	SP SP	
120	MS21919WCH19	SCREW (S/N 35081 THRU SUB)		SP	
122	MS21919WCH9	CLAMP (S/N 35081 THRU SUB)	4	SP	
123	MS21919WCH14	. CLAMP (S/N 35081 THRU SUB)	3	SP	
124	MS21919WCH16	. CLAMP (S/N 35081 THRU SUB)	1	SP	
125	70-009K115C194A	. HOSE ASSY, LH (PRE TB 212-96-157) (S/N 30504 THRU 31124) (REPLACED BY 70-009K245W347A)	1	SP	
125	70-009K245W347A	. HOSE ASSY, LH (PRE TB 212-96-157) (S/N 30504 THRU 31311,	1	SP	
		35001 THRU 35080) (REPLACES 70-009K115C194A)			
125	70-078K145F144	. HOSE ASSY, LH (POST TB 212-96-157) (S/N 35081 THRU SUB).	1	SP	
126	70-009K274W220A	. HOSE ASSY, RH (PRE TB 212-96-157) (S/N 30504 THRU 31124)	1	SP	
126	70-009K120W371A	(REPLACED BY 70-009K120W371A)	1	NP	
120	70.003K1Z0W371A	35001 THRU 35080) (REPLACES 70-009K274W220A)	'	INF	
126	70-078K120F374	. HOSE ASSY, RH (POST TB 212-96-157) (S/N 35081 THRU SUB)	1	SP	
127	70-009F180F194	HOSE ASSY, LH (S/N 35081 THRU SUB) (REPLACED BY	1	NP	
		70-009F180F194A)			
127	70-009F180F194A	. HOSE ASSY, LH (S/N 35081 THRU SUB) (REPLACES	1	NP	
128	70-009F250Z124	70-009F180F194)	1	NP	
120	70-0091 2302124	70-009F250Z124A)	'	INI	
128	70-009F250Z124A	HOSE ASSY, RH (S/N 30504 THRU 30530) (REPLACES	1	SP	
129	70-009F180F194A	70-009F250Z124)	2	NP	
130	70-0091 1001 194A 70-078F000Y302	. HOSE ASSY (3/N 30331 THRO 31311, 35001 THRO 33000)	1	SP	
131	70-078F000Y274	. HOSE ASSY, RH (POST TB 212-96-157) (S/N 35081 THRU SUB)	1	SP	
132	110-089-12C	REDUCER TEE	2	SP	
133	AN919-15J	. REDUCER	2	NP	
134	MS29512-08	. PACKING, PREFORMED	2	SP	
		,			<u> </u>



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-16. Engine Assembly (Cont'd)			
135	MS21042L3	. NUT, SELF-LOCKING	2	SP	
136	AN960JD10L	. WASHER, FLAT (REPLACED BY NAS1149D0332J)	2	Р	
136	NAS1149D0332J	. WASHER, FLAT (REPLACES AN960JD10L)	2	SP	
137	MS27039-1-08	. SCREW	2	SP	
138 138	MS21919H14 MS21919WCH14	. CLAMP (REPLACED BY MS21919WCH14)	5 5	NP SP	
139	70-009F000Y244	. CLAMP (REPLACES MS21919H14)	2	NP	
139	70-009F000Y244A	70-009F000Y244A)	2	SP	
140	70-009G000Y186A	70-009F000Y244)	1	SP	
141	70-009G000Y324A	. HOSE ASSY, EH (S/N 30531 THRU 31311, 35001 THRU SUB)	1	SP	
142	32005-005	. TACH GENERATOR (S/N 30504 THRU 31124) (REPLACED BY GEU-7/A, 32005-007)	2	NP	
142	32005-007	. TACH GENERATOR (S/N 30504 THRU 31124) (REPLACES 32005-005) (REPLACED BY GEU-7/A)	2	NP	
142	GEU-7/A	. TACH GENERATOR (REPLACES 32005-005, 32005-007) (REPLACED BY 32005-037)	2	NP	
142	32005-037	. TACH GENERATOR (REPLACES GEU-7/A)	2	SP	
143	MS9134-01	. GASKET (REPLACED BY 60-015-1)	2	NP	
143	60-015-1	. GASKET (REPLACES MS9134-01)	2	SP	
144	209-060-221-001	. STARTER-GENERATOR ASSEMBLY (SEE FIG. 71-19 FOR BREAKDOWN)	2	Р	
		(ALTERNATE PART)			
144	200SG119Q-1	. STARTER-GENERATOR ASSEMBLY (SEE FIG. 71-20 FOR BREAKDOWN)	2	Р	
145 145	MS29561-113 M83248/1-113	PACKING, PREFORMED (REPLACED BY M83248/1-113)	REF REF	NP SP	
		BY AS3209-113)			
145	AS3209-113	. PACKING, PREFORMED (REPLACES M83248/1-113)	REF	SP	
146	MS28034-3	. TEMP BULB, TRANSMITTER, TEMPERATURE	2	SP P	
147 147	MS29561-110 M83248/1-110	PACKING, PREFORMED (REPLACED BY M83248/1-110)	2	SP	
147	1003240/1-110		_	J.	
147	AS3209-110	BY AS3209-110)	2	SP	
148	209-062-018-001	TRANSMITTER, OIL PRESSURE (S/N 30504 THRU 31124) (REF.	2	NP	
148	130-020-5	DES. B3, B4) (REPLACED BY 130-020-5)	2	NP	
140	100-020-0	TRANSMITTER, OIL PRESSURE (REF. DES. B3, B4) (REPLACES	-	111	
148	APTE-138-150G	209-062-018-001) (REPLACED BY APTE-138-150G) TRANSMITTER, OIL PRESSURE (REF. DES. B3, B4) (REPLACES	2	NP	
148	APTE-138A-100G	130-020-5)	1	SP	
149	212-061-031-001	RESTRICTOR	2	SP	
150	MS29561-213	PACKING, PREFORMED (REPLACED BY M83248/1-213)	2	NP	
150	M83248/1-213	. PACKING, PREFORMED (REPLACES MS29561-213) (RÉPLACED	2	SP	
150	AS3209-213	BY AS3209-213)	2	SP	
151	100-016-1	PLUG (USBL ON 130-020-5)	2	SP	
152	NAS617-4	. PACKING, PREFORMED (USBL ON 130-020-5) (REPLACED BY M83248/1-904)	2	P	
152	M83248/1-904	. PACKING, PREFORMED (USBL ON 130-020-5) (REPLACES NAS617-4) (REPLACED BY AS3208-04)	2	SP	
152	AS3208-04	. PACKING, PREFORMED (USBL ON 130-020-5) (REPLACES M83248/1-904)	2	SP	
153	70-030H000Y134	. HOSE ASSY	2	SP	
154	MS17826-5	. NUT (REPLACED BY MS14145L5)	2	NP	
154	MS14145L5	. NUT (REPLACES MS17826-5)	2	SP	
155	AN960C516L	. WASHER (REPLACED BY NAS1149C0532R)	2	Р	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
155 156 157 157 158	NAS1149C0532R 212-060-723-003 AN919-3J AS5174J0504 MS29512-04	Figure 71-16. Engine Assembly (Cont'd) . WASHER (REPLACES AN960C516L) . LEVER . REDUCER(FOR HOSE ASSY GOING TO DIFFERENTIAL PRESSURE SWITCH) (REPLACED BY AS5174J0504) . REDUCER(FOR HOSE ASSY GOING TO DIFFERENTIAL PRESSURE SWITCH) (REPLACES AN919-3J) . PACKING, PREFORMED	2 2 2 2	SP SP NP SP SP	
		AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 71-17. Engine Assembly



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-17. Engine Assembly			
	212-062-005-001	ENGINE ASSY (S/N 30504 THRU 30530) (SEE FIG. 71-16, 71-18	REF	NP	
	212-062-005-003	FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-005-005	FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-005-103	FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-005-105	FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-002-003-103	ENGINE ASSY (S/N 31282 THRU 31306) (SEE FIG. 71-16, 71-18 FOR BALANCE OF BREAKDOWN) (REPLACED BY	KEF	INF	
	212-062-005-107	212-062-005-107)	REF	NP	
	212-062-005-113	212-062-005-105)	REF	NP	
	212-062-005-119	ENGINE ASSY (S/N 35081 THRU 35102) (SEE FIG. 71-16, 71-18	REF	Р	
	212-062-005-131	FOR BALANCE OF BREAKDOWN) ENGINE ASSY (S/N 35103) (SEE FIG. 71-16, 71-18 FOR BALANCE OF BREAKDOWN)	REF	Р	
1	MS9575-09	BOLT	4	SP	
2	AN960C10	. WASHER (REPLACED BY NAS1149C0363R)	4	Р	
2 3	NAS1149C0363R 3751B13T12	. WASHER (REPLACES AN960C10)	4 2	SP NP	
3	212-061-012-005	212-061-012-005)	2	SP	
4	M83248/1-214	PACKING, PREFORMED	1	SP	
5	3601-16-9	WASHER	2	SP	
6	3605-16-3	NUT BODY (REPLACED BY 3605-16D-3)	1	NP	
6	3605-16D-3	NUT BODY (REPLACES 3605-16-3)	1	SP	
7	3751B13T12-1	BODY (REPLACED BY 3751B13T12)	1	Р	
7	3751B13T12	ELBOW ASSY (REPLACES 3751B13T12-1) (REPLACED BY 212-061-012-005)	1	NP	
7 8	212-061-012-005 212-060-002-001	ELBOW ASSY (REPLACES 3751B13T12)	1 2	SP NP	
8	212-060-002-003	212-060-002-003, 209-063-010-001)	2	NP	
	209-063-010-001	(REPLACED BY 209-063-010-001)	2	SP	
8 9	209-063-010-001	GASKET (REPLACES 212-060-002-001 AND -003)	2	SP	
10	212-061-014-001	ORIFICE	1	NP	
10	70-031C110-000	(REPLACED BY 70-031C110-000)	1	SP	
10	70-061F000Y124A	(REPLACES 212-061-014-001)	1	SP	
11	212-061-014-001	35001 THRU SUB)	1	NP	
11	70-031C110-000	(REPLACED BY 70-031C110-000)	1	SP	
11	70-061F000Y140A	(REPLACES 212-061-014-001)	1	SP	
12	212-061-015-001	HOSE ASSY	2	SP	
13	100-016-1	PLUG (USBL ON 130-020-3)	1	SP	
14	NAS617-4	PACKING, PREFORMED (USBL ON 130-020-3) (REPLACED BY M83248/1-904)	1	P	
		IVIO3246/ 1-904)			



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-17. Engine Assembly (Cont'd)			
14	M83248/1-904	. PACKING, PREFORMED (USBL ON 130-020-3) (REPLACES	1	SP	
14	AS3208-04	NAS617-4) (REPLACED BY AS3208-04)	1	SP	
15	130-020-3	M83248/1-904)	1	SP	
15	APTE-138-100G	APTE-138-100G)	1	NP	
15	APTE-138A-100G	130-020-3) (REPLACED BY APTE-138A-100G)	1	SP	
16	MS29561-213	APTE-138-100G)	1	NP	
16	M83248/1-213	PACKING, PREFORMED (REPLACES MS29561-213) (REPLACED BY AS3209-213)	1	SP	
16	AS3209-213	. PACKING, PREFORMED (REPLACES M83248/1-213)	1	SP	
17	212-061-031-001	RESTRICTOR	1	SP	
18	NAS1306-8H	BOLT (REPLACED BY NAS6606H8)	4	NP	
18	NAS6606H8	BOLT (REPLACES NAS1306-8H)	4	SP	
19	NAS1306-5H	BOLT (S/N 30504 THRU 31124) (REPLACED BY NAS6606H5)	4	NP	
19	NAS6606H5	BOLT (S/N 30504 THRU 31124) (REPLACES NAS1306-5H)	4	SP	
20	AN960C616 NAS1149C0663R	. WASHER (REPLACED BY NAS1149C0663R)	8	P SP	
20		. WASHER (REPLACES AN960C616)	8 2	SP	
21 22	212-061-101-001 212-060-730-001	BEARING	2	SP	
23	MS20206DSP4	. MOUNT	1	NP	
23	MS27643-4	BEARING (REPLACED BY MS27643-4)	1	SP	
24	MS17825-3	NUT (REPLACED BY MS14144L3)	2	NP	
24	MS14144L3	NUT (REPLACED BY MS14144L3)	2	SP	
25	AN960C10L	. WASHER (REPLACED BY NAS1149C0332R)	2	P	
25	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	2	SP	
26	AN173-11	BOLT (S/N 30504 THRU 31124)	4	SP	
26	NAS6603D12	BOLT (S/N 31125 THRU 31311, 35001 THRU SUB)	4	SP	
27	NAS679A4	. NUT (REPLACED BY MS21042L4)	1	P.	
27	MS21042L4	NUT (REPLACES NAS679A4)	1	SP	
28	AN960-416L	. WASHER (REPLACED BY NAS1149F0432P)	1	P	
28	NAS1149F0432P	. WASHER (REPLACES AN960-416L)	1	SP	
29	212-060-728-005	. JACKSHAFT ASSY (S/N 30504 THRU 31281) (REPLACED BY	1	NP	
29	212-060-728-101	212-060-728-101)	1	SP	
30	212-060-729-003	. FITTING ASSY	1	SP	
31	212-060-729-001	FITTING ASSY	1	SP	
32	212-060-727-001	LEVER	1	SP	
33	212-060-726-001	LEVER	1	SP	
34	212-060-725-003	BELLCRANK (S/N 30504 THRU 31281) (REPLACED BY 212-060-725-101)	1	NP	
34	212-060-725-101	BELLCRANK (REPLACES 212-060-725-003)	1	SP	
35	212-060-728-003	TUBE	1	P	
36	212-060-724-003	. TUBE ASSY	1	SP	
37	204-061-717-001	BEARING	1	SP	
38	AN316-4R	NUT	1	SP	
39	AN960PD416	WASHER (REPLACED BY AN960JD416)	1	NP	
39	AN960JD416	WASHER (REPLACES AN960PD416) (REPLACED BY	1	Р	
39	NAS1149D0463J	NAS1149D0463J)	1	SP	
39		WASHER (REPLACES AN960JD416)	1	SP	
40	212-060-724-005 204-061-717-003	TUBE ASSY	1	SP SP	
40 41	212-060-724-001	BEARING	1	SP	
41 42	204-061-717-003	TUBE ASSY (PRE TB 212-93-145)	2	SP	
44	204-001-111-003	BEARING		OΓ	



NOEX NUMBER ITEM NAME NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER NUMBER	(1)	(2)	(3)	(4)	(5)	(6)
A3 209-062-780-001		PART NUMBER	ITEM NAME	PER	V A I	0
	43 43 44 44 45 45	209-062-780-001 209-062-780-101 MS17825-3 MS14144L3 AN960C416L NAS1149C0432R	Figure 71-17. Engine Assembly (Cont'd) ACTUATOR (POST TB 212-93-145) (REF. DES. B81) (REPLACED BY 209-062-780-101) ACTUATOR (REPLACES 209-062-780-001) NUT (REPLACED BY MS14144L3) NUT (REPLACES MS17825-3) WASHER (REPLACED BY NAS1149C0432R) WASHER (REPLACES AN960C416L) LEVER AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts	1 1 2 2 2 2 2	NP SP NP SP NP SP	C




Figure 71-18. Engine Assembly, Rear (Sheet 1 of 2)

212_IPB_71_0018a






Figure 71-18. Engine Assembly, Rear (Sheet 2 of 2)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	4 > 4 _ L	U 0 C
		Figure 71-18. Engine Assembly, Rear			
	212-062-005-001	ENGINE ASSY (S/N 30504 THRU 30530) (SEE FIG. 71-16, 71-17	REF	NP	
	212-062-005-003	FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-005-005	FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-005-103	FIG. 71-16, 71-17 FOR BALANCE OF BREAKDOWN) ENGINE ASSY (S/N 31125 THRU 31281) (SEE FIG. 71-16, 71-17	REF	NP	
	212-062-005-105	FOR BALANCE OF BREAKDOWN)	REF	NP	
	212-062-005-107	212-062-005-107)	REF	NP	
	212-062-005-113	212-062-005-105)	REF	NP	
	212-062-005-119	FOR BALANCE OF BREAKDOWN)	REF	Р	
	212-062-005-131	FOR BALANCE OF BREAKDOWN)	REF	Р	
1 2 3 4 5 5A 6	DELETED DELETED DELETED DELETED DELETED DELETED DELETED DELETED	(POST ASB 212-83-31) (POST ASB 212-83-31) (POST ASB 212-83-31) (POST ASB 212-83-31) (POST ASB 212-83-31) (POST ASB 212-83-31)	NA NA NA NA NA NA		
7 8 8A 9 10	212-062-015-001 212-062-015-009 30-036-8 MS21042L6 209-062-502-009	(POST ASB 212-83-31) . SHIELD ASSY GASKET CLAMP NUT . BLOWER, OIL COOLER (S/N 30504 THRU 30939) (REPLACED BY	1 1 1 1 12 2	SP SP SP SP	
10	209-062-502-101	212-062-514-101)	2	NP	
10	212-062-514-101	212-062-514-101)	2	SP	
10A	212-062-515-101	-101)	1	SP	
11	MS29561-210	31311, 35001 THRU 35103)	2	Р	
11	M83248/1-210	M83248/1-210)	2	SP	
11	MS9388-210	MS29561-210)	2	NP	
11 12 13 13 14 14	AS3209-210 212-060-515-001 AN815-4J AS5174J0404 NAS617-4 M83248/1-904	(REPLACED BY AS3209-210) . PACKING, PREFORMED (REPLACES MS9388-210)	2 1 1 1 1	SP SP SP SP SP	
14 15 16 16	AS3208-04 AN783J4 AN6289J4 AS5179J04	AS3208-04) . PACKING, PREFORMED (REPLACES M83248/1-904) . TEE . NUT (REPLACED BY AS5179J04) . NUT (REPLACES AN6289J4)	1 1 1	SP SP SP SP	




(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-18. Engine Assembly, Rear (Cont'd)			
17 18 18	MS28773-04 MS29561-110 M83248/1-110	. RETAINER	1 1 1	SP P SP	
18 19 20	AS3209-110 212-060-513-001 AN815-4J	BY AS3209-110)	1 1 1	SP SP SP	
21 21	NAS617-4 M83248/1-904	. PACKING, PREFORMED (REPLACED BY M83248/1-904)	1	P SP	
21 22 23 23 24 25 25	AS3208-04 AN833-4J AN6289J4 AS5179J04 MS28773-04 MS29561-110 M83248/1-110	AS3208-04)	1 1 1 1 1 1	SP SP SP SP SP SP	
25 26	AS3209-110 7G186	BY AS3209-110)	1	SP NP	
26 27 27	209-062-003-001 NAS617-4 M83248/1-904	209-062-003-001)	1 1 1	SP P SP	
27 28 28 29 29	AS3208-04 NAS679A3 MS21042L3 AN960PD10L AN960JD10LL	AS3208-04)	1 4 4 4 4	SP NP SP P	
29 30 30 31 32 33 34 34	NAS1149D0316J AN3-4A NAS6603-2 209-062-002-001 212-061-522-001 212-061-523-001 32005-005 32005-007	NAS1149D0316J) WASHER (REPLACES AN960JD10LL) . BOLT (S/N 30504 THRU 31124) . BOLT (S/N 31125 THRU SUB, 35001 THRU SUB) . INDICATOR, DIFFERENTIAL PRESSURE BRACKET BRACKET TACH GENERATOR (REPLACED BY 32005-007, GEU-7/A) . TACH GENERATOR (S/N 30504 THRU 31124) (REPLACES	4 4 4 1 1 1 2 2	SP SP SP SP SP NP NP	
34	GEU-7/A	32005-005) (REPLACED BY GEU-7/A)	2	NP	
34 35 35 36 36 37 37	32005-037 MS9134-01 60-015-1 AN3H4A NAS6603H2 AN960PD10L AN960JD10LL	(REPLACED BY 32005-037) TACH GENERATOR (REPLACES GEU-7/A) GASKET (REPLACED BY 60-015-1) GASKET (REPLACES MS9134-01) BOLT (S/N 30504 THRU 31124) BOLT (S/N 31125 THRU SUB, 35001 THRU SUB) WASHER (REPLACED BY AN960JD10LL) WASHER (REPLACES AN960PD10L) (REPLACED BY	2 2 2 4 4 4 4	SP SP SP SP P P	
37 38 39 40 41 41	NAS1149D0316J 212-060-506-002 212-060-506-001 AN929-4 MS29561-120 M83248/1-120	NAS1149D0316J)	4 1 1 2 2 2	SP SP SP SP SP SP	
41	AS3209-120	BY AS3209-120)	2	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-18. Engine Assembly, Rear (Cont'd)			
42	7G186	. SWITCH, PRESSURE (S/N 30504 THRU 31124) (REPLACED BY 209-062-003-001)	2	NP	
42	209-062-003-001	. SWITCH, PRESSURE (REPLACES 7G186)	2	SP	
43	NAS617-4	PACKING, PREFORMED (REPLACED BY M83248/1-904)	2	P	
43	M83248/1-904	PACKING, PREFORMED (REPLACES NAS617-4) (REPLACED BY AS3208-04)	2	SP	
43	AS3208-04	. PACKING, PREFORMED (REPLACES M83248/1-904)	2	SP	
44	70-010F000D207A	. HOSE ASSY, LH (REPLACED BY 70-061F000D207A)	1	NP	
44	70-061F000D207A	. HOSE ASSY, LH (REPLACES 70-010F000D207A)	1	SP	
45	70-010F000X240A	. HOSE ASSY, RH (REPLACED BY 70-061F000X240A)	1	NP	
45	70-061F000X240A	. HOSE ASSY, RH (REPLACES 70-010F000X240A)	1	SP	
46	AN815-4	UNION (REPLACED BY AN815-4J)	2	NP	
46	AN815-4J	. UNION (REPLACED BY AN815-4) (REPLACED BY AS5174J0404)	2	SP	
46	AS5174J0404	UNION (REPLACES ANS 15-4) (REPLACED BY ASS 17430404)	2	SP	
47	NAS617-4	PACKING, PREFORMED (REPLACED BY M83248/1-904)	2	P	
47	M83248/1-904	PACKING, PREFORMED (REPLACED BY M63246/1-904)	2	SP	
47	AS3208-04	PACKING, PREFORMED (REPLACES M83248/1-904)	2	SP	
48	70-010F000X110A	. HOSE ASSY (S/N 30504 THRU 31124) (REPLACED BY 70-061F000X110A)	2	NP	
48	70-061F000X110A	. HOSE ASSY (S/N 30504 THRU 31124) (REPLACES 70-010F000X110A)	2	SP	
49	AN815-4	. UNION (REPLACED BY AN815-4J)	2	NP	
49	AN815-4J	. UNION (REPLACES AN815-4) (REPLACED BY AS5174J0404)	2	SP	
49	AS5174J0404	UNION (REPLACES AN815-4J)	2	SP	
50	NAS617-4	PACKING, PREFORMED (REPLACED BY M83248/1-904)	2	P	
50	M83248/1-904	PACKING, PREFORMED (REPLACES NAS617-4) (REPLACED BY AS3208-04)	2	SP	
50	AS3208-04	PACKING, PREFORMED (REPLACES M83248/1-904)	2	SP	
51	AN833-4	ELBOW (REPLACED BY AN833-4J)	2	SP	
51	AN833-4J	ELBOW (REPLACES AN833-4)	2	SP	
52	AN924-4	NUT (REPLACED BY AS5178-04)	2	SP	
52	AS5178-04	NUT (REPLACES AN924-4)	2	SP	
53	NAS617-4	PACKING, PREFORMED (REPLACED BY M83248/1-904)	2	P	
53	M83248/1-904	. PACKING, PREFORMED (REPLACES NAS617-4) (REPLACED BY	2	SP	
53	AS3208-04	AS3208-04)	2	SP	
54	3567758-6501	. TRANSMITTER, TORQUE (S/N 30504 THRU 31124) (REPLACED BY 18-1814)	2	P	
54	18-1814	. TRANSMITTER, TORQUE (S/N 30504 THRU 31124) (REPLACES 3567758-6501)	2	SP	
		(ALTERNATE PART)			
54	3567758-6503	. TRANSMITTER, TORQUE (S/N 30504 THRU 31124)	2	NP	
54	412-075-205-101	. TRANSMITTER, TORQUE (POST TB 212-81-52) (S/N 31125 THRU 31311, 35001 THRU 35103) (SEE FIG. 71-2 FOR BALANCE OF	2	Р	
54	800-0001	BREAKDOWN) (REPLACED BY 800-0001)	2	Р	
		OF BREAKDOWN) (REPLACES 412-075-205-101)			
55 55	NAS617-12 M83248/1-912	PACKING, PREFORMED (REPLACED BY M83248/1-912)	2 2	P SP	
-		AS3208-12)			
55	AS3208-12	PACKING, PREFORMED (REPLACES M83248/1-912)	2	SP	
56	MS28034-3	TEMP BULB	1	SP	
00	MS29561-110	PACKING, PREFORMED (REPLACED BY M83248/1-110)	1	P	
57	W3Z9301-11U				



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 71-18. Engine Assembly, Rear (Cont'd)			
57	M83248/1-110	. PACKING, PREFORMED (REPLACES MS29561-110) (REPLACED	1	SP	
57 58 58 58 59 60 61 62 62 63 64 65 66 67 67 67	M83248/1-110 AS3209-110 PT6T3 3015300 PT6T-3B 70-009F000X194A AN815-4J AS5174J0404 MS21042L3 AN960PD10L AN960JD10LL NAS1149D0316J MS27039-1-08 MS21919DG4 MS21919WDG4 212-062-014-001 AN815-4J AS5174J0404 NAS617-4 M83248/1-904 AS3208-04	PACKING, PREFORMED (REPLACES MS29561-110) (REPLACED BY AS3209-110). PACKING, PREFORMED (REPLACES M83248/1-110). ENGINE (S/N 30504 THRU 31124) (REPLACED BY 3015300). ENGINE (S/N 30504 THRU 31124) (REPLACES PT6T3). ENGINE (S/N 31125 THRU SUB, 35001 THRU SUB). HOSE ASSY. UNION (REPLACED BY AS5174J0404). UNION (REPLACED BY AS5174J0404). UNION (REPLACES AN815-4J). NUT, SELF-LOCKING. WASHER (REPLACES AN960D10LL) WASHER (REPLACES AN960D10LL) SCREW. CLAMP (REPLACES AN960JD10LL). SCREW. CLAMP (REPLACED BY MS21919WDG4). CLAMP (REPLACED BY MS21919WDG4). UNION (REPLACED BY AS5174J0404). UNION (REPLACED BY AS5174J0404). UNION (REPLACED BY AS5174J0404). UNION (REPLACED BY AS5174J0404). PACKING, PREFORMED (REPLACED BY M83248/1-904). PACKING, PREFORMED (REPLACES NAS617-4) (REPLACED BY AS3208-04). PACKING, PREFORMED (REPLACES M83248/1-904) AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	S SPPPSSSPP SSPSSSPS S	



71-99-00 Page 108



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-19. Starter Generator (209-060-221)			
	209-060-221-001	STARTER-GENERATOR ASSEMBLY (NOTE 2) (SEE FIG. 71-16 FOR	REF	Р	
1	209-060-221-103	NHA)	1	SP	
2 3	23046-1790 23072-1125	END BELL, DRIVE END PAD (NOTE 1)	1	SP	
3	23072-1325 209-060-221-101	COUPLING CLAMP, RIM CLINCHING	1	SP	
4	AN502-10-14	(ALTERNATE PART)	1	SP	
5	05-321002	NUT (REPLACED BY NAS1329H3K130L)	1	SP	
5	NAS1329H3K130L	RIVNUT, BLIND (REPLACES 05-321002)	1	SP	
6	23046-1724	COVER, BRUSH	1	P	
7	05-340201	SCREW	4	SP	
8	30300-1285	BRUSH, STARTER	4	SP	
8	23088-1324		4	NP	
8	23093-1300	BRUSH, STARTER	4	P	
9	23032-1580	BRUSH, STARTER	1	Р	
•	00000 4500	(ALTERNATE PART)		0.0	
9	23032-1586	CLAMP, RIM CLINCHING	1	SP	
10	23048-1000	COVER, FAN	1	Р	
11	23048-1041	AIR INLET ASSY (MATCHED SET)	1	SP	
12	MS35266-65	SCREW	2	SP	
13	AN960-10	WASHER (REPLACED BY NAS1149F0363P)	2	Р	
13	NAS1149F0363P	WASHER (REPLACES AN960-10)	2	SP	
14	MS21042-4	NUT, SELF LOCKING (REPLACED BY MS21042L4)	1	NP	
14	MS21042L4	NUT, SELF LOCKING (REPLACES MS21042-4)	1	SP	
15	AN960-416	WASHER (REPLACED BY NAS1149F0463P)	1	NP	
15	NAS1149F0463P	WASHER (REPLACES AN960-416)	1	SP	
16	23048-1480	FAN	1	SP	
17	02-6100-04	DRIVESHAFT	1	SP	
18	M83248/1-113	PACKING, PREFORMED (REPLACED BY AS3209-113)	1	SP	
18	AS3209-113	PACKING, PREFORMED (REPLACES M83248/1-113)	1	SP	
19	23032-1900	HUB DAMPENER	1	SP	
20	23032-1910	PLATE DAMPENER	1	SP	
21	02-5600-05	FRICTION DISC, CLUTCH DAMPENER (REPLACED BY 02-5600-13)	1	NP	
21	02-5600-13	FRICTION DISC, CLUTCH DAMPENER (REPLACES 02-5600-05)	1	SP	
22	23032-2710	BACKPLATE DAMPENER	1	SP	
23	NAS1189-08P16KW	SCREW	12	SP	
24	23046-1630	END BELL, DRIVE END	1		
25	MS21318-15	SCREW (REPLACES AN535-2-4)	6	SP	
26	AN960-4L	WASHER (REPLACED BY NAS1149FN416P)	6	Р	
26	NAS1149FN416P	WASHER (REPLACES AN960-4L)	6	SP	
27	23046-1180	SCREEN	1		
28	MS16628-1078	RETAINER	1	SP	
29	G128-178	BAFFLE DISC	2	SP	
30	03-6010-08	BEARING (REPLACED BY 03-6010-15)	1	NP	
30	03-6010-15	BEARING (REPLACES 03-6010-08) (REPLACED BY 03-6010-18)	1	NP	
30 31	03-6010-18 23046-1030	BEARING (REPLACES 03-6010-15)	1	SP NP	
		(ALTERNATE PART)			
31	23046-1031	ARMATURE	1	SP	
32	MS35265-43	SCREW	4	SP	
33	23046-1110	RETAINER	1	P	
00					
34	03-6010-08	BEARING (REPLACED BY 03-6010-15)	1	NP	



NOREX NUMBER	NOMER PART NUMBER Figure 71-19. Starter Generator (209-060-221) (Cont'd)	(1)	(2)	(3)	(4)	(5)	(6)
34	34		PART NUMBER	ITEM NAME	PER	V A I	0
codes as well as general use of the Illustrated Parts		35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 50 51 51 52 52 53 53	23046-340 23048-1010 05-350206 AN3-10A AN960-10L 05-374094 05-631145 23033-1121 23064-1284 MS21318-14 MS21318-13 06-201020 23046-313 MS35266-65 MS35338-43 AN960-10L NAS1149F0332P 23032-1516 23032-1516 23032-1516 MS21042-6 MS21042-6 NAS1149C0663R MS21042-3 MS21042-3 MS21042-3	BEARING (REPLACES 03-6010-15) SUPPORT ASSY, BEARING AND BRUSH HOLDER END BELL, ANTI-DRIVE END SCREW, FLAT HEAD BOLT. WASHER (REPLACED BY NAS1149F0332P) WASHER SLEEVE SPRING, BRUSH BRUSH HOLDER ASSY (REPLACES 23064-1283) SCREW (REPLACED BY MS21318-13) SCREW (REPLACES BY MS21318-14) DECAL, INSTRUCTION. STATOR AND HOUSING ASSY SCREW. WASHER, LOCK WASHER (REPLACED BY NAS1149F0332P) WASHER (REPLACED BY NAS1149F0332P) WASHER (REPLACES AN960-10L) BLOCK, TERMINAL (REPLACED BY 23032-1512) BLOCK, TERMINAL (REPLACED BY 23032-1516) NUT (REPLACES BY 21042-6) NUT (REPLACES BY 21042-6) WASHER (REPLACES AN960-616) NUT, SELF-LOCKING (REPLACED BY MS21042L3) NUT, SELF-LOCKING (REPLACED BY MS21042-3) WASHER NOTE 1: FOR SPARE PART REPLACEMENT, ORDER NHA MOUNTING KIT 209-060-221-103. NOTE 2: UNLESS LISTED OTHERWISE, ALL ITEMS ARE FROM STARTER GENERATOR ASSEMBLY 209-060-221-001. NOTE 3: QUICK ATTACH DETACH KIT (QAD) CAN NOT BE MIXED BETWEEN STARTER GENERATOR MODELS. STARTER GENERATOR ASSEMBLY 209-060-221-001. NOTE 3: QUICK ATTACH DETACH KIT (QAD) CAN NOT BE MIXED BETWEEN STARTER GENERATOR MODELS. STARTER GENERATOR 209-060-221-103. AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts	1 1 1 8 8 8 8 8 8 4 4 4 1 1 2 2 2 2 2 1 1 3 3 3 3 3 3 3 3 3 2 2 2 2	P SPPS SPS SPPS PSPSPS	







Figure 71-20. Starter Generator (200SG119Q-1) (Sheet 1 of 2)

71-99-00 Page 112

Rev. 8 30 APR 2010

ECCN EAR99





DETAIL A

212_IPB_71_0021b+

Figure 71-20. Starter Generator (200SG119Q-1) (Sheet 2 of 2)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 71-20. Starter Generator (200SG119Q-1)			
	200SG119Q-1	STARTER-GENERATOR ASSEMBLY	REF	Р	
1	250SG1083	. QUICK ATTACH DETACH KIT (QAD) (NOTE 1)	1	NP	
2	250SG1040-1	MOUNTING FLANGE	1	NP	
3	250SG1108-1	V-BAND CLIP	1	NP	
4	200SGL119Q	. STARTER-GENERATOR (NOTE 1) (SEE FIG. 71-16 FOR NHA)	1	NP	
5	M83248/1-113	PACKING, PREFORMED (REPLACED BY AS3209-113)	1	SP	
5 6	AS3209-113 200SG1103-3	PACKING, PREFORMED (REPLACES M83248/1-113)	1	SP NP	
7	150SG1070	SHAFT, DRIVE ASSY	1	NP	
8	250SG1073	PLATE DAMPENER		NP	
9	NAS118908P16LKW	SCREW, FLAT HEAD	12	NP	
10	250SG1301	HSG & SCREEN ASSY	1	NP	
11	250SG1028	BELL, END DRIVE	1	NP	
12	250SG1004	SCRÉEN	1	NP	
13	AN960-4	WASHER (REPLACED BY NAS1149FN432P)	6	SP	
13	NAS1149FN432P	WASHER (REPLACES AN960-4)	6	SP	
14	MS21318-15	SCREW	6	SP	
15	MS16628-4078	RING, RETAINING	1	NP	
16	250SG1017	DISC, BAFFLE	2	NP	
17	250SG1052-B	BEARING, BALL	4	NP	
18 19	MS21318-13 150SG1139	SCREW	1	SP NP	
20	150SG1159 150SG1168	DECAL, HI-POT WARNING	1	NP	
21	200SG1126-1	DECAL, QAD WARNING	1 1	NP	
22	200SG1156	STATOR A TERMINAL BLOCK ASSEMBLET		NP	
23	250SG1061-1	TERMINAL BLOCK	1	NP	
24	MS35266-65	SCREW	2	SP	
25	MS35338-43	WASHER, LOCK	2	SP	
26	AN960-10L	WASHER (REPLACED BY NAS1149F0332P)	2	Р	
26	NAS1149F0332P	WASHER (REPLACES AN960-10L)	2	SP	
27	SPS27FT-1032	NUT, TERMINAL BLOCK	2	NP	
28	AN960C10	WASHER (REPLACED BY NAS1149C0363R)	2	Р	
28	NAS1149C0363R	WASHER (REPLACES AN960C10)	2	SP	
29 30	SPS27FT-624 AN960C616	NUT, TERMINAL BLOCK	3	NP P	
30	NAS1149C0663R	WASHER (REPLACED BY NAST149C0663R)	3	SP	
31	200SG1064	ARMATURE ASSY	1	NP	
32	250SG1250	STRAP ASSEMBLY, BRUSH COVER	1	NP	
33	MS35266-67	SCREW	1	SP	
34	250SG1153-1	COMM. END BELL ASSY	1	NP	
35	NAS118908P12LKW	SCREW, FLAT HEAD	8	NP	
36	250SG1006-1	RETAINER, BEARING	1	NP	
37	MS24694-S3	SCREW	4	NP	
38	250SG1107	FAN ASSY	1	NP	
39 40	200SGL1093 150SG1071	SPRING, BELLEVILLE	2	NP NP	
40	250SG1011	NUT, SELF LOCKING	1	NP	
42	200SGL1011-2	COVER ASSY, FAN	1	NP	
43	150SG1108	CLAMP	1 1	P	
44	MS35266-65	SCREW	2	SP	
45	MS35338-138	WASHER	2	SP	
46	AN960C10	WASHER (REPLACED BY NAS1149C0363R)	2	Р	
46	NAS1149C0363R	WASHER (REPLACES AN960C10)	2	SP	
47	250SG1215	HOLDER, BRUSH	4	NP	
48	250SG1005	. SPRING	8	NP	
49	250SG1009	BRUSH, STARTER	4	SP	
50	200SG1020	SCREW BRUSH HOLDER	4	NP	
51 52	250SG1046 150SG1045	INSULATOR	4 8	NP NP	
5∠	15056 1045	TUBE, INSULATOR	ŏ	INP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	0 C
53 54 54 55 56	AN3-7A AN960-10L NAS1149F0332P 150SG1046 250SG1008-1	Figure 71-20. Starter Generator (200SG119Q-1) (Cont'd) . BOLT WASHER (REPLACED BY NAS1149F0332P) . WASHER (REPLACES AN960-10L) . WASHER, INSULATOR BR. BOX . HEAD, COMMUTATOR NOTE 1: QUICK ATTACH DETACH KIT (QAD) CAN NOT BE MIXED BETWEEN STARTER GENERATOR MODELS. STARTER GENERATOR 200SGL119Q USES MOUNTING KIT 250SG1083 AND STARTER GENERATOR 209-060-221-101 USES MOUNTING KIT 209-060-221-103.	8 8 8 8 1	SP P SP NP NP	
		AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 71-21. Ejector and Ejector/Deflector Assemblies

212_IPB_71_0020



INDEX			(4)	(5)	(6)
NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	O C
		Figure 71-21. Ejector and Ejector/Deflector Assemblies			
1	212-061-201-005	EJECTORASSY, EXHAUST, LH (NOTE 1) (S/N 30504 THRU 30553)	REF	NP	
1	212-061-201-009	(SEE FIG.13 FOR NHA) (REPLACED BY AAL-061-204-001) EJECTORASSY, EXHAUST, LH (NOTE 1) (S/N 30554 THRU 30596, 30604 THRU 30610) (SEE FIG.13 FOR NHA) (REPLACED BY	REF	SP	
1	212-061-201-011	AAL-061-204-001)	REF	NP	
1	AAL-061-204-001	EJECTOR/DEFLECTOR ASSY, EXHAUST, LH (REFER TO ITEM 23)	REF	Р	
2	212-061-201-006	EJECTORASSY, EXHAUST, RH (NOTE 1) (S/N 30504 THRU 30553)	REF	SP	
		(SEE FIG.13 FOR NHA) (REPLACED BY AAL-061-204-002)			
2	212-061-201-010	EJÉCTORASSY, EXHAUST, RH (NOTE 1) (S/N 30554 THRU 30596, 30604 THRU 30610) (SEE FIG.13 FOR NHA) (REPLACED BY	REF	SP	
2	212-061-201-012	AAL-061-204-002) EJECTORASSY, EXHAUST, RH (NOTE 1) (S/N 30597 THRU 30603, 30611 THRU 31311, 35001 THRU 35103) (SEE FIG.13 FOR NHA)	REF	NP	
2	AAL-061-204-002 212-061-201-049	(REPLACED BY AAL-061-204-002)	REF 1	P SP	
4	212-061-201-073	RETAINER, LH	1	NP	
5	212-061-201-074	. RETAINER, LH	1	NP	
6	212-061-201-075	. SEAL (MAKE FROM .37 X 1.00 150-15A)	1	Р	
7	212-061-201-029	. BRACKET, BOTTOM, LH (USBL ON 212-061-201-005 AND -009) .	1	NP	
8	212-061-201-030	. BRACKET, BOTTOM, RH (USBL ON 212-061-201-006 AND -010).	1	NP	
9	212-061-201-031	BRACKET, BOTTOM (USBL ON 212-061-201-005, -006, -009 AND -010)	1	NP	
10	212-061-201-053	BRACKET, SIDE (USBL ON 212-061-201-005, -006, -009 AND -010)	2	Р	
11 12	NAS42HT3-17 212-061-201-011D	SPACER (USBL ON 212-061-201-005, -006, -009 AND -010)	1	P NP	
12	212-061-201-011Q	(REPLACED BY 212-061-201-011Q)	1	SP	
13	212-061-201-011H	(REPLACES 212-061-201-011D)	1	NP	
13	212-061-201-011E	(REPLACED BY 212-061-201-011E)	1	SP	
14	212-061-201-105	SUPPORT, LH	1	SP	
15	212-061-201-106	. SUPPORT, RH	1	SP	
16	212-061-201-117	. SUPPORT, LH	1	Р	
17	212-061-201-118	. SUPPORT, RH	1	Р	
18	212-061-201-023	. RING	1	SP	
19	212-061-201-025	. RING	1	SP	
20	212-061-201-027	. RING	1	SP	
21	212-061-201-061	. RING	3	SP	
22	212-060-212-001	. FITTING	1	Р	
23	AAL-061-204-001	EJECTOR/DEFLECTOR ASSY, EXHAUST, LH (NOTE 1, 3) (SEE	REF	Р	
24	AAL-061-204-002	FIG.13 FOR NHA) (REPLACES 212-061-201-005, -009 AND -011) EJECTOR/DEFLECTOR ASSY, EXHAUST, RH (NOTE 1, 3) (SEE FIG.13 FOR NHA) (REPLACES 212-061-201-006, -010 AND -012)	REF	Р	
25	AAL-061-201-001	EJECTOR ASSY, LH	1	SP	
26	AAL-061-201-002	EJECTOR ASSY, RH.	1	SP	
27	AAL-061-201-125	DOUBLER, MOUNT, BOTTOM	1	NP	
28	AAL-061-201-126	DOUBLER, MOUNT, SIDE	1	NP	
29	AAL-061-201-137	GASKET, MOUNT FLANGE	1	NP	
30	AAL-061-201-144	SEAL	1	NP	
31	AAL-061-203-001	DEFLECTOR ASSY, EXHAUST, LH (NOTE 2, 5)	1	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBE	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
22	AAL-061-203-002	Figure 71-21. Ejector and Ejector/Deflector Assemblies (Cont'd)	4	SP	
32 33 34 35 36 37 37 38 39 39A 40 41 42 43 44 45 46 47 48	AAL-061-203-002 AAL-061-203-003 AAL-061-205-001 AAL-061-205-003 MS27039C0805 AN960C8 NAS1149CN832R AAL-061-207-001 AAL-061-207-002 MS20427M AAL-061-207-003 AAL-061-207-005 AAL-061-207-005 AAL-061-207-006 AAL-061-207-007 AAL-061-207-007 AAL-061-207-008 AAL-061-207-104 MS103C1032 AAL-061-207-103 AAL-061-207-103 AAL-061-207-011	DEFLECTOR ASSY, EXHAUST, RH (NOTE 2, 5) VANE, EXHAUST DEFLECTOR BRACKET, MOUNT, BOTTOM. BRACKET, MOUNT, SIDE SCREW WASHER (REPLACED BY NAS1149CN832R). JACKET ASSY, LH (NOTE 2, 5). JACKET ASSY, RH (NOTE 2, 5). RIVET (NOTE 4). CLAMP, JACKET, UPPER, LH. CLAMP, JACKET, UPPER, RH. CLAMP, JACKET, LOWER, LH. CLAMP, JACKET, LOWER, RH. CLAMP, JACKET, LOWER, RH. CLAMP, JACKET, LOWER, RH. STANDOFF, CLAMP (USBL ON AAL-061-207-007 AND -008). NUT. PLATE, JACKET WEAR. REPAIR KIT, JACKET (NOTE 5).	1 1 1 1 10 10 10 1 1 AR 3 2 2 1 1 1 3 1 REF	5	
		NOTE 1: REFER TO FIGURE 71-13 FOR INTERCHANGEABILITY BETWEEN EJECTOR ASSEMBLY 212-061-201-005/-006, -009/-010, -011/-012 AND EJECTOR/DEFLECTOR ASSEMBLY AAL-061-204-001/-002.			
		NOTE 2: FOR JACKET REPAIR, ORDER KIT AAL-061-207-011.			
		NOTE 3: USE EJECTOR/DEFLECTOR ASSEMBLY AAL-061-204-001 AND EJECTOR/DEFLECTOR ASSEMBLY AAL-061-204-002 AS A SET.			
		NOTE 4: RIVET LENGTH TO BE DETERMINED UPON INSTALLATION.			
		NOTE 5: THE ALPINE JACKET REPAIR AND OVERHAUL KIT AAL-061-207-011 CONTAINS THE FOLLOWING ITEMS: FOUR EACH SECTIONS OF PRECUT FABRIC WEAR STRIP, TWO EACH (REV. A & B) JACKET DOUBLERS/OIL COOLER CUT OUT, ONE EACH TUBE OF SILICON SEALANT/ADHESIVE FOR FABRIC WEAR STRIP, ALL REPLACEMENT RIVETS AND WASHERS REQUIRED, AND ONE EACH JACKET REPAIR KIT ILLUSTRATED INSTALLATION INSTRUCTIONS.			
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			