

CONTENTS - IPB

Figure	Figure Title	Chapter/Section	Page
Number		Number	Number
11-1	Markings installation	11-99-00	2



212 11 1001 1 C0001

Figure 11-1. Markings installation (Sheet 1 of 2)



212-11-1001-2 C0001

Figure 11-1. Markings installation (Sheet 2)

11-99-00 Rev. 5 Page 3

BHT-212-IPB

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	noc
		FIGURE: 11-1. Markings installation			
	212-070-600-001	MARKINGS INSTL, FWD (S/N 30504 THRU 31157)	1		
	212-070-600-009	MARKINGS INSTL, FWD (S/N 30504 THRU 31157)	1	1 -	
	212-070-600-101	MARKINGS INSTL, FWD (S/N 31158 THRU 31264)	1		
	212-070-600-115	MARKINGS INSTL, FWD (S/N 31265 THRU 31273, 31275)	1		
	212-070-600-123	MARKINGS INSTL, FWD (S/N 31274, 31276 THRU 31300)	1		
1	212-070-600-127 31-055-1DFHP	MARKINGS INSTL, FWD (S/N 31301 THRU SUB)	1		
2	31-055-IDFHP 31-044-7DHF	DECAL (STRUCTURAL PANEL)	2	1	
3	31-044-7DHF 31-044-3CJP	DECAL (MAXIMUM BALLAST) DECAL (STRUCTURAL PANEL)	1 12	1	
4	31-044-3C0F 31-042-12CFK	DECAL (SIROCIORAL PANEL)	4	1	
5	31-042-3DFP	DECAL (PULL)	2	1	
6	205-070-854-007	DECAL (ON DEFROST OFF)	1	1 1	
7	31-053-2DFHP	DECAL (TURN AND PULL)	2	1	
8	31-043-14CGL	.DECAL (FIRE EXTINGUISHER)	1	-	
9	31-039-3LA	.DECAL (FIRE EXTINGUISHER ARROW)	1	1	
10	31-042-7DHF	.DECAL (OPEN) (USBL ON 212-070-600-001)	2	1	
10	31-042-7BHF	.DECAL (OPEN) (USBL ON 212-070-600-009, -101,	2	1	
		-115, -123 AND -127)			
11	31-042-13DHF	.DECAL (LOCKED)	2	1	
12	31-057-1EH	.DECAL (ARROW) (USBL ON 212-070-600-001)	1	1	
12	31-057-3EH	.DECAL (ARROW) (USBL ON	1	1	
		212-070-600-009,-101,-115, -123 AND -127)			
12	31-057-2EH	.DECAL (ARROW) (USBL ON 212-070-600-001)	1	1	
12	31-057-4EH	.DECAL (ARROW) (USBL ON	1	1	
		212-070-600-009,-101,-115, -123 AND -127)			
13	31-042-10DGL	.DECAL (EMERGENCY RELEASE) (USBL ON	4		
14	31-043-43CKF	212-070-600-001)	•		
14	31-043-43CKF	.DECAL (EMERGENCY EXIT ONLY) (USBL ON	8	1	
15	212-072-635-101	DECAL (EMERGENCY PUSH HERE) (S/N 31158 THRU	32	1	
	212 072 033 101	31300)	24	_	
16	212-072-635-101	.DECAL (EMERGENCY PUSH HERE) (S/N 31301 THRU SUB)	16	1	
17	212-072-636-101	.DECAL (EMERGENCY PUSH, PUSH WINDOW AT ANY CORNER) .	4	-	
		(S/N 31158 THRU 31300) (REPLACED BY			
		212-072-636-109)			
17	212-072-636-109	.DECAL (EMERGENCY PUSH CORNER-OUTSIDE DOOR)	4	1	
		(REPLACES 212-072-636-101)			
18	212-072-637-101	.DECAL (EMERGENCY PUSH CORNER-INSIDE DOOR) (S/N	4		
		31158 THRU 31300) (REPLACED BY 212-072-637-107)			
18	212-072-637-107	.DECAL (EMERGENCY PUSH CORNER-INSIDE DOOR)	4	1	
		(REPLACES 212-072-637-101)			
19	31-044-5DGL	.DECAL (PULL COVER) (USBL ON 212-070-600-001)	4	1	
19	31-044-16DKF	.DECAL (PULL EMERGENCY COVER) (USBL ON	4	1	
	21 042 7777	212-070-600-009)			
20	31-042-7TKP	.DECAL (OPEN) (USBL ON 212-070-600-001 AND -009)	8	1	ľ
21	CAN/AC/4-P	.DECAL (EMERGENCY RELEASE) (USBL ON	4	1	
	21 040 25	212-070-600-001 AND -009)			
22 23	31-040-3D	.DECAL (ARROW) (USBL ON 212-070-600-001 AND -009)	4	1	
23	31-040-4D 31-054-5DFHP	.DECAL (ARROW) (USBL ON 212-070-600-001 AND -009)	4	1	
44	21-024-2DLUL	.DECAL (FUEL SUMP DRAIN)	2	1	
	·				i

11-99-00 Page 4

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	000
		FIGURE: 11-1. Markings installation (Cont'd)			
25	212-070-652-007	.DECAL (FUEL CAP)	1	1	
26	204-070-626-009	.DECAL (GROUND HERE)	3	1	
27	31-054-6DFHP	.DECAL (28 VDC)	1	1	
28	212-070-662-003	.DECAL (ENGINE OIL SIGHT GAUGE, LH)	1	1	
28	212-070-662-004	.DECAL (ENGINE OIL SIGHT GAUGE, RH)	1	1	
29	100-018-1	.DECAL (INSIGNIA) (REPLACED BY 100-109-1)	2		
29	100-109-1	.DECAL (INSIGNIA) (REPLACES 100-018-1)	2		
30	100-029-1	.ID PLATE (RADIO CALL)	1	1	
31	31-043-28DMP	DECAL (SEAL DRAIN)	2	1	
32	31-043-11DMP	DECAL (VENT TANK)	2	1	
33	31-043-12DMP	.DECAL (FUEL CONNECT)	2	1	
34	31-043-13DMP	.DECAL (SUMP DRAIN)		1	
35	204-070-626-011	.DECAL (GROUND HERE)	1	1	
36	31-052-1JP	.DECAL (GROUND MARK)	1	1	
37	31-043-15DJG	.DECAL (LATCH PIN INSPECTION HOLE) (S/N 30504 THRU .	10	1	
		31157)			
38	CAN/AC/4-0	.DECAL (EMERGENCY EXIT)	4	1	
39	31-072-1	DECAL (DANGER-TAIL ROTOR) (S/N 31274, 31276 THRU 31300)	4	1	
	212-070-600-003	MARKINGS INSTL, AFT (S/N 30504 THRU 31264)	1	0	
	212-070-600-111	MARKINGS INSTL, AFT (S/N 31265 THRU 31270)	1		
	212-070-600-119	MARKINGS INSTL, AFT (S/N 31271 THRU SUB)	1		
40	31-044-2CMP	.DECAL (INSTALL SHAFT CLAMPS)	2	1	
41	212-070-644-003	DECAL (CLOSE AND OPEN)	1	1	
42	212-070-645-007	.DECAL (MAX. ELEV NOSE DOWN)	1	1	
43	212-070-645-009	.DECAL (FULL AFT CYCLIC STICK)	1	1	
44	212-070-645-011	.DECAL (FULL FWD CYCLIC STICK)	1	1	
45	31-071-1	DECAL (DANGER ARROW) (S/N 31271 THRU 31299)	1	0	
45	31-075-1	.DECAL (DANGER ARROW) (S/N 31271 THRU 31299) (REPLACES 31-071-1)	1	1	
46	31-071-2	DECAL (DANGER ARROW) (S/N 31271 THRU 31299)	1	0	
		(REPLACED BY 31-075-2)			
46	31-075-2	DECAL (DANGER ARROW) (S/N 31271 THRU 31299) (REPLACES 31-071-2)	1	1	
	212-070-655-003	.MARKINGS (TAIL ROTOR)	1	0	
47	31-018-5	DECAL (RED SPOT)	7	1	
47A	31-018-7	DECAL (WHITE SPOT)	7	1	
48	31-054-33SFHP	.DECAL (42 DEG. GEARBOX OIL CAPACITY)	1	1	
49	31-054-34SFHP	.DECAL (90 DEG. GEARBOX OIL CAPACITY)	1	1	
50	31-056-1DFHP	.DECAL (OIL SERVICE MARKINGS) (S/N 30504 THRU 31311, 35001 THRU 35035)	3	1	
50	31-064-5EFHP	.DECAL (OIL SERVICE MARKINGS) (S/N 30680 THRU SUB) .	3	1	
	212-070-600-005	MARKINGS INSTL, COWL	1	0	
51	31-056-1DFHP	.DECAL (OIL SERVICE MARKINGS) (S/N 30504 THRU 31311, 35001 THRU 35035) (REPLACED BY 31-064-2EFHP)	6	1	
51	31-064-2EFHP	DECAL (OIL SERVICE MARKINGS) (REPLACES	6		
52	31-054-3DFHP	DECAL (ENG OIL FILLER CAP INSIDE)	2	1	
			_		

BHT-212-IPB

(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	4>4-L	000
		FIGURE: 11-1. Markings installation (Cont'd)			
53	31-054-1DFHP	.DECAL (GEARBOX FILLER CAP ON TOP)	2	1	
	31-054-4DFHP	.DECAL (XMSN OIL ACCESS)	3	1	
				1	
56		31-054-32DFHP)	1	0	
56	31-054-32DFHP	.DECAL (TRANSMISSION OIL CAPACITY) (REPLACES 31-054-7DFHP)	1	1	
57	31-054-10DFHP	.DECAL (ENG OIL CAPACITY) (REPLACED BY	2	0	
57	31-054-35DFHP	.DECAL (ENG OIL CAPACITY) (REPLACES	2	1	
58	31-054-11DFHP	.DECAL (COMBINING GEARBOX OIL CAPACITY) (REPLACED . BY 31-054-36DFHP)	3	0	
58	31-054-36DFHP	.DECAL (COMBINING GEARBOX OIL CAPACITY) (REPLACES . 31-054-11DFHP)	3	1	
59	31-030-61F22	.DECAL (CAUTION - INSTL. REQD. PRIOR TO FLIGHT) (USBL ON 212-070-600-127)	4		
60	31-030-63A10	.DECAL (CAUTION - COMPASS UNRELIABLE WITH	1	1	
	212-070-600-007	MARKINGS INSTL, PYLON	1		
61	31-054-2DFHP	.DECAL (OIL SERVICE MARKINGS)	2	1	
62	31-018-5	.DECAL (RED SPOT)	4	1	
63	31-018-7	.DECAL (WHITE SPOT)	4	1	
ļ					
	53 54 55 56 56 57 57 58 58 59 60 61 62	PART NUMBER 53	PART NUMBER FIGURE: 11-1. Markings installation (Cont'd)	PART NUMBER FIGURE: 11-1. Markings installation (Cont'd)	PART NUMBER ITEM NAME PART NUMBER FIGURE: 11-1. Markings installation (Cont'd)

11-99-00

Page 6 Rev. 5