



DETAIL A

- 1. Airspeed indicator
- 2. Marker beacon light
- 3. NAV CMD CPLT PLT light
- 4. PITCH ROLL YAW light
- 5. Attitude indicator
- 6. Horizontal situation indicator
- 7. Clock
- 8. Master caution light
- 9. Altimeter
- 10. Vertical speed indicator
- 11. RPM caution light
- 12. Triple tachometer
- 13. Dual torque pressure indicator
- 14. Fire 1 pull handle
- 15. Cargo release armed indicator
- 16. Baggage compartment fire indicator
- 17. Airspeed limits typical
- 18. Hydraulic temperature and pressure indicator
- 19. Fuel quantity selector switch
- 20. Master caution panel
- 21. Fire extinguisher test switch
- 22. Fire extinguisher selector switch
- 23. Baggage compartment fire test switch
- 24. Fuel quantity indicator
- 25. Transmission oil temperature and pressure indicator

- 26. Gearbox oil temperature and pressure indicator
- 27. Dual DC ammeter
- 28. Fire 2 pull handle
- 29. Engine 1 out indicator
- 30. Gas producer tachometer indicator
- 31. Inter turbine temperature indicator
- 32. Engine oil temperature and pressure indicator
- 33. Fuel pressure indicator
- 34. Dual AC and DC voltmeter
- 35. Engine 2 out indicator
- 36. DME indicator
- 37. Radar altimeter indicator
- 38. NAV fail lights
- 39. Panel typical to PT6T-3B engines
- 40. Static source switch

NOTES



Helicopters with alternate static air.

212-M-95-2 212-075-718K 212-075-043B

Figure 95-2. Instrument panel (S/N 30597 and subsequent)