

oC° Value from Torque Transmitter Setting Instruction Plate	Corresponding Torque Indicator Reading (%) for oc° Value at Left	oC° Value from Torque Transmitter Setting Instruction Plate	Corresponding Torque Indicator Reading (%) for oc° Value at Left	oC° Value from Torque Transmitter Setting Instruction Plate	Corresponding Torque Indicator Reading (%) for oc° Value at Left
82.0	40.94	85.4	42.64	88.8	44.33
82.1	40.99	85.5	42.69	88.9	44.38
82.2	41.04	85.6	42.74	89.0	44.43
82.3	41.09	85.7	42.79	89.1	44.48
82.4	41.14	85.8	42.84	89.2	44.53
82.5	41.19	85.9	42.89	89.3	44.58
82.6	41.24	86.0	42.94	89.4	44.63
82.7	41.29	86.1	42.99	89.5	44.68
82.8	41.34	86.2	43.04	89.6	44.73
82.9	41.39	86.3	43.09	89.7	44.78
83.0	41.44	86.4	43.14	89.8	44.83
83.1	41.49	86.5	43.19	89.9	44.88
83.2	41.54	86.6	43.24	90.0	44.93
83.3	41.59	86.7	43.29	90.1	44.98
83.4	41.64	86.8	43.33	90.2	45.03
83.5	41.69	86.9	43.38	90.3	45.08
83.6	41.74	87.0	43.43	90.4	45.13
83.7	41.79	87.1	43.48	90.5	45.18
83.8	41.84	87.2	43.53	90.6	45.23
83.9	41.89	87.3	43.58	90.7	45.28
84.0	41.94	87.4	43.63	90.8	45.33
84.1	41.99	87.5	43.68	90.9	45.38
84.2	42.04	87.6	43.73	91.0	45.43
84.3	42.09	87.7	43.78	91.1	45.48
84.4	42.14	87.8	43.83	91.2	45.53
84.5	42.19	87.9	43.88	91.3	45.58
84.6	42.24	88.0	43.93	91.4	45.63
84.7	42.29	88.1	43.98	91.5	45.68
84.8	42.34	88.2	44.03	91.6	45.73
84.9	42.39	88.3	44.08	91.7	45.78
85.0	42.44	88.4	44.13	91.8	45.83
85.1	42.49	88.5	44.18	91.9	45.88
85.2	42.54	88.6	44.23	92.0	45.93
85.3	42.59	88.7	44.28		

 $\frac{\circ C^{\circ}}{K}$ = % Torque Indicator Reading

K = 2.003 Test pressure is 35.4 PSIG

Figure 76-7A. Torque Transmitter Calibration — Benz System

76-00-00 ECCN EAR99 30 APR 2010 Rev. 11 Page 24A