





NOTES

1 Use appropriate grip length of rivets to accommodate doubler and skid tube thickness.

2 Break all sharp edges on doubler.

212_MM_32_0006

Figure 32-6. Skid Tube (AAI 412-320-119/-120/-123/-124) Patch Repair