




212\_MM\_67\_0003a

Figure 67-3. Cyclic Controls (Sheet 1 of 2)





DETAIL B
BEARING INSTALLATION



DETAIL C
(SOME PARTS OMITTED FOR CLARITY)

- Bolt
   Spring
   Extension tube
   Boot
   Universal
   Cylinder support
   Hydraulic cylinder
   Bellcrank
   Control tube (2)
   Extension tube
   Boot
- Universal
   Support
   Hydraulic cylinder
   Bellcrank
   Control tube
   Magnetic brake
   Force gradient
   Control tube
   Magnetic brake
   Force gradient
   Control tube
   Control tube
   Control tube
- 23. Bellcrank
  24. Control tube
  25. Pilot cyclic stick
  26. Cyclic jackshaft
  27. Control tube
  28. Mixing lever
  29. Control tube
  30. Valve arm
  31. Stop bolt
  32. Stop bolt
  33. Bolt

34. Plate

35. SpringBellcrank
36. Transducer
37. Support assembly
38. Bolt
39. Washer
40. Nut
41. Sleeve
42. Bearing
43. Bolt
44. Washer
45. Nut
46. Cotter pin

212\_MM\_67\_0003b\_c01

Figure 67-3. Cyclic Controls (Sheet 2 of 2)