

- 1. Packing
- 2. Carbon seal
- 3. Magnetic ring
- 4. Packing

- 5. Packing
- 6. Seal retainer
- 7. Retaining ring
- 8. Main driveshaft curvic coupling adapter

212-M-63-53

Figure 63-53. Main input quill curvic coupling adapter and magnetic seal assembly