

- 1. Tachometer generator right power section (N1)
- 2. Transmitter, gearbox oil pressure
- Tachometer generator left power section (N1) 3.
- Oil pressure transmitter left power section 4.
- 5. Temperature bulb left power section
- 6. Oil pressure transmitter right power section
- 7. Temperature bulb right power section


## NOTE

/1\ Installed on helicopter S/N 30501 through 30999, 31101 through 31124, and 32101 through 32142 if not modified by Technical Bulletin.

Installed on helcopter S/N 31125 and 32143 and subsequent, and helicopters modified by Technical Bulletin.

212-M-71-28-1

Figure 71-28. Engine accessories (sheet 1 of 3)






- 8. Indicator differential pressure
- 9. Tachometer generator left power section (N2)
- 10. Torque transmitter left power section
- 11. Torque transmitter right power section
- 12. Tachometer generator right power section (N2)
- 13. Oil pressure switch right power section

- 14. Temperature bulb combining gearbox
- 15. Oil pressure switch (gearbox)
- 16. Oil pressure switch left power section.
- 17. Bracket
- 18. Combining gearbox data plate

212-M-71-28-2

Figure 71-28. Engine accessories (sheet 2)



19. Pressure hose24. Washer20. Vent hose25. Nut21. Electrical connector26. Packing22. Torque transmitter27. Nut23. Support28. Elbow

212-M-71-28-3

Figure 71-28. Engine accessories (sheet 3)