


CHAPTER 32 — LANDING GEAR

CONTENTS — ILLUSTRATED PARTS BREAKDOWN

Figure Number		Chapter/Section Number	Page Number
32-1	Standard Landing Gear Assembly	. 32-99-00	2
32-2	High Landing Gear Kit	. 32-99-00	6
32-3	High Crosstube Kit, BHT-212-SI-76	. 32-99-00	10
32-4	Skid Tube Assembly		14
32-5	Skid Tube Assembly (AAI)		22
32-6	Forward Crosstube Assembly		26
32-7	Forward Crosstube Assembly (AAI)		28
32-8	Aft Crosstube Assembly		30
32-9	Aft Crosstube Assembly (AAI)		32
32-10	Forward High Crosstube Assembly		34
32-11	Forward High Crosstube Assembly (AAI)	. 32-99-00	36
32-12	Aft High Crosstube Assembly	. 32-99-00	38
32-13	Aft High Crosstube Assembly (AAI)		42
32-14	Skid Installation, Tailboom		44
32-15	Fixed Step Kit	. 32-99-00	46





32-99-00 Page 2

Rev. 8 30 APR 2010



PART NUMBER Figure 32-1. Standard Landing Gear Assembly LANDING GEAR ASSY, SKID (S/N 30504 THRU 30614) (REPLACED BY 205-050-400-027 LANDING GEAR ASSY, SKID (S/N 30504 THRU 30910) (REPLACED BY 205-050-400-071) LANDING GEAR ASSY, SKID (S/N 30504 THRU 30910) (REPLACED BY 205-050-400-071) LANDING GEAR ASSY, SKID (S/N 30504 THRU 31311, 32101 THRU 32142, 35001 THRU 35102) (REPLACES 205-050-400-009 AND -027) (REPLACED BY 212-050-225-103) LANDING GEAR ASSY, SKID (S/N 30504 THRU 31311, 32101 THRU 32142, 35001 THRU 35102) (REPLACES 205-050-400-009 AND -027) (REPLACED BY 212-050-225-103) LANDING GEAR ASSY, SKID (S/N 30504 THRU SUB) (REPLACES 205-060-400-009 -027 (REPLACED BY 212-050-225-103) LANDING GEAR ASSY, SKID (S/N 30504 THRU SUB) (REPLACES 205-060-400-009 -027 AND -071) (REPLACED BY 212-050-225-103) LANDING GEAR ASSY, SKID (S/N 30504 THRU SUB) (REPLACES 205-060-400-009, -027 AND -071) (REPLACED BY 304-050-050-400-009, -027 AND -071) (REP		(2)	(3)	(4)	(5)	(6)
205-050-400-009		PART NUMBER	ITEM NAME	PER	A V A I L	U O C
BY 205-050-400-027			Figure 32-1. Standard Landing Gear Assembly			
205-050-400-027	20	05-050-400-009		1	NP	
205-050-400-071	20	05-050-400-027	LANDING GEAR ASSY, SKID (S/N 30504 THRU 30910) (REPLACED	1	NP	
212-050-225-103	20	05-050-400-071	LANDING GEAR ASSY, SKID (S/N 30504 THRU 31311, 32101 THRU	1	NP	
1 AN4-10A BOLT (USBL ON 205-050-400-009, -027 AND -071) 4 2 AN960PD416L WASHER (USBL ON 212-050-225-103) 4 2 AN960JD416L WASHER (REPLACES AN960PD416L) (REPLACED BY AN960JD416L) 4 2 AN960JD416L WASHER (REPLACES AN960JD416L) 4 2 NAS1149D0416J WASHER (REPLACES AN960JD416L) 4 2 NAS1149D0416K WASHER (USBL ON 212-050-225-103) 4 3 AN6-10A BOLT (USBL ON 212-050-225-103) 4 4 AN960PD616L BOLT (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD616L) 8 4 AN960JD616L WASHER (REPLACES AN960JD616L) (REPLACED BY AN960JD616L) 8 4 NAS1149D0616J WASHER (REPLACES AN960JD616L) (REPLACED BY NA960JD616L) 8 4 NAS1149D0616J WASHER (USBL ON 212-050-225-103) 8 5 AN6-10A BOLT (USBL ON 205-050-400-009 AND -027) 4 6 AN960JD616L WASHER (REPLACES AN960JD616L) 4 6 AN960JD616L WASHER (REPLACED BY AN960JD616L) 4 6 NAS1149D0616J WASHER (REPLACES AN960JD616L) 4	21	12-050-225-103	-027) (REPLACED BY 212-050-225-103)	1	Р	
2 AN960PD416L WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD416L). 4 2 AN960JD416L WASHER (REPLACES AN960PD416L) (REPLACED BY NAS1149D0416J) 4 2 NAS1149D0416J WASHER (REPLACES AN960JD416L). 4 2 NAS1149D0416K WASHER (USBL ON 212-050-225-103). 4 3 AN6-10A BOLT (USBL ON 212-050-225-103). 4 4 AN960PD616L WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD616L). 8 4 AN960JD616L WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD616L). 8 4 AN960JD616L WASHER (REPLACES AN960PD616L) (REPLACED BY AN960JD616L). 8 4 AN51149D0616J WASHER (REPLACES AN960JD616L). 8 5 AN6-10A BOLT (USBL ON 205-050-400-009 AND -027). 4 5 AN6-11A BOLT (USBL ON 205-050-400-009). 8 6 AN960JD616L WASHER (REPLACES AN960JD616L). 4 6 AN960JD616L WASHER (REPLACES AN960JD616L). 4 6 NAS1149D0616J WASHER (REPLACES AN960JD616L).		-	. BOLT (USBL ON 205-050-400-009, -027 AND -071)	-	SP	
BY AN960JD416L			. BOLT (USBL ON 212-050-225-103)		SP	
NAS1149D0416J			BY AN960JD416L)		NP	
2 NAS1149D0416J WASHER (REPLACES AN960JD416L) 4 2 NAS1149D0416K WASHER (USBL ON 212-050-225-103) 4 3 AN6-10A BOLT (USBL ON 205-050-400-009, -027 AND -071) 8 4 AN960PD616L WASHER (USBL ON 212-050-225-103) 8 4 AN960PD616L WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD616L) 8 4 AN960JD616L WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J) 8 4 NAS1149D0616J WASHER (REPLACES AN960JD616L) 8 5 AN6-10A BOLT (USBL ON 212-050-225-103) 8 6 AN6-10A BOLT (USBL ON 205-050-400-007) 4 5 AN6-11A BOLT (USBL ON 205-050-400-0071) 4 6 AN6-01A BOLT (USBL ON 212-050-225-103) 4 6 AN960PD616L WASHER (REPLACED BY AN960JD616L) 4 6 AN960PD616L WASHER (REPLACES AN960JD616L) 4 6 NAS1149D0616J WASHER (REPLACES AN960JD616L) 4 7 AN6-7A BOLT (USBL ON 205-050-400-00	1	N960JD416L	NAS1149D0416J)	4	Р	
3 AN6-10A BOLT (USBL ON 205-050-400-009, -027 AND -071) 8 4 AN960PD616L WASHER (USBL ON 212-050-225-103) 8 4 AN960JD616L WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD616L) 8 4 AN960JD616L WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J) 8 4 NAS1149D0616J WASHER (REPLACES AN960JD616L) 8 5 AN6-10A BOLT (USBL ON 205-050-400-009 AND -027) 4 5 AN6-11A BOLT (USBL ON 205-050-400-071) 4 5 AN6-11A BOLT (USBL ON 212-050-225-103) 4 6 AN960PD616L WASHER (REPLACED BY AN960JD616L) 4 6 AN960JD616L WASHER (REPLACES AN960PD616L) (REPLACED BY AN960JD616L) 4 6 NAS1149D0616J WASHER (REPLACES AN960JD616L) 4 6 NAS1149D0616J WASHER (USBL ON 212-050-225-103) 4 6 NAS1149D0616K WASHER (USBL ON 212-050-225-103) 4 7 AN6-7A BOLT (USBL ON 205-050-400-009) AND -027) 6 8 AN960P			. WASHER (REPLACES AN960JD416L)	-	SP	
NAS6206-9			. WASHER (USBL ON 212-050-225-103)	-	SP	
4 AN960PD616L				-	SP	
BY AN960JD616L			BUL1 (USBL UN 212-050-225-103)	-	SP SP	
4 AN960JD616L	٠,	N9001 DOTOL		0	01	
4 NAS1149D0616J WASHER (REPLACES AN960JD616L) 8 4 NAS1149D0616K WASHER (USBL ON 212-050-225-103) 8 5 AN6-10A BOLT (USBL ON 205-050-400-009 AND -027) 4 5 AN6-11A BOLT (USBL ON 205-050-400-071) 4 6 NAS6206-12 BOLT (USBL ON 212-050-225-103) 4 6 AN960JD616L WASHER (REPLACED BY AN960JD616L) 4 6 AN960JD616L WASHER (REPLACES AN960JD616L) 4 6 NAS1149D0616J WASHER (REPLACES AN960JD616L) 4 6 NAS1149D0616J WASHER (REPLACES AN960JD616L) 4 7 AN6-7A BOLT (USBL ON 212-050-225-103) 4 7 AN6-10A BOLT (USBL ON 205-050-400-0071) 6 8 AN960PD616L WASHER (REPLACED BY AN960JD616L) 6 8 AN960PD616L WASHER (REPLACED BY AN960JD616L) 6 8 NAS1149D0616J WASHER (REPLACES AN960PD616L) 6 8 NAS1149D0616J WASHER (BEPLACES AN960JD616L) 6 9	14	N960JD616L	. WASHER (REPLACES AN960PD616L) (REPLACED BY	8	Р	
4 NAS1149D0616K WASHER (USBL ON 212-050-225-103) 8 5 AN6-10A BOLT (USBL ON 205-050-400-009 AND -027) 4 5 AN6-11A BOLT (USBL ON 205-050-400-0071) 4 5 NAS6206-12 BOLT (USBL ON 212-050-225-103) 4 6 AN960PD616L WASHER (REPLACED BY AN960JD616L) 4 6 AN960JD616L WASHER (REPLACES AN960JD616L) 4 6 NAS1149D0616J WASHER (REPLACES AN960JD616L) 4 6 NAS1149D0616J WASHER (USBL ON 212-050-225-103) 4 6 NAS1149D0616K WASHER (USBL ON 212-050-225-103) 4 7 AN6-7A BOLT (USBL ON 205-050-400-009 AND -027) 6 8 AN960PD616L WASHER (REPLACED BY AN960JD616L) 6 8 AN960JD616L WASHER (REPLACED BY AN960JD616L) 6 8 NAS1149D0616J WASHER (REPLACES AN960JD616L) 6 8 NAS1149D0616K WASHER (USBL ON 205-050-400-009) 2 9 AN6-7A BOLT (USBL ON 205-050-400-009) 2	٧	AS1149D0616J	. WASHER (REPLACES AN960JD616L)	8	SP	
5 AN6-10A BOLT (USBL ON 205-050-400-009 AND -027). 4 5 AN6-11A BOLT (USBL ON 205-050-400-071). 4 5 NAS6206-12 BOLT (USBL ON 212-050-225-103). 4 6 AN960PD616L WASHER (REPLACED BY AN960JD616L). 4 6 AN960JD616L WASHER (REPLACES AN960PD616L) (REPLACED BY NS1149D0616J). 4 6 NAS1149D0616J WASHER (REPLACES AN960JD616L). 4 6 NAS1149D0616K WASHER (USBL ON 212-050-225-103). 4 7 AN6-7A BOLT (USBL ON 205-050-400-009 AND -027). 6 7 AN6-10A BOLT (USBL ON 205-050-400-007). 6 8 AN960PD616L WASHER (REPLACED BY AN960JD616L). 6 8 AN960JD616L WASHER (REPLACES AN960JD616L). 6 8 NAS1149D0616J WASHER (REPLACES AN960JD616L). 6 8 NAS1149D0616J WASHER (USBL ON 205-050-400-009). 2 9 AN6-7A BOLT (USBL ON 205-050-400-007). 2 9 AN6-10A BOLT (USBL ON 205-050-400-007). 2				8	SP	
5 NAS6206-12 BOLT (USBL ON 212-050-225-103) 4 6 AN960PD616L WASHER (REPLACED BY AN960JD616L) 4 6 AN960JD616L WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J) 4 6 NAS1149D0616J WASHER (REPLACES AN960JD616L) 4 6 NAS1149D0616K WASHER (USBL ON 212-050-225-103) 4 7 AN6-7A BOLT (USBL ON 205-050-400-009 AND -027) 6 7 AN6-10A BOLT (USBL ON 212-050-225-103) 6 8 AN960PD616L WASHER (REPLACED BY AN960JD616L) 6 8 AN960JD616L WASHER (REPLACED BY AN960JD616L) 6 8 NAS1149D0616J WASHER (REPLACES AN960JD616L) 6 8 NAS1149D0616K WASHER (REPLACES AN960JD616L) 6 9 AN6-7A BOLT (USBL ON 205-050-400-009) 2 9 AN6-10A BOLT (USBL ON 205-050-400-009) 2 9 AN6-10A BOLT (USBL ON 205-050-400-009) 2 9 AN6-11A BOLT (USBL ON 205-050-400-009) 2 10 AN960JD616L WASHER (REPLACES AN960JD616L) (REPLACED BY NAS1149D0616J)<			. BOLT (USBL ON 205-050-400-009 AND -027)	-	SP	
6 AN960PD616L		=	. BOLT (USBL ON 205-050-400-071)		SP	
6 AN960JD616L .WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J). 4 6 NAS1149D0616J .WASHER (REPLACES AN960JD616L). 4 6 NAS1149D0616K .WASHER (USBL ON 212-050-225-103). 4 7 AN6-7A .BOLT (USBL ON 205-050-400-009 AND -027). 6 7 AN6-10A .BOLT (USBL ON 205-050-400-071). 6 8 AN960PD616L .WASHER (REPLACED BY AN960JD616L). 6 8 AN960JD616L .WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J). 6 8 NAS1149D0616J .WASHER (REPLACES AN960JD616L). 6 8 NAS1149D0616K .WASHER (REPLACES AN960JD616L). 6 9 AN6-7A .BOLT (USBL ON 205-050-400-009). 2 9 AN6-10A .BOLT (USBL ON 205-050-400-027). 2 9 AN6-11A .BOLT (USBL ON 205-050-400-0071). 2 10 AN960JD616L .WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J). 2 10 NAS1149D0616J .WASHER (REPLACES AN960JD616L). 2 10 NAS1149D0616J .WASHER (REPLACES AN960JD616L). 2			BOLT (USBL ON 212-050-225-103)		SP	
6 NAS1149D0616J WASHER (REPLACES AN960JD616L) 4 6 NAS1149D0616K WASHER (USBL ON 212-050-225-103) 4 7 AN6-7A BOLT (USBL ON 205-050-400-009 AND -027) 6 7 AN6-10A BOLT (USBL ON 205-050-400-071) 6 8 NAS6206-10 BOLT (USBL ON 212-050-225-103) 6 8 AN960PD616L WASHER (REPLACED BY AN960JD616L) 6 8 AN960JD616L WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J) 6 8 NAS1149D0616J WASHER (REPLACES AN960JD616L) 6 8 NAS1149D0616K WASHER (USBL ON 212-050-225-103) 6 9 AN6-7A BOLT (USBL ON 205-050-400-009) 2 9 AN6-10A BOLT (USBL ON 205-050-400-007) 2 9 AN6-11A BOLT (USBL ON 205-050-400-007) 2 10 AN960PD616L WASHER (REPLACES AN960PD616L) (REPLACED BY NA960JD616L) 2 10 NAS1149D0616J WASHER (REPLACES AN960JD616L) 2 10 NAS1149D0616J WASHER (REPLACES AN960JD616L) 2 10 NAS1149D0616J WASHER (REPLACES AN960J			. WASHER (REPLACES AN960PD616L) (REPLACED BY		SP P	
6 NAS1149D0616K . WASHER (USBL ON 212-050-225-103). 4 7 AN6-7A . BOLT (USBL ON 205-050-400-009 AND -027). 6 7 AN6-10A . BOLT (USBL ON 205-050-400-071). 6 8 AN960PD616L . BOLT (USBL ON 212-050-225-103). 6 8 AN960JD616L . WASHER (REPLACED BY AN960JD616L) 6 8 NAS1149D0616J . WASHER (REPLACES AN960JD616L) 6 8 NAS1149D0616K . WASHER (USBL ON 212-050-225-103). 6 9 AN6-7A . BOLT (USBL ON 205-050-400-009). 2 9 AN6-10A . BOLT (USBL ON 205-050-400-009). 2 9 AN6-11A . BOLT (USBL ON 205-050-400-007). 2 10 AN960PD616L . WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY NAS1149D0616L). 2 10 NAS1149D0616J . WASHER (REPLACES AN960JD616L) (REPLACED BY NAS1149D0616J). 2 10 NAS1149D0616J . WASHER (REPLACES AN960JD616L) 2 10 NAS1149D0616J . WASHER (REPLACES AN960JD616L) 2	NI A	ΔS1149D0616 I	NAS1149D0616J)	4	SP	
7 AN6-7A			WASHER (USBL ON 212-050-225-103)	-	SP	
7 AN6-10A .BOLT (USBL ON 205-050-400-071) 6 7 NAS6206-10 .BOLT (USBL ON 212-050-225-103) 6 8 AN960PD616L .WASHER (REPLACED BY AN960JD616L) 6 8 AN960JD616L .WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J) 6 8 NAS1149D0616J .WASHER (REPLACES AN960JD616L) 6 9 AN6-14A .WASHER (USBL ON 212-050-225-103) 6 9 AN6-10A .BOLT (USBL ON 205-050-400-009) 2 9 AN6-11A .BOLT (USBL ON 205-050-400-027) 2 10 AN960JD616L .WASHER (USBL ON 205-050-400-009), -027 AND -071) (REPLACED BY NA960JD616L) 2 10 AN960JD616L .WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J) 2 10 NAS1149D0616J .WASHER (REPLACES AN960JD616L) 2 10 NAS1149D0616K .WASHER (REPLACES AN960JD616L) 2			BOLT (USBL ON 205-050-400-009 AND -027)	-	SP	
7 NAS6206-10	1	N6-10A		6	SP	
8 AN960JD616L WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J)			. BOLT (USBL ON 212-050-225-103)		SP	
8 NAS1149D0616J . WASHER (REPLACES AN960JD616L) 6 8 NAS1149D0616K . WASHER (USBL ON 212-050-225-103) 6 9 AN6-7A . BOLT (USBL ON 205-050-400-009) 2 9 AN6-10A . BOLT (USBL ON 205-050-400-027) 2 9 AN6-11A . BOLT (USBL ON 205-050-400-071) 2 10 AN960PD616L . WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD616L) 2 10 AN960JD616L . WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J) 2 10 NAS1149D0616J . WASHER (REPLACES AN960JD616L) 2 10 NAS1149D0616K . WASHER (USBL ON 212-050-225-103) 2			. WASHER (REPLACES AN960PD616L) (REPLACED BY	-	SP P	
8 NAS1149D0616K . WASHER (USBL ON 212-050-225-103). 6 9 AN6-7A . BOLT (USBL ON 205-050-400-009). 2 9 AN6-10A . BOLT (USBL ON 205-050-400-027). 2 9 AN6-11A . BOLT (USBL ON 205-050-400-071). 2 10 AN960PD616L . WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD616L). 2 10 AN960JD616L . WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J). 2 10 NAS1149D0616J . WASHER (REPLACES AN960JD616L) 2 10 NAS1149D0616K . WASHER (USBL ON 212-050-225-103). 2	v	AS1149D0616.I	WASHER (REPLACES ANGENIDE 161)	6	SP	
9 AN6-7A				-	SP	
9 AN6-10A . BOLT (USBL ON 205-050-400-027) 2 9 AN6-11A . BOLT (USBL ON 205-050-400-071) 2 10 AN960PD616L . WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD616L) 2 10 AN960JD616L . WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J) 2 10 NAS1149D0616J . WASHER (REPLACES AN960JD616L) 2 10 NAS1149D0616K . WASHER (USBL ON 212-050-225-103) 2	1	N6-7A	. BOLT (USBL ON 205-050-400-009)	2	SP	
9 AN6-11A . BOLT (USBL ON 205-050-400-071) 2 10 AN960PD616L . WASHER (USBL ON 205-050-400-009, -027 AND -071) (REPLACED BY AN960JD616L) 2 10 AN960JD616L . WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J) 2 10 NAS1149D0616J NAS1149D0616K . WASHER (REPLACES AN960JD616L) 2 10 NAS1149D0616K . WASHER (USBL ON 212-050-225-103) 2			. BOLT (USBL ON 205-050-400-027)		SP	
10 AN960JD616L . WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J)			BOLT (USBL ON 205-050-400-071)		SP SP	
10 NAS1149D0616J . WASHER (REPLACÉS AN960JD616L) 2 10 NAS1149D0616K . WASHER (USBL ON 212-050-225-103) 2	12	N960JD616L	BY AN960JD616L)	2	Р	
10 NAS1149D0616K WASHER (USBL ON 212-050-225-103)		A C 4 4 4 0 D 0 C 4 C !	NAS1149D0616J)	_	0.0	
1. W. CHER (OODE ON E12 000 120 100)					SP SP	
		05-050-400-011	. WASHER (USBL ON 212-050-225-103)	1	NP	
ON 205-050-400-009 AND -027)			ON 205-050-400-009 AND -027)	-		
11 205-050-400-073 . TUBE ASSY, SKID, LH (SEE FIG. 32-4 FOR BREAKDOWN) (USBL 1 ON 205-050-400-071) (REPLACED BY 205-050-400-105)	∠(ub-ubu-4UU-U/3		1	NP	
11 205-050-400-105 . TUBE ASSY, SKID, LH (NOTE 1) (SEE FIG. 32-4 FOR BREAKDOWN) (USBL ON 205-050-400-071) (REPLACES	20	05-050-400-105	. TUBE ASSY, SKID, LH (NOTE 1) (SEE FIG. 32-4 FOR	1	NP	
205-050-400-073) (REPLACED BY 412-050-023-105)						



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	0 C
		Figure 32-1. Standard Landing Gear Assembly (Cont'd)			
11	412-050-023-105	. TUBE ASSY, SKID, LH (NOTE 1) (SEE FIG. 32-4 FOR BREAKDOWN) (USBL ON 212-050-225-103) (REPLACES	1	NP	
11	412-050-030-101	205-050-400-105) (REPLACED BY 412-320-119)	1	NP	
11	412-050-034-103	. TUBE ASSY, SKID, LH (SEE FIG. 32-4 FOR BREAKDOWN)	1	NP	
11	412-320-119	(REPLACES 412-050-030-101) (REPLACED BY 412-320-119). . TUBE ASSY, SKID, LH (SEE FIG. 32-5 FOR BREAKDOWN)	1	NP	
11	412-320-123	(REPLACES 412-050-023-105) (REPLACED BY 412-320-123). TUBE ASSY, SKID, LH (SEE FIG. 32-5 FOR BREAKDOWN)	1	SP	
12	205-050-400-012	(REPLACES 412-320-119)	1	NP	
12	205-050-400-074	ON 205-050-400-009 AND -027)	1	NP	
12	205-050-400-106	ON 205-050-400-071) (REPLACED BY 205-050-400-106)	1	NP	
12	412-050-023-106	205-050-400-074) (REPLACED BY 412-050-023-106) TUBE ASSY, SKID, RH (NOTE 1) (SEE FIG. 32-4 FOR	1	NP	
12	412-050-030-102	BREAKDOWN) (USBL ON 212-050-225-103) (REPLACES 205-050-400-106) (REPLACED BY 412-320-120)	1	NP	
12	412-050-034-104	(REPLACED BY 412-050-034-104)	1	NP	
12	412-320-120	(REPLACES 412-050-030-102) (REPLACED BY 412-320-120). TUBE ASSY, SKID, RH (SEE FIG. 32-5 FOR BREAKDOWN)	1	NP	
12	412-320-124	(REPLACES 412-050-023-106) (REPLACED BY 412-320-124). . TUBE ASSY, SKID, RH (SEE FIG. 32-5 FOR BREAKDOWN)	1	SP	
13	212-075-649-015	(REPLACES 412-320-120)	1	Р	l
14	MS3126E10-6P	CABLE ASSY		SP	ľ
	MS35489-93	CONNECTOR (REF. DES. P195)		SP	ĺ
15		. GROMMET	1	-	
16	205-050-400-013	. CROSSTUBE ASSY, FWD (SEE FIG. 32-6 FOR BREAKDOWN) (USBL ON 205-050-400-009 AND -027) (REPLACED BY 205-050-400-039 AND -055)	1	NP	
16	205-050-400-039	. CROSSTUBE ASSY, FWD (SEE FIG. 32-6 FOR BREAKDOWN) (USBL ON 205-050-400-009 AND -027) (REPLACES	1	NP	
		205-050-400-013) (REPLACED BY 205-050-400-055)			ľ
16	205-050-400-055	. CROSSTUBE ASSY, FWD (SEE FIG. 32-6 FOR BREAKDOWN) (USBL ON 205-050-400-009, -027 AND -071) (REPLACES	1	NP	
16	412-050-040-101	205-050-400-013 AND -039) (REPLACED BY 412-050-040-101) . CROSSTUBE ASSY, FWD (SEE FIG. 32-6 FOR BREAKDOWN) (USBL ON 212-050-225-103) (REPLACES 205-050-400-055)	1	NP	
16	212-320-103	(REPLACED BY 212-320-103)	1	SP	
17	205-050-400-007	(REPLACES 412-050-040-101)	1	NP	
		(USBL ON 205-050-400-009) (REPLACED BY 205-050-400-029, -035 AND -053)			
17	205-050-400-029	. CROSSTUBE ASSY, AFT (SEE FIG. 32-8 FOR BREAKDOWN) (USBL ON 205-050-400-009 AND -027) (REPLACES	1	NP	
17	205-050-400-035	205-050-400-007) (REPLACED BY 205-050-400-035 AND -053) . CROSSTUBE ASSY, AFT (SEE FIG. 32-8 FOR BREAKDOWN) (USBL ON 205-050-400-009 AND -027) (REPLACES 205-050-400-007 AND -029) (REPLACED BY 205-050-400-053)	1	NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 32-1. Standard Landing Gear Assembly (Cont'd)			
17	205-050-400-053	. CROSSTUBE ASSY, AFT (SEE FIG. 32-8 FOR BREAKDOWN) (USBL ON 205-050-400-009 AND -027) (REPLACES	1	NP	
17	205-050-400-063	205-050-400-007, -029 AND -035)	1	NP	
17	212-050-222-101	(USBL ON 205-050-400-071)	1	NP	
17	212-320-104	(USBL ON 212-050-225-103) (REPLACED BY 212-320-104)	1	SP	
18 19 20 20	140-009D7T24 140-009C7T40 NAS43DD3-16 NAS43DD3-16N	(REPLACES 212-050-222-101) . WASHER . WASHER . SPACER (REPLACED BY NAS43DD3-16N) . SPACER (REPLACES NAS43DD3-16) NOTE 1: SKID TUBE ASSEMBLIES 412-050-023-105 AND -106 MUST REPLACE SKID TUBE ASSEMBLIES 205-050-400-105 AND -106 AS A SET.	2 2 2 2	SP SP SP SP	
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable			
		SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 32-2. High Landing Gear Kit

32-99-00 Page 6

Rev. 8 30 APR 2010



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 32-2. High Landing Gear Kit			
	205-706-078-003	LANDING GEAR ASSY KIT, HIGH SKID (S/N 30680 THRU 31311, 32101 THRU 32124, 35001 THRU 35010)	1	NP	
	205-706-078-103	(REPLACED BY 205-706-078-103)	1	Р	
	205-706-078-105	205-706-078-003) (REPLACED BY 205-706-078-105) LANDING GEAR ASSY KIT, HIGH SKID (S/N 35011 THRU 35105) (REPLACES 205-706-078-103) (REPLACED BY 205-706-078-109)	1	NP	
	205-706-078-109	LANDING GEAR ASSY KIT, HIGH SKID (S/N 31312 THRU SUB,	1	Р	
	205-050-403-001	35106 THRU SUB) (REPLACES 205-706-078-105)	1	NP	
	205-050-403-101	(REPLACED BY 205-050-403-101)	1	NP	
	205-050-403-107	(REPLACED BY 205-050-403-107)	1	NP	
	205-050-403-109	205-050-403-109)	1	Р	
1	AN6-10A	BOLT	12	SP	
2 2	AN960PD616L AN960JD616L	WASHER (REPLACED BY NAS1149D0616J, AN960JD616L) WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J)	12 12	SP P	
2 3	NAS1149D0616J AN6-10A	WASHER (REPLACES AN960JD616L, AN960PD616L)	12 4	SP SP	
3	NAS6606-11	BOLT (USBL ON 205-050-403-001)	4	SP	
4	AN6-7A	BOLT (USBL ON 205-050-403-101, -107 AND -103)	8	SP	
4	NAS6606-9	BOLT (USBL ON 205-050-403-101, -107 AND -109)	8	SP	
5	AN960PD616L	WASHER (REPLACED BY AN960JD616L)	12	SP	
5	AN960JD616L	WASHER (REPLACES AN960PD616L) (REPLACED BY	12	Р	
5 6	NAS1149D0616J 205-050-400-003	NAS1149D0616J)	12 1	SP NP	
6	205-050-400-073	ON 205-050-403-001)	1	NP	
6	205-050-400-105	ON 205-050-403-101) (REPLACED BY 205-050-400-105) TUBE ASSY, SKID, LH (NOTE 1) (SEE FIG. 32-4 FOR BREAKDOWN) (REPLACES 205-050-400-073) (REPLACED BY	1	NP	
6	412-050-023-105	412-050-023-105)	1	NP	
6	412-050-030-101	412-320-119)	1	NP	
6	412-050-034-103	(REPLACED BY 412-050-034-103)	1	NP	
6	412-320-119	(REPLACES 412-050-030-101)	1	NP	
6	412-320-123	(REPLACES 412-050-023-105) (REPLACED BY 412-320-123) TUBE ASSY, SKID, LH (SEE FIG. 32-5 FOR BREAKDOWN)	1	SP	
7	205-050-400-004	(REPLACES 412-320-119)	1	NP	
]



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 32-2. High Landing Gear Kit (Cont'd)			
7	205-050-400-074	TUBE ASSY, SKID, RH (SEE FIG. 32-4 FOR BREAKDOWN) (USBL	1	NP	
7	205-050-400-106	ON 205-050-403-101) (REPLACED BY 412-050-030-102)TUBE ASSY, SKID, RH (SEE FIG. 32-4 FOR BREAKDOWN) (REPLACES 205-050-400-074)	1	NP	
7	412-050-023-106	(REPLACED BY 412-050-023-106)	1	NP	
7	412-050-030-102	ON 205-050-400-074)	1	NP	
7	412-050-034-104	(REPLACED BY 412-050-034-104)	1	NP	
7	412-320-120	(REPLACES 412-050-030-102) (REPLACED BY 412-320-120) TUBE ASSY, SKID, RH (SEE FIG. 32-5 FOR BREAKDOWN)	1	NP	
7	412-320-124	(REPLACES 412-050-034-104) (REPLACED BY 412-320-124) TUBE ASSY, SKID, RH (SEE FIG. 32-5 FOR BREAKDOWN)	1	SP	
8	205-050-403-003	(REPLACES 412-320-120)	1	NP	
8	205-050-403-007	205-050-403-007, -023 AND -031)	1	NP	
8	205-050-403-023	205-050-403-023 AND -031)	1	NP	
8	205-050-403-031	(REPLACED BY 205-050-403-031)	1	NP	
8	412-050-046-101	(REPLACED BY 412-050-046-101)	1	NP	
8	212-321-103	BREAKDOWN) (REPLACES 205-050-403-031)	1	SP	
9	205-050-403-005	BREAKDOWN)	1	NP	
9	205-050-403-009	205-050-403-009, -025 AND -033)	1	NP	
9	205-050-403-025	205-050-403-025 AND -033)	1	NP	
9	205-050-403-033	(REPLACED BY 205-050-403-033)	1	NP	
9	205-050-403-103	(REPLACED BY 205-050-403-103)	1	NP	
9	205-050-403-111	205-050-403-111)	1	NP	
9	212-050-224-101	(REPLACED BY 212-050-224-101)	1	NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A L	U O C
9	212-321-304	Figure 32-2. High Landing Gear Kit (Cont'd) CROSSTUBE ASSY, AFT HIGH SKID (SEE FIG. 32-13 FOR BREAKDOWN) NOTE 1: SKID TUBE ASSEMBLIES 412-050-023-105 AND -106 MUST REPLACE SKID TUBE ASSEMBLIES 205-050-400-105 AND -106 A SET.	1	SP	
		AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 32-3. High Crosstube Kit, BHT-212-SI-76

32-99-00 Page 10

Rev. 8 30 APR 2010




(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 32-3. High Crosstube Kit, BHT-212-SI-76			
	205-706-078-001	CROSSTUBE KIT, HIGH (S/N 30680 THRU 31311, 32101 THRU	1	Р	
	205-706-078-101	32124, 35001 THRU 35010) (REPLACED BY 205-706-078-101) . CROSSTUBE KIT, HIGH (S/N 30680 THRU 31311, 35001 THRU 35105) (REPLACES 205-706-078-001)	1	NP	
	205-706-078-107	(REPLACED BY 205-706-078-107)	1	NP	
	205-706-078-111	205-706-078-101) (REPLACED BY 205-706-078-111)	1	Р	
1	AN6-10A	BOLT	12	SP	
2	AN960PD616L	. WASHER (REPLACED BY AN960JD616L)	12	SP	
2	AN960JD616L	WASHER (REPLACES AN960PD616L) (REPLACED BY NAS1149D0616J)	12	Р	
2	NAS1149D0616J	. WASHER (REPLACÉS AN960JD616L)	12	SP	
3	AN6-10A	. BOLT (USBL ON 205-706-078-001)	4	SP	
3	NAS6606-11	BOLT (USBL ON 205-706-078-101, -107 AND -109)	4	SP	
4 4	AN6-7A NAS6606-9	BOLT (USBL ON 205-706-078-001)	8 8	SP SP	
5	AN960PD616L	BOLT (USBL ON 205-706-078-101, -107 AND -109)	12	SP	
5 5	AN9607D616L	. WASHER (REPLACED BY AN960JD616L)	12	P	
3	ANGOODDOTOL		12	'	
5	NAS1149D0616J	NAS1149D0616J)	12	SP	
6	205-050-403-003	. CROSSTUBE ASSY, FWD HIGH SKID (SEE FIG. 32-10 FOR BREAKDOWN) (USBL ON 205-706-078-001) (REPLACED BY	1	NP	
6	205-050-403-007	205-050-403-007)	1	NP	
6	205-050-403-023	205-050-403-023)	1	NP	
6	205-050-403-031	205-050-403-031)	1	NP	
6	412-050-046-101	205-050-403-023) (REPLACED BY 412-050-046-101)	1	NP	
6	212-321-103	BREAKDOWN) (REPLACES 205-050-403-031)	1	SP	
7	205-050-403-005	BREAKDOWN)	1	NP	
7	205-050-403-009	. CROSSTUBE ASSY, AFT HIGH SKID (SEE FIG. 32-12 FOR BREAKDOWN) (REPLACES 205-050-403-005) (REPLACED BY	1	NP	
7	205-050-403-025	205-050-403-025)	1	NP	
7	205-050-403-033	205-050-403-033)	1	NP	
7	205-050-403-103	205-050-403-103)	1	NP	
7	205-050-403-111	205-050-403-111)	1	NP	



INDEX NUMBER PART NUMBER ITEM NAME UNIT PER ASSY	A V A I L	0 C
NUMBER ITEM NAME PER	A I	0





SKID TUBES 205-050-400-003, -004, -011, -012, -073, -074, -105, -106, 412-050-023-105, -106

212_IPB_32_0004a+

Figure 32-4. Skid Tube Assembly (Sheet 1 of 2)




Figure 32-4. Skid Tube Assembly (Sheet 2 of 2)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 32-4. Skid Tube Assembly			
1 1	205-050-400-003 205-050-400-011	TUBE ASSY, SKID, LH (SEE FIG. 32-2 FOR NHA) TUBE ASSY, SKID, LH (SEE FIG. 32-1, 32-2 FOR NHA) (USBL ON	REF REF	NP NP	
1	205-050-400-073	205-050-400-009 AND -027)	REF	NP	
1	205-050-400-105	205-050-400-071) (REPLACED BY 205-050-400-105) TUBE ASSY, SKID, LH (NOTE 1) (SEE FIG. 32-1, 32-2 FOR NHA) (USBL ON 205-050-400-071) (REPLACES 205-050-400-073)	REF	NP	
1	412-050-023-105	(REPLACED BY 412-050-023-105)	REF	NP	
1	412-050-030-101	(REPLACED BY 412-320-119)	REF	NP	
1	412-050-034-103	TUBE ASSY, SKID, LH (SEE FIG. 32-1, 32-2 FOR NHA) (REPLACES 412-050-030-101) (REPLACED BY 412-320-119)	REF	NP	
1	412-320-119	TUBE ASSY, SKID, LH (SEE FIG. 32-1, 32-2 FOR NHA) (SEE FIG. 32-5 FOR BREAKDOWN) (REPLACES 412-050-023-105,	REF	NP	
1	412-320-123	412-050-034-103) (REPLACED BY 412-320-123) TUBE ASSY, SKID, LH (SEE FIG. 32-1, 32-2 FOR NHA) (SEE FIG. 32-5 FOR BREAKDOWN) (REPLACES 412-320-119)	REF	SP	
2 2	205-050-400-004 205-050-400-012	TUBE ASSY, SKID, RH (SEE FIG. 32-2 FOR NHA)	REF REF		
2	205-050-400-074	205-050-400-009 AND -027)	REF	NP	
2	205-050-400-106	205-050-400-071) (REPLACED BY 205-050-400-106) TUBE ASSY, SKID, RH (NOTE 1) (SEE FIG. 32-1, 32-2 FOR NHA) (USBL ON 205-050-400-071) (REPLACES 205-050-400-074)	REF	NP	
2	412-050-023-106	(REPLACED BY 412-050-023-106)	REF	NP	
2	412-050-030-102	TUBE ASSY, SKID, RH (SEE FIG. 32-1, 32-2 FOR NHA) (REPLACED BY 412-050-034-104)	REF	NP	
2	412-050-034-104	TUBE ASSY, SKID, RH (SEE FIG. 32-1, 32-2 FOR NHA) (REPLACES 412-050-030-102) (REPLACED BY 412-320-120)	REF	NP	
2	412-320-120	TUBE ASSY, SKID, RH (SEE FIG. 32-1, 32-2 FOR NHA) (SEE FIG. 32-5 FOR BREAKDOWN) (REPLACES 412-050-023-106)	REF	NP	
2	412-320-124	(REPLACED BY 412-320-124)	REF	SP	
3	OSR-10C	RIVET (USBL ON 205-050-400-011, -012, -073, -074, -105 AND -106)	2	SP	
4	OSR-10A	. RIVET (USBL ON 205-050-400-011, -012, -073, -074, -105 AND	12	SP	
5 6 7 8 9	OSR-10D OSR-10C MS27039-5-16 MS27039-5-14 AN960JD516L	-106)	2 12 2 12 14	SP SP SP SP P	
9 10 11 12 13	NAS1149D0516J NAS1330H5K256L MS27039-5-17 MS27039-5-15 AN960JD516L	NAS1149D0516J)	14 14 2 14 14	SP SP SP SP P	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	J 0 U
		Figure 32-4. Skid Tube Assembly (Cont'd)			
13	NAS1149D0516J	. WASHER (USBL ON 412-050-034-103 AND -104) (REPLACES AN960JD516L)	14	SP	
14	NAS1330H5K256L	NUT (USBL ON 412-050-034-103 AND -104)	14	SP	
15	204-050-107-011	. SADDLE, OUTBD (NOTE 2) (REPLACED BY 205-050-400-101)	1	NP	
15A	204-050-107-013	. SADDLE, INBD (NOTE 2) (REPLACED BY 205-050-400-101)	1	NP	
16	205-050-400-101	. SADDLE ASSY, FWD (NOTE 2) (USBL ON 205-050-400-073, -074, -105 AND -106) (REPLACES 204-050-107-011 AND -013) (REPLACED BY 412-050-101-101)	1	NP	
17	412-050-101-101	. SADDLE, FWD (USBL ON 412-050-023-105, -106, 412-050-030-101, -102, 412-050-034-103 AND -104) (REPLACES	1	NP	
17A	604-007-111	205-050-400-101) (REPLACED BY 412-728-121)	1	Р	
17	412-728-121	. SADDLE, FWD (USBL ON 412-050-023-105, -106, 412-050-030-101, -102, 412-050-034-103 AND -104, 412-320-123, 412-320-124)	1	Р	
		(REPLACES 412-050-101-101) (REPLACED BY 412-728-221).			
17 18	412-728-221 OSR-10D	SADDLE, FWD (NOTE 4) (REPLACES 412-728-121)	1 2	SP SP	
19	OSR-10B	. RIVET (USBL ON 205-050-400-011, -012, -073, -074, -105 AND -106)	11	SP	
20	OSR-10F	. RIVET (USBL ON 205-050-400-011, -012, -073, -074, -105 AND -106)	1	SP	
21	OSR-10B	. RIVET (USBL ON 205-050-400-073, -074, -105 AND -106)	3	SP	
22	OSR-10F	. RIVET (USBL ON 205-050-400-073, -074, -105 AND -106)	1	SP	
23	OSR-10D	. RIVET (USBL ON 412-050-023-105 AND -106)	3	SP	
24	OSR-10C	. RIVET (USBL ON 412-050-023-105 AND -106)	10	SP	
25 26	OSR-10G MS27039-5-16	RIVET (USBL ON 412-050-023-105 AND -106)	1 2	SP SP	
26 27	MS27039-5-16 MS27039-5-14	SCREW (USBL ON 412-050-030-101 AND -102)	16	SP	
28	AN960JD516L	. WASHER (USBL ON 412-050-030-101 AND -102) (REPLACED BY NAS1149D0516J)	14	P	
28	NAS1149D0516J	. WASHER (REPLACES AN960JD516L)	14	SP	
29	NAS1330H5K256L	. NUT (USBL ON 412-050-030-101 AND -102)	18	SP	
30	MS27039-5-17	. SCREW (USBL ON 412-050-034-103 AND -104)	2	SP	
31 32	MS27039-5-15 AN960JD516L	SCREW (USBL ON 412-050-034-103 AND -104)	16 32	SP P	
32	NAS1149D0516J	. WASHER (REPLACES AN960JD516L)	32	SP	
33	NAS1330H5K256L	NUT (USBL ON 412-050-034-103 AND -104)	32	SP	
34	205-050-107-003	. SADDLE, OUTBD (USBL ON 205-050-400-011 AND -012)	1	NP	
34	205-050-107-101	. SADDLE, OUTBD (NOTE 3) (USBL ON 205-050-400-073, -074, -105 AND -106) (REPLACED BY 205-050-400-103)	1	NP	
34A 34A	205-050-107-001 205-050-107-103	. SADDLE, INBD (USBL ON 205-050-400-011 AND -012)	1	P P	
35	205-050-400-103	AND -106) (REPLACED BY 205-050-400-103)	1	NP	
36	412-050-100-101	(REPLACED BY 412-050-100-101)	1	NP	
36A	604-007-113	205-050-400-103) (REPLACED BY 412-728-122)	1	Р	
36	412-728-122	. SADDLE, AFT (USBL ON 412-050-023-105, -106, 412-050-030-101, -102, 412-050-034-103 AND -104, 412-320-123, 412-320-124)	1	NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	0 C
		Figure 32-4. Skid Tube Assembly (Cont'd)			
36 37	412-728-222 AN3-5A	. SADDLE, AFT (NOTE 4) (REPLACES 412-728-122)	1 3	SP SP	
38 39 39	MS27039C1-10 AN960PD10L AN960JD10LL	SCREW (USBL ON 412-050-034-103 AND -104)	3 3 3	SP P P	
39 40 41 41 42 42 43 43	NAS1149D0316J 204-050-149-001 NAS697A3 MS21069L3 NAS679A6 MS21042L6 AN960PD616L AN960JD616L	NAS1149D0316J) WASHER (REPLACES AN960JD10LL) . STEP NUTPLATE (REPLACED BY MS21069L3) NUTPLATE (REPLACES NAS697A3) . NUT (REPLACED BY MS21042L6) . NUT (REPLACES NAS679A6) WASHER (REPLACED BY AN960JD616L) . WASHER (REPLACES AN960PD616L) (REPLACED BY	3 1 3 3 1 1 1	SP SP NP SP NP SP SP P	
43 44	NAS1149D0616J 204-050-104-001	NAS1149D0616J)	1 1	SP SP	
44 44A	604-013-103 204-050-104-101	(ALTERNATE PART) . FITTING, WELDED	1	SP SP	
44A 45 45	604-013-007 AN960PD1016L AN960JD1016L	(ALTERNATE PART) . FITTING, FORGED	1 1 1	SP P SP	
45 46 47	NAS1149D1016J 204-050-143-003 AN960PD1016L	NAS1149D1016J)	1 1 1	SP SP P	
47	AN960JD1016L	(REPLACED BY AN960JD1016L)	1	SP	
47 47A 48 49 50	NAS1149D1016J 140-009A33T102 204-050-205-005 214-050-010-001 AN960PD1016L AN960JD1016L	NAS1149D1016J)	1 1 1 1 1	SP P SP SP P SP	
50 51 52 53	NAS1149D1016J 212-050-225-117 204-050-227-001 MS35207-279	. WASHER (REPLACES AN960JD1016L)	1 1 1 4	SP SP SP SP	
53 53 53 54	MS35207-280 MS35207-281 NAS1134-6 NAS1329C4K140	-106)	4 2 4 4	SP SP P	
54 54 55 56	NAS1329H4K140L NAS1329H4K200L NAS1149D0432H MS35207-262	(REPLACED BY NAS1329H4K140L)	4 2 4 4	SP SP SP SP	
56	MS35207-264	-105, -106, 412-050-023-105 AND -106)	4	SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 32-4. Skid Tube Assembly (Cont'd)			
56 57	NAS1133E5 NAS1330C3K266	. SCREW (USBL ON 412-050-034-103 AND -104)	4 4	SP P	
57 57	NAS1330H3K266L NAS1330C3K316L	(REPLACED BY NAS1330H3K266L) . NUT (REPLACES NAS1330C3K266)	4 4	SP NP	
57 58	NAS1330C3K316L NAS1330H3K216L NAS1149C0332R	NUT (USBL ON 412-050-023-105 AND -106)	4 4 4	SP SP	
59	MS27039-1-09	-104)	34	SP	
60	AN960-10L	-105 AND -106)	40	Р	
60	NAS1149F0332P	. WASHER (REPLACES AN960-10L)	40	SP	
61	2R1350	NUT (REPLACED BY NAS1330H3K116L)	34	NP	
61	NAS1330H3K116L	. RIVNÙT (REPLACES 2R1350)	34	SP	
62	MS27039-1-11	. SCREW (USBL ON 205-050-400-003, -004, -011, -012, -073, -074, -105 AND -106)	6	SP	
63	2R1350-3	. NUT (USBL ON 205-050-400-003, -004, -011, -012, -073, -074, -105 AND -106) (REPLACED BY NAS1330H3K266L)	3	NP	
63	NAS1330H3K266L	. NUT (REPLACES 2R1350-3)	3	SP	
64	2R1350-2	NUT (USBL ON 205-050-400-003, -004, -011, -012, -073, -074, -105 AND -106) (REPLACED BY NAS1330H3K216L)	3	NP	
64	NAS1330H3K216L	. NUT (REPLACES 2R1350-2)	3	SP	
65	NAS1801-3-10	. SCREW (USBL ON 412-050-023-105 AND -106)	34	SP	
66	NAS1801-3-11	. SCREW (USBL ON 412-050-023-105 AND -106)	2	SP	
67	NAS1330H3K216L		1	SP	
68		NUT (USBL ON 412-050-023-105 AND -106)	1	SP	
	NAS1330H3K166L	. RIVNUT (USBL ON 412-050-023-105 AND -106)			
69	NAS1801-3-12	. SCREW (USBL ON 412-050-023-105 AND -106)	2	SP	
70	NAS1330H3K266L	. NUT (USBL ON 412-050-023-105 AND -106)	2	SP	
71	NAS1801-3-13	. SCREW (USBL ON 412-050-023-105 AND -106)	2	SP	
72	NAS1330H3K316L	. NUT (USBL ON 412-050-023-105 AND -106)	2	SP	
73	NAS1801-3-11	. SCRÈW (USBL ON 412-050-030-101 AND -102)	34	SP	
74	AN960-10L	. WASHER (USBL ON 412-050-030-101 AND -102) (REPLACED BY NAS1149F0332P)	40	Р	
74	NAS1149F0332P	. WASHER (REPLACÉS AN960-10L)	40	SP	
75	NAS1330H3K166L	. RIVNUT (USBL ON 412-050-030-101 AND -102)	18	SP	
76	NAS1330H3K216L	. NUT (USBL ON 412-050-030-101 AND -102)	16	SP	
77	NAS1801-3-10	. SCREW (USBL ON 412-050-030-101 AND -102)	6	SP	
78	NAS1330H3K116L	RIVNUT (USBL ON 412-050-030-101 AND -102)	6	SP	
79	MS27039C1-10	. SCREW (USBL ON 412-050-034-103 AND -104)	12	SP	
80	AN960C10L	. WASHER (USBL ON 412-050-034-103 AND -104) (REPLACED BY NAS1149C0332R)	40	P	
80	NAS1149C0332R	. WASHER (REPLACES AN960C10L)	40	SP	
81	NAS1330H3K116L	RIVNUT (USBL ON 412-050-034-103 AND -104)	6	SP	
82	NAS1330H3K166L		10	SP	
		RIVNUT (USBL ON 412-050-034-103 AND -104)	-	_	
83	MS27039C1-11	. SCREW (USBL ON 412-050-034-103 AND -104)	24	SP	
84	NAS1330H3K216L	. NUT (USBL ON 412-050-034-103 AND -104)	24	SP	
85	MS27039C1-09	. SCREW (USBL ON 412-050-034-103 AND -104)	4	SP	
86	205-050-174-003	SHOE ASSY, FWD, LH (USBL ON 205-050-400-011 AND -073) (REPLACED BY 205-050-174-035)	1	NP	
86 86	205-050-174-035 205-050-174-004	SHOE ASSY, FWD, LH (REPLACES 205-050-174-003)	1 1	NP NP	
		(REPLACED BY 205-050-174-036)	,	_	
86 87	205-050-174-036 205-050-174-001	. SHOE ASSY, FWD, RH (REPLACES 205-050-174-004)	1	P NP	
0.7	205 050 171 000	(REPLACED BY 205-050-174-033)	,	C.D.	
	205-050-174-033	. SHOE ASSY, AFT, LH (REPLACES 205-050-174-001)	1	SP	
87	005 050 174 000	OLIGE AGOV AFT BUILDED GOVERN GOOD GOOD GOOD GOOD GOOD GOOD GOOD GOO			
87	205-050-174-002	SHOE ASSY, AFT, RH (USBL ON 205-050-400-012 AND -074) (REPLACED BY 205-050-174-034)	1	NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A L	0 C
		Figure 32-4. Skid Tube Assembly (Cont'd)			
87 88	205-050-174-034 205-050-401-001	. SHOE ASSY, AFT, RH (REPLACES 205-050-174-002)	1 2	NP P	
88 89 90	205-050-401-101 205-050-400-017 20-041-2	-105 AND -106)	2 1 2	P P SP	
91 92	205-050-402-001 NAS1031A8	. DOUBLER ASSY (USBL ON 205-050-400-003 AND -004)	2 1	SP SP	
93 94 95 96 97 98 99 100 101 102	412-050-054-101 NAS1031A8 205-050-402-001 NAS1031A8 214-050-004-105 NAS1031A8 MS27039-8-11 NAS1149D0816K MS35489-42 MS35489-71	AND -106). . DOUBLER ASSY (USBL ON 412-050-023-105 AND -106). . NUTPLATE (USBL ON 412-050-023-105 AND -106). . DOUBLER ASSY (USBL ON 412-050-023-105 AND -106). . NUTPLATE (USBL ON 412-050-023-105 AND -106). . NUTPLATE (USBL ON 412-050-023-105 AND -106). . DOUBLER ASSY (USBL ON 412-050-030-101, -102, 412-050-034-103 AND -104). . NUTPLATE . SCREW (USBL ON 412-050-023-105 AND -106) (REPLACES AN565B820H12). . WASHER (USBL ON 412-050-023-105 AND -106). . GROMMET (USBL ON 412-050-023-105 AND -106). . GROMMET (USBL ON 412-050-030-101, -102, 412-050-034-103 AND -104). NOTE 1: SKID TUBE ASSEMBLIES 412-050-023-105 AND -106 MUST REPLACE SKID TUBE ASSEMBLIES 205-050-400-105 AND -106 AS A SET. NOTE 2: FOR SPARE PART REPLACEMENT, USE SADDLE ASSEMBLY 205-050-400-101 TO REPLACE SADDLES 204-050-107-011 AND -013 AS A UNIT. NOTE 3: FOR SPARE PART REPLACEMENT, USE SADDLE ASSEMBLY 205-050-400-103 TO REPLACE SADDLES 204-050-107-011 AND -103 AS A UNIT.	1 2 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			




Figure 32-5. Skid Tube Assembly (AAI)

32-99-00 Page 22

Rev. 8 30 APR 2010



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 32-5. Skid Tube Assembly (AAI)			
1	412-320-119	TUBE ASSY, SKID, LH (SEE FIG. 32-1, 32-3 FOR NHA) (REPLACED	REF	NP	
1	412-320-123	BY 412-320-123)	REF	SP	
2	412-320-120	412-320-119)	REF	NP	
2	412-320-124	BY 412-320-124)	REF	SP	
3	OSR-10C	412-320-120)	14	SP	
4	OSR-10B	. RIVET (USBL ON 412-320-123, 412-320-124)	12	SP	
5	OSR-10D	. RIVET (USBL ON 412-320-123, 412-320-124)	2	SP	
6	604-007-111	SADDLE, FWD (USBL ON 412-320-119, 412-320-120) (REPLACED BY 412-728-121)	1	Р	
6A	412-728-121	SADDLE, FWD (USBL ON 412-320-123, 412-320-124) (REPLACED BY 412-728-221)	1	Р	
6A	412-728-221	. SADDLE, FWD (NOTE 1) (REPLACES 412-728-121)	1	SP	
7	OSR-10C	RIVET (USBL ON 412-320-119, 412-320-120)	18	SP	
8	OSR-10C	RIVET (USBL ON 412-320-119, 412-320-120)	16	SP	
9	OSR-10E	RIVET (USBL ON 412-320-123, 412-320-124)	2	SP	
10	604-007-113	. SADDLE, AFT (USBL ON 412-320-119, 412-320-120) (REPLACED	1	P	
10A	412-728-122	BY 412-728-122)	1	NP	
10A	412-728-222	. SADDLE, AFT (NOTE 1) (REPLACES 412-728-122)	1	SP	
11	AN3-5A	BOLT	3	SP	
12	NAS1149D0332J	. WASHER, FLAT (REPLACED BY AN960JD10LL, AN960JD10L)	3	SP	
13	604-033-001	STEP	1	P	
14	NAS1330H3K166L	RIVNUT	3	SP	
15	MS21042L6	. NUT (REPLACES NAS679A6)	1	SP	
16	NAS1149D0663J	. WASHER (REPLACED BY AN960JD616L)	l i	SP	
17	604-013-103	FITTING, WELDED	1	SP	
17A	604-013-007	FITTING, FORGED	1	SP	
18	NAS1149D1063J	. WASHER (REPLACES AN960JD1016L)	Ιί	SP	
19	604-011-001	EYEBOLT	1	SP	
20	604-011-005	. WASHER, CONCAVE		SP	
21	604-011-003		1	SP	
22	604-011-007	EYEBOLT	1	SP	
23	604-019-001	. WASHER	1	SP	
24	MS27039-4-10		4	SP	
25	NAS1329H4K140L	SCREW	4	SP	
26	NAS1149D0416J		4	SP	
27	AN3-5A	WASHER	4	SP	
28	NAS1330C3K316L	BOLT NUT NUT	4	NP	
29	NAS1149C0332J	. WASHER	4	SP	
30	AN3-4A		34	SP	
31	NAS1149F0332P	BOLT	40	SP	
32	NAS1330H3K116L	RIVNUT	34	SP	
33	AN3-6A	BOLT	6	SP	
34	NAS1330H3K116L	RIVNUT.	6	SP	
35	604-015-101	SHOE ASSY, FWD, LH	1	SP	
35 35	604-015-102	SHOE ASSY, FWD, RH		SP	
36	604-015-103	SHOE ASSY, FWD, RH	1	SP	
36	604-015-104	QUOE ASST, AFT, LET	1	SP	
36 37	604-017-003	SHOE ASSY, AFT, RH		P	
38	604-017-003	DOUBLER		P	
39	604-011-111	DOUBLER ASSY		P	
	MS21059L8	NUTPLATE	2	P	
	IVIO2 UUJEU	I NO I FLATE	ı -	' '	i
40 41	604-011-109	DOUBLER ASSY	1	Р	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A L	U O C
42 43 44	MS21059L8 NAS1081C8D16 MS35489-42	Figure 32-5. Skid Tube Assembly (AAI) (Cont'd) . NUTPLATE . SETSCREW . GROMMET . NOTE 1: SADDLE IS UNDRILLED.	1 1 1	P P SP	
		AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 32-6. Forward Crosstube Assembly

32-99-00 Page 26

Rev. 8 30 APR 2010



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 32-6. Forward Crosstube Assembly			
1A	205-050-400-013	CROSSTUBE ASSY, FWD (SEE FIG. 32-1 FOR NHA) (USBL ON 205-050-400-009 AND -027) (REPLACED BY 205-050-400-039	REF	NP	
1B	205-050-400-039	AND -055)	REF	NP	
1C	205-050-400-055	(REPLACED BY 205-050-400-055)	REF	NP	
1D	412-050-040-101	AND -039) (REPLACED BY 412-050-040-101)	REF	NP	
1	212-320-103	212-320-103)	REF	SP	
2	204-050-011-009	FOR BREAKDOWN) (REPLACES 412-050-040-101)	2	NP	
3	204-050-011-021	. SUPPORT (USBL ON 205-050-400-039) (REPLACES	2	SP	
4 5 6 7	MS20601M6W8 MS20601MP6W8 MS21042L4 AN960-416	204-050-011-009)	16 12 8 8	NP NP SP NP	
7 8 9 10 11 12 13 14 14 15 15 16	NAS1149F0463P 205-050-134-001 205-050-133-001 205-050-132-001 412-050-038-101 CR4622CW-6 206-050-301-109 204-050-151-005 90-018-1 MS21051L6 MS21051-L6 90-019-2 MS21069L6	NAS1149F0463P)	8 4 2 2 2 8 2 4 4 2 2 4 1	SP SP SP SP SP SP SP SP SP SP SP SP SP S	
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 32-7. Forward Crosstube Assembly (AAI)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
1 2 3 4 5 6 7 8 9 10	212-320-103 604-025-001 MS21043-4 NAS1149C0463R 604-025-003 604-023-103 MS21051-L6 604-023-101 MS21069L6	Figure 32-7. Forward Crosstube Assembly (AAI) CROSSTUBE ASSY, FWD (SEE FIG. 32-1 FOR NHA) (REPLACES 412-050-040-101) SUPPORT ASSY, UPPER, FWD (NOTE 1) NUT WASHER U-BOLT SUPPORT ASSY, LOWER, FWD (NOTE 1) RADIUS BLOCK NUTPLATE RADIUS BLOCK NUTPLATE NOTE 1: SUPPORT ASSEMBLY IS SUPPLIED WITH A BLACK NYLON COATING ON INNER SURFACE. AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.	REF 2 8 8 4 2 4 2 4 1		






Figure 32-8. Aft Crosstube Assembly

212_IPB_32_0008+

32-99-00 Page 30

Rev. 8 30 APR 2010



	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 32-8. Aft Crosstube Assembly			
1A	205-050-400-007	CROSSTUBE ASSY, AFT (SEE FIG. 32-1 FOR NHA) (USBL ON	REF	NP	
1A	205-050-400-029	205-050-400-009) (REPLACED BY 205-050-400-029)	REF	NP	
1B	205-050-400-035	(REPLACED BY 205-050-400-035)	REF	NP	
1C	205-050-400-053	(REPLACED BY 205-050-400-053)	REF	NP	
1C	205-050-400-063	205-050-400-009 AND -027) (REPLACES 205-050-400-035) CROSSTUBE ASSY, AFT (SEE FIG. 32-1 FOR NHA) (USBL ON	REF	NP	
1D	212-050-222-101	205-050-400-071)	REF	NP	
1	212-320-104	212-050-225-103) (REPLACED BY 212-320-104)	REF	SP	
2	204-050-011-017	FOR BREAKDOWN) (REPLACES 212-050-222-101)	1	NP	
3	204-050-011-023	204-050-011-023)	2	SP	
4 5 6 7 8 8 9 10 11 12 13 14 15	MS20601M6W7 MS20601MP6W8 MS20601MP6W8 MS21042L4 AN960-416 NAS1149F0463P 205-050-134-003 205-050-132-003 205-050-132-003 204-050-011-115 CR4622CW-6 206-050-301-109 204-050-151-005	RIVET (USBL ON 205-050-400-007) RIVET BLIND (USBL ON 205-050-400-029) RIVET BLIND (USBL ON 205-050-400-035) NUT (USBL ON 205-050-400-053 AND -063) WASHER (USBL ON 205-050-400-053 AND -063) (REPLACED BY NAS1149F0463P) WASHER (REPLACES AN960-416) U-BOLT (USBL ON 205-050-400-053 AND -063) (REPLACED BY 604-025-015) SUPPORT ASSY, LOWER, AFT (USBL ON 205-050-400-053 AND -063) SUPPORT ASSY, UPPER, AFT (USBL ON 205-050-400-053 AND -063) SUPPORT (USBL ON 212-050-222-101) RIVET (USBL ON 212-050-222-101) STRIP, ABRASION PLATENUT ASSY (S/N 30504 THRU 30614) (REPLACED BY 90-018-1)	16 16 12 8 8 8 4 2 2 6 2 4	NPPPPP SP S	
15 16 16 17	90-018-1 MS21051L6 MS21051-L6 204-050-223-001	RADIUS BLOCK ASSY (REPLACES 204-050-151-005)	4 2 2 4	SP NP SP NP	
17 18	90-019-1 MS21069L6	RADIUS BLOCK ASSY (REPLÁČES 204-050-223-001)	4 1	SP SP	
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 32-9. Aft Crosstube Assembly (AAI)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
INDEX			UNIT PER	A V A I L	U






Figure 32-10. Forward High Crosstube Assembly

212_IPB_32_0010+

32-99-00 Page 34

Rev. 8 30 APR 2010



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	0 C
		Figure 32-10. Forward High Crosstube Assembly			
1A	205-050-403-003	CROSSTUBE ASSY, FWD (SEE FIG. 32-2, 32-3 FOR NHA)	REF	NP	
1B	205-050-403-007	(REPLACED BY 205-050-403-007)	REF	NP	
1C	205-050-403-023	(REPLACES 205-050-403-003) (REPLACED BY 205-050-403-023) CROSSTUBE ASSY, FWD (SEE FIG. 32-2, 32-3 FOR NHA)	REF	NP	
1D	205-050-403-031	(REPLACES 205-050-403-007) (REPLACED BY 205-050-403-031) CROSSTUBE ASSY, FWD (SEE FIG. 32-2, 32-3 FOR NHA)	REF	NP	
1E	412-050-046-101	(REPLACES 205-050-403-023) (REPLACED BY 412-050-046-101) CROSSTUBE ASSY, FWD (SEE FIG. 32-2, 32-3 FOR NHA)	REF	NP	
1	212-321-103	(REPLACES 205-050-403-031) (REPLACED BY 212-321-103) CROSSTUBE ASSY, FWD (SEE FIG. 32-2, 32-3 FOR NHA) (SEE FIG.	REF	SP	
2 3 4 5 6 7 8 9 10 11 12 12 13 14 15 16 16 17 18	204-050-011-009 204-050-011-013 204-050-011-025 NAS1739MW6 NAS1739MW6 MS21042L4 AN960-416 NAS1149F0463P 205-050-134-001 205-050-132-001 412-050-038-101 412-050-038-103 CR4622CW-6 206-050-301-109 204-050-151-005 90-018-1 MS21051-L6 90-019-2 MS21069L6	32-11 FOR BREAKDOWN) (REPLACES 412-050-046-101) . SUPPORT (USBL ON 205-050-403-003) . SUPPORT (USBL ON 205-050-403-007) . SUPPORT (USBL ON 205-050-403-023) . RIVET (USBL ON 205-050-403-023) . RIVET (USBL ON 205-050-403-023) . NUT (USBL ON 205-050-403-023) . NUT (USBL ON 205-050-403-031) . WASHER (USBL ON 205-050-403-031) (REPLACED BY NAS1149F0463P) . WASHER (USBL ON 205-050-403-031) (REPLACES AN960-416) . U-BOLT (USBL ON 205-050-403-031) (REPLACED BY 604-025-005) . SUPPORT, LOWER, FWD (USBL ON 205-050-403-031) . SUPPORT, UPPER, FWD (USBL ON 205-050-403-031) . SUPPORT (REPLACED BY 412-050-038-103) . SUPPORT (NOTE 1) (USBL ON 412-050-046-101) (REPLACES 412-050-038-101) . RIVET (USBL ON 412-050-046-101) . STRIP, ABRASION (USBL ON 412-050-046-101) . STRIP, ABRASION (USBL ON 412-050-046-101) . RADIUS BLOCK ASSY (REPLACES 204-050-151-005) . NUTPLATE (REPLACED BY MS21051-L6) . NUTPLATE (REPLACES MS21051-L6) . RADIUS BLOCK ASSY . NUTPLATE NOTE 1: SUPPORT IS SUPPLIED WITH ADHESIVE FILM BONDED TO INNER SURFACE.	2 2 2 16 12 8 8 4 2 2 2 2 4 4 2 2 4 1	NP P P P P P P P P P P P P P P P P P P	
		AVAIL CODE DEFINITION			
		P Procurable			
		NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 32-11. Forward High Crosstube Assembly (AAI)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
1 2 3 4 5 6 7 8 9	212-321-103 MS21042L4 NAS1149F0463P 604-025-005 604-025-003 604-025-001 90-018-1 MS21051-L6 90-019-2 MS21069L6	Figure 32-11. Forward High Crosstube Assembly (AAI) CROSSTUBE ASSY, FWD (SEE FIG. 32-2, 32-3 FOR NHA) . NUT . WASHER (REPLACES AN960-416). . U-BOLT . SUPPORT ASSY, LOWER, FWD (NOTE 1) . SUPPORT ASSY, UPPER, FWD (NOTE 1) . RADIUS BLOCK ASSY . NUTPLATE . RADIUS BLOCK ASSY . NUTPLATE . NOTE 1: SUPPORT ASSEMBLY IS SUPPLIED WITH A BLACK NYLON COATING ON INNER SURFACE.	REF 8 8 4 2 2 4 2 4	P P P P P P P P P P P P P P P P P P P	
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 32-12. Aft High Crosstube Assembly

32-99-00 Page 38

Rev. 8 30 APR 2010

ECCN EAR99



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 32-12. Aft High Crosstube Assembly			
1A	205-050-403-005	CROSSTUBE ASSY, AFT (SEE FIG. 32-2,32-3 FOR NHA) (USBL ON 205-050-400-009) (REPLACED BY 205-050-403-009, -025 AND	1	NP	
1B	205-050-403-009	-033)	1	NP	
1C	205-050-403-025	(REPLACED BY 205-050-403-025 AND -033)	1	NP	
1D	205-050-403-033	-009) (REPLACED BY 205-050-403-033)	1	NP	
1D	205-050-403-103	AND -025) (REPLACED BY 212-050-224-101)	1	NP	
1D	205-050-403-111	CROSSTUBE ASSY, AFT (SEE FIG. 32-2,32-3 FOR NHA)	1	NP	
1E	212-050-224-101	(REPLACES 205-050-403-103) (REPLACED BY 212-050-224-101) CROSSTUBE ASSY, AFT (SEE FIG. 32-2,32-3 FOR NHA) (USBL ON	1	NP	
1	212-321-304	212-050-225-103) (REPLACED BY 212-321-304)	1	SP	
2 3	204-050-011-017 204-050-011-019	SUPPORT (USBL ON 205-050-403-005)	2 2	NP P	
4	204-050-011-027	. SUPPORT (USBL ON 205-050-403-025)	2	Р	
5 6	NAS1739MW6 NAS1739MW6	RIVET (USBL ON 205-050-403-005 AND -009)	16 12	NP NP	
7 8	MS21042L4 AN960-416	. NUT (USBL ON 205-050-403-033, -103 AND -111)	8	SP NP	
8	NAS1149F0463P	BY NAS1149F0463P)	8	SP	
9 10	205-050-134-003 205-050-133-003	. U-BOLT (USBL ON 205-050-403-033, -103 AND -111)	4 2	SP SP	
11	205-050-132-003	AND -111)	2	SP	
12	204-050-011-115	. SUPPORT (ÚSBL ON 212-050-224-101)	2	SP	
13 14	CR4622CW-6 206-050-301-109	RIVET (USBL ON 212-050-224-101)	12 2	NP SP	
15	204-050-151-005	. PLATENUT ASSY (S/N 30504 THRU 30614) (RÉPLACED BY	4	NP	
15	90-018-1	90-018-1)	4	SP	
16	MS21051L6	NUTPLATE (REPLACED BY MS21051-L6)	2	NP	
16 17	MS21051-L6 204-050-223-001	NUTPLATE (REPLACES MS21051L6)	2 4	SP NP	
17 18	90-019-1 MS21069L6	RADIUS BLOCK ASSY (REPLACES 204-050-223-001)	4 1	SP SP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 32-12. Aft High Crosstube Assembly (Cont'd)			
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			
					1






Figure 32-13. Aft High Crosstube Assembly (AAI)



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
1 2 3 4 5 6 7 8 9 10	212-321-304 MS21042L4 NAS1149F0463P 604-025-015 205-050-133-003 205-050-132-003 90-018-1 MS21051-L6 90-019-1 MS21069L6	Figure 32-13. Aft High Crosstube Assembly (AAI) CROSSTUBE ASSY, AFTNUTWASHERU-BOLT .SUPPORT ASSY, LOWER, AFT (NOTE 1) .SUPPORT ASSY, UPPER, AFT (NOTE 1) .RADIUS BLOCK ASSY .NUTPLATE .RADIUS BLOCK ASSY .NUTPLATE .RADIUS BLOCK ASSY .NUTPLATE .RADIUS BLOCK ASSY .NUTPLATE .ROTE 1: SUPPORT ASSEMBLY IS SUPPLIED WITH A BLACK NYLON COATING ON INNER SURFACE.	1 8 8 4 2 2 4 2 4 1	SP S	
		AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			




Figure 32-14. Skid Installation, Tailboom



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
1 1 2 2 3 4 4 5 5 6 7 7 8 9	204-030-947-015 NAS679A3 MS21042L3 AN960C10L NAS1149C0332R AN525-10R26 NAS221-16 MS27039-1-16 NAS221-22 MS27039-1-22 204-030-946-002 MS29561-325 M83248/1-325 204-030-947-003 204-030-947-007	Figure 32-14. Skid Installation, Tailboom SKID INSTL NUT (REPLACED BY MS21042L3) . NUT, SELF-LOCKING (REPLACES NAS679A3) . WASHER (REPLACED BY NAS1149C0332R) . WASHER (REPLACES AN960C10L) . SCREW . SCREW (REPLACED BY MS27039-1-16) . SCREW (REPLACES NAS221-16) . SCREW (REPLACED BY MS27039-1-22) . SCREW (REPLACES NAS221-22) . SCREW (REPLACES NAS221-22) . BLOCK . PACKING, PREFORMED (REPLACED BY M83248/1-325) . PACKING, PREFORMED (REPLACES MS29561-325) . TUBE ASSY . PLUG	1 1 1 3 3 1 2 2 2 2 1 1 1	P P P P P P P P P P P P P P P P P P P	
		AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			






Figure 32-15. Fixed Step Kit



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 32-15. Fixed Step Kit			
1 2 2	212-706-057-001 212-706-057-002 MS21042L4 AN960PD416 AN960JD416	FIXED STEP KIT, LH. FIXED STEP KIT, RH. . NUT	1 1 1 1	NP NP SP NP P	
2 3 4 5 5	NAS1149D0463J AN43B-10A MS21042L3 AN960PD10 AN960JD10	NAS1149D0463J)	1 1 1 1	SP SP SP SP	
5 6 7 8 8	NAS1149D0363J AN3-6A MS21042L4 AN960PD416 AN960JD416	NAS1149D0363J)	1 1 1 1	SP SP SP NP P	
8 9 11 11	NAS1149D0463J AN4-10A AN960PD516 AN960JD516	. WASHER (REPLACÉS AN960JD416)	1 1 2 2	SP SP P	
11 12 13 13 14 15 15 15	NAS1149D0563J AN5-10A 212-030-616-001 212-030-616-002 MS21042L3 AN960PD10 AN960JD10 NAS1149D0363J AN3-6A 212-030-615-003	NAS1149D0563J) . WASHER (REPLACES AN960JD516) . BOLT STEP ASSY, LH . STEP ASSY, RH . NUT, SELF-LOCKING . WASHER (REPLACED BY AN960JD10) . WASHER (REPLACES AN960PD10) (REPLACED BY NAS1149D0363J) . WASHER (REPLACES AN960JD10) . BOLT.	2 2 1 1 1 1 1 1	SP SP P SP P SP P	
17 18 19 20 21 21	MS27975-4 AN490HT6 MS21042L3 AN960PD10 AN960JD10	STRUT ASSY	1 1 1 1 1	SP SP SP SP P	
21 22 23 24 24	NAS1149D0363J AN3-6A MS21042L4 AN960PD416 AN960JD416	WASHER (REPLACES AN960JD10)	1 1 1 1 1	SP SP SP NP P	
24 25 25 26 27 28 28 29 30 31 31	NAS1149D0463J AN43B4A AN43B-4A 212-030-615-005 MS27975-4 AN316-4 AN316-4R AN490HT6 MS21042L3 AN960PD10 AN960JD10	. WASHER (REPLACES AN960JD416) . EYEBOLT (REPLACED BY AN43B-4A) . EYEBOLT (REPLACES AN43B4A) . STRUT ASSY . CLEVIS NUT (REPLACED BY AN316-4R) . NUT (REPLACES AN316-4P) . ROD END . NUT, SELF-LOCKING . WASHER (REPLACED BY AN960JD10) . WASHER (REPLACES AN960PD10) (REPLACED BY NAS1149D0363J)	1 1 1 1 2 2 2 2 1 1	SP SP SP SP SP SP P	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	0 C
31 32 33 34 35 36 37 38 39 40 40 41	NAS1149D0363J AN3-6A 212-030-615-001 MS27975-4 AN490HT6 MS21042L3 AN960JD10L NAS1149D0332J MS27039-1-09 212-030-617-003 212-030-617-001 212-030-617-001 212-030-619-001	Figure 32-15. Fixed Step Kit (Cont'd) WASHER (REPLACES AN960JD10) BOLT STRUT ASSY CLEVIS ROD END NUT, SELF-LOCKING WASHER, FLAT (REPLACED BY NAS1149D0332J) WASHER, FLAT (REPLACES AN960JD10L) SCREW SUPPORT ASSY, LH SUPPORT ASSY, LH SUPPORT ASSY, RH SUPPORT ASSY, RH STEP ASSY AVAIL CODE DEFINITION P Procurable NP Non Procurable SP Normal Stock/Procurable Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.		1	