

Chinrest Setup Guide

Follow these steps to adjust your Embrace Strings chinrest for natural posture, comfort, and effortless play. Take your time, and remember: small adjustments make a big difference.

1. Attach the Chinrest Clamp Barrels

Screw the clamp barrels onto the chinrest. These barrels are what secure the chinrest to your instrument, so make sure they are firmly in place before moving on.

2. Position and Secure the Chinrest

Place the chinrest to the **left of the tailpiece** and tighten the clamp using the tightener until snug.

- **Important:** Don't overtighten — this could damage your instrument.
- The chinrest should sit firmly but without forcing your instrument.

3. Set Your Shoulder and Instrument

Place your instrument on your shoulder and look straight ahead — **don't worry about your chin yet.**

- Adjust your **shoulder rest** so the instrument sits comfortably on your collarbone.
- The instrument should come out at roughly a **45° angle** and stay in place with just your shoulder and left hand.

This ensures that your chinrest fills in the natural space between your chin and the instrument, rather than forcing your neck into tension.

4. Adjust Height and Tilt

Use the **top dials** to set the chinrest's **height and tilt**:

- Fill the gap between your chin and the instrument comfortably.
- Chinrest should be **as the same angle as your jawline**.
- Ideally, it rests about **2 fingers below your head**, allowing your head's natural weight to help secure the instrument.

Think of the chinrest as a **pillow for your jaw**, helping you *Embrace* the instrument.

5. Lock the Chinrest in Place

Once the height and tilt feel right, use the **center dial** to stabilize the chinrest:

- Turn until it **cannot easily rotate**.
- You do **not** need to overtighten — firm is enough.

6. Tips and Troubleshooting

- If the **top part of the chinrest comes off**, simply pull it back down onto the threaded rod and retighten the top dial.
- **Always unlock the center dial** before making further adjustments.
- After playing, it's **best practice to unlock the center dial** to prolong the life of your chinrest.