

440 446 442 448 444 472

Headquarters:

Novus Dahle GmbH & Co. KG Breslauer Straße 34-38 49808 Lingen | Germany

Service contact:

Novus Dahle GmbH & Co. KG Nikolaus-A.-Otto-Straße 11 96472 Rödental | Germany

Tel.: +49 9563 75299-0 Fax: +49 9563 75299-333 E-Mail: info@dahle.de Web: www.dahle.de

DE Bedienungsanleitun	g
------------------------------	---

UK/US Operating instructions

FR Instructions de service

ES Manual de instrucciones

IT Istruzioni per l'uso

PT Manual de instruções

NL Gebruiksaanwijzing

DK Betjeningsvejledning

FI Käyttöohje

NO Bruksanvisning

SE Bruksanvisning

SI Navodila za uporabo

HR Upute za uporabu

HU Kezelési útmutató

RU Руководство по эксплуатации

EE Kasutusjuhend

LT Naudojimo instrukcija

LV Lietošanas instrukcija

CZ Návod k obsluze

SK Návod na obsluhu

PL Instrukcja obsługi

RO Instrucțiuni de utilizare

BG Упътване за употреба

TR Kullanım Kılavuzu

GR Οδηγίες χειρισμού

تعليمات الاستعمال **AE**

JP 取扱説明書

CN 操作指南











DE Technische Änderungen vorbehalten

UK/US Technical data is subject to change without notice.

FR Sous réserve de modifications techniques

ES Dahle se reserva el derecho de modificar, sin previo aviso, los datos tecnicos del producto.

IT I dati tecnici sono soggetti a modifiche senza preavviso.

PT Dados técnicos podem mudar sem infromação.

NL Technische data is zonder kennisgeving aan verandering onderhevig.

DK Tekniske specifikationer kan ændres uden varsel.

FI Tekniset tiedot annetaan sitoumuksetta

NO Tekniske spesifikasjoner kan endres uten forutgående varsel.

SE Tekniska specifikationer kan ändras utan föregående meddelande.

SI Tehnični podatki se lahko spremenijo brez vnaprejšnjega opozorila.

HR Tehničke karakteristike mogu se promijeniti bez prethodnog upozorenja.

HU A technikai adatokat előzetes értesítés is nélkül megváltoztathatjuk.

RU Сохранение технических данных без напоминания.

EE Jätame endale õiguse teha tehnilisi muudatusi

Galimi techniniai pakeitimai

LV Paturētas tiesības veikt tehniskas izmaiņas.

CZ Změna technických údajů vyhrazena

SK Technické zmeny vyhradené

PL Dane techniczne urządzenia mogą ulec zmianie bez powiadomienia.

RO Datele tehnice pot fi schimbate fara o notificare prealabila.

BG Запазваме си правото на технически промени

TR Teknik bilgiler önceden haber verilmeksizin değiştirilebilir.

GR Βελτιώσεις των τεχνικών χαρακτηριστικών πιθανόν να γίνουν άνευ ειδοποίησης.

6

المعلومات التقنية عرضة للتغيير بدون إنذار مسبق

JP 製品の仕様は予告なく一部変更されることがあります。

CN 技术资料如若改变另行通知。



















7



















444	446	448	472
a = 870 mm b = 384 mm	a = 1120 mm b = 384 mm	a = 1500 mm b = 384 mm	a = 2030 mm b = 384 mm
c = 135 mm	c = 135 mm	c = 135 mm	c = 135 mm
= 5,8 kg	= 7,7 kg	= 10,0 kg	= 13,0 kg
d = 670 mm	d = 920 mm	d = 1300 mm	d = 1830 mm
x = 3.0 mm	$\mathbf{x} = 2,5 \text{ mm}$	X = 2,0 mm	x = 1,0 mm




































































796 798 799

UK/US	Assambly instructions
FR	Instructions de montage
ES	Instrucciones de montaje
IT	Istruzioni di montaggio
PT	Instruções de montagem
NL	Montage Handleiding

Monteringsvejledning

Monteringsveiledning

Navodila za montažo

Szerelési útmutató

Szerelési útmutató

Monteringsinstruktioner

Kokoamisohje

Montageanleitung

DE

DK

FI

NO

SE

SI

HR

HU

110	Time by marini the dooping
EE	Paigaldusjuhend
LT	Surinkimo instrukcija
LV	Montāžas pamācība
CZ	Montážní návod
SK	Návod na montáž
PL	Instrukcja montażu
RO	Instrucțiuni de asamblare
BG	Упътване за монтаж
TR	Kurulum talmatlari
GR	Οδηγίες Συναρμολό γησης
AE	تعليمات التركيب
JP	組立方法について
CN	安装指南

Инструкция по сборке

RU





