
## HOW TO UNCRATE



- Stand Crate Upright
  - Remove Crate Screws
    - Carefully Roll Shredder Out



REMOVE CRATE SCREWS Remove Crate Screws-Using a screwdriver or cordless drill, remove each of the 4 phillips head screws securing

Please call or email to return shipping crate

eterborough, Vose Farm Road North America, ' www.dahle.com

From:

## SLOWLY REMOVE SHREDDER

on the front panel.



Slowly Remove Shredder-Carefully slide the shredder out of the crate until all four wheels touch the ground. Crate return instructions on back.





Easy Crate Return Instructions-

Dahle is environmentally friendly and we would be happy to reuse this shipping crate. Simply give us a call or send us an email at info@dahle.com. We will arrange to have this crate returned to us.