Transistors

Emmanuel Estallo

August 18, 2021

1 Bipolar Junction Transistor

The behavior of the majority carriers are dictated by the behavior of the minority. If we let the minority carriers propagate over time, eventually all of them will recombine. The goal is to manipulate these minority carriers in a region where there is no significant amount of recombination. Basically, we want to get these minority carriers to a place where they are the majority carriers again.

1.1 Basic Operation

Adding an n region beside the p region of a np junction gives us an npn transistor. An external voltage source connected to the pn regions lowers the potential barrier. In a sense, the added n region is used to collect the emitted electrons from the first n region.

Since there are two pn junctions, there will be two depletion regions with electric fields both pointing to the p region. For the **Base-Emitter** junction, we should apply a forward voltage bias V_{BE} to lower the potential barrier and decrease the strength of electric field that is generated by the depletion region. For the **Base-Collector** junction, we should apply a reverse voltage bias V_{BC} to increase the electric field strength. This allows electrons to pass through easier.

We want to get the electrons from the emitter region to the collector. Thus, it will be better to make the base region as thin as possible. Because of this, the concentration of the minority carriers decrease immediately. This resembles the diode. The collector current is obtained by

$$I_C = I_S \exp\left(rac{V_{BE}}{V_T}
ight)$$

We want to make the base very thin so that more electrons can pass through easier. If we do this, the depletion regions might overlap. As a general rule, to scale transistors smaller, we should adjust the doping concentrations on all sides. This allows us to scale the depletion regions at a desired ratio. This also decreases the resistivity at the base. The bigger problem is that more holes will get to the emitter.

We define the emitter injection efficiency as

$$\gamma = \frac{I_{nE}}{I_{nE} + I_{nE}}$$

Where I_{nE} is the emitter current carried by electrons and I_{pE} is the emitter current carried by the holes. We want this efficiency to be close to 100%. A way to do this is by heavily doping the emitter and lightly doping the base. Another is that we can use a different semiconductor material. This semiconductor material will have a different bandgap. This is the foundation of **Heterojunction Bipolar Transistors**.

Define the base transfer factor as

$$lpha_T = rac{I_{nC}}{I_{nE}}$$
 $lpha_0 = rac{I_C}{I_E}$

This is the current that goes to the collector from the emitter.

1.2 Early Effect and Dynamics