Transistors

Emmanuel Estallo

July 29, 2021

1 Bipolar Junction Transistor

The behavior of the majority carriers are dictated by the behavior of the minority. If we let the minority carriers propagate over time, eventually all of them will recombine. The goal is to manipulate these minority carriers in a region where there is no significant amount of recombination. Basically, we want to get these minority carriers to a place where they are the majority carriers again.

1.1 Basic Operation

Adding an n region beside the p region of a np junction gives us an npn transistor. An external voltage source connected to the pn regions lowers the potential barrier. In a sense, the added n region is used to collect the emitted electrons from the first n region.

Since there are two pn junctions, there will be two depletion regions with electric fields both pointing to the p region. For the **Base-Emitter** junction, we should apply a forward voltage bias V_{BE} to lower the potential barrier and decrease the strength of electric field that is generated by the depletion region. For the **Base-Collector** junction, we should apply a reverse voltage bias V_{BC} to increase the electric field strength. This allows electrons to pass through easier.

We want to get the electrons to the collector region from the emitter. Thus, it will be better to make the base region as thin as possible.