User Description

Welcome to your own incubator box! This box will regulate temperature between 85-90 degrees Fahrenheit!

To start:

1. Plug incubator into an outlet
2. Use the Warmup code to preheat your incubator box

(The warmup process may take a couple of minutes, but once ready the incubator should automatically control the temperature to keep the sample within 85F-90F degrees)

When the Micro:bit is working as intended it should do the following:

- If your box is within the required temperature range (85-90°F)
  - The micro-bit will play a middle F tone.
  - Will show check mark icon

- If temperature is above required range (> 90°F)
  - micro-bit will play a melody C tone.
  - Will show X mark on the Micro:bit

After this point your incubator box should be good to go! However, if your box goes over or under the expected temperature range, here's what to do!

In the scenario that the temperature goes above 90°F:

After 20 seconds of the Micro:bit being above the 90°F threshold you will hear a third tone (Middle E). This means that the water sample is destroyed!!, please do the following listed below:

1. Open lid to let the incubator cool down
2. Press button B to manually shut down
3. Unplug the incubator

In the scenario that the temperature goes below 85°F:

1. Open incubator box lid
2. Press button A to manually turn on heater

Following these steps will ensure that your incubator works successfully!