

Standard Wiring Example of Main Circuit


• Frame A, B



• Frame C, D



• Frame E, F



 * One of the connections shown right applies according to series of the motor. Refer to "Connector and Plug Specifications" on page A4-142.

[Motor portion]

$ \begin{array}{ccc} D & \triangle & A \\ O & O & B \end{array} $
JL04V-2E20-4PE-B-R
JL04HV-2E22-22PE-B-R

PIN No.	Application
Α	U-phase
В	V-phase
С	W-phase
D	Ground
	Ground





JL04V-2E20-18PE-B-R

-	-		
PIN No.	Application	PIN No.	Appl
G	Brake	Α	В
Н	Brake	В	В

G	Brake
Н	Brake
Α	NC
F	U-phase
I	V-phase
В	W-phase
Ε	Ground
D	Ground
С	NC
	_

PIN No.	Application
Α	Brake
В	Brake
С	NC
D	U-phase
E	V-phase
F	W-phase
G	Ground
Н	Ground
I	NC

<Remark> Do not connect anything to NC.

Frame G

