AquaPearl 500 Pro — Product Manual | Page 1: Welcome

This fictional manual covers the AquaPearl 500 Pro household water purifier. Read all safety instructions before installation. Keep this manual and your purchase invoice for future support.

The purifier is designed for indoor household use with cold municipal or appropriately pre-treated feed water. It is not a medical device and does not guarantee removal of every possible contaminant.

Page 2: Box contents

The standard carton contains one purifier body, wall mounting bracket, inlet tubing kit, power adapter, quick-start sheet, one installed sediment pre-filter, one installed carbon cartridge, and a warranty registration card. Inspect the carton for visible transit damage before discarding packaging.

If a listed accessory is missing, report it within 48 hours of delivery with photographs of the carton label and contents.

Page 3: Technical specifications

Rated supply: 220-240 V AC, 50 Hz using the supplied adapter. Nominal tank capacity: 8 litres. Typical rated flow: up to 1.8 litres per minute under approved inlet conditions. Approved inlet pressure: 15-60 PSI. Operating temperature: 5-38 °C ambient.

Dimensions: 410 mm high × 260 mm wide × 300 mm deep. Keep at least 100 mm clearance around ventilation areas. Do not connect to hot water or an unregulated pressure source.

Page 4: Filtration stages

Stage 1: washable sediment screen protects the inlet path; inspect monthly. Stage 2: replaceable sediment pre-filter captures suspended particles. Stage 3: activated carbon cartridge reduces chlorine taste and odour. Stage 4: membrane module performs the product-specific membrane filtration. Stage 5: final polishing cartridge improves taste.

Filter-life estimates depend on incoming water quality and usage. The app estimate is a reminder, not a laboratory measurement of water safety.

Page 5: Control panel

Power indicator: steady green indicates normal powered operation. Filter indicator: amber means a scheduled filter replacement is approaching; red means the relevant filter service is due. Water indicator: blinking blue means the tank is filling.

RESET button: after replacing the sediment pre-filter, press and hold RESET for five seconds when the unit is powered and no active leak warning is present. Do not reset an unresolved fault code.

Page 6: Operating instructions

Open the inlet shutoff valve slowly. Confirm that the area and electrical connection are dry. Connect the supplied adapter and allow the initial tank fill to complete. Flush the system for 10 minutes and discard the first full tank after a new installation or full filter-set replacement.

Do not drink water during the first flush. If water leaks, the pump runs continuously, or an electrical warning appears, stop use and follow the troubleshooting guide.

Page 7: Filter replacement schedule

Sediment pre-filter: inspect monthly and typically replace every 3-6 months depending on feed-water sediment. Carbon cartridge: typically replace every 6-9 months. Membrane module: typical service interval is 18-24 months, subject to water quality and measured performance. Final polishing cartridge: typically replace every 9-12 months.

These are planning intervals, not a guarantee of filter life. Use the device alert and authorised service guidance. Replacement cartridges are consumables and are excluded from the standard purifier warranty.

Page 8: Cleaning and descaling

Wipe the external housing with a soft damp cloth. Do not immerse the unit or spray cleaning liquid into vents. Do not use abrasive powders, solvents or bleach on the housing. The manual does not provide a customer procedure for internal descaling; request authorised service if scale is suspected.

Keep the installation area ventilated and dry. Inspect visible tubing for kinks or damage during routine cleaning.

Page 9: Safety warnings

Never open the purifier housing, bypass a sensor, modify electrical wiring, or operate the unit with a damaged adapter. Keep the adapter away from water. Do not allow children to play with tubing or control buttons.

If smoke, burning smell, electric shock or uncontrolled leakage occurs, stop using the appliance. Disconnect power only if it is safe to do so, close the inlet valve and contact human support.

Page 10: Audible alert codes

E-01: startup self-test issue; power-cycle once, then contact support if repeated. E-02: inlet pressure below operating range; check that the inlet valve is open and seek plumbing assistance. E-03: sediment pre-filter saturation; replace the pre-filter and reset the alert. E-04: tank fill timeout; check supply and contact support if repeated.

E-05: leak sensor alert; close inlet water, disconnect power if safe and do not restart until inspected. E-06: pump temperature alert; switch off for 30 minutes; recurring alerts require service. E-07: sensor communication fault; do not open the unit. E-08: internal electronics fault; disconnect power and arrange service.

Page 11: Maintenance and service

Keep a record of filter changes and retain receipts for replacement cartridges. Use only compatible cartridges listed in the Pearlz pricing guide. Unapproved consumables may affect performance and service diagnosis.

For a warranty or service claim, prepare the invoice number, serial number, product photographs and a short fault description. The service agreement explains appointment and claim handling.

Page 12: Warranty and document references

The AquaPearl 500 Pro standard limited warranty is 24 months from the invoice purchase date, subject to exclusions and inspection. Filter cartridges and other consumables are not covered by the standard purifier warranty. See warranty_policy.md for the full policy.

For installation requirements, use installation_guide.md. For symptom diagnosis and safe actions, use troubleshooting_guide.md. Firmware 2.4 changed the E-03 sound to three short beeps; see product_changelog.md.