



Type-C Interface




Max: 5V

Power




VBAT




ESP32-C6


Waveshare
Waveshare_logo




e-Paper&Touch




RTC




EXIO




SHTC3




OUTPUT




SD_Card



Codec



PA&SPEAKER&MIC



GPIO	ePaper	SD Card	Audio	RTC	KEY_IO	Other	PINOUT
GP0						BAT ADC	
GP1						EXIO INT	
GP2						BAT KEY	
GP3							GP3
GP4		SD CS					GP4
GP5	EPD_SDI	SD MISO					
GP6	EPD_SCLK	SD MOSI					
GP7	EPD_CS	SD CLK					
GP8							
GP9							
GP10	EPD_BUSY						
GP11	EPD_RST						
GP12							
GP13							
GP14							
GP15	EPD_D/C						
GP16							
GP17							
GP18							
GP19							
GP20							
GP21							
GP22							
GP23							
EXIO0							
EXIO1							
EXIO2							
EXIO3							
EXIO4							
EXIO5							
EXIO6	EPD_TP_INT						
EXIO7							

