FREQUENTLY ASKED QUESTIONS

App and Account FAQ

Document number	LHS-FAQ-APP-005
Revision	3.4
Effective date	April 6, 2026
Document owner	Customer Care Knowledge Team
Audience	Customer Care agents; approved answers may be shared with customers
Classification	Internal - do not distribute outside Lumora

Purpose. Approved answers to questions about the Lumora Home app, account security, household sharing, data and privacy, and app features such as Away mode and energy reports.

1. Account and Sign-In

Q1. What are the password requirements?

Passwords must be at least 10 characters long and include at least one letter and one number. Passwords used in known data breaches are rejected. The app never asks for the password by email, and agents must never ask customers for their password.

Q2. I am locked out of my account.

After 5 failed sign-in attempts the account is locked for 15 minutes. After the lock expires the customer can try again or use Forgot Password. Password reset links are valid for 1 hour. Agents cannot unlock accounts manually.

Q3. How does two-step verification work?

Two-step verification can use an authenticator app or a text message code. It is optional for most users but mandatory for the home Owner when the home has more than 3 members. If the customer loses access to their second step, they can use one of the 10 recovery codes shown at setup. Without recovery codes, identity must be verified by Tier 2 using the order history, which takes up to 2 business days.

Q4. How do I change my email address?

The email address is changed in Account > Profile. A verification link is sent to the new address and is valid for 24 hours; the change only takes effect after the link is opened. A notice is also sent to the old address.

2. Household Sharing

Q5. Can other people in my home use the app?

Yes. The Owner can invite up to 8 household members per home. Each member has one of three roles:

Role	Permissions
Owner	Everything, including billing, deleting the home and transferring ownership. Each home has exactly one Owner.
Admin	Add and remove devices, change schedules and settings, invite Members. Cannot manage billing or remove the Owner.
Member	Change temperatures and use Away mode. Cannot change schedules, devices or other members.

Table 2-1. Household roles.

Invitations expire after 7 days. Members can leave a home at any time; the Owner must transfer ownership to an Admin before leaving.

Q5a. Can I give temporary access to a guest or a babysitter?

Yes. Owners and Admins can create guest access in Settings > Members > Guest. Guests have the same permissions as Members but their access expires automatically after the end date chosen by the Owner, at most 30 days later. Guests do not count toward the limit of 8 household members.

Q5b. How do I remove a household member?

Owners and Admins can remove Members in Settings > Members. Only the Owner can remove an Admin. Removed members are signed out of the home immediately but keep their own Lumora account.

3. App Features

Q6. How does Away mode work?

Away mode uses the location of household members' phones to detect when everyone has left. The home switches to the Away temperatures when all members with location sharing turned on are outside the geofence, and back when the first member returns. The default geofence radius is 500 m (about 0.3 mi) and can be set between 150 m and 3,000 m in Settings > Away.

Q7. When are energy reports sent?

Energy reports for the previous month are sent by email and shown in the app on the 3rd day of each month. Reports need at least 20 days of data in the month; homes set up later in the month receive their first report the following month.

Q8. Does the app work without internet?

The app needs an internet connection to control devices remotely. Homes with a Hub H1 can still be controlled from a phone on the same local network when the internet is down. Thermostats always keep running their schedules without internet.

4. Data and Privacy

Q9. How long is my data kept?

Temperature and runtime history is kept for 90 days on the free plan and for 3 years with Lumora Plus. Location data used for Away mode is processed on the phone and only the result (home or away) is sent to Lumora; it is kept for 30 days.

Q10. How do I delete my account?

The Owner can request deletion in Account > Privacy > Delete Account. Devices must be removed from the home first. The account is deactivated immediately and permanently deleted after 30 days; during those 30 days, signing in again cancels the deletion. Order and invoice records are kept for 7 years because of tax requirements, even after the account is deleted.

Q11. Can I download my data?

Yes. In Account > Privacy > Download My Data the customer can request an export of account, device and history data. The download link is emailed within 72 hours and is valid for 7 days.

5. Homes, Devices and Updates

Q12. Can I manage more than one home?

Yes. One account can own or be a member of up to 5 homes, for example a main residence and a vacation home. Each home has its own devices, members, schedules and Lumora Plus subscription. Switch homes from the home name at the top of the app.

Q13. How are device firmware updates handled?

Firmware updates are installed automatically. Thermostats update overnight when idle, and the Hub H1 updates between 2:00 and 4:00 AM local time. The app shows the current version of each device under Device > About and notifies the Owner when an update has been installed. Customers cannot install older firmware versions.

Q14. Can I use the app on a tablet or computer?

The Lumora Home app runs on phones and tablets. A web dashboard at the Lumora website offers schedules, history and energy reports from a computer, but device setup and Away mode require the mobile app.

Q15. What happens when I sell my home?

The Owner should transfer the home to the buyer in Account > Homes > Transfer Home, or remove all devices from the account before moving out. The buyer can then add the devices to their own account. Warranty transfer is a separate request described in the Lumora Limited Warranty Policy.

Q16. Which notifications does the app send?

Notification	Default	Can be turned off?
Device offline for more than 30 minutes	On	Yes
Indoor temperature below 45 °F or above 95 °F	On	No
Low battery (S1 or T3)	On	Yes
Filter reminder	Every 90 days	Yes; interval 30-180 days
Firmware update installed	On	Yes
Monthly energy report ready	On	Yes

Table 5-1. App notifications.

Extreme temperature alerts cannot be turned off because they can indicate a heating or cooling failure that may damage the home, such as frozen pipes. They are sent to the Owner and all Admins.

6. Troubleshooting the App

- **Devices show offline in the app but work on the wall:** check the home network; see the product guide error codes (E4 on the T2, E12 on the T3).

- **Notifications not arriving:** confirm notifications are allowed for the app in the phone settings and that the member has not muted the home.
- **App crashes on start:** update the app to the latest version. The app supports the current and the previous major version of each mobile operating system.

7. Accessibility and Languages

Q17. Which languages does the app support?

The app and the thermostat displays support English, Spanish and French. The app follows the phone language; thermostats are set during setup or under Settings > Language. Energy reports are sent in the language of the Owner's app.

Q18. Does the app support screen readers and large text?

Yes. All app screens support the screen reader and text size settings of the phone. The thermostat setpoint can be read aloud by double-tapping the temperature in the app. Customers who have difficulty using the app can ask an agent to set up schedules on their behalf after verifying their identity.