PRODUCT GUIDE

Lumora Hub H1 Product Guide

Document number	LHS-PG-H1-001
Revision	1.7
Effective date	February 9, 2026
Document owner	Product Support Engineering
Audience	Customer Care, Technical Support
Classification	Internal - do not distribute outside Lumora

Purpose. Reference for supporting the Lumora Hub H1 (model LH-H1), the bridge that connects LumoraLink sensors and thermostats to the home network and runs local automations.

1. Product Overview

The Hub H1 bridges LumoraLink devices to the internet and to the Lumora Home app. It stores schedules and automations locally so that the home keeps working when the internet connection is down. A hub is optional for homes with a single thermostat but required for sensor-only setups and for homes with more than one thermostat.

The H1 is sold under SKU LH-H1-01 at a list price of $79.00. It connects up to 32 LumoraLink devices, including thermostats, room sensors and future accessories. Devices beyond 32 are rejected with the message "Hub is full"; a second hub can be added to the same home.

2. Specifications

Item	Hub H1 (LH-H1)
Radios	LumoraLink 915 MHz mesh; 802.11 b/g/n 2.4 GHz
Wired network	One 10/100 Ethernet port (cable included)
Device capacity	Up to 32 LumoraLink devices
Power	5 V 2 A USB-C adapter (included); no battery
Local storage	Schedules and automations for up to 7 days offline
Firmware updates	Automatic, between 2:00 and 4:00 AM local time
Dimensions	3.5 x 3.5 x 1.0 in (89 x 89 x 25 mm)
Warranty	2 years (24 months) limited warranty

Table 2-1. Hub H1 specifications.

3. Installation

1. Place the hub in a central location, at least 3 ft from the router and away from large metal objects. A shelf at mid-height gives the best mesh range.
2. Connect the USB-C power adapter. Use the included adapter; low-power phone chargers cause random restarts.
3. Optionally connect the Ethernet cable to the router. Ethernet is recommended when more than 15 devices are paired.
4. In the Lumora Home app tap Add Device > Hub and scan the QR code on the bottom of the hub.
5. Wait until the status light turns solid teal. Setup normally takes 2 to 5 minutes, longer if a firmware update is installed during setup.

3.1 Placement Guidance

Location	Suitability	Comment
Central hallway shelf	Best	Good mesh coverage for most homes.
Next to the router	Acceptable	Keep at least 3 ft apart to avoid interference.
Inside a metal cabinet or media rack	Avoid	Metal blocks the LumoraLink radio.
Basement	Avoid	Sensors on upper floors may lose connection.
Garage or outdoors	Not supported	Operating range 32 °F to 104 °F, indoor use only.

Table 3-1. Hub placement.

4. Status Light

Light	Meaning	Action
Solid teal	Online and working normally	None.
Pulsing amber	Setting up or installing an update	Wait up to 15 minutes; do not unplug.
Blinking amber	Factory reset in progress	Wait for restart.
Blinking red	No internet connection; local control still works	Check router; reconnect in the app.
Solid red	Hardware fault	Unplug for 1 minute; if it returns, start an RMA.
Off	No power	Check the adapter and outlet.

Table 4-1. H1 status light.

5. Offline Operation

If the internet connection is lost, the H1 keeps running schedules and automations stored on the device for up to 7 days. After 7 days without a connection, time-based automations pause until the clock can be verified, but thermostats continue their own schedules. Remote access from the app is not available while the hub is offline, but the app can still control devices when the phone is on the same local network.

6. Troubleshooting

6.1 Devices Drop Off the Hub

- Check how many devices are paired; the limit is 32.
- Move the hub away from the router, microwave ovens and cordless phone bases.
- Add a mains-powered LumoraLink device (such as a thermostat) between the hub and distant sensors to extend the mesh.

6.2 Factory Reset

To factory reset the H1, press and hold the reset button on the bottom with a paper clip for 15 seconds until the status light blinks amber. All paired devices must be paired again afterwards. Before suggesting a reset, confirm the customer can access the app to re-add devices.

6.3 Firmware

The current H1 firmware is 5.2.0. Updates install automatically between 2:00 and 4:00 AM local time. Customers cannot postpone updates for more than 14 days; after 14 days the update installs at the next maintenance window.

7. Network Requirements

Requirement	Value
Wireless band	2.4 GHz (5 GHz-only networks are not supported)
Security	Password-protected personal network; enterprise sign-in is not supported
Outbound ports	TCP 443 and 8883 must be open
Bandwidth	Less than 50 MB per month for a typical home
Captive portals	Not supported (hotel, dormitory or guest networks)
IP addressing	DHCP required; a reserved address is recommended

Table 7-1. Hub H1 network requirements.

If the customer's router uses a firewall with strict outbound rules, ask the customer or their network administrator to allow TCP ports 443 and 8883. A blinking red light together with a working internet connection for other devices usually points to blocked ports.

8. Homes With More Than One Hub

Large homes or homes with more than 32 devices can use additional hubs. Each device is paired to exactly one hub. Automations can use devices from any hub in the same home, but they run in the cloud rather than locally when they combine devices from different hubs, so they stop during an internet outage.

1. Add the second hub in the app under Add Device > Hub.
2. Choose which existing devices to move. The app moves them one at a time; each move takes about 30 seconds.
3. Check the mesh map in Settings > Network > Mesh to confirm every device has a strong or good signal.

9. Automations

The H1 runs automations that combine triggers and actions, for example "when nobody is home after 9:00 AM, set the thermostat to Away". Each home can have up to 50 automations. Automations that use only devices on one hub run locally on that hub.

Trigger type	Examples
Time	Specific time, sunrise or sunset with an offset
Occupancy	Room occupied or empty for a set time (from S1 sensors)
Temperature	A room is above or below a threshold
Presence	First member arrives or last member leaves (Away mode)

Table 9-1. Automation triggers.

10. Quick Answers for Agents

Does a home with one thermostat need a hub?

No. A single T2 or T3 connects directly to the home network. A hub is needed for homes with more than one thermostat, for sensor-only setups and for local automations.

Can the H1 run on battery during a power outage?

No. The H1 has no battery. Customers who want the hub to stay online during outages can connect it and the router to a small uninterruptible power supply.

Can the H1 connect to the 5 GHz band?

No. The H1 wireless radio supports 2.4 GHz only. If the router offers only 5 GHz, connect the hub with the Ethernet cable instead.

11. Warranty and Replacement

The Hub H1 carries a 2-year (24-month) limited warranty. Advance replacement is available for the H1 to all customers because the home loses remote access while the hub is out of service. A solid red light that returns after a power-cycle is treated as a confirmed hardware fault and does not require further troubleshooting before an RMA is created.