## Pressure advance

This document provides information on tuning the "pressure advance" configuration variable for a particular nozzle and filament. The pressure advance feature can be helpful in reducing ooze. For more information on how pressure advance is implemented see the kinematics document.

## Tuning pressure advance

Pressure advance does two useful things - it reduces ooze during non-extrude moves and it reduces blobbing during cornering. This guide uses the second feature (reducing blobbing during cornering) as a mechanism for tuning.

In order to calibrate pressure advance the printer must be configured and operational as the tuning test involves printing and inspecting a test object. It is a good idea to read this document in full prior to running the test.

Use a slicer to generate g-code for the large hollow square found in docs/prints/square\_tower.stl. Use a high speed (eg, 100mm/s), zero infill, and a coarse layer height (the layer height should be around 75% of the nozzle diameter). Make sure any "dynamic acceleration control" is disabled in the slicer.

Prepare for the test by issuing the following G-Code command:

```
SET_VELOCITY_LIMIT SQUARE_CORNER_VELOCITY=1 ACCEL=500
```

This command makes the nozzle travel slower through corners to emphasize the effects of extruder pressure. Then for printers with a direct drive extruder run the command:

```
TUNING_TOWER COMMAND=SET_PRESSURE_ADVANCE PARAMETER=ADVANCE START=0 FACTOR=.005
```

For long bowden extruders use:

```
TUNING_TOWER COMMAND=SET_PRESSURE_ADVANCE PARAMETER=ADVANCE START=0 FACTOR=.020
```


Then print the object. When fully printed the test print looks like:



The above TUNING\_TOWER command instructs Klipper to alter the pressure\_advance setting on each layer of the print. Higher layers in the print will have a larger pressure advance value set. Layers below the ideal pressure\_advance setting will have blobbing at the corners, and layers above the ideal setting can lead to rounded corners and poor extrusion leading up to the corner.

One can cancel the print early if one observes that the corners are no longer printing well (and thus one can avoid printing layers that are known to be above the ideal pressure\_advance value).

Inspect the print and then use a digital calipers to find the height that has the best quality corners. When in doubt, prefer a lower height.



The pressure\_advance value can then be calculated as pressure\_advance = <start> + <measured\_height> \* <factor> . (For example, 0 + 12.90 \* .020 would be .258.)

It is possible to choose custom settings for START and FACTOR if that helps identify the best pressure advance setting. When doing this, be sure to issue the TUNING\_TOWER command at the start of each test print.

Typical pressure advance values are between 0.050 and 1.000 (the high end usually only with bowden extruders). If there is no significant improvement with a pressure advance up to 1.000, then pressure advance is unlikely to improve the quality of prints. Return to a default configuration with pressure advance disabled.

Although this tuning exercise directly improves the quality of corners, it's worth remembering that a good pressure advance configuration also reduces ooze throughout the print.

At the completion of this test, set pressure\_advance = <calculated\_value> in the
[extruder] section of the configuration file and issue a RESTART command. The RESTART
command will clear the test state and return the acceleration and cornering speeds to their
normal values.

## Important Notes

- The pressure advance value is dependent on the extruder, the nozzle, and the filament. It is common for filament from different manufactures or with different pigments to require significantly different pressure advance values. Therefore, one should calibrate pressure advance on each printer and with each spool of filament.
- Printing temperature and extrusion rates can impact pressure advance. Be sure to tune the extruder rotation\_distance and nozzle temperature prior to tuning pressure advance.
- The test print is designed to run with a high extruder flow rate, but otherwise "normal" slicer settings. A high flow rate is obtained by using a high printing speed (eg, 100mm/s) and a coarse layer height (typically around 75% of the nozzle diameter). Other slicer settings should be similar to their defaults (eg, perimeters of 2 or 3 lines, normal retraction amount). It can be useful to set the external perimeter speed to be the same speed as the rest of the print, but it is not a requirement.
- It is common for the test print to show different behavior on each corner. Often the slicer will arrange to change layers at one corner which can result in that corner being significantly different from the remaining three corners. If this occurs, then ignore that corner and tune pressure advance using the other three corners. It is also common for the remaining corners to vary slightly. (This can occur due to small differences in how the printer's frame reacts to cornering in certain directions.) Try to choose a value that works well for all the remaining corners. If in doubt, prefer a lower pressure advance value.
- If a high pressure advance value (eg, over 0.200) is used then one may find that the
  extruder skips when returning to the printer's normal acceleration. The pressure advance
  system accounts for pressure by pushing in extra filament during acceleration and
  retracting that filament during deceleration. With a high acceleration and high pressure
  advance the extruder may not have enough torque to push the required filament. If this
  occurs, either use a lower acceleration value or disable pressure advance.
- Once pressure advance is tuned in Klipper, it may still be useful to configure a small retract
  value in the slicer (eg, 0.75mm) and to utilize the slicer's "wipe on retract option" if
  available. These slicer settings may help counteract ooze caused by filament cohesion
  (filament pulled out of the nozzle due to the stickiness of the plastic). It is recommended
  to disable the slicer's "z-lift on retract" option.
- The pressure advance system does not change the timing or path of the toolhead. A print with pressure advance enabled will take the same amount of time as a print without pressure advance. Pressure advance also does not change the total amount of filament extruded during a print. Pressure advance results in extra extruder movement during move acceleration and deceleration. A very high pressure advance setting will result in a very large amount of extruder movement during acceleration and deceleration, and no configuration setting places a limit on the amount of that movement.