## RISO ME9450U

## Print from RISO LAB imac:

You can print from the imac in the RISO rm. Just log in with net id / pass to access the driver.

## Print from personal laptop (mac instructions):

The printer isn't network enabled meaning you have to plug in via USB cord to print to it from your laptop.

- 1. Go here <a href="https://www.riso.com/download/">https://www.riso.com/download/</a>
- 2. Series Category: Duplicator / Device: ME
- 3. Select OS
- 4. "Download"
- 5. Click on the ME 9 Series
- 6. Download ME 9x5xU Series
- 7. Unzip / Open ME 9 Series Folder / Install ME 9x5xU Series Installer
- 8. When prompted, Serial Key: 01821071
- 9. Plug your laptop in VIA USB to the RISO
- Go to / Printers and Scanners / Add Printer / Choose RISO