क्षेत्रीय रेल प्रशिक्षण संस्थान, भूली

ZONAL RAILWAY TRAINING INSTITUTE, BHULI

SENDING OF ASSISTING ENGINE IN ABSOLUTE BLOCK SECTION

Dhananjay Kumar Singh
Instructor
ZRTI / Bhuli

SENDING OF ASSISTING ENGINE IN ABSOLUTE BLOCK SECTION

If it is necessary to send an assisting train in to obstructed block section to assist a disabled train, the SM will take following Actions:-

a) Inform the SM of the other end of the section on telephone. The section controller shall be informed.

b) Advise the Guard and Loco Pilot of the assisting train of the circumstance.

SENDING OF ASSISTING ENGINE IN ABSOLUTE BLOCK SECTION

c) Prepare and hand over the prescribed authorities to the Loco Pilot of the assisting train form T/A602 (authority to proceed for Relief Engine/train into an occupied block section) which contains:-

i. Authority to proceed without line clear.
ii. Authority to pass the signal/signals at ON or T/511 to start train from non-signaled line.
iii. Caution order 15/10/WP kmph.

SENDING OF ASSISTING ENGINE IN ABSOLUTE BLOCK SECTION

2) The Loco Pilot of assisting train shall be informed about the kilometers of obstruction and the station where the train is to be cleared.
3) When the assisting Engine/Train enters the block section in single line or in right direction on double line the SM inform the LP,GUARD and SM of other end.

SENDING OF ASSISTING ENGINE IN ABSOLUTE BLOCK SECTION

5) The section controller shall also be informed about the time of departure of Assisting Engine/ Train.
6) When the assisting train and the disabled train arrives at the station, the SM of receiving station confirm the complete arrival from the Guard, SM shall clear the section as follows:-

SENDING OF ASSISTING ENGINE IN ABSOLUTE BLOCK SECTION

a) If Train with Assisting Train/Engine arrives next station in right direction, the SM will send "Train out of Block Section " (four beats) to the SM in rear.

b) If the train with Assisting Engine and Disabled Train returns to the same station from where the assisting Engine/Train was dispatched, the SM shall send "Cancel last signal" (5 beats) to the SM in rear.

Thank you

Dhananjay Kumar Singh
Instructor
ZRTI / Bhuli