MACHINE FOR ASSEMBLING PLASTIC BALL VALVES

COMPONENTS

- Valve body
- Teflon
- Sleeve Male
- Ball
- Sleeve Female
- Pin Doing

WORK CYCLE / MAIN FEATURES
ROUND TABLE WITH 16 DIVISIONS

- 16 positions for the valve body
- 16 positions for teflon
- 16 positions for the sleeve male
- 16 positions for the sleeve female
- 16 positions for the ball
- 16 positions for the pin

It consists of a rectangular base, a servo-controlled rotating table that is electronically programmable via a Touch Screen control panel, and a rotating disk with positions for the placement of the parts.

The machine is also equipped with a Touch Screen control panel from which the machine setup can be easily managed automatically during each equipment change, batch and/or article change, and production data can be monitored via mobile devices.

The centralized supervisor can be connected to the management database for data transfer, strictly following the requirements of the **Smart Factory and Industry 4.0 project.**

All components are manually loaded by the operator. The unloading is automatic with the selection of good parts and discrimination of waste types.



CUSTOMIZED PRODUCTS

POLİNAR
her şey çekirdekten gelişir



POSITIONS

1. Loading the Sleeve Male Parts
2. Controlling the position of the Sleeve Male Parts
3. Loading the Sleeve Female Parts
4. Controlling the position of the Sleeve Female Parts
5. Loading the Teflon Rings into the Sleeve Male
6. Controlling the position of the Teflon Rings
7. Loading the Pin Parts
8. Controlling the position of the Pin Parts
9. Loading the Ball Parts
10. Controlling the position of the Ball Parts
11. Joining the Sleeve Male Parts and Sleeve Female Parts
12. Rotating the Ball Parts 90°
13. Unloading the Products
14. Unloading the Defective Products
15. Station Control
16. Empty

POLİNAR PLASTİK MAKİNE ve KALIP SANAYİ
TİCARET LİMİTED ŞİRKETİ
İkitelli O.S.B Eskoop San. Sit. D Blok
No: 34 Başakşehir / İSTANBUL - TURKEY

Phone : +90 212 549 88 20 – 21
Fax : +90 212 549 88 19
E-Mail : info@polinar.com.tr

www.polinar.com.tr

PTE (POLİNAR TEST EQUIPMENT)
İkitelli O.S.B. Eskoop San. Sit.
D Blok No.34 Başakşehir
İstanbul / TURKEY

Phone : +90 212 549 88 20 – 21
Fax : +90 212 549 88 19
E-Mail : info@polinar.com.tr

www.pte.com.tr

POLINAR GmbH
THE ICON VIENNA, Tower 24
Wiedner Gürtel 13 1100
Vienna AUSTRIA

Phone : +43 (0) 1 253535 4044
Fax : +43 (0) 1 253535 4044
Mobile : +43 676 5983869
E-Mail : office@polinar.at

www.polinar.at