

Operating Instructions

This lock is preset at the factory to open at P-L-A-Y.

To set your own combination:

Step 1: Decide on your new 4 letter combination - choose from suggestions on reverse side or create your own.

Step 2: With dials set to P-L-A-Y (middle of letters should be aligned with red stripe), pull out shackle.

Step 3: Turn shackle 90° (1/4 turn) so notch on shackle is aligned with notch in lock body. Step 4: Press and hold the shackle down.

Step 5: Set dials to your desired combination by lining up middle of letters with red stripe.

Step 6: Lift shackle, return to closed position, and hold shackle down while scrambling

letters to lock. Step 7: To re-open lock, set dials to your combination and lift shackle.



Ce cadenas est préréglé à l'usine pour s'ouvrir à P-L-A-Y.

Pour réaler votre propre combinaison:

Étape 1: Décider de votre nouvelle combinaison à 4 lettres - choisir à partir des suggestions incluses ou créer votre propre combinaison.

Étape 2: Les cadrans étant réglés sur P-L-A-Y (le milieu des lettres devrait s'aligner sur la bande rouge), tirer sur la branche.

Étape 3: Tourner l'arceau de 90° (1/4 de tour) pour que l'encoche de l'arceau s'aligne avec l'encoche dans le corps du cadenas.

Étape 4: Appuver sur la branche et maintenir.

Étape 5: Régler les cadrans à la combinaison désirée en alignant le milieu des chiffres sur la bande rouge.

Étape 6: Soulever la branche, retourner à la position fermée et maintenir la branche tout en brouillant les lettres pour verrouiller.

Étape 7: Pour réouvrir le verrou, régler les cadrans à votre combinaison et soulever la branche.

Instrucciones de operación

Este candado viene pre configurado de fábrica para abrirse con la combinación P-L-A-Y. Para fijar su propia combinación:

Paso 1: Decida una nueva combinación de 4 letras - elija una de las sugerencias adjuntas o cree su propia combinación.

Paso 2: Con los selectores fijos en P-L-A-Y (el centro de los cartas debe alinearse con la frania roia), tire de la argolla.


Paso 3: Gire el gancho 90° (1/4 de vuelta) para que encaje la muesca en el gancho con la muesca en el cuerpo del candado.

Paso 4: Presione v mantenga abaio la argolla.

Paso 5: Fije los selectores en la combinación que desea alineando el centro de los cartas con la frania roia.

Paso 6: Levante la argolla, vuélvala a la posición cerrada, y mantenga hacia abajo la argolla mientras revuelve los cartas para cerrar.

Paso 7: Para abrir de nuevo el cerrojo, fije los selectores en su combinación y levante la argolla.



Align Combination Dials Here





Dials Here





Choose from these possible combinations or create your own: Choisissez l'une de ces combinaisons ou créez la vôtre: Elija de estas posibles combinaciones o cree la suya propia:

WORDS MOTS PALABRAS

BALD **BORN DOCK LEAN** MART MOTH PAST PORE **RISK SURE** BALL **BRAN** DONE **LEEK** MASH MUCH PATH **PORK** SACK **TACK BANK BRAT** DOTE LENT MASK MULE PATS **PORT** SALE **TACT BARE BUCK** DOTS **LESS** MASS MUSE PEAK POSE SALT **TALK BARK BUDS** DUCK LIAR MAST MUSH **PEAR** POSH **TALL** SANE LICK **PECK BARN BULK** DUDE MATE MUSK POST SAND TANK BASE BULL DUET LIES MATH MUTE **PEEK POTS** SANK TASK **BASH BUNK DULL** LINE MEAL MUTT **PEER PRAY** SASS **TEAR BATH BUNS** DUNE LINK MEAN MYTH PELT PREY SEAL **TEEN BATS BURN DUNK** LINT MEAT NEAT **PENS PUCK** SEEK **TENT** NECK **BEAD BURR JARS** LION **MELD PERK PUNS** SHED TEST **BEAK BURY JEST** LOAN **MELT NEED** PEST **PUNT** SHOT TICK **BEAN** BUSH **JETS** LOCK MEND **NEST PETS PURE** SICK TILE **BEAR BYTE** JILT LONE **MESH NETS** PICK PUSH SIDE TILT **BEER DADS JOCK** LOOK MESS NICE PIES RACE SILK TINT **BEET** DARE JOLT LORD MICE NINE PILE **RACK** SINK TINY **BELT** DARK **JUNK LORE** MILE NONE PINE **RANK** SIRS TIRE LOST **TOES BEND** DART JUST MILK NOOK **PINK** RANT SLAY **BEST** DASH JUTE **LUCK** MINE NOON PINT RARE SLED **TOLL** LACE TONE **BETS** DATE **LURE** MINK NOSE **PITS** RASH SLOT BIRD **DEAR** LACK **LURK** MINT NOTE PITY RATS SOAR TONS BITE DENT LADS LUSH MIRE NUNS PLAN READ SOCK TOOT **BOAT** DIAL LADY LUST MISS **NUTS PLAY** REAL SOLD TOSS DICE LARD SOLE **BOLD** MACE MIST PACE **PLOT** REED TOTE **BOLT** DIET LARK MALE MOAT **PACK** PLOY REEL SOOT TOTS **BOND** DILL LASH MALL MOCK **PACT PODS** RENT SORE TRAY BONE DINE LAST MALT MOLE **PARE POET** REST STAR **TREK** BOOK DIRT LATE MANE MONK PARK POLE RIDE STAY TROT

BOOT BORE	DISH DISK	LEAD LEAK	MARE MARS	MOON MORE	PART PASS	POLL POND	RINK RIOT	SULK SUNK	
NAMES BART BERT BESS BETH BILL	BRET BURT DICK DION DIRK	DYAN JACK JADE JANE JEAN	RES JETT JOAN JODY JOEL JOEY	JOSH JOSS JUDE JUDY JULS	LACY LEAH LYLE MACK MADY	MARY MATT MICK MORT NATE	NILS NOAH RICH RICK RYAN	SETH STAN TATE TESS TISH	TREY TROY
BRAD	DORY	JESS	JORY	JUNE	MARK	NICK	SEAN	TONY	