## Rat Rig V-Core 3.0 base\_panel to 3.1 Template

## **Directions:**

- 1. Once printed, verify the dimensions of the template using a ruler
- 2. Cut the three templates around the perimeter
- 3. Position each template on to the 3.0 base\_panel, as shown in the guide, and mark around the edges
- 4. Cut the marked material away

Last updated: 13 July 2022





