UPC / EAN Addenda

Tera 1100L scanner configuration card

ON | Extended UPC

Read the 12-digit UPC plus the 5-digit comic addendum.



Tested scanner: both barcode sections must be readable.

OFF | Base UPC only

Read the 12-digit main UPC without the addendum.



Use when scanning a main UPC without its supplemental barcode.

Scan the desired setting directly; no Enter / Exit sequence.

Print at Actual size / 100%. Keep the white space around each barcode.

Configuration barcodes are reproduced from the original manual, not regenerated.

Source: Tera TR-UM018-EN-ZQ-2021.12.21-S01, printed page 03 (PDF page 6).

Mode descriptions reflect tests with this Tera 1100L. Prefix and terminator stay unchanged.