Connect Bouncer to your router

One setting in your router, once. About 10 minutes.

How it works

Your phones, TV and laptops ask your router where to find websites. The router passes these questions to your internet provider. After this one change, the router tells every device to ask Bouncer instead. Bouncer then answers normal questions and quietly refuses ads, trackers and scam websites.

What you need

1. Bouncer plugged in (power and, ideally, a network cable to the router) for at least 5 minutes.
2. Bouncer's address. Open **http://bouncer.local** (on a FRITZ!Box also **http://bouncer.fritz.box**), enter your PIN and open **Advanced settings**. Write the addresses into the box below.
3. The password of your router. It is usually printed on a sticker on the router.

Bouncer's addresses

IPv4 (looks like 192.168.178.20): _____

IPv6 (starts with fd, may be empty): _____

The 3 steps for every router

1. **Give Bouncer a fixed address**, so it never changes.
2. **Enter Bouncer's address as DNS server** for your home network.
3. **Check**: turn Wi-Fi off and on on a phone. The Bouncer dashboard turns green and says “This device is protected”.

Which page is for my router?

Look at the brand name printed on your router, or find your internet provider below.

Your provider or router	Usual router	Page
POST Luxembourg	FRITZ!Box	**3**
Tango	FRITZ!Box (4050, 4060, 4690, 5690)	**3**
Eltrona	FRITZ!Box (cable models)	**3**
Luxembourg Online, Visual Online	FRITZ!Box	**3**
Orange	Livebox	**4**
Bought yourself: TP-Link (Archer)	TP-Link	**5**
Bought yourself: TP-Link Deco (mesh)	TP-Link Deco	**6**
Bought yourself: ASUS	ASUS	**7**
Bought yourself: NETGEAR Nighthawk	NETGEAR	**8**
Bought yourself: NETGEAR Orbi (mesh)	Orbi	**9**
Bought yourself: Google Nest Wifi / Google Wifi	Google	**10**
Bought yourself: Amazon eero	eero	**11**
Bought yourself: Ubiquiti UniFi	UniFi	**12**
Something else		**13**

Internet providers sometimes change the router they hand out. If the name on your router differs from this table, follow the name on the router.

AVM FRITZ!Box

POST, Tango, Eltrona, Luxembourg Online, Visual Online, and bought in shops

✓ Checked against published instructions (manufacturer or the Pi-hole project).

› **How to log in**

Open **http://fritz.box**. The password is on the sticker under the FRITZ!Box (“FRITZ!Box password”). If a menu below is missing, switch the view to **Advanced** (at the bottom of the menu).

1 **Step 1 · Fixed address for Bouncer**

Home Network › Network. Click the pencil next to **bouncer**. Tick **Always assign this network device the same IPv4 address**. Click **OK**.

2 **Step 2 · Bouncer as DNS server**

Home Network › Network › Network Settings, then **IPv4 Settings** (or “IP Addresses › IPv4 Configuration”). In the field **Local DNS server** enter Bouncer's IPv4 address. Click **OK**.

3 **Step 3 · IPv6 (if your router uses it)**

Same page, **IPv6 Settings** (or “IPv6 Addresses”):

• Select **Always assign unique local addresses (ULA)**.

• Under **DNSv6 Server in the Home Network**, enter Bouncer's IPv6 address (starting with fd) as **Local DNSv6 server**.

• Tick **Also announce DNSv6 server via router advertisement (RFC 5006)**.

Click **OK**.

Bouncer only gets its fd address after the ULA option is on: wait 5 minutes, reload the dashboard and read it under Advanced settings.

✓ **Check**

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

Good to know

On a German-language FRITZ!Box the menus are: Heimnetz › Netzwerk › Netzwerkeinstellungen › IPv4-Einstellungen › „Lokaler DNS-Server“. Devices in the FRITZ!Box guest Wi-Fi stay unprotected.

Orange Livebox

Orange Luxembourg

! Based on user reports; this router could not be checked against official instructions. Menus may differ.

› How to log in

Open **http://192.168.1.1** (or the address on the Livebox sticker). The administrator password is on the sticker.

1 Step 1 · Fixed address for Bouncer

Not needed: in this mode Bouncer keeps its address by itself.

2 Step 2 · Bouncer as DNS server

As far as is known, the Livebox does not let you change the DNS server it gives to devices. Bouncer therefore takes over handing out addresses (“address mode”):

1. Open the Bouncer dashboard in a second browser tab: **Advanced settings › Address mode**.
2. In the Livebox: **Advanced settings › Network › DHCP**. Switch the **DHCP server off** and save.
3. Right away, in the Bouncer tab, press **Turn on address mode**.
4. Restart Wi-Fi on your devices (or restart them).

3 Step 3 · IPv6 (if your router uses it)

If the dashboard then shows “IPv6 still uses the router”, switch IPv6 off in the Livebox (**Advanced settings › Network › IPv6**, if your model offers it).

✓ Check

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

Good to know

If your Livebox does show a DNS field in its DHCP settings, use it instead: enter Bouncer's address there and skip address mode. To undo address mode: switch the Livebox DHCP server back on first, then turn off address mode in Bouncer.

TP-Link (Archer and similar)

Routers bought in shops

✓ Checked against published instructions (manufacturer or the Pi-hole project).

› **How to log in**

Open **http://tplinkwifi.net** (or http://192.168.0.1). Use the password you chose when setting up the router. Or use the TP-Link Tether app.

1 **Step 1 · Fixed address for Bouncer**

Advanced › Network › DHCP Server, section **Address Reservation**: **Add**, choose **bouncer**, save.

2 **Step 2 · Bouncer as DNS server**

Advanced › Network › DHCP Server. Enter Bouncer's IPv4 address as **Primary DNS**. Leave **Secondary DNS** empty. Click **Save**, then restart the router.

3 **Step 3 · IPv6 (if your router uses it)**

Advanced › IPv6: if there is a DNS setting for the LAN, enter Bouncer's IPv6 address. If there is none and the dashboard shows “IPv6 still uses the router”, switch IPv6 off.

✓ **Check**

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

TP-Link Deco (mesh Wi-Fi)

Mesh systems bought in shops

✓ Checked against published instructions (manufacturer or the Pi-hole project).

› **How to log in**

Use the **Deco app** on your phone. The phone must be connected to the Deco Wi-Fi, logged in as the owner.

1 **Step 1 · Fixed address for Bouncer**

More › Advanced › Address Reservation: add **bouncer**.

2 **Step 2 · Bouncer as DNS server**

More › Advanced › DHCP Server. Enter Bouncer's IPv4 address as **Primary DNS** and tap **Save**. Then restart the main Deco.

3 **Step 3 · IPv6 (if your router uses it)**

More › Advanced › IPv6: if the dashboard shows “IPv6 still uses the router”, switch IPv6 off here.

✓ **Check**

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

Good to know

If the change doesn't seem to apply, close the app completely and open it again.

ASUS

Routers bought in shops (ASUSWRT)

✓ Checked against published instructions (manufacturer or the Pi-hole project).

How to log in

Open **http://www.asusrouter.com** (or http://192.168.50.1). Use the login you chose when setting up the router. Or use the ASUS Router app.

1 · Step 1 · Fixed address for Bouncer

LAN › DHCP Server, section **Manually Assigned IP**: choose **bouncer**, click **+**, then **Apply**.

2 · Step 2 · Bouncer as DNS server

Same page: enter Bouncer's IPv4 address as **DNS Server 1** (older software: **DNS Server**). If shown, set **Advertise router's IP in addition to user-specified DNS** to **No**. Click **Apply**.

3 · Step 3 · IPv6 (if your router uses it)

IPv6: set **Connect to DNS Server automatically** to **Disable** and enter Bouncer's IPv6 address as **IPv6 DNS Server 1**. Click **Apply**.

✓ Check

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

If you can't find this setting

Some ASUS software versions only offer the DNS field under **WAN › Internet Connection** (“Connect to DNS Server automatically: No”, then enter Bouncer). This blocks ads too, but the dashboard can't tell your devices apart.

NETGEAR (Nighthawk and similar)

Routers bought in shops

! Based on user reports; this router could not be checked against official instructions. Menus may differ.

› **How to log in**

Open **http://www.routerlogin.net**. Use the admin password you chose. Or use the Nighthawk app.

1 **Step 1 · Fixed address for Bouncer**

Advanced › Setup › LAN Setup, **Address Reservation**: **Add**, choose **bouncer**, **Apply**.

2 **Step 2 · Bouncer as DNS server**

Most NETGEAR routers can't hand out a different DNS server to devices. Two ways:

A (simple): Advanced › Setup › Internet Setup, section **Domain Name Server (DNS) Address**: choose **Use These DNS Servers** and enter Bouncer's IPv4 address as **Primary DNS**. **Apply**. Blocking works; the dashboard shows all devices as “your router”.

B (with device names): Advanced › Setup › LAN Setup: untick **Use Router as DHCP Server**, **Apply**, then in Bouncer turn on **Advanced settings › Address mode** right away.

3 **Step 3 · IPv6 (if your router uses it)**

Advanced › Advanced Setup › IPv6: if there is a DNS choice, select **Use These DNS Servers** and enter Bouncer's IPv6 address.

✓ **Check**

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

NETGEAR Orbi (mesh Wi-Fi)

Mesh systems bought in shops

! Based on user reports; this router could not be checked against official instructions. Menus may differ.

› **How to log in**

Open **http://orbilogin.com**. Use the admin password you chose. Or use the Orbi app.

1 **Step 1 · Fixed address for Bouncer**

Advanced › Setup › LAN Setup, **Address Reservation**: **Add**, choose **bouncer**, **Apply**.

2 **Step 2 · Bouncer as DNS server**

Advanced › Setup › Internet Setup, section **Domain Name Server (DNS) Address**: choose **Use These DNS Servers**, enter Bouncer's IPv4 address as Primary (and Secondary) DNS, **Apply**.

3 **Step 3 · IPv6 (if your router uses it)**

Advanced › Advanced Setup › IPv6: if there is a DNS choice, enter Bouncer's IPv6 address.

✓ **Check**

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

Good to know

The Orbi passes all requests on to Bouncer itself, so blocking works but the dashboard shows all devices as “your router”. For device names: in **LAN Setup** untick **Use Router as DHCP Server** and turn on Bouncer's address mode.

Google Nest Wifi / Google Wifi

Mesh systems bought in shops

✓ Checked against published instructions (manufacturer or the Pi-hole project).

How to log in

Use the **Google Home app** on your phone.

Step 1 · Fixed address for Bouncer

Wi-Fi › **Network settings** › **Advanced networking** › **DHCP IP reservations**: tap **+** and choose **bouncer**.

Step 2 · Bouncer as DNS server

Wi-Fi › **Network settings** › **Advanced networking** › **DNS**. Choose **Custom** and enter Bouncer's IPv4 address as primary server. Tap **Save**.

Step 3 · IPv6 (if your router uses it)

On the same DNS screen, if IPv6 fields are shown, enter Bouncer's IPv6 address as primary IPv6 server.

Check

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

Good to know

Google Wifi usually passes requests on to Bouncer itself, so the dashboard may show all devices as “your router”. Blocking still works. A wrong address in this field cuts the internet: double-check it.

Amazon eero

Mesh systems bought in shops

✓ Checked against published instructions (manufacturer or the Pi-hole project).

How to log in

Use the **eero app** on your phone.

Step 1 · Fixed address for Bouncer

Devices, tap **bouncer** › **Advanced** › **Reserve IP**.

Step 2 · Bouncer as DNS server

Settings › **Advanced networking** › **DNS**. Switch on **Custom DNS** and enter Bouncer's IPv4 address (and IPv6 address, if you have it). Tap **Save**. The network restarts.

Step 3 · IPv6 (if your router uses it)

Included in step 2.

Check

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

Good to know

If “Local DNS caching” is switched on, the eero passes all requests on itself and the dashboard shows all devices as “your router”. Switch it off for device names.

Ubiquiti UniFi

UniFi gateways (UniFi Network app)

! Based on user reports; this router could not be checked against official instructions. Menus may differ.

› **How to log in**

Open the **UniFi Network** app or **unifi.ui.com**.

1 **Step 1 · Fixed address for Bouncer**

Client Devices, choose **bouncer** › **Settings** › turn on **Fixed IP Address**.

2 **Step 2 · Bouncer as DNS server**

Settings › **Networks**, choose your network (usually **Default**). In the DHCP area click **Show Options** next to **DHCP Service Management**, untick **Auto** for the DNS server, enter Bouncer's IPv4 address, then **Apply Changes**.

3 **Step 3 · IPv6 (if your router uses it)**

Same network, IPv6 section: set the DNS server to manual and enter Bouncer's IPv6 address.

✓ **Check**

Turn Wi-Fi off and on on a phone, then open the Bouncer dashboard. It shows a green line “Your router sends all devices through Bouncer”.

My router isn't listed

Almost every router has the setting; only the name differs. Log in to your router (address and password are usually on its sticker) and look for:

1. A page called **LAN**, **Home network**, **Local network** or **DHCP**.
2. A field called **DNS server**, **Primary DNS** or **Local DNS server**. Enter Bouncer's IPv4 address there and leave any second DNS field empty.
3. Not the **Internet**/**WAN** DNS setting: that one works as a last resort, but then Bouncer can't tell your devices apart.

My router has no DNS setting at all

Address mode: switch off the DHCP server in the router, then turn on **Advanced settings › Address mode** in Bouncer. Bouncer hands out the addresses and protects every device (see the Orange Livebox page).

Device by device: set the DNS server manually on each phone or computer (in its Wi-Fi settings). This only protects the devices you change.

Problems and how to undo

Some websites or apps don't work
On the dashboard, use **A website doesn't work?**: choose the device and press Fix. Or pause protection for 5 minutes.

The dashboard says “This device is not protected”
Turn Wi-Fi off and on, or restart the device. Some browsers use their own “secure DNS”: switch it off in the browser settings (Chrome: Privacy and security › Use secure DNS; Firefox: Settings › Privacy › DNS over HTTPS).

“IPv6 still uses the router”
Do step 3 for your router. If your router has no such setting, switching IPv6 off in the router also works.

No internet at all after the change
Check the address you typed. Is Bouncer plugged in? To undo, put the router's DNS field back to empty (or “automatic”) and save. Everything works as before.

Bouncer is unplugged or broken
Without Bouncer, devices can't find websites. Undo the router setting (see above) until Bouncer is back.

Guest Wi-Fi
Devices in the router's guest Wi-Fi usually stay unprotected. This is normal.