Corne Keymap v22 — Reference Guide

2026-11-01

Contents

1 Overview **2**

2 Notation **2**

3 Layer switching **2**

4 L0 — Default **3**

5 L1 — Lower (green) **3**

6 L2 — Raise (blue) **3**

7 L3 — Func (purple) **4**

8 Underglow per layer **4**

9 v21 vs v22 Differences **4**

10 v20 vs v21 Differences **5**

11 Flashing **5**

1 Overview

ZMK keymap for the 42-key Keebmaker Corne (Nice!Nano, split). v22 has exactly four layers. Layer changes are *persistent one-tap switches* (no hold-layers), every layer has its own underglow colour, and there are no transparent keys: a key either has a binding on that layer or does nothing (shown as —).

Layer	Name	Reached by	Underglow
L0	Default (QWERTY)	LT2 or RT2 on L1–L3	white
L1	Lower	LT3 on L0	green
L2	Raise	LT3 on L1	blue
L3	Func	LT3 on L2	purple

2 Notation

Name	Meaning
LP1–LP3 / RP1–RP3	Outer pinky column (left / right), numbered top → bottom
LT1–LT3 / RT1–RT3	Thumb keys, numbered outer → inner (LT1, RT1 farthest from centre)
L0–L3	Layers by ZMK index
M1, M2, M3, M4	Left Ctrl, Alt/Option, Command, Shift
M1b–M4b	Right-hand versions of the same modifiers
→Ln	One tap switches to layer n (and sets its colour)
—	No key

LP1	Q	W	E	R	T	Y	U	I	O	P	RP1
LP2	A	S	D	F	G	H	J	K	L	;	RP2
LP3	Z	X	C	V	B	N	M	,	.	/	RP3
			LT1	LT2	LT3	RT3	RT2	RT1			

3 Layer switching

On	LT3	LT2	RT2
L0	→L1	Backspace	Space
L1	→L2	→L0	→L0
L2	→L3	→L0	→L0
L3	—	→L0	→L0

LT3 steps forward and stops at L3; either main thumb (LT2/RT2) goes home. On L1–L3 the first press of LT2/RT2 only returns to L0 (no Backspace / Space is sent). The OLED shows the active layer name (L0–L3).

4 L0 — Default

TAB	Q	W	E	R	T	Y	U	I	O	P	M1
M2+BSPC	A	S	D	F	G	H	J	K	L	;	'
M4	Z	X	C	V	B	N	M	,	.	/	M4b
			M3	BSPC	→L1	ESC/M2	SPC	ENT			

Key	**Behavior**
LP1 TAB	Tab
LP2 M2+BSPC	Alt+Backspace (delete previous word on macOS)
LP3 / RP3	Left / right Shift (hold)
RP1 M1	Ctrl (hold)
RP2	' (Shift gives ")
LT1 M3	Command (hold)
LT2 / RT2	Backspace / Space
RT3 ESC/M2	Tap = Escape (sent on release); hold >200 ms = Alt
RT1	Enter

5 L1 — Lower (green)

‘	1	2	3	4	5	6	7	8	9	0	—
—	SC	SCA	—	C-b	—	←	↓	↑	→	—	—
M4	M1	M2	M3	—	—	—	—	M3b	M2b	M1b	M4b
			—	→L0	→L2	—	→L0	—			

SC = macOS screenshot to clipboard (Cmd + Ctrl + Shift + 4); SCA = screenshot with annotation (Cmd + Shift + 4); C-b = Ctrl + B (tmux prefix). In v22, SC, SCA and C-b *return to L0* (white underglow) right after sending their shortcut, so no extra LT2/RT2 press is needed. Modifiers on the bottom row allow e.g. Shift+arrows (select), Alt+arrows (word jump), Cmd+arrows (line start/end), Cmd+1–5.

6 L2 — Raise (blue)

~	!	@	#	$	%	^	&	*	(	)	—
—	—	—	—	—	—	[	-	=	]	\	'
M4	M1	M2	M3	—	—	{	_	+	}	|	"
			—	→L0	→L3	—	→L0	—			

On the right half each plain symbol has its shifted version directly below it. Left-hand modifiers allow shortcuts such as Cmd+Shift+[/].

7 L3 — Func (purple)

BT_CLR	BT0	BT1	BT2	BT3	BT4	—	F1	F2	F3	F4	—
—	TOG	EFF	HUI	HUD	BRI	—	F5	F6	F7	F8	—
—	M1	M2	M3	—	BRD	—	F9	F10	F11	F12	—
			—	→L0	—	—	→L0	—			

Key	Behavior
BT0–BT4	Select Bluetooth profile 0–4
BT_CLR	Clear the pairing of the *current* profile (before re-pairing)
TOG	Underglow on / off (the only key that turns it on or off)
EFF	Next effect (use *solid* so layer colours show cleanly)
HUI / HUD	Hue up / down (overridden by the next layer switch)
BRI / BRD	Brightness up / down — persists across layer switches and reboots

8 Underglow per layer

Every layer-switch key is a macro that switches the layer *and* sets that layer's colour via the custom `&rgb_hs` behavior (`src/behaviors/behavior_rgb_hue_sat.c`), which changes hue and saturation but keeps the current brightness. It never turns the underglow on or off; TOG controls that. With the underglow off, colours are still tracked and appear when it is switched on.

Layer	Colour	Hue / Saturation
L0	white	0 / 0
L1	green	120 / 100
L2	blue	240 / 100
L3	purple	280 / 100

Startup: underglow is off at first boot (`ON_START=n`); ZMK remembers the on/off state and brightness after that.

9 v21 vs v22 Differences

Key / feature	v21	v22
L1 C-b	Ctrl+B, stay on L1	Ctrl+B, then →L0 (white)
L1 SC	screenshot, stay on L1	screenshot, then →L0 (white)
L1 SCA	screenshot, stay on L1	screenshot, then →L0 (white)

10 v20 vs v21 Differences

Key / feature	**v20**	**v21**
Return to L0	LP2 on L1–L3	LT2 or RT2 on L1–L3
LP2 on L1–L3	→L0	—
Underglow	manual only	colour per layer (white/green/blue/purple)
Brightness keys	none	BRI / BRD on L3 (G / B)
L0 RP2	M2 (Alt)	'
L0 RT3	ESC	tap ESC / hold M2 (Alt)
L2 *	keypad multiply	plain *
L2 LP3	—	M4 (Shift)

11 Flashing

1. Firmware: `ysconfig/keyboard/keebmaker_corne/zmk_firmware/v22/firmware/`.
2. Plug in the left half, double-press reset; drive `NICENANO` appears.
3. Copy `corne_left-nice_nano__zmk-zmk.uf2` onto it; it reboots.
4. Repeat for the right half with the right `.uf2`.