<mark>PowerLok™ 插座安装说明/PowerLok™</mark>Receptacle Installation Instructions

PowerLok™ 插座安装面板要求

PowerLok[™] Receptacle Install Panel Requirements


- 1.面板厚度需依照如下表格
- 1.Panel Thickness should According to bellow Table

Series	Max. Panel Thickness
120 Series	7.2mm
300 Series	12mm
500 Series	17mm

- 2.面板与插座接触一起之间的垫片应符合要求: 2.The Gasket between Panel and Receptacle should achieve bellow Requirements:
- 平面度应小于或等于0.1毫米
- Planeness should be less than or equal to 0.1mm
- 表面粗糙度应为6.4或更好
- Surfaceness should be 6.4 or Better

PowerLok™ 插座测试要求

PowerLok[™] Receptacle Testing Requirements






禁止直接接触测试

No touching Pin to test

PowerLok[™] 螺丝最大扭紧扭矩 PowerLok[™] MAX Tightening Torque



请插上插头进行测试 Please Plug in then Test




PowerLok[™] 安装操作指引 / PowerLok[™] Mating Guideline

单芯插头插入指引 / Pluging in ONE POS Receptacle Guideline

步骤1:对准二次锁扣方向 Step 1:Aiming at Secondary Lock



步骤2:将插头插入插座 Step 2:Plug in Receptacle



步骤4:锁入,完成 Step 4:Lock in and Finish




PowerLok[™] 安装操作指引 / PowerLok[™] Mating Guideline

单芯插头拔出指引 / Pulling Out Plug Form ONE POS Receptacle Guideline

步骤1:将插头上的红色按钮向前推 Step 1:Push the Red Key on Plug

步骤2:向下按住红色按钮 Step 2:Press the Red Key



步骤3:将插头拔出插座 Step 3:Pull Out The Plug From Receptacle



步骤4:松开红色按钮,完成 Step 4:Loosen the Red Key and Finish

注意 / Caution

禁止在按下插头的红色按键前将 插头拔出插座

No Pulling out the Plug Before Pushing and Pressing the Red Key on Plug



PowerLok[™] 安装操作指引 / PowerLok[™] Mating Guideline

多芯90°插头插入指引 / Multi POS 90°Pluging in Receptacle Guideline

步骤1:将摇杆底的黑色按钮向上按 Step 1:Press the Black Key under the Rocker

步骤2:提起摇杆至固定位置 Step 2::Lift up the Rocker to the Fixed Position

步骤3:将摇杆滑槽对准插座两侧圆柱,然后插入至切合位置 Step 3:Aim the Rocker Groove to the Cylinder on both Sides of the Receptacle and Push the plug into the Receptacle 関柱 (Spout) (

步骤4:按下摇杆至复位,完成操作 Step 4:Press down the Rocker to fined position and Finish

注意 / Caution

禁止在圆柱与滑槽非切合状态前 按下摇杆

No Pressing down the Rocker Before the Cylinder and the Groove suit




PowerLok[™] 安装操作指引 / PowerLok[™] Mating Guideline

多芯90°插头拔出指引 / Multi POS 90°Pulling Out Plug Form Receptacle Guideline

步骤1:将摇杆底的黑色按钮向上按 Step 1:Press the Black Key under the Rocker

步骤2:提起摇杆至固定位置 Step 2:Lift up the Rocker to the Fixed Position



步骤3:握紧摇杆将插头拔出 Step 3:Hold the Rocker and Pull Out the Plug From



步骤4:按下摇杆至复位,完成 Step 4:Press down the Rocker and Finish



注意 / Caution

禁止在按下摇杆黑色按键前将摇杆 拔起


No Lifting up the Rocker Before Press the Black Key on Rocker



PowerLok[™] 安装操作指引 / PowerLok[™] Mating Guideline

多芯180°插头插入指引 / Multi POS 180° Pluging in Receptacle Guideline

步骤1:将摇杆底的黑色按钮向上按







步骤2:提起摇杆至固定位置 Step 2::Lift up the Rocker to the Fixed Position





步骤3:将摇杆滑槽对准插座两侧圆柱,然后插入至切合位置 Step 3:Aim the Rocker Groove to the Cylinder on both Sides of the Receptacle and Push the plug into the Receptacle





步骤4:按下摇杆至复位,完成 Step 4: Press down the Rocker and Finish






注意 / Caution

禁止在圆柱与滑槽非切合状态前 按下摇杆

No Pressing down the Rocker Before the Cylinder and the Groove suit



PowerLok[™] 安装操作指引 / PowerLok[™] Mating Guideline

多芯180°插头拔出指引 /Multi POS 180° Pulling Out Plug Form Receptacle Guideline

步骤1:将摇杆底的黑色按钮向上按 Step 1:Press the Black Key under the Rocker





步骤2:提起摇杆至固定位置 Step 2::Lift up the Rocker to the Fixed Position





步骤3:握紧摇杆将插头拔出 Step 3:Hold the Rocker and Pull Out the Plug From



步骤4:按下摇杆至复位 , 完成 Step 4:Press down the Rocker and Finish



注意 / Caution

禁止在按下摇杆黑色按键前将摇杆 拔起

Prohibit Pulling up the Rocker Before Press the Black Key on Rocker

